

## K00159 ADAPTER KIT

## Installation Instructions

- 1. The K00159 kit is used for installing two P-0520 ice machines on a Manitowoc S-970 or a C-970 bin.
- 2. Installation (bin must be level before starting):
  - A. Place adapter on bin, as shown. Using the adapter as a template, drill three 5/32" (4 mm.) holes, .500" (12.7 mm.) deep maximum, in the back of the bin. Warning: Do not drill through interior liner. Attach with (3) 10-24 x .500" screws provided.
  - B. Apply foam tape to the edge of the adapter openings as shown in the (A) position. Note: It is recommended to RTV intersections and along front inside edge of foam tape (see drawing) to prevent water tracking.
  - C. Place the ice machines on the adapter. Secure them to the adapter with the (4) machine screws provided. Assemble the support bracket between the two ice machines with flange on bracket flush with front of ice machine. Install top covers.
  - D. Assemble trim panel by hooking it over the top of the support bracket flange. Fasten bottom of panel to the ice machines by using the (2) screws holding the bottom brackets on.
- 3. Refer to ice machine installation manual for ice machine installation procedures.