

Software Installation

- 1. Insert the SpeedStream® USB 10/100 Ethernet adapter Installation CD into your CD-ROM drive.
- 2. The New Hardware Wizard will appear.
- 3. When prompted for the device driver location, select CD-ROM drive.
- 4. Click Next.
- 5. Follow the on-screen instructions.
- 6. When prompted, click Yes to reboot.

When the reboot is complete, verify that the USB 10/100 Ethernet adapter has a valid connection by observing the LED light.

LED Indicator Light

Color	Status	Description
_	OFF	No network connectivity
		or No driver loaded
RED	ON	10 Mbps connection
	Blinking	10 Mbps traffic
GREEN	ON	100 Mbps connection
	Blinking	100 Mbps traffic

Technical Support for North America is available 24 hours a day, 7 days a week, by phone, email or online:

Phone: 1-877-823-6722

Email: support@speedstream.com

Online: http://www.support.speedstream.com

SIEMENS

For more information regarding SpeedStream® products visit: www.speedstream.com. Efficient Networks, Inc. A Stemens Company

4849 Alpha Road Dallas, TX 75244

©2001 Efficient Networks, Inc. All rights reserved. Efficient Networks, its logos, "Live a Broadband Life" and SpeedStream are registered and unregistered trademarks of Efficient Networks, Inc. Siemens and the Siemens logo are registered trademarks of Siemens AG, Germany. All lother brand names and trademarks are held by their respective companies. Efficient Networks reserves the right to make changes to product specifications at any time without notice.

SIEMENS



SpeedStream® USB 10/100 Ethernet Adapter

Before you begin:

Verify that the following items came with your kit:









USB 10/100 Ethernet Adapter

Software CD-ROM

Quick-Start Guide

Safety and Certification information

Before installing the SpeedStream $^{\circ}$ USB 10/100 Ethernet Adapter, ensure that your PC is equipped with the following. Note that the adapter is not installable on Macintosh computers.

- Microsoft[®] Windows[®] 98 Retail, Windows[®] 98 SE (Second Edition), Windows[®] 2000, or Windows[®] Me (Millennium Edition)
- 32 MB RAM
- Available USB Port

Step 1 Connect the USB Cable to the computer

Connect the USB cable to the USB port on your computer



Step 2 Connect the Ethernet Cable

Using an RJ-45 cable (not included), connect the Ethernet port of the adapter to an Ethernet modem, bridge, router, switch or hub.

