


Manual Instruction



Model AD-40A

FAX

Precautions

CONTENTS

■ Precautions	2
Operation and performance	5
Parts names and functions	6
For selecting functions properly	8
■ Preparation and checking before operation	10
■ How to operate	11
For maintenance	14
For continuous draining	16
Specification	17
■ Trouble-shooting	17

Thank you very much for purchasing our Dehumidifier.

Please read this manual instruction carefully before operating your dehumifier.

This manual contains further important instructions for proper operation. Please save it for your further reference.

37.	1.126106	CX (61):5377411	D: 1202211	31.2-7 SEP	工程 100 101 105	经经验	艾莱克	REPORTS.	4.5	医结合性结膜的	(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	100 N 100 N	221101	刺激化器	27125 321-1	312 8225	5.200	15.
ш				FIGURE 11X		THE PERSON NAMED IN	استكمناك	444	10.70	CARLO TAURED	WILL LINE	14.54		均:据则	NIGHT 1582 S		4.1	570
238	0.4		The set 5		F 1. F 1 1886	** 1 * 1	5 In 16 4 .			1111	1 10	11:11:11		14 M	et Giscolini	3.10(4)13.52	しかい おいかき	1613
	37 (STIES)	THE COLUMN STATES	2.00	经净额 经收款	ideli miti	SERVICE	areli, itta i	1775-5171	ALL HARRY	(1) (H) (H) : 최고	经海损 化物性	ALC: NO THE	SECTION OF		of the same	333,000,000	er ruter	200
'n	MARKET LINE	A Principle	La La System	وتمخط بكانانا	efortion and the	Little Co.	100 C	A-1078-1814	A 150 C	Maria de Sant	Parameter Company	Barrier Holland	wide bases at	68566bar	LUL THE	22-11-199	400	dir.
:A					E			1800	10.00							400		222
	4.6	PETONE BETT	De Lan	AUTOR	PRESCRIPTION	bule to the	ACMMARK.	27,010,010,000	ALCOHOL: N	STREET, STREET, ST	Marie Property	LIMBUR HARRY	machining of	enterral risk	If Late Late	West Harriston	1000	13

- Warming means improper handling may result in a death or a sortcus injury to a person.
- △ Cautions means improper handling may result in an injury or damage to properties.
- Shows Prohibition
- Shows Computation
- △ Shows Caution

Warnings

 in case of any abnormality, be sure to turn off the dehundrifier, disconnect the plug and make context to the seller of your appliance.



(Abnormal operation may result in a failure of the unit, electric shock, fire, or the like.)

. _

- Never attempt to turn off the dehumidifier by disconnecting the plug.
- Probleti
- Never modify the dehumidifier. Do not attempt to diseasemble or service the unit by yourself.
- N Prohibit diseasembly
- To avoid the risk of the electric shock, never connect of discompact the plug by your hand wet.
- (g)
 Prohibit wet hand
- This unit is intended for the connection to the power source of #20 volts alternative current.
- Use ellemation power 120V
- Remove any dust from the blades of the power plug and insert the plug into an outset accurate.
- (E) Yripe off dust
- To avoid the risk of fire or explosion, do not spray to the dehumidifier. Do not put any inflammables or chemicals near the unit.
- (<u>)</u>) Prohibit
- To prevent resin perts from meiting or catching on fire, do not place the dehumidifier near heating appliances.
- ,wpipss (7)

•	Do not connect the dehumidiller to an outlet having the electrical ratings below the dehumidiller's.	Prohibit
•	The power cord must not be damaged or modified. Do not put anything hot or heavy on the cord. Do not pull it out, or bundle it during operation.	O Prohibit
•	To avoid damages to the power cord, do not pinch the cord in a door.	O Prohibit
•	Never put rods or objects into the openings of the debumidifier. Because this unit contains a tan running at high speed, contact with the moving fan will cause serious injury.	S Prohibit
•	Remove water that has been collected in the tank. (Accidentally drinking of the water or using it for other purpose may cause tiness and or unforeseen accidents.)	① Throw ewey



•	The dehumiditier must be used on a level and stable surface.	Use in flat groun
•	To prevent the water from treezing, do not use the dehumidifier end the drain tose at ambient temperature below 32 °F	○ Prohjalit
•	Do not use the determidifier outside. Exposure to direct sunlight or rein may result in overheating, electric shock and fire.	○ Prohibit
•	Do not use the defundifier outside. Exposure to direct sunlight or rain may result in overheating, electric shock and fire.	O Prohibit
•	Do not put water vessel on the dehumidifier	Ø
	(in case of any split of water, the water gets into the unit and deterforates the insulation.)	Prohibit
•	Never attempt to use the delumidifier for special uses, such as food or preservation of art objects, or the like. The deterioration of preserving quality may be caused.	○ Profibit
•	Do not use the dehumidifier where any leakage of oil or flammable gas may bake blace	○ Prohibit

•	Do not use the unit in places subject to chemicals.	() Prohibit
•	For continuous draining, make sure that the drain hose is set properly without a rising slope.	① Emure drain aces
•	Be caneful that a heating eppliance is not exposed to the wind from the deburnktifier.	○ Prohibit
•,	Do not use the dehumidifier as a chair or a foolstool.	Prohibit
•	For safety purpose, disconnect the power plug if the unit is not use for a long time.	
•	Be sure to take hold of the power plug when plugging in and out of an cullet.	
•	In case of using the dehumidifier in a closet, be sure to prevent children from gaiting in the closet.	Prohibit
•	Do not remove the float lever from the water lank.	O Prohibit
•	To avoid damages to the power cord, do not pull out the cord when moving the unit.	O Prohibit
•	Do not block up the air intakes and the stroutlets. Do not cover the unit with weshed dottes.	○ Prohibit
•	Prior to continuous operation for a long duration, periodical checking is required especially for the sir clean filter, the drain hose, or the like.	() Schadule check out
•	Turn off the unit and disconnect the power plug before starting any cleaning or other routine maintenance.	
•	To avoid the risk of electric shock, never sprinkle or split water on the dehunidifier when cleaning.	O Problèt
•	Turn off the unit and empty the water out of the water tank when moving the unit. Be sure to hold the leantle when moving.	(i) Binut off operation and drain water when moving

FAX

Operation and Performance

Defrosting operation

The evaporator within the dehumidifier freets during the dehumidifying operation at room temperature of approx. 59 °F or less. For removing freet the defrecting device works automatically at an interval of approx. 30 minutes or more (for duration of approx. 5 minutes).

- Both the dehumidifying function and the air cleaning function stop during the defloating operation.
- Do not disconnect the plug of the unit or turn off the unit during the defrosting operation.

This dehumidifier is not suitable for keeping the humidity very low (approx. 50% or less)


This dehumidifier is designed to remove uncomfortable humidity in daily life and to use for auditory drying of washed clothes indoors. This is not suitable for keeping the humidity very low.

Room temperature rises during the operation.


This dehumidifier does not have cooling function, it produces heat during the operation and recon temperature rises by 1°F to 8°F. The temperature gets higher while it is operated in a closel, or the title. Furthermore, noon temperature rises because doors and windows are closed and heat is produced from other appliances in the room and the sun reclasion.

Parts Names and Functions

Front



Back




Accessory 4-



Anti Bateria Air Clean Filter...1 piece

Instaliation

For efficient operation of the dehumidifier, spacing are required as shown below.




Note


In case TV sets, radio etc. are disturbed with noises, keep them apart form the dehumidifier by 70cm or more.


FAX

For Selecting Functions Properly

Controls







Built-in microcomputer memorizes the operation of dehumidifier, once It is set. The unit repeats the same operation by pressing "Power" switch. (In case of disconnection by unplugging or power failure, etart over the setting again.)

Preparation and Checking before Operation

Set an air clean filter to a dehumidifier.

1.Remove the back cover.

To open the upward air outlet flap.

To open the downward air outlet flan.



2. Remove the fitter holder from the back cover.





3.To set the air clean filter to the back cover.

Take the air clean fifter out of polyethylene beg, and put it onto the back filter. Set the air clean filter to the back cover with the fitter fitted into the four ceiches in the COMME

Put the filter holder on the back cover with the flat surface of the holder up, and set the holder to the four catches in the cover(with the convex portions of the holder unward).


To set the holder securely, prose its perimeter with fingers. Then check the condition.





 In case of improper setting conditions, you cannot set the back cover to the unit.

Set the cover in position.





For easy installation, please Install one aide first, and then the other side.


Make sure that the water tank is set properly.


Your dehumiditier will not be operated when the water tank is full of water or it is not set properly.


Draw the water tank gently toward you by holding the conceve part of the teak.

How to set

Push the tank horizontally and gently. The handle lies down by itself.







Operation mode "Automatio"

Operations made "Continuous"

Open either the upward flap or the downward flap

Open either the upward flap or the downward flac

- The initial timer setting is "2H", You can change the setting to "4H"er "8H"
- Be sure to put the dehumidifier in a closet with the tank side toward the closet door.
- Try to close the closest doors to a degree that the power cord may not be placed in the doors.

Confinuous operation with additional air flow

Open either the upward flep or the downward flap for drying washed clothes uniformly.

Continuous operation with the downward flap open.

Open the downward flap of air outlet only.

Continuous operation with the spot flap open.

Open the spot flep of air outlet only.

Air Clean

- This unit is not intended for use as an exclusive air cleaner.
- Open either the upward flap or the downward flap.
- Air cleaning function does not work without eir diesen filites.


When you empty water from a water tank

- 1.Remove water tank from the dehumidifier.
- 2. Hold the task by the handle and carry it gently.
- 3. Tilt the tank to the direction as shown.
- and slowly empty the water out of the tank.
- 4.Set the tank in the dehumiditier.

Note -

After the dehumidifying operation, water is collected in the water tank. When the tank is full of water, the dehumidifier stops operating automatically and the buzzer sounds. The buzzer sounds for 10 seconds when the tank is taken out during the operation.

For continuous draining, see the page 16.




How to Operate

- Your dehumidilier will stop automatically after the hours set by the timer (2H, 4H or 8H)
- If the unit is set to "Continuous" mode, the tritial timer setting is "2H". You can change the setting to "4H" or "6H".

Plug in the dehumidifier to an outlet.

- "Automatic"mode lamp will flesh.
- Make sure that the water tank is set properly.



Open one of the air outlet flaps suitable for the desired operation.


Press "Power" switch.


"Automatio"mode iamp wilt light up.



Set the unit to the desired operation by pressing "Mode" switch.

 Every timer you press the ewitch, the mode select lamps light up in turn as shown and the operation mode will be changed.







Wiffs the lapse of time, the Omer lamp lighting up will hidicate the remaining time.

The unit will stop operating after the lapse of the set time.

Warning

To avoid damages to the power cord, do not pinch the cord in a door.

Caution

Be sure to prevent children from getting in a closet when using the unit in the closet.

Stop operating

Press "Power" switch again.

- The mode select lamp will go off and the unit will step operating.
- Cices the flap.

Buzzer

Whenever each switch is pressed, the buzzer will sound.

Note ←

Be sure to open one of the flaps. If the flap is not opened fully during operation the overheat prevention device will work and the unit will stop

Due to the protetive function for the machine,the dehumidifying operation or it begguld after approx.3 minutes, when the unit is plugged in or restarted immediately after stopped.

After receipt from a power failure, "Automatic" mode lamp will flash press "power" switch again to atan't the operation.

Efficiency of the dehumidifier is in fluenced by the air cutside the room. For operating efficiently, try to evoke opening and closing the windows and

For proper performance, operate the dehumidifier under the usable operating temperature. For safety purpose, the dehumidifying operation will be stopped automatically and changed to the air cleaning operation when the ambient temperature is higher than approx. 97°F.

Circulation of the refrigerent may cause sound within the dehumidifier when the operation is started. After the circulation is stable, the sound will be lowed.

To change the timer set


Press "Timer Select" Switch to set the desired time.

To cancel the timer operation Press' Timer Select' Switch the Timer temp will go all.

To stop the timer operation Press "Power" switch again

Notes

- Except "Continuous"mode operation the timer set will be conceiled whenever 'Mode's witch is pressed. Set the timer again after pressing "Mode"switch. If necessary.
- The timer stops when the water tank is full of water. After the tank is emptied, the timer will start.



To avoid of the risk of electric shock, never connect and disconnect the plug with your hand wet.



Turn off the unit and disconnect the power plug before cleaning or other routine maintenance.

Do not remove the float lever from the water tank.



Prohibit was hand





When the unit is not in use for a long time.

- 1. Unplug the unit, bundle the power cord, and hang the bundled cord at the back of the unit as shown.
- 2. Empty the water out of water tank, wips the tank with cloth and replace in position.
- 4. For storing, stand the unit upright and evold the exposure to the direct auxilight.

Request

To avoid multiunction or abnormal sound, keep the unit upright.

Body of Dehumidifier


Wips the dehumidifier with a dry an soft cloth.

- To remove heavy dirt, wipe it with a cloth wrung tightly.(Never use a wet cloth for cleaning the controls).
- To avoid deformation or cracking, do not use benzine. thinner or liquid cleaners.
- Chemical cloth may cause the chance in color or the unit.

Water tank


- Pull out the water tank and take it out.
- Remove the tank cover and wash the inside of the tank with water.
- The tank may be accelched, if you accurb it strongly with a brush.
- Do not remove the float lever from the tank.
- Wipe off the water on the cutside of tank with a cloth. Put the tank cover onto the tank and replace the tank as it was.
- Pass the handle through the hole of the tank cover as shown.







Back & Side Air Intakes (Maintenance every 2 weeks)

- The dehumidifying capacity will be towared when the air clean filter gets clogged.
- Remove the back cover from the unit and remove the filter holder. Then take out the air clean filter and the back filter.



- Pull the sider cover toward you and remove it from the unit. Remove the sider filter from the unit.
- To dislodge the dust from these filters, use a vacuum cleaner or pat them lightly.
- If the filters are fouled seriously, wash in water including neutral detergent, rinse well with water and leave until dry.
- Pat the air clean filter and dislodge dust from it.





Air Clean Filter (Maintenance every 6 months)


Time to replace the air clean filter.

- The life span of an air clean filter is approx.6 month.
- In case of replacing with new sir clean filler, be sure to purchase the filter specified as below:

Model No.: AD-40A

Model No. Of Anti bacteria Air clean filler: AD-40AF

Request Do not make the sir clean litter round or damage it. Do not leave the filter unused after it is taken out of the bag.



(1)

• For continuous draining, make sure that the drain hose is set properly without e rising slope.

Ensure drain hose

To prevent the water from freezing, do not use the dehumidifier and drain hose at ambient temperature below 32 °F.


 Θ

if there is a place suitable for draining nearby, you can carry out the continuous draining operation.

The continuous operation enables the dehumidiving operation for hours and it is not necessary to empty out the

Before operating continuous draining, be sure to turn off the dehumidifier and disconnect the power plug.

Preparation for continuous draining: Hose for draining (viny) hose on the market) lenght:Distance to the place for draining+approx.30cm inner diameter: 15mm Outer diameter: 20mm or less




Make the hose opening

To make the opening, remove the cover for the drain hosebymeansof a minus screwdriver.

Fit a drain hose.

Put the drain hase into the hase opening and fit the hose to the drain hole fully and ecounety.



Set the water tank as it was before

The unit will not be operated without the tank.





Model No. Power Supply Dehumidity Capacity Power Consumption Capacity of water tank Net weight Dimensions Room Temperaturs

AD-40A 115V/60Hz 40 Pints/Day(86°F/80%) 340W Operationstops a pprox.5.0L 28.7 LB 22.5(H)x15.4(L)x15.3(W) inch 41°F-95°F

The specification may be subject to change without notice for purpose of improvement.

Troubel-Shooting

Prior to requesting to repair, please check for the following:

Malfunction	Points to be checked	Messures to be taken	Ref.Page
	Check to see If the power plug is disconnected.	inport the plug into an electric outlet fully and securely.	2
	Check to see if the water tank is full of water.	Empty the water out of the tank.	2
No operation	Chack to see if the water tank is not set properly in position.	Set the tank to the unit properly in position.	11
	Check to see If all the flaps are closed.	Open one of the flaps.	13
	To see if the filters get dirty.	Clean the filters as specified.	13
Debumklifed vokuse it smeli	Check to see if the air openings are blocked up.	Remove obstacles from the air openings.	13
	Check to see if the dehumidifier is in air chean mode.	Change the operation mode to the dehemicitying mode.	13
Lound sound while operating	Check to see if the unit is not installed as specified.	Install the unit on a level and stable floor.	18
Operation stops during spot dehtsuklijdag	Check to see if the room temperature is higher than the usable opeating temperature.	The dehumidifying operation will be started entomatically when the temperature lowers.	13
Washed clothes are	Check to see if washed elethes are not exposed to the eir from the unit.	Try to expose the washed clothes to the air flow.	13
not drive	Check to see if the room temperature is too low.	Washed ciothes are hard to be dried under low temperature conditions.	13

Nothing is wrong with your dehumidifier in case of the following phenomena

Phenomenon	Reason
Operation stops occasionally	The unit is defrosting (See the page 5).
Dehumidited volume is intell	Dehumidifier volume less when the norm temperature is low (see the page of) The unit stops operating when the room temperature is below approx. The unit stops dehumidifying because the humidity in a room drops to 60 % or less in "Automatic" mode. (See the page 5).
The humbility in a room is still high	The room size may be too large. (see the page 5) The doors or the windows of the room may be opened and for closed frequently. (See the page 5) The dehumiditier is used together with a kerosene heater which emits veppor
Ead smell during operation	Smell is emitted from the walls, furniture or other objects.
Sound is produced within the unit	Circulation of the refrigerent may cause sound until it is stable.
Water is left in the water tenk	The water is left because the unit is subjected to dehumidifying test in the factory.
The buzzer sounds	The buzzer sounds when the water tank is full of water. (See the page11).

Customer's Sheet:	
Please record the follow	ving Kams.
	Model AD-40A
	Purchase Date
	Store III