

USER'S GUIDE

CLASS H PART#7710901 REV.B

Version: 805109 Revision: 03/15/04

TABLE OF CONTENTS

Safety Statement.....2 General Notes......3 Tools Required......3 Gym Layout.....4 Parts list......5 Assembly Instructions.....5-8 General Maintenance.....9 Warranty Statement......10 Product Services......11 Insert-Registration Card

IMPORTANT SAFETY INFORMATION



THERE IS A RISK ASSUMED BY INDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE RISK FOLLOW THESE RULES!

1. Before using, read all the warnings and instructions on the use of this machine. Use only for intended exercise. **DO NOT** modify the machine.

2. Obtain a medical exam before beginning any exercise program.

3. Keep body and clothing free of all moving objects.

4. Inspect the machine before use. **DO NOT** use it if it appears damaged. **DO NOT** attempt to fix a broken or jammed machine. Notify your authorized ParaBody dealer before use and have repairs made by an authorized service technician.

5. Be certain that weight pin is completely inserted. Use only the pin provided by the manufacturer. If unsure, call your authorized ParaBody dealer. 6. Never pin the weights or prop plate into an elevated position. **DO NOT** use the machine if found in this condition. **DO NOT** attempt to fix. Notify your authorized ParaBody dealer.

7. Inspect cables and their connections before using machine. Pay particular attention to the cable ends. **DO NOT** attempt to fix. Notify your authorized ParaBody dealer before use and have repairs made by an authorized service technician.

8. Make sure all spring loaded pull pins are fully engaged in the adjustment position and fully tighten thumbscrew before use.

9. Children must not be allowed near this machine. Supervise teenagers.

NOTE: In a continual effort to improve our products, specifications are subject to change © 2004 Life Fitness, a division of Brunswick Corporation. All rights reserved. ParaBody is a trademark of Brunswick Corporation

www.parabody.com

IMPORTANT NOTES

Please note:

- * Thank you for purchasing the ParaBody 805 Gym System. Please read these instructions thoroughly and keep them for future reference. This product must be assembled on a flat, level surface to assure its proper function.
- * This product must be assembled on a flat, level surface to assure its proper function. DO NOT securely tighten any frame connections until the entire frame has been assembled, unless otherwise stated.

Tools Required for Assembly

- * 3/4" wrench
- * 9/16" wrench
- * Ratchet with 3/4" and 9/16" sockets
- * Adjustable wrench
- * Tape measure

Bolt Length Ruler

NOTE: BOLT LENGTH IS MEASURED FROM THE UNDERSIDE OF THE HEAD OF THE BOLT.







1 Square = 1' X 1'

PARTS LIST

KEY	PART#	DESCRIPTION	QTY
1	7710709	REAR BASE	1
2	6706209	SWIVELPLATE	1
3	6705709	BENCHFRAME	1
4	6681910	1/4 X 2 X 16-1/2" PLATE	2
5	6624210	LEFT BACK PAD ANGLE	1
6	6624310	RIGHT BACK PAD ANGLE	1
7	6623710	WOLFFSLEEVE	1
8	6236509	2 SQ. X 18" TUBE	1
9	6706021	BACK PAD	1
10	6705821	SEAT PAD	1
11	6412001	3/8" SPRING PIN ASSEMBLY	1
12	6692601	3 X 2" END CAP	1
13	6406401	HINGE TAB	2
14	7234801	2" SQ END CAP COVER	4
15	6590801	3 X 2" GUIDE INSERT	2

STEP 1:

- Insert one 3 X 2" END CAP (12) into top of the REAR BASE (1) as shown in FIGURE 1.
- Slide two END CAPS (14) over the ends of the REAR BASE (1). See FIGURE 1.
- **SECURELY** assemble two WHEELS (28) to the REAR BASE (1) using two 3/8 X 1-3/4" BOLTS (29) and two 3/8" LOCK NUTS (26) as shown in FIGURE 1.

KEY	PART #	DESCRIPTION	QTY
16	7339901	U-PIN	1
17	3118401	4" VINYL CAP	1
18	3235204	3/8 X 1" BOLT	6
19	3235212	3/8 X 3" BOLT	2
20	3235405	1/2 X 1-1/4" BOLT	2
21	3235312	1/2 X 3" BOLT	2
22	3235426	1/2 X 6-1/2" BOLT	1
23	3114403	3/8" FLAT WASHER	10
24	3114401	1/2" FLAT WASHER	4
25	3114702	3/8" NYLOCK NUT	4
26	3114701	1/2" NYLOCK NUT	5
27	3221705	E-RING	1
28	7656301	WHEEL	2
29	3235207	3/8 X 1-3/4" BOLT	2



STEP 2:

• Slide two 2" SQ END CAP COVER (14) over the ends of the 2 SQ. X 18" TUBE (8). See FIGURE 2.





STEP 3:

- Snap two 3 X 2" GUIDE INSERTS (15) into the ends of the WOLFF SLEEVE (7) as shown in FIGURE 3.
- Insert 3/8" SPRING PIN ASSEMBLY (11) into the spring pin barrel on WOLFF SLEEVE (7) and tighten nut securely. See FIGURE 3.
- Slide one 4" VINYL CAP (17) over the U-PIN (16) as shown in FIGURE 3.
- Slide U-PIN (16) through the bushing on WOLFF SLEEVE (7) and attach with E-RING (27)
- Slide the WOLFF SLEEVE (7) over the BENCH FRAME (3).
- Securely assemble the BENCH FRAME (3) to the REAR BASE (1) & the SWIVEL PLATE (2) using two 1/2 X 3" BOLTS (21), two 1/2" FLAT WASHERS (24), and two 1/2" NYLOCK NUTS (26) as shown in FIGURE 3.
- Securely assemble the 2 SQ. X 18" TUBE (8) to the BENCH FRAME (3) using two 3/8 X 3" BOLTS (19), four 3/8" FLAT WASHERS (23), and two 3/8" NYLOCK NUTS (25). See FIGURE 3.

Γ	1/2	2			1/	2			1/	2			1/	/2			1/	2			1/	2	
0			1	l			2	2			3	3			4	4			4	5			6
L																							



STEP 4:

- Attach two 1/4 X 2 X 16-1/2" PLATES (4) to the bushing on the SWIVEL PLATE (2) using one 1/2 X 6-1/2" BOLT (22) and one 1/2" NYLOCK NUT (26). See FIGURE 4.
- Slide two HINGE TABS (13) over the shaft on the WOLFF SLEEVE (7) as shown in FIGURE 4.



STEP 5:

- Slide the LEFT (5) & RIGHT (6) BACK PAD ANGLES over the shaft on the WOLFF SLEEVE (7) as shown in FIGURE 5.
- Attach the LEFT (5) & RIGHT (6) BACK PAD ANGLES to the 1/4 X 2 X 16-1/2" PLATES (4) using two 1/2 X 1-1/4" BOLTS (20), two 1/2" FLAT WASHERS (24), and two 1/2" NYLOCK NUTS (26).



STEP 6:

- Securely fasten the BACK PAD (9) to the LEFT (5) and RIGHT (6) BACK PAD ANGLES using four 3/8 X 1" BOLTS (18) and four 3/8" FLAT WASHERS (23) as shown in FIGURE 6.
- Securely fasten the SEAT PAD (10) to the HINGE TABS (13) using two 3/8 X 1" BOLTS (18) and two 3/8" FLAT WASHERS (23) as shown in FIGURE 6.
- Securely tighten the four connections on the 1/4 X 2 X 16-1/2" PLATES (4), then back nuts off 1/4 of a turn or until the BACK PAD (9) adjusts easily.

THIS CONCLUDES THE ASSEMBLY OF THE 805 FLAT & INCLINE BENCH

ſ		1	/2			1	2			1	2		1	/2			1/	2		1	/2	
0)		1	1	L			1	2			3			4	1			5			6
L																						

MAINTENANCE

Please note:

- * We recommend cleaning your product (pads and frame) on a regular basis, using warm soapy water. Touch-up paint can be purchased from your ParaBody customer service representative at (800) 328-9714.
- * Inspect equipment daily. Tighten all loose connections are replace worn parts immediately. Failure to do so may result in serious injury

* PLEASE RECORD THE INFORMATION REQUESTED BELOW. IN THE EVENT YOU MAY NEED SERVICE YOU WILL BE ASKED FOR THIS INFORMATION. REMEMBER TO FILL OUT YOUR WARRANTY REGISTRATION CARD AND MAIL BACK.

	MODEL #
	SERIAL #
	DATE OF PURCHASE:
	DEALERS NAME:
SERIAL NUMBER	DEALERS PHONE #

Thank you for purchasing the ParaBody 805 Gym System.

LIMITED WARRANTY

ParaBody extends the following LIMITED WARRANTY to the original owner of the ParaBody products. The Warranty terms apply to IN HOME USE ONLY.

- 1. LIMITED WARRANTY ON FRAME AND WELDS. If the frame of the ParaBody product or a weld should crack or break, it will be repaired or replaced by ParaBody. Terms: Lifetime for so long as the Customer owns the ParaBody product.
- 2. LIMITED WARRANTY ON PARTS. If the following parts are defective in material or workmanship, ParaBody will supply replacement parts: all bolts, nuts, washers, bearings, bushings, pulleys, thumbscrews, collars, cable retaining clips, adjustable pre-stretch slides, roller pad shafts, allen head bolts, weight selector pin, weight stack shaft, set screws, protector caps, adjustment chain, cotter pin, plunger, spring and knob. Terms: Lifetime for so long as the Customer owns the ParaBody product.
- 3. LIMITED WARRANTY ON CABLES AND UPHOLSTERY. If the coated cables or upholstery are defective in material or workmanship, ParaBody will repair or replace them, at its option. Terms: Three (3) years.
- 4. CONDITIONS AND EXCEPTIONS. Any product misuse, abuse or alteration, any attempt to repair by a person other than an authorized ParaBody Service Center, any improper assembly, accident, or any other condition resulting from occurrences beyond the control of ParaBody will void this Limited Warranty.
- 5. REPLACEMENT AND REPAIR EXPENSES. ParaBody will provide only replacement parts or repair under this warranty. The Owner is responsible for all other costs. Such costs may include, but are not limited to: a. labor charges for service, removal, repair or reinstallation of the ParaBody product or any component part; b. shipping, delivery, handling and administrative charges for returning parts to ParaBody; and c. all necessary or incidental costs related to installation of the replacement parts.
- 6. SHIPPING. If shipping by the Owners is deemed necessary (in sole discretion of ParaBody), parts should be shipped in their original carton or equivalent packaging, fully insured with shipping charges prepaid. ParaBody will not assume any responsibility for any loss or damage incurred in shipping.
- 7. CLAIM PROCEDURES. If service on your ParaBody product is required during the warranty period, please contact our Customer Service Department at 1-800-328-9714 for instructions regarding returning or replacing parts. Please have available the following information: (i) the dealer's name; (ii) the date of purchase; (iii) the serial # (s) of your product (the serial number location is called out on the final assembly drawing included with your assembly instruction); (iv) a description of the nature of the problem.
- 8. OWNER'S RIGHT. This Limited Warranty gives you specific legal rights. You may also have other rights, which vary depending on local law.
- 9. LIMITATION OF IMPLIED WARRANTIES. All implied warranties, except to the extent prohibited by applicable law, shall have no greater duration than the warranty period set forth above. There are no warranties which extend beyond the description in this Limited Warranty. Because local laws do not allow limitations on how long an implied warranty lasts, the above limitations may not apply to you.
- 10. DISCLAIMER. No other express warranty has been made or will be made on behalf of ParaBody with respect to any ParaBody product or the operation, repair or replacement of any ParaBody product. ParaBody shall not be responsible for injury, loss of use of the ParaBody product, inconvenience, loss or damage to personal property, whether direct or indirect, and incidental or consequential damages, so the above limitation or exclusion may not apply to you.

NOTES:

LIFEFITNESS

5100 North River Road. Schiller Park, IL. 60176 U.S.A. Tel: 847.288.3300 Fax: 800.216.8893 800.328.9714 (Toll-free within the U.S. and Canada) www.parabody.com

INTERNATIONAL OFFICES

Life FitnessAtlantic BV Atlantic Headquarters Bijdorpplein 25-31 2992 LB Barendrecht The Netherlands Phone: (180) 646 666 Fax: (180) 646 703

Life Fitness EUROPE GmbH Siemensstrasse 3 85716 Unterschleissheim Germany Phone: (089) 31 77 51-0 Fax: (089) 31 77 51 99

Life Fitness Italia S.R.L. Via Elvas 92 39042 Bressanone Italy Phone: 39 (472) 835-470 Fax: 39 (472) 833-150

Life Fitness Asia Pacific Limited Room 2610, Miramar Tower 132 Nathan Road, Tsimshatsui Kowloon, Hong Kong Phone: (852) 2891-6677 Fax: (852) 2575-6001 Life Fitness (UK) Ltd. Queen Adelaide Ely, Cambs CB7 4UB United Kingdom Phone CSS: (01353) 665507 Fax CSS: (01353) 666719

Life Fitness Benelux N.V. Bijdorpplein 25-31 2992 LB Barendrecht The Netherlands Phone: 31 (180) 64 66 69 Fax: 31 (180) 64 66 99

Life Fitness Japan 8/F, Nippon Brunswick Building 5-27-7 Sendagaya Shibuya-Ku, Tokyo 151-0051 Japan Phone: 81 (3) 3359-4309 Fax: 81 (3) 3359-4307

Life Fitness Do Brazil Al. Rio Negro, 433-Predio 2-Sala 2 3° andar (Confab) Aplhaville-Barueri-Sao Paulo CEP: 06454-904 Brazil Phone: 55 (11)7295-2217 Fax: 55 (11) 7295-2218