

# **User Manual**

# **PPC-155T**

Pentium / Celeron M Processor-Based Panel PC with 15" Color TFT LCD Display

**Trusted ePlatform Services** 



## Copyright

The documentation and the software included with this product are copyrighted 2007 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

## **Acknowledgements**

Award is a trademark of Award Software International, Inc. VIA is a trademark of VIA Technologies, Inc. IBM, PC/AT, PS/2 and VGA are trademarks of International Business Machines Corp. Intel and Pentium are trademarks of Intel Corporation. Microsoft WindowsÆ is a registered trademark of Microsoft Corp. RTL is a trademark of Realtek Semi-Conductor Co., Ltd. Winbond is a trademark of Winbond Electronics Corporation. Ricoh is a trademark of Ricoh Company LTD. All other product names or trademarks are properties of their respective owners.

- For more information on this and other Advantech products, please visit our websites at:
  - http://www.advantech.com
  - http://www.advantech.com/ppc
- For technical support and service, please visit our support website at: *http://support.advantech.com*

This manual supports the PPC-155T.

Part No. 2006C15500 Printed in Taiwan

Edition 1 January 2008

## **Product Warranty (2 years)**

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For outof-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

- 1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal, and list any onscreen messages when the problem occurs.
- 2. Call your dealer and describe the problem. Please have the manual, product, and any helpful information readily available.
- 3. If the product is diagnosed as defective, obtain an RMA (return merchandize authorization) number from the dealer. This allows Advantech to process the return more quickly.
- 4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
- 5. Write the RMA number visibly on the outside of the package and ship it prepaid to the dealer.

## **Declaration of Conformity**

### CE

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from Advantech. Please contact your local supplier for ordering information.

### CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

### FCC Class A

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can

radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### FCC Class B

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FΜ

This equipment has passed the FM certification. According to the National Fire Protection Association, work sites are classified into different classes, divisions and groups, based on hazard considerations. This equipment is compliant with the specifications of Class I, Division 2, Groups A, B, C and D indoor hazards.

## **Technical Support and Assistance**

- 1. Visit the Advantech web site at www.advantech.com/support where you can find the latest information about the product.
- 2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

## Warnings, Cautions and Notes



Warning! Warnings indicate conditions, which if not observed, can cause personal injury!



**Caution!** Cautions are included to help you avoid damaging hardware or losing data.



Ex.: There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Note!
-------

If the unit you have bought is basic (i.e. without a CPU, HDD, or SDRAM), you will find this optional item in the accessory box...

## **Document Feedback**

To assist us with making improvements to this manual, we welcome comments and constructive criticism. Please send all suggestios in writing to: support@advantech.com

## Packing List

Before setting up the system, check that the items listed below are included and in good condition. If any item does not accord with the table, please contact your dealer immediately.

- PPC-155T series panel PC
- User's manual
- Accessories for PPC-155T
- A power cord is not included with this product, but is available for purchase as a separate option.
- "Drivers and Utilities" CD-ROM disc
- Heat sink (optional) (refer to Notes 1 and 2 below)



If the supplied unit is the basic version (i.e. without a CPU, HDD, or SDRAM), look for optional items in the accessory box.

### Note!

If installing an Intel Æ processor, it is necessary to install a heat sink above the CPU. This will avoid heat damage to the CPU.

## **Additional Information and Assistance**

- 1. Visit the Advantech web site at *www.advantech.com* tocan find the latest information about the product.
- 2. Contact the distributor, sales representative, or Advantech's customer service center for technical support and additional assistance. Please have the following information ready before calling:
- Product name and serial number
- Description of peripheral attachments
- Description of software (operating system, version, application software, etc.)

Input voltage rated 100-240 VAC, 50/60 Hz, 4 A.

- A complete description of the problem
- The exact wording of any error messages

Warning! 1.



- 2. Use a 3 V @ 196 mA lithium battery.
- 3. Packing: please carry the unit with both hands, handle with care.
- 4. Maintenance: to properly maintain and clean the surfaces, use only approved products or clean with a dry applicator.
- 5. CompactFlash: Turn off power before insert- ing or removing CompactFlash storage card.

#### **Contact information:**

Our European representative:

Advantech Europe GmbH Kolberger Strafle 7 D-40599 Dusseldorf, Germany Tel: 49-211-97477350 Fax: 49-211-97477300

## **Safety Instructions**

- 1. Read these safety instructions carefully.
- 2. Keep this User Manual for later reference.
- 3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
- 4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
- 5. Keep this equipment away from humidity.
- 6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
- 7. The openings on the enclosure are for air convection. Protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- 9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- 10. All cautions and warnings on the equipment should be noted.
- 11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- 12. Never pour any liquid into an opening. This may cause fire or electrical shock.
- 13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
- 14. If one of the following situations arises, get the equipment checked by service personnel:
- 15. The power cord or plug is damaged.
- 16. Liquid has penetrated into the equipment.
- 17. The equipment has been exposed to moisture.
- 18. The equipment does not work well, or you cannot get it to work according to the user's manual.
- 19. The equipment has been dropped and damaged.
- 20. The equipment has obvious signs of breakage.
- 21. DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -20° C (-4° F) OR ABOVE 60° C (140° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.
- 22. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER, DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.
- 23. The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

DISCLAIMER: This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

## Wichtige Sicherheishinweise

- 1. Bitte lesen sie Sich diese Hinweise sorgfältig durch.
- 2. Heben Sie diese Anleitung für den späteren Gebrauch auf.
- 3. Vor jedem Reinigen ist das Gerät vom Stromnetz zu trennen. Verwenden Sie Keine Flüssig-oder Aerosolreiniger. Am besten dient ein angefeuchtetes Tuch zur Reinigung.
- 4. Die NetzanschluBsteckdose soll nahe dem Gerät angebracht und leicht zugänglich sein.
- 5. Das Gerät ist vor Feuchtigkeit zu schützen.
- 6. Bei der Aufstellung des Gerätes ist auf sicheren Stand zu achten. Ein Kippen oder Fallen könnte Verletzungen hervorrufen.
- 7. Die Belüftungsöffnungen dienen zur Luftzirkulation die das Gerät vor überhitzung schützt. Sorgen Sie dafür, daB diese Öffnungen nicht abgedeckt werden.
- 8. Beachten Sie beim. AnschluB an das Stromnetz die AnschluBwerte.
- 9. Verlegen Sie die NetzanschluBleitung so, daB niemand darüber fallen kann. Es sollte auch nichts auf der Leitung abgestellt werden.
- 10. Alle Hinweise und Warnungen die sich am Geräten befinden sind zu beachten.
- 11. Wird das Gerät über einen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
- 12. Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könnte einen Brand bzw. elektrischen Schlag auslösen.
- 13. Öffnen Sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von authorisiertem Servicepersonal geöffnet werden.
- 14. Wenn folgende Situationen auftreten ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu überprüfen:
- 15. Netzkabel oder Netzstecker sind beschädigt.
- 16. Flüssigkeit ist in das Gerät eingedrungen.
- 17. Das Gerät war Feuchtigkeit ausgesetzt.
- 18. Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
- 19. Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
- 20. Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
- 21. VOSICHT: Explisionsgefahr bei unsachgemaben Austausch der Batterie.Ersatz nur durch densellben order einem vom Hersteller empfohlene-mahnlichen Typ. Entsorgung gebrauchter Batterien navh Angaben des Herstellers.
- 22. ACHTUNG: Es besteht die Explosionsgefahr, falls die Batterie auf nicht fachmännische Weise gewechselt wird. Verfangen Sie die Batterie nur gleicher oder entsprechender Type, wie vom Hersteller empfohlen. Entsorgen Sie Batterien nach Anweisung des Herstellers.
- 23. Der arbeitsplatzbezogene Schalldruckpegel nach DIN 45 635 Teil 1000 beträgt 70dB(A) oder weiger.

Haftungsausschluss: Die Bedienungsanleitungen wurden entsprechend der IEC-704-1 erstellt. Advantech lehnt jegliche Verantwortung für die Richtigkeit der in diesem Zusammenhang getätigten Aussagen ab.

## **Safety Precaution - Static Electricity**

Follow these simple precautions to protect yourself from harm and the products from damage.

- To avoid electrical shock, always disconnect the power from the PC chassis before working on it. Don't touch any components on the CPU card or other cards while the PC is on.
- Disconnect power before making any configuration changes. The sudden rush of power while connecting a jumper or installing a card may damage sensitive electronic components.

1.1       Introduction       2         1 able 1.1       Touchscreen specifications       3         1.3       Dimensions       5         Figure 1.1       Dimensions of PPC-15ST       5         Chapter       2       System Setup       8         2.1       A Quick Tour of the Panel PC       8       8         Figure 2.1       Front panel of PPC-15ST       8       8         Figure 2.2       Left side view of the panel PC       8       9         Figure 2.1       Rear view of the panel PC       9       9         Figure 2.1       Rear view of the panel PC       9       9         Figure 2.3       Nornecting the power cord       10       2.3.1       Connecting the power cord       10         2.3.3       Switching on the power       10       2.3.3       Switching on the power       10         2.4       Running the BIOS Setup Program       10       2.3.3       Switching on the power       11         4       Running the BIOS Setup Program       10       2.3.3       Switching and ejecting a CD-ROM       11         5       Drivers and Utilities on the CD-ROM       11       Figure 3.2       14       14         3.1       Introduction       14	Chapter	1	General Information	2
Table 1.1:         Touchscreen specifications         3           1.3         Dimensions         5           Figure 1.1         Dimensions of PPC-155T         5           Chapter         2         System Setup         8           2.1         A Quick Tour of the Panel PC         8           Figure 2.1         Front panel of PPC-155T         8           Figure 2.2         Left side view of the panel PC         8           Figure 2.4         Rear view of the panel PC         9           Preparing for First-time Use         10         2.3           2.3         Svitching on the power         10           2.3.3         Svitching on the power         10           2.3.3         Svitching on the power         10           2.3         Installing System Software         11           Chapter         3         Using the Panel PC         14           Figure 3.1         Introduction         14           3.1         Introduction         14           3.2         CD-ROM Drive (optional )         14           Figure 3.2         Inserting and ejecting a CD-ROM         15           3.4         PS/2 Mouse and Keyboard         15           3.4         PS/2 Mouse an		1.1	Introduction	2
1.3         Dimensions         5           Figure 1.1         Dimensions of PPC-155T         5           System Setup         8           2.1         A Quick Tour of the Panel PC         8           Figure 2.1         From panel of PPC-155T         8           Figure 2.2         Left side view of the panel PC         9           Preparing for First-time Use         10         2.3           2.2         Preparing for First-time Use         10           2.3.1         Connecting the keyboard and mouse         10           2.3.2         Connecting the keyboard and mouse         10           2.3.3         Switching on the power         10           2.3.3         Switching on the power         10           2.3.4         Connecting the keyboard and mouse         10           2.3.3         Switching on the power         10           2.4         Running the BIOS Setup Program         10           2.5         Installing the Drivers         11           Figure 3.1         Instruction         14           3.1         Introduction         14           3.2         CD-ROM         11           Figure 3.1         Instruing and ejecting a PCMCIA card         15		1.2		
Figure 1.1         Dimensions of PPC-155T         5           Chapter         2         System Setup         8           2.1         A Quick Tour of the Panel PC         8           Figure 2.1         IrFont panel of PPC-155T         8           Figure 2.3         I/O Peripheral Connectors Panel         9           Figure 2.4         Rear view of the panel PC         9           2.2         Preparing for First-time Use         10           2.3.1         Installation Procedures         10           2.3.3         Stotking on the power         11           Chapter         3         Installing System Software         11           1         Histoling System Software         11           2.6         Installing the Drivers         11           3.1         Introduction         14           3.2         CD-ROM Drive (optional )         14           4         Figure 3.1 <th></th> <td></td> <td>•</td> <td></td>			•	
Chapter         2         System Setup         8           2.1         A Quick Tour of the Panel PC.         8           Figure 2.1         Front panel of PPC-155T         8           Figure 2.2         Left side view of the panel PC.         9           9         Figure 2.4         Rear view of the panel PC.         9           2.2         Preparing for First-time Use         10         2.3.1         Connecting the power cord         10           2.3.1         Connecting the power cord         10         2.3.3         Witching on the power         10           2.3.3         Switching on the power         10         2.3.3         Switching on the power         10           2.3.3         Switching be Divers         11         11         5.5         Installing the Drivers         11           2.6         Installing the Drivers         11         11         Figure 3.1         Inserting and ejecting a CD-ROM         14           3.1         Introduction         14         14         14         14           3.3         PCMCIA         15         15         15         16         16           3.4         PS/2 Mouse and Keyboard         15         15         16         16         16         <		1.3		
2.1       A Quick Tour of the Panel PC.       8         Figure 2.1       Front panel of PPC-155T       8         Figure 2.2       Left side view of the panel PC.       9         Preparing for First-time Use       10         2.3       Installation Procedures.       10         2.3       Installation Procedures.       10         2.3.1       Connecting the power cord.       10         2.3.2       Connecting the keyboard and mouse       10         2.3.3       Switching on the power.       10         2.3.3       Switching on the power.       10         2.3.3       Switching on the power.       10         2.4       Running the BIOS Setup Program.       10         2.5       Installing the Drivers.       11         Figure 3.1       Instrailing and ejecting a CD-ROM.       14         3.1       Introduction       14         3.2       CD-ROM Drive (optional )       14         Figure 3.2       Inserting and ejecting a CD-ROM.       14         3.3       PCMCIA       15         Figure 3.3       Inserting and ejecting a PCMCIA card.       15         3.4       PS/Z Mouse and Keyboard       16         Figure 3.4       I/O ports	Observes	•	•	
Figure 2.1       Front panel of PPC-155T	Chapter	2	System Setup	ð
Figure 2.2       Left side view of the panel PC.       8         Figure 2.4       Rear view of the panel PC.       9         2.2       Preparing for First-time Use       10         2.3       Installation Procedures.       10         2.3       Connecting the power cord       10         2.3.1       Connecting the power cord       10         2.3.2       Connecting the power       10         2.3.3       Connecting the power       10         2.3.4       Connecting the power       10         2.3.5       Connecting the power       10         2.3.6       Installing the Drivers       11         1       Installing the Drivers       11         2.6       Installing the Drivers       11         1       Figure 3.1       Insterting and ejecting a CD-ROM       14         3.1       Introduction       14       14         3.3       PC/MOIA       15       15         3.4       PS/2 Mouse and Keyboard       15       15         3.4       PS/2 Mouse and Keyboard       16       17         3.6       Serial COM Ports       17       17         3.6       Serial COM Ports       17       17 <t< th=""><th></th><th>2.1</th><th>A Quick Tour of the Panel PC</th><th>8</th></t<>		2.1	A Quick Tour of the Panel PC	8
Figure 2.3       1/O Peripheral Connectors Panel.       9         Figure 2.4       Rear view of the panel PC       9         Preparing for First-time Use       10         2.3       Installation Procedures.       10         2.3       Installation Procedures.       10         2.3.1       Connecting the keyboard and mouse       10         2.3.3       Switching on the power cord.       10         2.4       Running the BIOS Setup Program       10         2.5       Installing the BIOS Setup Program       10         2.6       Installing the Drivers.       11         Figure 2.5       Drivers and Utilities on the CD-ROM       11         Figure 3.1       Inserting and ejecting a CD-ROM       14         3.1       Introduction       14         3.2       CD-ROM Drive (optional )       14         3.3       PC/CA       15         3.4       PS/Z Mouse and Keyboard       15         3.5       PCI Bus Expansion       16         5.6       Serial COM Ports       17         3.7       VGA Port       17         3.8       USB Ports       17         3.9       Audio Interface       18         3.10       <			Figure 2.1 Front panel of PPC-155T	8
Figure 2.4       Rear view of the panel PC.       9         2.2       Preparing for First-time Use       10         2.3       Installation Procedures.       10         2.3.1       Connecting the power cord       10         2.3.2       Connecting the keyboard and mouse       10         2.3.3       Switching on the power       10         2.4       Running the BIOS Setup Program       10         2.5       Installing System Software       11         2.6       Installing System Software       11         3.1       Introduction       14       14         3.1       Introduction       14       15         5       Swite Kpansion       16       16         3.1       Installing the Veloard       15         7       Figure 3.4       I/O ports       17         3.7       VGA				
2.2       Preparing for First-time Use       10         2.3       Installation Procedures.       10         2.3.1       Connecting the power cord       10         2.3.2       Connecting the power cord       10         2.3.3       Switching on the power       10         2.3.3       Switching on the power       10         2.4       Running the BIOS Setup Program       10         2.5       Installing System Software       11         1       Figure 2.5       Drivers and Utilities on the CD-ROM         11       Figure 2.5       Drivers and Utilities on the CD-ROM         14       3.1       Introduction       14         3.2       CD-ROM Drive (optional)       14         3.3       PCMCIA       15         Figure 3.1       Inserting and ejecting a PCMCIA card       15         3.4       PS/2 Mouse and Keyboard       16         6       Serial COM Ports       17         3.5       PCI Bus Expansion       16         6       Serial COM Ports       17         3.6       Serial COM Ports       17         3.7       VGA Port       17         3.8       USB Ports       17         3.9 <th></th> <th></th> <th></th> <th></th>				
2.3       Installation Procedures			5	
2.3.1       Connecting the power cord       10         2.3.2       Connecting the keyboard and mouse       10         2.3.3       Switching on the power       10         2.4       Running the BIOS Setup Program       10         2.5       Installing the Drivers       11         10       1       Installing the Drivers       11         Figure 2.5       Drivers and Utilities on the CD-ROM       11         Chapter 2.         3.1       Introduction       14         3.2       CD-ROM Drive (optional)       14         Figure 3.1       Inserting and ejecting a CD-ROM       14         3.3       PCMCIA       15         3.4       PS/2 Mouse and Keyboard       15         3.5       PCI Bus Expansion       16         3.5       PCI Bus Expansion       16         3.6       Serial COM Ports       17         3.7       VGA Port       17         3.8       USB Ports       17         3.9       Audio Interface       18         3.11       Front Bezel LED and Light Sensor       18         3.12       Touchscreen (Optional)       19         4       HardWare Installintin function       <				
2.3.2 Connecting the keyboard and mouse       10         2.3.3 Switching on the power       10         2.4 Running the BIOS Setup Program       10         2.5 Installing System Software       11         2.6 Installing the Drivers       11         Figure 2.5 Drivers and Utilities on the CD-ROM       11         Chapter 3         3.1 Introduction       14         3.2 CD-ROM Drive (optional)       14         3.1 Introduction       14         3.2 CD-ROM Drive (optional)       14         3.3 PCI Dus Expansion       15         Figure 3.1 Inserting and ejecting a PCMCIA card       15         3.4 PS/2 Mouse and Keyboard       16         3.5 PCI Bus Expansion       16         5.4 PS/2 Mouse and Keyboard       17         3.5 PCI Bus Expansion       16         7 Syz Mouse and Keyboard       17         3.6 Serial COM Ports       17         3.7 VGA Port       17         3.8 USB Ports       17         3.10 Ethernet       18         3.11 Front Bezel LED and Light Sensor       18         3.12 Touchscreen (Optional)       19         4.1 Jumpers and Connectors       22         Figure 4.1 Unfastening the rear cover       22		2.3		
2.3.3 Switching on the power.       10         2.4       Running the BIOS Setup Program.       10         2.5       Installing System Software.       11         2.6       Installing the Drivers.       11         2.6       Installing the Drivers.       11         Figure 2.5       Drivers and Utilities on the CD-ROM.       11         Chapter 3         3.1       Introduction       14         3.2       CD-ROM Drive (optional)       14         Figure 3.1       Inserting and ejecting a CD-ROM.       14         3.3       PCMCIA       15         3.4       PS/2 Mouse and Keyboard       15         3.5       PCI Bus Expansion       16         Figure 3.1       PCI Bus Expansion       16         3.5       PCI Bus Expansion       16         3.6       Serial COM Ports       17         3.7       VGA Port       17         3.8       USB Ports       17         3.9       Audio Interface       18         3.11       Front Bezel LED and Light Sensor       18         Figure 3.5       LED & light sensor       18         3.12       Touchscreen (Optional)       19 <td< th=""><th></th><th></th><th></th><th></th></td<>				
2.4       Running the BiOs Setup Program				
2.5       Installing System Software       11         2.6       Installing the Drivers       11         Figure 2.5       Drivers and Utilities on the CD-ROM       11         Figure 3.1       Introduction       14         3.1       Introduction       14         3.2       CD-ROM Drive (optional )       14         3.3       PCMCIA       14         3.4       PCMCIA       15         Figure 3.2       Inserting and ejecting a PCMCIA card       15         3.4       PS/2 Mouse and Keyboard       15         3.5       PCI Bus Expansion       16         Figure 3.3       PCI bus expansion       16         3.6       Serial COM Ports       17         3.7       VGA Port       17         3.8       USB Ports       17         3.9       Audio Interface       18         3.11       Front Bezel LED and Light Sensor       18         3.12       Touchscreen (Optional)       19         Chapter       4       Hardware Installation       22         4.1       Jumpers and Connectors       22       22         4.2       Disassembling the Panel PC       22       19         5.2		2.4		
2.6       Installing the Drivers			•	
Chapter         3         Using the Panel PC		2.6		
3.1Introduction143.2CD-ROM Drive (optional )14Figure 3.1Inserting and ejecting a CD-ROM143.3PCMCIA15Figure 3.2Inserting and ejecting a PCMCIA card153.4PS/2 Mouse and Keyboard153.5PCI Bus Expansion163.6Serial COM Ports17Figure 3.3PCI bus expansion163.6Serial COM Ports173.7VGA Port173.8USB Ports173.9Audio Interface183.10Ethernet183.11Front Bezel LED and Light Sensor183.12Touchscreen (Optional)19Hardware Installation4Hardware Installation22Figure 4.1Unfastening the HDD side cover22Figure 4.2Unfastening the HDD side cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive244.3Installing the 2.5" Hard Disk Drive244.4Installing the CPU in the socket25Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the CPU in the socket264.4Installing the CPU in the socket26Figure 4.10Placing the cPU in the socket26Figure 4.10Placing the CPU module to the motherboard284.5Ins			Figure 2.5 Drivers and Utilities on the CD-ROM	11
3.1Introduction143.2CD-ROM Drive (optional )14Figure 3.1Inserting and ejecting a CD-ROM143.3PCMCIA15Figure 3.2Inserting and ejecting a PCMCIA card153.4PS/2 Mouse and Keyboard153.5PCI Bus Expansion163.6Serial COM Ports17Figure 3.3PCI bus expansion163.6Serial COM Ports173.7VGA Port173.8USB Ports173.9Audio Interface183.10Ethernet183.11Front Bezel LED and Light Sensor183.12Touchscreen (Optional)19Hardware Installation4Hardware Installation22Figure 4.1Unfastening the HDD side cover22Figure 4.2Unfastening the HDD side cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive244.3Installing the 2.5" Hard Disk Drive244.4Installing the CPU in the socket25Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the CPU in the socket264.4Installing the CPU in the socket26Figure 4.10Placing the cPU in the socket26Figure 4.10Placing the CPU module to the motherboard284.5Ins	Chapter	3	Using the Panel PC	14
3.2       CD-ROM Drive (optional )       14         Figure 3.1       Inserting and ejecting a CD-ROM       14         3.3       PCMCIA       15         Figure 3.2       Inserting and ejecting a PCMCIA card       15         3.4       PS/2 Mouse and Keyboard       15         3.4       PS/2 Mouse and Keyboard       15         3.5       PCI Bus Expansion       16         Figure 3.3       PCI bus expansion       16         3.6       Serial COM Ports       17         Figure 3.4       I/O ports       17         3.7       VGA Port       17         3.8       USB Ports       17         3.9       Audio Interface       18         3.10       Ethernet       18         3.11       Front Bezel LED and Light Sensor       18         S112       Touchscreen (Optional)       19         4       Hardware Installation       22         4.1       Jumpers and Connectors       22         4.2       Disassembling the Panel PC       22         Figure 4.3       Disconnecting the fan connector       23         Figure 4.4       The PPC without the Rear Cover       24         Figure 4.5       Fastenin				
Figure 3.1       Inserting and ejecting a CD-ROM				
3.3PCMCIA15Figure 3.2Inserting and ejecting a PCMCIA card.153.4PS/2 Mouse and Keyboard153.5PCI Bus Expansion163.6Serial COM Ports17Figure 3.4I/O ports173.7VGA Port.173.8USB Ports173.9Audio Interface183.10Ethernet.183.11Front Bezel LED and Light Sensor18Figure 3.5LED & light sensor183.12Touchscreen (Optional)194Hardware Installation224.1Jumpers and Connectors22Figure 4.2Disassembling the Panel PC22Figure 4.3Disconnecting the fan connector23Figure 4.4The PC without the Rear Cover23Figure 4.5Fastening the HDD side cover24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the HDD frame254.4Installing the Central Processing Unit (CPU)26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.11Fastening the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29		5.2		
Figure 3.2 Inserting and ejecting a PCMCIA card.153.4PS/2 Mouse and Keyboard.153.5PCI Bus Expansion16Figure 3.3PCI bus expansion.16Serial COM Ports17Figure 3.4I/O ports173.7VGA Port.173.8USB Ports173.9Audio Interface183.10Ethernet.183.11Front Bezel LED and Light Sensor18Figure 3.5LED & light sensor183.12Touchscreen (Optional).194.1Jumpers and Connectors22Figure 4.1Unfastening the Panel PC22Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the far connector23Figure 4.4The PPC without the Rear Cover24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the Central Processing Unit (CPU)26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.11Fastening the CPU module to the motherboard .284.5Installing the DDR SDRAM Memory Module29		33		
3.4PS/2 Mouse and Keyboard153.5PCI Bus Expansion16Figure 3.3PCI bus expansion163.6Serial COM Ports17Figure 3.4I/O ports173.7VGA Port173.8USB Ports173.9Audio Interface183.10Ethernet183.11Front Bezel LED and Light Sensor18Figure 3.5LED & light sensor183.12Touchscreen (Optional)19Hardoware Installation4.1Jumpers and Connectors22Figure 4.1Unfastening the Panel PC22Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the CPU in the socket26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29		0.0		
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		3.4		
3.6       Serial COM Ports       17         Figure 3.4       I/O ports       17         3.7       VGA Port       17         3.8       USB Ports       17         3.9       Audio Interface       18         3.10       Ethernet       18         3.11       Front Bezel LED and Light Sensor       18         Figure 3.5       LED & light sensor       18         3.12       Touchscreen (Optional)       19         4       Hardware Installation       22         4.1       Jumpers and Connectors       22         4.2       Disassembling the Panel PC       22         Figure 4.1       Unfastening the rear cover       23         Figure 4.2       Unfastening the rear cover       23         Figure 4.3       Disconnecting the fan connector       23         Figure 4.4       The PPC without the Rear Cover       24         4.3       Installing the 2.5" Hard Disk Drive       24         4.3       Installing the Central Processing Unit (CPU)       26         Figure 4.6       Plugging in the EIDE cable       25         Figure 4.8       Placing the CPU in the socket       26         Figure 4.10       Placing the CPU in the socket		3.5	<b>,</b>	
Figure 3.4I/O ports173.7VGA Port173.8USB Ports173.9Audio Interface183.10Ethernet183.11Front Bezel LED and Light Sensor18Figure 3.5LED & light sensor187Touchscreen (Optional)194Hardware Installation224.1Jumpers and Connectors224.2Disassembling the Panel PC22Figure 4.1Unfastening the franc cover23Figure 4.2Unfastening the franc cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the HDD frame25Figure 4.8Placing the CPU in the socket26Figure 4.10Placing the CPU in the socket26Figure 4.10Placing the CPU in the socket26Figure 4.10Placing the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29				
3.7       VGA Port		3.6		
3.8USB Ports173.9Audio Interface183.10Ethernet183.11Front Bezel LED and Light Sensor18Figure 3.5LED & light sensor183.12Touchscreen (Optional)194Hardware Installation224.1Jumpers and Connectors224.2Disassembling the Panel PC22Figure 4.1Unfastening the HDD side cover22Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the CPU in the socket26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the heatsink and fan on the CPU27Figure 4.10Placing the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29				
3.9Audio Interface183.10Ethernet183.11Front Bezel LED and Light Sensor18Figure 3.5LED & light sensor183.12Touchscreen (Optional)194Hardware Installation224.1Jumpers and Connectors224.2Disassembling the Panel PC22Figure 4.1Unfastening the HDD side cover22Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the CPU in the socket26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the heatsink and fan on the CPU27Figure 4.10Placing the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29				
3.10Ethernet			· ·· · · · ·	
3.11Front Bezel LED and Light Sensor.18Figure 3.5LED & light sensor.183.12Touchscreen (Optional).19Hardware Installation				
Since in the second s				
3.12Touchscreen (Optional)		5.11		
Chapter4Hardware Installation224.1Jumpers and Connectors224.2Disassembling the Panel PC22Figure 4.1Unfastening the HDD side cover22Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the HDD frame254.4Installing the Central Processing Unit (CPU)26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the heatsink and fan on the CPU27Figure 4.11Fastening the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29		3.12		
4.1Jumpers and Connectors224.2Disassembling the Panel PC22Figure 4.1Unfastening the HDD side cover22Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the Central Processing Unit (CPU)26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the heatsink and fan on the CPU27Figure 4.11Fastening the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29	Chanter			
4.2Disassembling the Panel PC	onapter	-		
Figure 4.1Unfastening the HDD side cover22Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the HDD frame254.4Installing the Central Processing Unit (CPU)26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the heatsink and fan on the CPU27Figure 4.11Fastening the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29				
Figure 4.2Unfastening the rear cover23Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the HDD frame254.4Installing the Central Processing Unit (CPU)26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the heatsink and fan on the CPU27Figure 4.11Fastening the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29		4.2		
Figure 4.3Disconnecting the fan connector23Figure 4.4The PPC without the Rear Cover244.3Installing the 2.5" Hard Disk Drive24Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable25Figure 4.7Aligning the HDD frame254.4Installing the Central Processing Unit (CPU)26Figure 4.8Placing the CPU in the socket26Figure 4.9Tightening the screws on the CPU27Figure 4.10Placing the heatsink and fan on the CPU27Figure 4.11Fastening the CPU module to the motherboard284.5Installing the DDR SDRAM Memory Module29				
<ul> <li>Figure 4.4 The PPC without the Rear Cover</li></ul>				
<ul> <li>4.3 Installing the 2.5" Hard Disk Drive</li></ul>				
Figure 4.5Fastening the HDD metal frame to the HDD24Figure 4.6Plugging in the EIDE cable		4.3		
Figure 4.6 Plugging in the EIDE cable			•	
<ul> <li>4.4 Installing the Central Processing Unit (CPU)</li></ul>			• •	
Figure 4.8 Placing the CPU in the socket				
Figure 4.9 Tightening the screws on the CPU		4.4		
Figure 4.10 Placing the heatsink and fan on the CPU			<b>v</b>	
<ul><li>Figure 4.11 Fastening the CPU module to the motherboard28</li><li>4.5 Installing the DDR SDRAM Memory Module</li></ul>				
4.5 Installing the DDR SDRAM Memory Module			•	
<b>o</b> ,		15		
		- <del>1</del> .J	Figure 4.12 Placing the memory module in the DIMM	

Chapter 5	Jumpers & Connectors32
5.1	Jumpers and Connectors325.1.1 Setting jumpers325.1.2 Jumpers32Table 5.1: PCI slot voltage setting (JP2)33Table 5.2: Clear CMOS (JP3)33Table 5.3: LVDS voltage setting (JP5)33Figure 5.1 Jumpers and connectors on the PPC-155T motherboard345.1.3 Connectors35Table 5.4: PPC-155T connectors table35
Chapter 6	Driver Installation38
6.1 6.2 Appendix A	Driver Installation
A.1	Disassembly Procedure40Figure A.1Unfastening the HDD side cover40Figure A.2Unfastening the rear cover41Figure A.3Disconnecting the fan connector41Figure A.4The PPC without the rear cover42Figure A.5Removing the PCI riser card42Figure A.6Unfastening the middle plate43Figure A.7Removing the MDD module43Figure A.8Unfastening the HDD module44Figure A.9Removing the HDD cable44Figure A.10Disconnecting the HDD cable45Figure A.11Loosening the screws on the HDD bracket45Figure A.12Loosening the screws on the CD-ROM module46Figure A.13Pushing out the brace holding the CD-ROM46Figure A.14Removing the fixed brace47Figure A.15Unfastening the CD-ROM / PCMCIA slot cover48Figure A.17Removing the CD-ROM module48Figure A.18Disconnecting the CD-ROM connector49Figure A.19Removing the CD-ROM connector49Figure A.20Unfastening the CPU module49Figure A.21Removing the CPU50Figure A.21Removing the CPU50Figure A.22Removing the CPU50Figure A.22Removing the CPU51
Appendix B	PCI Card Size Limits       54         Figure B.1       PCI Card Dimensional Limits       54



## **General Information**

This chapter gives background information on the PPC-155T Sections include:

- Specifications
- Dimensions

## 1.1 Introduction

Advantech PPC-155T is an Intel Pentium-M processor based Panel PC with a bright 15" LCD display. The powerful Pentium-M/Celeron-M CPU and Intel 855GME chipset brings the most dynamic applications to life without sacrifices to any industrial reliability. Internal CF card interface can treat as alternative HDD solution for OS booting and Mini-PCI interface can equip with many expansion cards such as Wireless LAN card to extend mobility application. Front bezel LEDs display PPC Power on, HDD and LAN operating status and a built-in front light sensor can automatically adjust the brightness level in different operating conditions. In order to satisfy customers security concerns, PPC-155T is also offered in a two LAN port configuration; customers can contact local sales for OEM orders.

## 1.2 Specifications

### 1.2.0.1 General

- Dimensions (W x H x D): 396.5 x 317.6 x 103.5 mm (15.6" x 12.5" x 4.07")
- Weight: 6kg (13.2 lbs)
- Power supply:
  - AC model: 100 watts
  - Input voltage: 100 ~ 250 VAC @ 50 ~ 60 Hz
  - Max Output voltage: +3.3V@6A, +5V@8A, +12V@5A, -12V@0.5A,
  - +5VSB@0.75A, -3.3V, 5V total 50W(max)
- Disk drive housing: Space for one 2.5" HDD, one 12.7 mm compact CD-ROM drive
- Front panel: IP65 protection (not for the model with SAW touchscreen)

### 1.2.0.2 Standard PC functions

- CPU: Supports Intel Pentium-M and Celeron-M up to 1.8 / 1.5GHz.
- BIOS: Award 4 MB Flash BIOS, supports Plug & Play, APCI
- Chipset: Intel 855GME / ICH4
- RAM: Two 184-pin DDR DIMM sockets up to 2GB DDR SDRAM
- Serial ports: Three serial ports with three RS-232 ports (COM1, 3, and 4), one RS-232/422/485 port (COM2) which can be selected from BIOS set up program. All ports are compatible with 16C550 UARTs
- Universal serial bus (USB) port: Supports up to four USB V2.0 ports
- PCI bus expansion slot: Accepts one PCI bus card
- Watchdog timer: 255-level, interval timer, set up by software
- Battery: 3.0 V @ 196 mA lithium battery

### 1.2.0.3 AGP SVGA Flat panel interface

- Chipset: Intel 855GME chipset with integrated Intel Extreme Graphics 2
- Display memory: optimized shared memory architecture, supports up to 64MB frame buffer using system memory
- Display type: Simultaneously supports CRT and flat panel displays (EL, LCD and gas plasma)
- Display resolution: Supports non-interlaced CRT and TFT LCD displays up to 1024 x 768 @ 256K

### 1.2.0.4 Audio function

- Chipset: Realtek ALC650
- Audio controller: AC97 Ver. 2.0 compliant interface, Multi-stream, Direct Sound and Direct Sound 3D acceleration
- Stereo sound: 18-bit full-duplex codec
- Audio interface: Microphone-in, Line-in, Line-out

### 1.2.0.5 Ethernet interface

- Full compliance with IEEE 802.3u 100Base-T and 10 Base-T specifications. Includes software drivers and boot ROM.
- Wake on LAN (WOL) and wake on USB support: Wake on LAN/USB function support for ATX power control

### 1.2.0.6 PCMCIA interface

- Chipset: RICOH R5C842
- Cardbus controller: A PC card controller offers a single chip solution as a bridge between the PCI bus and the Cardbus
- PCI bus interface: Complies with PCI Local Bus Specification 2.1, and supports the 32-bit Cardbus (Card-32) and the 16-bit PC card (Card-16) without external buffers

Table 1.1: Touchscreen specifications						
Туре	Analog Resistive	Capacitive	Surface Acoustic Wave (SAW)			
Resolution	Continuous	1024 x 1024	4096 x 4096			
Light Transmission	75%	85%	91%			
Controller		RS-232 Interface				
Power Consumption	+5 V @ 200 mA	+5 V @ 100 mA	+5 V @ 150 mA			
Software Driver	Supports both DOS and Windows					
Durability (touches in a life- time)	35 million	225 million	50 million			

#### 1.2.0.7 Touchscreen specifications (optional)

#### 1.2.0.8 **Optional Modules**

- CPU: Intel Pentium-M or Celeron-M processor up to 1.8 / 1.5 GHz.
- Memory: Supports up to 2 GB DDR SDRAM (184-Pin)
- HDD 2.5" IDE HDD (Notices: It is advisable that customers equip the system with an HDD with an operating temperature rating of 50° C or above whenever the ambient temperature exceeds 35° C.)
- Touchscreen : Analog resistive, capacitive, or Surface Acoustic Wave
- CD-ROM drive : Slim type 24X CD-ROM or above
- DVD-ROM drive : Slim type 6X DVD-ROM or above
- PCMCIA interface: Complies with 1995 PCMCIA card standard. Supports two PCMCIA card/CardBus slots. Two sockets support both a 16-bit PCMCIA card and a 32-bit CardBus simultaneously. Hot insertion and removal.
- CF Interface: type II CF slot (IDE interface) for OS booting
- LAN: 2nd 10/100 Bases LAN or Giga LAN are optional

### 1.2.0.9 Environment

- Temperature: 0 ~ 45° C (32 ~ 122° F)
- Relative humidity: 10 ~ 95% @ 40° C (non-condensing)
- Shock: 10 G peak acceleration (11 msec duration)
- Power MTBF: >130,000hrs

### 1.2.0.10 Certifications:

- EMC: CE, FCC, VCCI, BSMI, 3C
- BSMI approved Safety: CE, UL, CB.

## 1.3 **Dimensions**



Figure 1.1 Dimensions of PPC-155T



## **System Setup**

This chapter gives system setup information for the PPC-155T Sections include:

- A Quick Tour
- Installation Procedures
- Running the BIOS Setup
- Installing System Software

## 2.1 A Quick Tour of the Panel PC

Before starting to set up the panel PC, take a moment to become familiar with the locations and purposes of controls, drives, connectors and ports, which are illustrated in the figures below.

When placed upright on the desktop, the front panel of the panel PC appears as shown in Figure 2-1:



Figure 2.1 Front panel of PPC-155T

When viewed from the left side of the panel PC, the CD-ROM drive and PCMCIA expansion sockets are visible, as shown in Fig. 2-2:



Figure 2.2 Left side view of the panel PC

Viewed from the bottom side, the PCI expansion slot is located along with other IO, on the bottom left side. This slot is covered by a side panel cover. The sunken I/O section is at the bottom of the panel PC, as shown in Fig. 2-3. (The I/O section includes various I/O ports, including serial ports, parallel port, the Ethernet port, USB ports, the audio jacks, and so on.)



Figure 2.3 I/O Peripheral Connectors Panel

Both standard VESA standard 75 x 75 / 100 x 100 mm mounting sizes are supported, so that customers may install different accessories for various applications.



Figure 2.4 Rear view of the panel PC

## 2.2 Preparing for First-time Use

Before commencing set up of the panel PC system, the following items should be available:

- Keyboard
- Mouse (for system software installation)

## 2.3 Installation Procedures

### 2.3.1 Connecting the power cord

The panel PC can only be powered through an AC electrical outlet ( $100 \sim 250$  volts,  $50 \sim 60$  Hz). Be sure to handle the power cords by holding the plug ends only. Follow these procedures in order:

- 1. Connect the female end of the power cord to the AC inlet of the panel PC.
- 2. Connect the 3-pin male plug of the power cord to an electrical outlet.

### 2.3.2 Connecting the keyboard and mouse

Connect the PS/2 mouse and keyboard to the I/O section of PPC.

If using a serial mouse and the panel PC has a touchscreen, it is possible to connect the mouse to any COM port *except* COM4.

### 2.3.3 Switching on the power

Switch on the power switch, which is located inside the bottom side cover.

## 2.4 Running the BIOS Setup Program

The panel PC will be properly set up and configured by the dealer prior to delivery. However, it may be necessary to use the panel PC's BIOS (Basic Input-Output System) setup program to change the system configuration information, such as the current date and time, or the type of hard drive. The setup program is stored in read-only memory (ROM). It can be accessed either when you turn on or reset the panel PC, by pressing the "Del" key on your keyboard immediately after powering on the computer.

The settings specified with the setup program are recorded in a special area of memory called "CMOS RAM." This memory is backed up by a battery so that it will not be erased after turning off or resetting the system. Whenever the power is turned on, the system reads the settings stored in CMOS RAM and compares them to the equipment check conducted during the power on self-test (POST). If a problem occurs, an error message will be displayed on screen, and the computer prompts the user to run the setup program.

#### Installing System Software 2.5

Recent releases of operating systems from major vendors include setup programs which load automatically and guide you through hard disk formatting and operating system installation. The guidelines below will help determine the steps necessary to install the operating system onto the panel PC hard drive.



Some distributors and system integrators may have already preinstalled system software prior to shipment.



The BIOS of the panel PC supports system boot-up directly from the CD-ROM drive. Alternatively, it is possible to insert the system installation CD into the CD-ROM drive.

To power on the panel PC, or to reset the system: press the "Ctrl"+"Alt"+"Del" keys simultaneously. The panel PC will automatically load the operating system from the diskette or CD-ROM.

If presented with a setup or installation program, follow the instructions on screen. The setup program guides the user through preparation of a new hard drive, and installation of the new operating system.

If presented with an operating system command prompt, such as E:\>, then partition and format the hard drive, and manually copy the operating system files to it. Refer to the operating system user manual for instructions on partitioning and formatting a hard drive.

#### 2.6 Installing the Drivers

After installing your system software, you will be able to set up the Chipset, Ethernet, VGA, audio, PCMCIA, light sensor and touchscreen functions. All the drivers are stored in a CD-ROM disc entitled "Drivers and Utilities." the CD-ROM can be found in your accessory box.



Figure 2.5 Drivers and Utilities on the CD-ROM

The various drivers and utilities in the CD-ROM disc which help users install the drivers and understand their functions. These files are a very useful supplement to the information in this manual.

### Note!

The drivers and utilities used for the PPC-155T panel PCs are subject to change without notice. If in doubt, check Advantech's website or contact our application engineers for the latest information regarding drivers and utilities.



## Using the Panel PC

This chapter explains onboard devices and peripherial I/O ports available on the PPC-155T Sections include:

- CD-ROM Drive
- PS/2 Mouse and Keyboard
- PCI Bus Expansion
- Serial COM Ports
- VGA Port
- USB Ports
- Audio Interface
- **Ethernet**
- Front Bezel LED and Light Sensor
- Touchscreen (Optional)

## 3.1 Introduction

This chapter describes basic features and procedures for using the panel PC. Topics covered include: the floppy drive, CD-ROM drive, I/O ports and the touchscreen.

## 3.2 CD-ROM Drive (optional)

It is possible to use the USB external optical device, or order the PPC-155T, which is equipped with slim optical devices.

To insert a CD-ROM disc, press the eject button on the CD-ROM drive.

To eject a CD-ROM disc, first ensure that the drive activity light is not active. Then press the eject button on the drive.



Figure 3.1 Inserting and ejecting a CD-ROM

## 3.3 PCMCIA

Memory Flash Cards are inserted and ejected in much the same way as diskettes.

To insert a Flash Memory card, align the card with the socket and slide the card into the socket until it locks into place. Take note that some FlashMemory cards must be properly configured thorugh the operating system before they can be used for data storage. (See the Flash Memory card manual for details.)

To eject a Flash Memory card, first ensure that the panel PC is not accessing the memory card or device. Then press the appropriate eject button on the socket.



Figure 3.2 Inserting and ejecting a PCMCIA card

## 3.4 PS/2 Mouse and Keyboard

To install a full-size desktop PS/2 keyboard and mouse with the panel PC, follow these instructions:

- 1. Be sure the panel PC is turned off.
- 2. Attach the keyboard to the purple colored 5-pin PS/2 port.
- 3. Attach the PS/2 mouse to the green colored port.
- 4. Turn on the panel PC.

## 3.5 PCI Bus Expansion

The panel PC supports PCI bus expansion cards. To integrate a new PCIbus card into the system, follow these instructions:

- 1. Turn off the panel PC.
- 2. Unscrew the eight screws on the top of the rear cover, and remove it.
- 3. Remove the metal plate by unscrewing the single attaching screw.
- 4. Insert the PCI bus card into the PCI slot of the riser card. (See Fig. 3-3)
- 5. Run the setup program within the OS to configure the system.



Figure 3.3 PCI bus expansion

## 3.6 Serial COM Ports

There are three serial COM ports on the bottom. It is simple to attach a serial device to the panel PC, like an external modem or mouse.

Follow these instructions:

- 1. Be sure the panel PC and any other peripheral devices that are connected to the panel PC are turned off.
- 2. Attach the interface cable of the serial device to the panel PC's serial port. (See *Fig. 3-4.*) If necessary, attach the other end of the interface cable to the serial device. Fasten any retaining screws.
- 3. Turn on any other peripheral devices that is connected to the panel PC, and then turn on the panel PC.
- 4. Refer to the manual(s) which accompanied any serial device(s) for instructions on configuring the operating environment to recognize the device(s).
- 5. Run the BIOS setup program and configure the jumper settings to change the mode of the COM ports.



Figure 3.4 I/O ports

## 3.7 VGA Port

An external VGA-compatible device may be connected to the system through the 15pin external port located on the bottom of the system unit.

The panel PC simultaneously supports an external CRT monitor in addition to the built-in LCD display.

- 1. Be sure the panel PC is turned off.
- 2. Connect the external monitor to the system. (See Fig. 3-4.)
- 3. Turn on the panel PC and the external monitor.

### 3.8 USB Ports

An external USB device may be connected to the system through the 4-pin USB ports located on the rear side of the system unit.

- 1. Connect the external device to the system. (See Fig. 3-4.)
- 2. The USB ports support hot plug-in connection. Install the device driver before using the device.

## 3.9 Audio Interface

The audio interface includes three jacks: Microphone in, Line out and Line in. (*See Fig. 3-4.*) Their functions are:

- Microphone in: Use an external microphone to record voice and sound.
- Line out: Output audio to external devices such as speakers or earphones.
- Line in: Input audio from an external CD player or radio.
- 1. Connect the audio device to the system. (See Fig. 3-4.)
- 2. Install the driver before using the device.

### 3.10 Ethernet

External devices on the network may be connected to the system through the external Ethernet port located on the bottom of the system unit.

- 1. Be sure the panel PC is turned off.
- 2. Connect the external device(s) to the panel PC.
- 3. Turn on the panel PC and the external device(s).



Customer can order two LAN ports or Change default LAN port to Giga LAN via Advantech OEM processes.

## 3.11 Front Bezel LED and Light Sensor

On the front bezel of the PPC-155T there are three LEDs to indicate Power, HDD, LAN. A light sensor with built-in panel brightness level control completes the array. (*See Figure 3.5*).



Figure 3.5 LED & light sensor

Details about the light sensor are available on the Driver CD, inside the "light sensor" folder. The Advantech "Smart Backlight Utility" is aimed to help the user adjust the backlighting of the panel. Users can also configure the backlight of the panel from desktop utility; switch between manual-mode/auto-mode set the backlight value. The SUSI software library is also available to support configuration and operation of the system controls and sensors.

## 3.12 Touchscreen (Optional)

The touchscreen is connected to the internal RS-232 port. Its function is similar to that of a mouse. There are 3 kinds of touchscreens that support the PPC-155T: *resistive*, *capacitive* and *SAW* type.

It is necessary to install the touchscreen driver before it will function. The touchscreen drivers for various operating systems are stored on the CD-ROM disc inside the accessory box.



## Hardware Installation

This chapter gives instructions for installing hardware devices on the PPC-155T

Sections include:

- Jumpers and Connectors
- Disassembling the Panel PC
- Installing the Central Processing Unit (CPU)
- Installing the DDR SDRAM Memory Module

### 4.1 Jumpers and Connectors

The panel PC consists of a PC-based computer that is housed in a metal shielding case with a plastic cover on the rear and bottom. All the computer devices, like the CPU, HDD, SDRAM, and power supply are all readily accessible after removing the rear panel or the HDD cover. Any maintenance or hardware upgrades can be easily completed after removing the rear panel and/or HDD cover.

For information about complete disassembly of the panel PC, refer to Appendix B.

**Warning!** Do not remove the plastic rear cover until verifying that no power is flowing within the panel PC. Power must be switched off and the power cord must be unplugged. Each time the panel PC is serviced, users should be aware of this condition.

### 4.2 Disassembling the Panel PC

The following are standard procedures for disassembling the panel PC before upgrading the system. All procedures are illustrated in Fig. 4-1, 4-2, 4-3 and 4-4.

1. Unscrew the side cover on the plastic HDD cover to expose the HDD module. The Type II CF slot lies underneath the HDD module.



Figure 4.1 Unfastening the HDD side cover

2. Unfasten the screws securing the rear plastic cover and remove it.



Figure 4.2 Unfastening the rear cover

3. Before removing the rear cover, disconnect the system fan connector.



Figure 4.3 Disconnecting the fan connector



Figure 4.4 The PPC without the Rear Cover

## 4.3 Installing the 2.5" Hard Disk Drive

One enhanced Integrated Device Electronics (IDE) hard disk drive may be attached to the panel PC's internal controller which uses a PCI local-bus interface. The following instructions are for installing the HDD:

- 1. A metal plate holds the HDD to the upper right-hand side of the metal shielding case. (*See Fig. 4-5.*) Fix the two screws on the metal plate of two side of HDD.
- 2. Connect IDE cable from main board.
- 3. Place the HDD on the metal plate, and tighten the four screws from the bottom of the metal plate.



Figure 4.5 Fastening the HDD metal frame to the HDD
4. Plug the EIDE cable connector into the HDD.



Figure 4.6 Plugging in the EIDE cable

5. Align the metal frame on the HDD to the mounting points and fasten the four screws.



Figure 4.7 Aligning the HDD frame

# 4.4 Installing the Central Processing Unit (CPU)

The panel PC is equipped with a central processing unit (CPU) that can be upgraded to improve system performance. The panel PC provides one 478-pin ZIF (Zero Insertion Force) socket, or "Socket 478." The CPU must be fitted with an appropriate heat-sink and CPU fan to prevent overheating.

*Warning!* The CPU may be damaged if operated without a heat sink, and if the fan is not connected to the CPU fan power connector.



**Caution!** Always disconnect the power cord from your panel PC when you are working on it. Do not make connections while the power is on as sensitive electronic components can be damaged by the sudden rush of power. Only experienced electronics personnel should open the panel PC.

Follow these instructions to install a CPU:

1. Place the CPU carefully into the socket, taking care to align it properly.



Figure 4.8 Placing the CPU in the socket

2. Fasten the screw on the CPU socket mounting plate.



Figure 4.9 Tightening the screws on the CPU

3. Place the heatsink and fan on top of the CPU, and fasten them with the retention bracket.



Figure 4.10 Placing the heatsink and fan on the CPU

4. Fasten the four screws onto the CPU cooler module.



Figure 4.11 Fastening the CPU module to the motherboard

## 4.5 Installing the DDR SDRAM Memory Module

It is possible to install from 256 MB to 2 GB of DDR SDRAM memory. The panel PC system provides two 184-pin DIMM (Dual Inline Memory Module) sockets and supports 2.5V DDR SDRAM.



Figure 4.12 Placing the memory module in the DIMM



## Chapter

# Jumpers and Connectors

This chapter gives information on setting jumpers and using the connectors on the PPC-155T motherboard

Sections include:

- Setting Jumpers
- Jumper and Connector Locations
- Connectors

### **5.1 Jumpers and Connectors**

This chapter supplies more detailed information about the internal jumper settings and an outline of the I/O ports avaiaable on the PPC-155T.

#### 5.1.1 Setting jumpers

The Panel PC can be configured to match the needs of each application by setting the jumpers. A jumper is the simplest kind of electrical switch. It consists of two metal pins and a small metal clip (often protected by a plastic cover), which slides over the pins to close the circuit and connect them. To "close" a jumper, connect the pins with the clip. To "open" a jumper, remove the clip. Sometimes a jumper has three pins, labeled 1, 2, and 3. In this case, it is possible to connect either pins 1 and 2 or pins 2 and 3 to each other.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers. If there are any doubts about the best hardware configuration for a particular application, contact the local distributor or sales representative before making any changes.

An arrow is printed on the motherboard to indicate the first pin of each jumper.

#### 5.1.2 Jumpers

The motherboard of the Vehicle Mounted Computer has a number of jumpers that help configure the system. It also has LED indicator lamps that display the system operation status. The table below lists the function of each jumper and LED.

The motherboard of the PPC-155T has a number of jumpers that allow you to configure your system to suit your applications.

#### 5.1.2.1 PCI slot voltage setting (JP2)

The panel PC supports 5V and 3.3V PCI\_VIO slot voltages. The default voltage is 3.3V (closed pins 1-2). 5V may be selected by closing jumpers 2-3.



#### 5.1.2.2 Clear CMOS (JP3)

This jumper erases the CMOS data and resets the system BIOS information.

Table 5.2: Clear CMOS (JP3)				
Normal operation (default)	Clear CMOS			

#### 5.1.2.3 LVDS voltage setting (JP5)

The panel PC supports 5V and 3.3V LVDS voltages. The default voltage is 3.3V (closed pins 1-2). 5V may be selected by closing jumpers 2-3.

Table 5.3: LVDS voltage setting (JP5)				
5V				
	1 2 3			

#### 5.1.2.4 Jumper and Connector Locations



Figure 5.1 Jumpers and connectors on the PPC-155T motherboard

#### 5.1.3 Connectors

Onboard connectors link the panel PC to external devices such as hard disk drives or floppy drives. The table below lists the function of each of connectors.

Table 5.4: PP	C-155T connectors tal	ble	
CN1	Serial port for touch	CN21	Х
CN2	Х	CN22	Audio Jack
CN3	Serial+VGA port	CN23	Х
CN4	Inverter power	CN24	PS/2*2
CN5	LAN+USB*2	CN25	Х
CN6	IDE-HDD	CN26	Х
CN7	Mini-PCI	CN27	Х
CN8	IDE-Slim CD-ROM	CN28	Х
CN9	LVDS	CN29	Х
CN10	Х	CN30	GPIO
CN11	ATX power	CN31	TYPE II CF slot
CN12	LPT	CN32	1394 port
CN13	CPU fan	CN33	1394 port
CN14	Х	CN34	System FAN
CN15	Х	CN35	COM*2
CN16	internal USB pin header	CN36	2nd LAN
CN17	internal Speakers	CN37	Power Switch
CN18	Х	CN38	Light sensor
CN19	FDD	CN39	LED*3
CN20	USB*2	CN40	Х



## **Driver Installation**

This chapter gives information on installing drivers for the PPC-155T Sections include:

- Driver Installation
- Updating Drivers

## **Chapter 6** Driver Installation

A Driver CD is supplied inside the accessory box. Customers may need to use an external USB CD-ROM related device to load the CD and install the drivers for the PPC-155T.

### 6.1 **Driver Installation**

Before installing the Ethernet driver, note the procedures below. It is necessary to know which operating system is installed on the PPC-155T. Then refer to the corresponding installation flow chart. Follow the steps described in the flow chart to complete the installation quickly. Drivers and documents included on the CD are for the chipset, LAN, Audio, Touchscreen, VGA, USB, light sensor utility, and the light sensor guide and a PDF copy of this user manual.



- 1. The CD-ROM drive is designated as "D" throughout this chapter.
- 2. <Enter> means pressing the "Enter" key on the keyboard.

## 6.2 Updating Driver Searching on the Advantech Website

For further information about installing drivers on the PPC-155T, and to access driver updates, troubleshooting guides and FAQ lists, visit the following web resources:

Advantech websites:

- www.advantech.com
- www.advantech.com.tw



## Disassembly

This chapter details a complete procedure for dissasembling the Panel PC

## A.1 Disassembly Procedure

To completely disassemble the panel PC, follow the step-by-step procedures below. Users should be aware that Advantech Co., Ltd. takes no responsibility whatsoever for any problems or damage caused by disassembly of the panel PC by the user.

*Warning!* Make sure the power cord of the panel PC is unplugged before starting disassembly.



The following procedures do not include detailed assembly procedures for the CPU, HDD, CD-ROM drive, FDD, and SDRAM. Further details can be found in Chapter 4.

1. Unfasten the HDD side cover.



Figure A.1 Unfastening the HDD side cover

2. Unfasten the rear cover and remove it.



Figure A.2 Unfastening the rear cover

3. Before removing the rear cover, disconnect the system fan connector.



Figure A.3 Disconnecting the fan connector

4. The PPC without the rear cover.



Figure A.4 The PPC without the rear cover

5. Remove the PCI riser card.



Figure A.5 Removing the PCI riser card

6. Unfasten the middle plate.



Figure A.6 Unfastening the middle plate

7. Remove the middle plate.



Figure A.7 Removing the middle plate

8. Unfasten the side screws on the HDD module and remove the left side plate.



Figure A.8 Unfastening the HDD module

9. Remove the right side plate and lift out the HDD.



Figure A.9 Removing the HDD

10. Disconnect the HDD cable from the PPC-155T motherboard.



Figure A.10 Disconnecting the HDD cable

11. Loosen the screws on the bracket holding the HDD module.



Figure A.11 Loosening the screws on the HDD bracket

12. Loosen the screws on the CD-ROM module.



Figure A.12 Loosening the screws on the CD-ROM module

13. Carefully push out the fixed brace holding the CD-ROM.



Figure A.13 Pushing out the brace holding the CD-ROM

14. Remove the fixed brace.



Figure A.14 Removing the fixed brace

15. Unfasten the CD-ROM / PCMCIA slot cover.



Figure A.15 Unfastening the CD-ROM / PCMCIA slot cover

16. Remove the CD-ROM / PCMCIA slot cover.



Figure A.16 Removing the CD-ROM / PCMCIA slot cover.

17. Remove the CD-ROM module.



Figure A.17 Removing the CD-ROM module

18. Disconnect the CD-ROM connector.



Figure A.18 Disconnecting the CD-ROM connector

19. Unfasten the four screws on the CPU module and remove it.



Figure A.19 Removing the CPU module

20. Unsfasten the CPU socket.



Figure A.20 Unfastening the CPU socket

21. Unfasten the screw on the CPU socket mounting plate and remove the CPU.



Figure A.21 Removing the CPU

22. Remove the SDRAM module.



Figure A.22 Removing the SDRAM module



## **PCI Card Size Limits**

This chapter details the size limits for PCI cards that may be installed on the Panel PC motherboard

## Appendix B PCI Card Size Limits

PCI Cards must be sized within the following dimensional limits:



Figure B.1 PCI Card Dimensional Limits





#### www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2006