

WordSenderTM Quick Guide

Setup

- 1. Remove the battery door by removing the screw with a Phillips screwdriver.
- 2. Install the 9 volt alkaline battery. Replace the battery door and screw.
- 3. Connect the telephone line between the jack on the back of the Word-Sender and the telephone wall outlet.
- Plug the power cord into the Power jack on the WordSender and then plug the AC adapter into an electrical outlet.

Adding a directory entry

A directory entry is a person's name, phone number and paging information stored in memory.

The grey boxes below represent the Word-Sender display screen.

 Press the Setup/Dir key to access the Directory.

Type Name or Speed #: Press ? for help

2. Type the person's name.

3. Press the **Return** key.

01: TOM [Add] Quit

4. Press the **Return** key.

01:

Type Telephone Number

5. Type the person's telephone number.

01: 2222222 Type Telephone Number

This is the person's home or office phone number used for Speed Dialing purposes.

6. Press the **Return** key.

01: [None] Numeric Alpha Select Pager Type

7. Press one of the **Arrow** keys to select pager type.

01: None Numeric [Alpha]Select Pager Type

If Numeric was selected, proceed to step 11.

8. Press the **Return** key.

01:

Type System Number

9. Type the System Number.

01: 18008888888 Type System Number

The system number is the paging service modem telephone number. Contact your paging service provider to get the System Number.

10.Press the **Return** key.

01:

Type Pager/PIN Number

11. Type the person's pager identification number (PIN).

01: 2228888

Type Pager/PIN Number

12.Press the **Return** key.

DIRECTORY ENTRY SAVED

Repeat steps 2-12 to save more directory entry names.

13.Press the **Esc** key when you are finished.

READY

Note: In some office settings you must dial a "9" to obtain an outside line. If this is the case, remember to add this prefix followed by a comma when you save the Telephone number, System number and the Pager/PIN number for Numeric paging.

Sending an Alphanumeric page

The grey boxes below represent the WordSender display screen.

1. Press the Page key.

Type Name, or Speed # Press ? for Help

2. Type the directory name that you wish to page.

01: TOM

3. Press the **Return** key to select the name.

Type message: Press to send, ? for Help

4. Type your message.

Please call home before you leave Ben's house

5. Press the **Return** key to send the message.

===PAGE SENT=== Press any key

Sending a Numeric Page

The grey boxes below represent the WordSender display screen.

1. Press the Page key.

Type Name, or Speed # Press ? for Help

2. Type the directory name that you wish to page.

3. Press the **Return** key to select the name.

LIFT HANDSET TO SEND Press ESC to quit 4. Pick up the handset and wait for the prompt.

Dialing: 5551234
Press ESC to guit

5. Enter you numeric message and hang up the handset.

Speed dialing

The grey boxes below represent the WordSender display screen.

1. Press the **Speed Dial** key.

Type Name, or Speed # Press ? for Help

2. Type the person's name or directory number that you want to call.

3. Press the **Return** key to dial the telephone number.

DIAL: 2222222

4. Lift the handset to talk.

LIFT HANDSET

Additional Features

The WordSender offers other convenient features:

- Help Screens are available anytime you are using the WordSender. Press the ? key whenever you need additional information about a function.
- Redial lift the handset and press the Return key to dial the last number dialed.
- Call Timer displays the length of your telephone call.

Please refer to the User's Manual for more information.

© 1996 Motorola Inc. All rights Reserved Messaging Systems Products Group Paging Products Group 3301 Quantum Boulevard Boynton Beach, FL 33426

Motorola, and WordSender are trademarks or registered trademarks of Motorola, Inc.