

IS-DM260

User's Manual

Ver1.5

00P3NX103ZXSEA5

TableofContents

| | | |
|---|---|-----------|
| 1. | Overview | 2 |
| 1.1 | Features | 2 |
| 1.2 | Package Contents | 3 |
| 1.3 | Dimensions..... | 4 |
| 1.4 | Installation (For Rugged Camera)..... | 5 |
| 1.5 | Connectors | 6 |
| 2. | Camera Cabling..... | 7 |
| 2.1 | Connect Ethernet Cable..... | 7 |
| 2.1.1 | Indoor Camera | 7 |
| 2.1.2 | Rugged Camera..... | 8 |
| 3. | System Requirements..... | 9 |
| 4. | Access Camera | 10 |
| 5. | Setup Video Resolution | 13 |
| 6. | Configuration Files Export/ Import | 14 |
| Appendix A: Technical Specifications..... | | 15 |
| Appendix B: Delete the Existing DC Viewer..... | | 16 |
| Appendix C: Setup Internet Security | | 17 |
| Appendix D: Video Resolution | | 18 |
| 2M- | Quad Streams..... | 18 |
| 2M- | Triple Streams..... | 22 |
| 2M- | Dual Streams | 24 |
| 2M- | Single Stream | 24 |
| 2M Real time- | Quad Streams..... | 25 |
| 2M Real time- | Triple Streams..... | 29 |
| 2M Real time- | Dual Streams | 31 |
| 2M Real time- | Single Stream | 32 |

1. Overview

The IS-DM260 IS-DM260 is capable of serving real-time streaming and makes image quality more smoothly. In addition to MJPEG real time streaming, this camera develops H.264 codec to apply for high resolution digital broadcast.

With compact and sophisticated mechanical design, the Full HD Multiple Streams Compact Fixed Dome IS-DM260 is easy installed and aesthetic.



1.1 Features

- Progressive Scan CMOS Sensor
- Quad Streams Compression: H.264 Baseline/ Main/ High Profile + MJPEG
- Multi-language Support
- Tampering Alarm
- Wide Dynamic Range
- Motion Detection
- Privacy Masks
- Smart Picture Quality/ 3D Noise Reduction
- Vertical View Mode (Image rotation by 90 degrees)
- Network Failure Detection
- Weatherproof Dongle Cable*
- Weatherproof (IP66 international)*
- Micro SD support
- Security Torx against tampering
- ONVIF Support

(*) Optional

1.2 Package Contents

Please check the package contains the following items listed below.



| | |
|---|---|
|  Indoor Camera/ Rugged Camera (with Cable) |  Rubber Washer ($\times 1$, Casing) Rubber Washers ($\times 3$, Baseplate) (Rugged Camera only) |
|  Self-tapping screws ($\times 3$) |  Plastic Anchors ($\times 3$) |
|  Security Torx |  Quick Guide |
|  CD | |



NOTE: The type of the supplied self-tapping screws is mainly for softer substrate/material installation such as wood. For other installation environment such as cement wall, it is required to pre-drill and use plastic anchors before fastening the supplied self-tapping screw on the wall.

1.3 Dimensions

The IS-DM260's dimensions are shown below.




Unit: [mm]

1.4 Installation (For Rugged Camera)

For Rugged Camera, we suggest you to install the Camera as the following steps to make sure the Camera is well waterproof.

Step 1:

Put the Rubber Washers in both sides of the holes on the Bottom Plate of the Camera.



Step 2:

Aim the installing hole to the target installing position and fasten the screws to attach the Camera to the ceiling.



Step 3:

Refer to [1.5Connectors](#) and [2.CameraCabling](#) to connect the cable and adjust the lens.

Step 4:

Aim the arch parts on both Dome Cover and Bottom Plate to attach two parts firmly together. And then fasten the security screws on the Dome Cover to finish installing the Camera.



1.5 Connectors

The diagram below shows the IP Dome Camera's reset button and various adjusting screws. Definition for each will be given as follows.



| Designation | | Description |
|-------------|--------------------|--|
| 1 | Reset Button | Restore to default setting; press the button with a proper tool |
| 2 | Lens | Rotate the lens right/left to adjust focus |
| 3 | Focus Fixed Screw | Loosen the screw to adjust the lens |
| 4 | Tilt Fixed Screw | Loosen the screw to adjust tilt angle |
| 5 | Micro SD Card Slot | For video recording storage |

2. Camera Cabling


Please follow the instructions below to complete IS-DM260 connection.

2.1 Connect Ethernet Cable

Please follow the instructions below to connect Indoor/Rugged IP Dome Camera's Ethernet cable.

2.1.1 Indoor Camera


The Ethernet connector, which is located in the rear of the camera, is shown below:



PoE Connection

Connect the one end of the Ethernet cable to the network port on the camera, and the other end to Power Sourcing Equipment (PSE) like hubs or routers.

Check the status of the link indicator and activity indicator LEDs; if the LEDs are unlit, please check the connections.



Green Link Light indicates good network connection.
Orange Activity Light flashes for network activity indication.

RJ-45 Lite Cable Connection



RJ-45 Lite Connector

- **RJ-45 Lite Cable Connection**

Connect one end of the Ethernet cable to the RJ-45 Lite Connector. Then connect the other end of the Ethernet cable to Power Sourcing Equipment (PSE) like hubs or routers.

2.1.2 Rugged Camera

The Rugged IP Dome Camera supports RJ-45 Dongle Cable.

RJ-45 Dongle Cable Connection



RJ-45 Dongle

- **RJ-45 Dongle Cable Connection**

Run the Ethernet cable through the Waterproof RJ-45 Screw-On Plug. Then connect one end of the Ethernet cable to the RJ-45 dongle, tightening the sealing nut of the Waterproof RJ-45 Screw-On Plug completely. Later on connect the other end of the Ethernet cable to Power Sourcing Equipment (PSE) like hubs or routers.



NOTE: Please use a PoE waterproof switch/hub so that the camera can work.

3. System Requirements

To perform the IS-DM260 via web browser, please ensure your PC is in good network connection, and meet system requirements as described below.

| Items | System Requirement |
|--------------------------|---|
| Personal Computer | 1. Intel® Pentium® M, 2.16 GHz or Intel® Core™ 2 Duo, 2.0 GHz 2. 2 GB RAM or more |
| Operating System | Windows VISTA/ Windows XP/ Windows 7 |
| Web Browser | Microsoft Internet Explorer 6.0 or later Firefox Chrome Safari |
| Network Card | 10Base-T (10 Mbps) or 100Base-TX (100 Mbps) operation |
| Viewer | ActiveX control plug-in for Microsoft IE |

4. Access Camera

For initial access to the IS-DM260, users can search the camera through the installer program: DeviceSearch.exe, which can be found in “DeviceSearch” folder in the supplied CD.

DeviceSearchSoftwareSetup


Step 1: Double click on the program Device Search.exe. After its window appears, click on the <Device Search> button on the top side.

Step 2: The security alert window will pop up. Click on <Unblock> to continue.

DeviceSearch

Step 3: Click on <Device Search> again, and all the finding IP devices will be listed in the page. The IS-DM260's default IP address is: **192.168.0.250**.

Step 4: Double click or right click and select <Browse> to access the camera directly via web browser.



Step 5: Then the prompt window of request for entering default username and password will appear for logging in to the IS-DM260.

The default login ID and password for the Administrator are:

| Login ID | Password |
|----------|----------|
| Admin | 1234 |



NOTE: ID and password are case sensitive.



NOTE: It is strongly advised that administrator's password be altered for the security concerns. Refer to [Full HD Multiple StreamsIS-DM260MenuTree](#) for further details.

Additionally, users can change the IS-DM260's network property, either DHCP or Static IP, directly in the device finding list. Refer to the following section for changing the IS-DM260's network property.

ExampleofChangingIS-DM260'sNetworkProperty

Users can directly change an IS-DM260's network property, ex. from static IP to DHCP, in the finding device list. The way to change the IS-DM260's network property is specified below:

Step 1: In the finding device list, click on the IS-DM260 that you would like to change its network property. On the selected item, right click and select "Network Setup." Meanwhile, record the IS-DM260's MAC address, for future identification.

Step 2: The "Network Setup" page will come out. Select "DHCP," and press "Apply" button down the page.

Step 3: Click on <OK> on the Note of setting change. Wait for one minute to re-search the IS-DM260.

Step 4: Click on the <Device Search> button to search all the devices. Then select the IS-DM260 with the correct MAC address. Double click on the IS-DM260, and the login window will come out.

Step 5: Enter User name and Password to access the IS-DM260.

InstallingDCViewerSoftwareOnline

For the initial access to the IS-DM260, a client program, DC Viewer, will be automatically installed to your PC when connecting to the IS-DM260.

If the Web browser doesn't allow DC Viewer installation, please check the Internet security settings or ActiveX controls and plug-ins settings (refer to [Section:SetupInternetSecurity](#)) to continue the process.

The Information Bar (just below the URL bar) may come out and ask for permission to install the ActiveX Control for displaying video in browser. Right click on the Information Bar and select <Install ActiveX Control...> to allow the installation.

The download procedure of DC Viewer software is specified as follows.

- Step 1:** In the DC Viewer installation window, click on <Next> to start installation.
- Step 2:** The status bar will show the installation progress. After the installation is completed, click on <Finish> to exit the installation process.
- Step 3:** Click on <Finish> to close the DC Viewer installation page.

Once the DC Viewer is successfully installed, the IS-DM260's Home page will be able to correctly display.

ImageandFocusAdjustment

The image displays on the Home page when successfully accessing to the IS-DM260. Adjust zoom and focus as necessary to produce a clear image.



Note: Please refer to [FullHDMultipleStreamsIS-DM260MenuTree](#) for more button function detail.

5. Setup Video Resolution

Users can setup Video Resolution on Video Format page of the user-friendly browser-based configuration interface.

Video Format can be found under this path: **Streaming> Video Formats**

The default value of Video Resolution is as below:

| | |
|---------------------|--|
| 2M | H.264- 1920 x 1080 (15 fps) + H.264- 1280 x 720 (30 fps) |
| 2M Real time | H.264- 1920 x 1080 (30 fps) + H.264 720 x 480 (30 fps) |

For more Video Resolution combination detail, please refer to [Appendix:Video Resolution](#). Click on <Save> to confirm the setting.

6. Configuration Files Export/ Import

To export/ import configuration files, users can access the Maintenance page on the user-friendly browser-based configuration interface.

The Maintenance setting can be found under this path: **System> Maintenance**.

Users can export configuration files to a specified location and retrieve data by uploading an existing configuration file to the IS-DM260.

Export

Users can save the system settings by exporting the configuration file (.bin) to a specified location for future use. Click on the <Export> button, and the popup File Download window will come out. Click on <Save> and specify a desired location for saving the configuration file.

Upload

To copy an existing configuration file to the IS-DM260, please first click on <Browse> to select the configuration file, and then click on the <Upload> button for uploading.

Appendix A: Technical Specifications

| Camera | 2M | 2M Real-time |
|------------------------|--|---------------|
| Image Sensor | 1/2.7" Progressive CMOS | |
| Effective Pixels | 1920(H) x 1080(V) | |
| Minimum Illumination | 0.1 lux (Color) | |
| White Balance | Manual / AWB / ATW | |
| Shutter Speed | 1~ 1/10000 sec. | |
| Lens | | |
| Focal Length | 4.0 mm | |
| F Number | F 1.5 | |
| FOV | 78° | |
| Operation | | |
| Multiple Languages | English / French / German / Italian / Korean / Simplified Chinese / Traditional Chinese / Russian | |
| Image Setting | Backlight Compensation | On / Off |
| | White Balance | Auto / Manual |
| | Noise Reduction (3D) | On / Off |
| | Wide Dynamic Range | On / Off |
| | Privacy Mask | On / Off |
| | Brightness | Manual |
| | Exposure | Auto / Manual |
| | Sharpness | Manual |
| | Contrast | Manual |
| | Saturation | Manual |
| | Hue | Manual |
| | Digital Zoom | Support |
| | Motion Detection | On / Off |
| | Privacy Mask Type | Color |
| | Tampering Alarm | On / Off |
| | One-way Audio* | Mic in |
| | Compression | G.711 / G.726 |
| Network | | |
| Interface | RJ-45, 10/100 Mbps Ethernet | |
| Video Compression | H.264 / MJPEG | |
| Video Streaming | Dual Streams- H.264 + H.264 / MJPEG Quad Streams- H.264 + H.264 + H.264 + H.264 / MJPEG | |
| Video Resolution | H.264- Full HD 1080P / SXGA / HD 720P / XGA / SVGA / D1 / VGA / CIF MJPEG- Full HD 1080P / SXGA / HD 720P / XGA / SVGA / D1 / VGA / CIF | |
| Protocol | IPv4/v6, TCP/IP, UDP, RTP, RTSP, HTTP, HTTPS, ICMP, FTP, SMTP, DHCP, PPPoE, UPnP, IGMP, SNMP, QoS, ONVIF | |
| Security | HTTPS / IP Filter / IEEE 802.1X | |
| Event Notification | HTTP / FTP / SMTP | |
| Micro SD* | microSDHC 32GB support | |
| Supported Web Browser | Internet Explorer (6.0+) / Chrome / Firefox / Safari | |
| User Account | 20 | |
| Password Levels | User and Administrator | |
| Mechanical | | |
| Lens Mounting | M12 Board Lens | |
| Connectors | Ethernet | RJ-45 |
| General | | |
| Operating Temperature | -10°C ~ 50°C (14°F ~ 122°F) | |
| User and Administrator | 10% ~ 90%, No Condensation | |
| Weatherproof Standard | Rugged Camera- IP66 | |
| Dimension | Ø 110.2 x 47.7 mm (Ø 4.3 x 1.9 in.) | |
| Weight | 180 g (0.40 lb) | |
| Power Source | PoE | |
| Power Consumption | 3.5 W | |
| Regulatory | CE / FCC / RoHS | |

(*) Optional

Appendix B: Delete the Existing DC Viewer

For users who have installed the DC Viewer in the PC previously, please first remove the existing DC Viewer from the PC before accessing to the IS-DM260.

DeletingtheDCViewer

In the Windows <Start Menu>, activate <Control Panel>, and then double click on <Add or Remove Programs>. In the <Currently installed programs> list, select <DCViewer> and click on the button <Remove> to uninstall the existing DC Viewer.

DeletingTemporaryInternetFiles

To improve browser performance, it is suggested to clean up the all the files in the Temporary Internet Files.

The procedure is as follows:

Step 1: Click on the <Tools> tab on the menu bar and select <Internet Options>.

Step 2: Click on the <Delete> button under <Browsing history> section. Then click on the <Delete Files> button under the <Temporary Internet files> section.

Step 3: A confirmation window will pop up. Click on <Yes> to start deleting the files.

Appendix C: Setup Internet Security

If ActiveX control installation is blocked, please either set Internet security level to default or change ActiveX controls and plug-ins settings.

InternetSecurityLevel:Default

Step 1: Start the Internet Explorer (IE).

Step 2: Click on the <Tools> tab on the menu bar and select <Internet Options>.

Step 3: Click on the <Security> tab, and select <Internet> zone.

Step 4: Down the page, click on the <Default Level> button and click on <OK> to confirm the setting. Close the browser window, and restart a new one later to access the IP Camera.

ActiveXControlsandPlug-insSettings

Step 1: Repeat **Steps 1~3** of the previous section above.

Step 2: Down the page, click on the <Custom Level> button to change ActiveX controls and plug-ins settings. The Security Settings window will pop up.

Step 3: Under <ActiveX controls and plug-ins>, set **ALL** items (as listed below) to <Enable> or <Prompt>. Please note that the items vary by IE version.

ActiveX controls and plug-ins settings:

1. Allow previously unused ActiveX controls to run without prompt.
2. Allow Scriptlets.
3. Automatic prompting for ActiveX controls.
4. Binary and script behaviors.
5. Display video and animation on a webpage that does not use external media player.
6. Download signed ActiveX controls.
7. Download unsigned ActiveX controls.
8. Initialize and script ActiveX controls not marked as safe for scripting.
9. Run ActiveX controls and plug-ins.
10. Script ActiveX controls marked safe for scripting.

Step 4: Click on <OK> to accept the settings and close the Security Settings window.

Step 5: Click on <OK> to close the Internet Options screen.

Step 6: Close the browser window, and restart a new one later to access the IS-DM260.

Appendix D: Video Resolution

2M- Quad Streams

| H.264 + H.264 + H.264 + H.264 / MJPEG | | | |
|---------------------------------------|----------------------|--------------------|--------------------|
| | 1280 x 1024 (15 fps) | 720 x 480 (15 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (15 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 1280 x 720 (15 fps) | 720 x 480 (15 fps) | 720 x 480 (15 fps) |
| | | 800 x 600 (15 fps) | 640 x 480 (15 fps) |
| | | | 352 x 240 (30 fps) |
| | | 720 x 480 (15 fps) | 720 x 480 (15 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (15 fps) | 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 1920 x 1080 (15 fps) | 1024 x 768 (15 fps) | 720 x 480 (15 fps) | 720 x 480 (15 fps) |
| | | 800 x 600 (15 fps) | 640 x 480 (15 fps) |
| | | | 352 x 240 (30 fps) |
| | | 720 x 480 (15 fps) | 720 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (15 fps) | 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 800 x 600 (15 fps) | 800 x 600 (15 fps) | 720 x 480 (30 fps) |
| | | 800 x 600 (30 fps) | 640 x 480 (30 fps) |
| | | 720 x 480 (15 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 800 x 600 (30 fps) | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 720 x 480 (15 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |

| H.264 + H.264 + H.264 + H.264 / MJPEG | | |
|---------------------------------------|----------------------|--|
| | | |
| 1280 x 1024 (15 fps) | 1280 x 1024 (15 fps) | 1280 x 720 (15 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 800 x 600 (15 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) 720 x 480 (15 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) |
| | | 1280 x 720 (15 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| 1280 x 1024 (15 fps) | 1280 x 720 (30 fps) | 352 x 240 (30 fps) 720 x 480 (30 fps) |
| | 1024 x 768 (15 fps) | 800 x 600 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | 1024 x 768 (30 fps) | 800 x 600 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| 1280 x 1024 (30 fps) | 800 x 600 (15 fps) | 800 x 600 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| 1280 x 1024 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | 800 x 600 (30 fps) | 352 x 240 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| 1280 x 1024 (30 fps) | 720 x 480 (30 fps) | 352 x 240 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | 640 x 480 (30 fps) | 640 x 480 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |

| H.264 + H.264 + H.264 + H.264 / MJPEG | | | |
|---------------------------------------|---------------------|---------------------|--|
| | | | |
| 1280 x 720 (15 fps) | 1280 x 720 (15 fps) | 1280 x 720 (15 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 1280 x 720 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | 1280 x 720 (30 fps) | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 1024 x 768 (15 fps) | 800 x 600 (30 fps) |
| | | 1024 x 768 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| 1280 x 720 (30 fps) | 1024 x 768 (30 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | 720 x 480 (30 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 1024 x 768 (15 fps) | 1024 x 768 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 800 x 600 (30 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 1024 x 768 (15 fps) | 1024 x 768 (15 fps) | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | 1024 x 768 (30 fps) | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 800 x 600 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 800 x 600 (30 fps) | 640 x 480 (30 fps) |

| H.264 + H.264 + H.264 + H.264 / MJPEG | | | |
|---------------------------------------|---------------------|--------------------|--------------------|
| 1024 x 768 (30 fps) | 1024 x 768 (30 fps) | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 720 x 480 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| 800 x 600 (30 fps) | 800 x 600 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 720 x 480 (30 fps) | 720 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 640 x 480 (30 fps) | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |

2M- Triple Streams

| | H.264-1 | H.264-2 | H.264-3 / MJPEG |
|----------------------|----------------------|---------------------|-----------------|
| 1920 x 1080 (15 fps) | 1280 x 1024 (15 fps) | 800 x 600 (15 fps) | |
| | | 720 x 480 (15 fps) | |
| | | 640 x 480 (15 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 1280 x 720 (15 fps) | |
| | | 800 x 600 (15 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| 1280 x 1024 (15 fps) | 1280 x 720 (15 fps) | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 1280 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| 1280 x 1024 (30 fps) | 1024 x 768 (30 fps) | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| 1280 x 720 (15 fps) | 1280 x 720 (15 fps) | 352 x 240 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 1280 x 720 (30 fps) | |
| 1280 x 720 (15 fps) | 1280 x 720 (30 fps) | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 1280 x 720 (30 fps) | |
| 1280 x 720 (15 fps) | 1024 x 768 (30 fps) | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 1280 x 720 (30 fps) | |

| | H.264-1 | H.264-2 | H.264-3 / MJPEG |
|---------------------|---------------------|--------------------|-----------------|
| 1280 x 720 (30 fps) | 1280 x 720 (30 fps) | 352 x 240 (30 fps) | |
| | 1024 x 768 (30 fps) | 352 x 240 (30 fps) | |
| | 800 x 600 (30 fps) | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | 720 x 480 (30 fps) | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| 1024 x 768 (15 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) | |
| | 1024 x 768 (30 fps) | 800 x 600 (30 fps) | |
| | 800 x 600 (30 fps) | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 800 x 600 (30 fps) | |
| | | 720 x 480 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| 800 x 600 (30 fps) | 720 x 480 (30 fps) | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | 640 x 480 (30 fps) | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| 720 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| | | 640 x 480 (30 fps) | |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) | |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | |
| | | 352 x 240 (30 fps) | |
| 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) | |

2M- Dual Streams

| H.264-1 | H.264-1 + H.264-2 / MJPEG | H.264-2 / MJPEG | BNC SUPPORT |
|----------------------|---------------------------|-----------------|-------------|
| 1920 x 1080 (15 fps) | 1280 x 1024 (15 fps) | | - |
| | 1280 x 720 (30 fps) | | - |
| | 1024 x 768 (30 fps) | | - |
| | 800 x 600 (30 fps) | | - |
| | 720 x 480 (30 fps) | ✓ | |
| | 640 x 480 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | ✓ | |
| 1280 x 1024 (30 fps) | 1280 x 1024 (15 fps) | | ✓ |
| | 1280 x 720 (15 fps) | | - |
| | 1024 x 768 (15 fps) | | - |
| | 800 x 600 (30 fps) | | - |
| | 720 x 480 (30 fps) | ✓ | |
| | 640 x 480 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | ✓ | |
| 1280 x 720 (30 fps) | 1280 x 720 (30 fps) | | ✓ |
| | 1024 x 768 (30 fps) | | - |
| | 800 x 600 (30 fps) | | - |
| | 720 x 480 (30 fps) | ✓ | |
| | 640 x 480 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | ✓ | |
| | 1024 x 768 (30 fps) | ✓ | |
| 800 x 600 (30 fps) | 800 x 600 (30 fps) | | - |
| | 720 x 480 (30 fps) | ✓ | |
| | 640 x 480 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | ✓ | |
| | 720 x 480 (30 fps) | ✓ | |
| | 640 x 480 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | ✓ | - |
| 720 x 480 (30 fps) | 720 x 480 (30 fps) | | ✓ |
| | 640 x 480 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | ✓ | |
| | 640 x 480 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | ✓ | |
| | 352 x 240 (30 fps) | | - |

2M- Single Stream

| H.264 Only | BNC SUPPORT |
|----------------------------------|-------------|
| 1920 x 1080 (15 fps) Low Latency | - |
| 1920 x 1080 (15 fps) | ✓ |
| 1280 x 1024 (30 fps) | ✓ |
| 1280 x 720 (30 fps) | ✓ |
| 1024 x 768 (30 fps) | ✓ |
| 800 x 600 (30 fps) | ✓ |
| 720 x 480 (30 fps) | ✓ |
| 640 x 480 (30 fps) | ✓ |
| 352 x 240 (30 fps) | - |

| MJPEG Only | BNC SUPPORT |
|----------------------|-------------|
| 1920 x 1080 (15 fps) | ✓ |
| 1280 x 1024 (30 fps) | ✓ |
| 1280 x 720 (30 fps) | ✓ |
| 1024 x 768 (30 fps) | ✓ |
| 800 x 600 (30 fps) | ✓ |
| 720 x 480 (30 fps) | ✓ |
| 640 x 480 (30 fps) | ✓ |
| 352 x 240 (30 fps) | - |

2M Real time- Quad Streams

| H.264 + H.264 + H.264 + H.264 / MJPEG | | | |
|---------------------------------------|----------------------|---------------------|--|
| H.264-1 | H.264-2 | H.264-3 | H.264-4 / MJPEG |
| 1920 x 1080 (15 fps) | 1280 x 1024 (15 fps) | 1280 x 720 (15 fps) | 720 x 480 (15 fps) 640 x 480 (15 fps) 352 x 240 (30 fps) |
| | | 800 x 600 (15 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (15 fps) | 720 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 1280 x 720 (15 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| 1920 x 1080 (30 fps) | 1280 x 720 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 1024 x 768 (15 fps) | 800 x 600 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 1024 x 768 (30 fps) | 800 x 600 (30 fps) 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 1920 x 1080 (30 fps) | 800 x 600 (30 fps) | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 1920 x 1080 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |

| H.264 + H.264 + H.264 + H.264 / MJPEG | | | |
|---------------------------------------|----------------------|---------------------|--|
| H.264-1 | H.264-2 | H.264-3 | H.264-4 / MJPEG |
| 1280 x 1024 (15 fps) | 1280 x 1024 (15 fps) | 1280 x 720 (15 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 1280 x 720 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | 1280 x 1024 (30 fps) | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 1280 x 720 (15 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | 1280 x 720 (30 fps) | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 1024 x 768 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| 1280 x 1024 (15 fps) | 800 x 600 (30 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| 1280 x 1024 (30 fps) | 1024 x 768 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 800 x 600 (30 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |

| H.264 + H.264 + H.264 + H.264 / MJPEG | | | |
|---------------------------------------|---------------------|---------------------|--|
| H.264-1 | H.264-2 | H.264-3 | H.264-4 / MJPEG |
| 1280 x 720 (15 fps) | 1280 x 720 (15 fps) | 1280 x 720 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 1280 x 720 (30 fps) | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 1024 x 768 (30 fps) | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 1280 x 720 (30 fps) | 1280 x 720 (30 fps) | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 1024 x 768 (30 fps) | 800 x 600 (30 fps) | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 800 x 600 (30 fps) | 800 x 600 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 720 x 480 (30 fps) | 720 x 480 (30 fps) 640 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 640 x 480 (30 fps) 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |

2M Real time- Triple Streams

| H.264-1 | H.264-1 + H.264-2 + H.264-3 / MJPEG | H.264-2 | H.264-3 / MJPEG |
|----------------------|-------------------------------------|----------------------|---------------------|
| | | | 1280 x 720 (15 fps) |
| | | | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 1280 x 1024 (15 fps) | 1280 x 720 (15 fps) |
| | | | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 1280 x 720 (15 fps) | 1280 x 720 (30 fps) |
| | | | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| 1920 x 1080 (15 fps) | | 1024 x 768 (30 fps) | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| 1920 x 1080 (30 fps) | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | | 1280 x 720 (30 fps) |
| | | | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | 1280 x 1024 (15 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 1280 x 1024 (30 fps) | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | 1280 x 720 (15 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 1280 x 720 (30 fps) | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | 1024 x 768 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | | 800 x 600 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | | 800 x 600 (30 fps) |
| | | 1024 x 768 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 1280 x 720 (30 fps) | 352 x 240 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | 1024 x 768 (30 fps) | 352 x 240 (30 fps) |
| | | | 800 x 600 (30 fps) |
| | | 800 x 600 (30 fps) | 720 x 480 (30 fps) |
| | | | 640 x 480 (30 fps) |
| | | 720 x 480 (30 fps) | 352 x 240 (30 fps) |
| | | | 800 x 600 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 1280 x 1024 (30 fps) | | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | | 1280 x 720 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) | 800 x 600 (30 fps) |
| | | | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 352 x 240 (30 fps) | 640 x 480 (30 fps) |
| | | | 352 x 240 (30 fps) |
| | | 1280 x 720 (15 fps) | 1280 x 720 (30 fps) |

| H.264-1 | H.264-2 | H.264-3 / MJPEG |
|---------------------|---------------------|--------------------|
| 1280 x 720 (30 fps) | 1280 x 720 (30 fps) | 800 x 600 (30 fps) |
| | | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) |
| | 1024 x 768 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | | 800 x 600 (30 fps) |
| | | 720 x 480 (30 fps) |
| 1024 x 768 (30 fps) | 800 x 600 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| 800 x 600 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | 352 x 240 (30 fps) | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) |
| | | 352 x 240 (30 fps) |
| | | 720 x 480 (30 fps) |
| | | 640 x 480 (30 fps) |
| 720 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 720 x 480 (30 fps) | 720 x 480 (30 fps) |
| | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 640 x 480 (30 fps) | 640 x 480 (30 fps) | 640 x 480 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| | 352 x 240 (30 fps) | 352 x 240 (30 fps) |
| 352 x 240 (30 fps) | 352 x 240 (30 fps) | 352 x 240 (30 fps) |

2M Real time- Dual Streams

| H.264-1 + H.264-2 / MJPEG | | BNC SUPPORT |
|---------------------------|----------------------|-------------|
| 1920 x 1080 (15 fps) | 1920 x 1080 (15 fps) | ✓ |
| | 1280 x 1024 (30 fps) | - |
| | 1280 x 720 (30 fps) | - |
| | 1024 x 768 (30 fps) | - |
| | 800 x 600 (30 fps) | - |
| 1920 x 1080 (30 fps) | 720 x 480 (30 fps) | ✓ |
| | 640 x 480 (30 fps) | ✓ |
| | 352 x 240 (30 fps) | ✓ |
| 1280 x 1024 (30 fps) | 1280 x 1024 (15 fps) | ✓ |
| | 1280 x 720 (30 fps) | - |
| | 1024 x 768 (30 fps) | - |
| | 800 x 600 (30 fps) | - |
| | 720 x 480 (30 fps) | ✓ |
| | 640 x 480 (30 fps) | ✓ |
| 1280 x 720 (30 fps) | 352 x 240 (30 fps) | ✓ |
| | 1280 x 720 (30 fps) | ✓ |
| | 1024 x 768 (30 fps) | - |
| | 800 x 600 (30 fps) | - |
| | 720 x 480 (30 fps) | ✓ |
| | 640 x 480 (30 fps) | ✓ |
| 1024 x 768 (30 fps) | 352 x 240 (30 fps) | ✓ |
| | 1024 x 768 (30 fps) | ✓ |
| | 800 x 600 (30 fps) | - |
| | 720 x 480 (30 fps) | ✓ |
| | 640 x 480 (30 fps) | ✓ |
| 800 x 600 (30 fps) | 352 x 240 (30 fps) | ✓ |
| | 800 x 600 (30 fps) | ✓ |
| | 720 x 480 (30 fps) | ✓ |
| | 640 x 480 (30 fps) | ✓ |
| 720 x 480 (30 fps) | 352 x 240 (30 fps) | ✓ |
| | 720 x 480 (30 fps) | ✓ |
| | 640 x 480 (30 fps) | ✓ |
| 640 x 480 (30 fps) | 352 x 240 (30 fps) | ✓ |
| | 640 x 480 (30 fps) | ✓ |
| 352 x 240 (30 fps) | 352 x 240 (30 fps) | - |

2M Real time- Single Stream

| H.264 Only | BNC SUPPORT |
|-----------------------------------|-------------|
| 1920 x 1080 (30 fps) Low Latency* | - |
| 1920 x 1080 (30 fps) | ✓ |
| 1280 x 1024 (30 fps) | ✓ |
| 1280 x 720 (30 fps) | ✓ |
| 1024 x 768 (30 fps) | ✓ |
| 800 x 600 (30 fps) | ✓ |
| 720 x 480 (30 fps) | ✓ |
| 640 x 480 (30 fps) | ✓ |
| 352 x 240 (30 fps) | - |

*1920 x 1080 (30 fps) Low Latency does not support BNC, 3DNR and Motion Detection.

| MJPEG Only | BNC SUPPORT |
|----------------------|-------------|
| 1920 x 1080 (30 fps) | ✓ |
| 1280 x 1024 (30 fps) | ✓ |
| 1280 x 720 (30 fps) | ✓ |
| 1024 x 768 (30 fps) | ✓ |
| 800 x 600 (30 fps) | ✓ |
| 720 x 480 (30 fps) | ✓ |
| 640 x 480 (30 fps) | ✓ |
| 352 x 240 (30 fps) | - |