

### 2-Channel Input Module for Thermocouples



- Monitor tank temperatures
- Monitor oven temperatures
- Refrigerator & Freezer monitoring
- Monitor temperatures in industrial environments such as:

Test chambers, steam plants, boilers, autoclaves, ice machines, and more...



a division of Xytronix Research & Design, Inc. located in Nibley, Utah, USA © 2014 Xytronix Research and Design, Inc.



	X-13s User Manual Revisions
Revision	Description
1.0	Initial release

# **Section 1: Introduction**

The X-13s<sup>™</sup> Thermocouple expansion module is used in conjunction with the X-600M<sup>™</sup> controller. The X-13s is a 2-channel signal conditioner for Type-K thermocouples. One or more X-13s thermocouple expansion modules can be connected to a X-600M control module with a ribbon cable. The ribbon cable provides both power and communications to the module.

The X-600M is a multifunction web-enabled industrial I/O controller. It performs control, logic, and monitoring functions similar to that of a Programmable Logic Controller (PLC). However, unlike a PLC, the X-600M is designed for web-based applications from the ground up. No add-on software or hardware is required. The X-600M can be fully configured, programmed and tested using its built-in web server. The web setup pages are intuitive and easy to use and do not require special programming skills.

The X-600M together with the X-13s provide an easy, flexible and reliable way to monitor temperature over a network. The X-13s is suitable for use with freezers, ovens, fermenters, generators – anywhere precision, rugged, temperature sensors are required.



### 1.1 Advantages of Thermocouples

Thermocouples are used extensively in the scientific and automation industries. Thermocouples are available in a wide variety of industrial housings, including thermowells, threaded wells, PFA coated thermowells for corrosive applications and high temperature lead wires. Thermocouples have a much wider range than with the "1-wire" digital sensors (-55°C to 125°C) supported by the X-600M. Thermocouples are workable in high temperature applications such as in a fermenter where steam is injected to sterilize the vessel.

Temperature Range: Type-K thermocouples have a measurement range of -200°C to +1250°C

**Robust:** Thermocouples are inexpensive, extremely simple, and rugged devices which are suitable for use in hazardous environments.

**Rapid response:** Because they are small and have low thermal mass, thermocouples respond rapidly to temperature changes.

**No self heating**: Thermocouples require no excitation power; therefore, they are not prone to self heating.

### 1.2 Connectors & Indicators

#### **Thermocouple Inputs**

The X-13s is a 2-channel input module for use with Type-K thermocouples. The X-13s has built-in miniature thermocouple connectors together with a precision cold-junction temperature compensation circuit. The cold junction compensation is accurate to +/-0.5°C from -40°C to 85°C. The X-13s only works with <u>ungrounded</u> or isolated thermocouples.

#### **Expansion Bus**

The expansion bus allows for a family of expansion modules to be connected directly to the X-600M without the need for an Ethernet switch. The cable can be a daisy chain with multiple connectors. The ribbon cable expansion bus provides both power and communications connections.

#### **Power Supply**

The expansion bus can provide up to 1.7 Amps for powering up to 32 expansion modules; however, the maximum number of expansion modules depends on the module type and power source attached to the X-600M.

The X-13s employs modern switch-mode power supply. With this type of power supply the current draw <u>decreases</u> as the voltage increases; therefore, you can add more expansion modules by using a 24-volt power supply than you can with a 12-volt power supply. See the *X*-600M User Manual for more details.

#### Indicators

The green Power LED indicator is illuminated whenever the module is powered. To identify the module during installation, the X-600M can send a blink command which will cause the power LED to blink for three seconds. The two yellow LEDs indicate the status of the thermocouple inputs and are illuminated if the respective thermocouple is open or the lead wire is disconnected.

### **1.3 Part Numbers and Accessories**

Device	Description	Part Number
X-13s	Thermocouple expansion module with two thermocouple inputs.	X-13s

# **Section 2: Installation and Connections**

Installation consists of mounting the X-13S<sup>™</sup> and connecting it to an X-600M controller with a 10conductor ribbon cable. Programming and testing is done by using a web browser to configure the web pages, inputs, and outputs for your specific needs.

### 2.1 Installation Guidelines

- This unit must be installed by qualified personnel.
- This unit must not be installed in unprotected outdoor locations.
- This unit must not be used for medical, life saving purposes, or for any purpose where its failure could cause serious injury or the loss of life.
- This unit must not be used in any way where its function or failure could cause significant loss or property damage.

### 2.2 Mounting

X-13s can be mounted to a standard (35mm by 7.55mm) DIN-Rail. Normally expansion modules are mounted to the left side (embossed logo side of the enclosure) of the X-600M controller so that the ribbon cable doesn't cover the power connector. The X-13s should be located in a clean, dry location where it is protected from the elements. Ventilation is recommend for installations where ambient air temperatures are expected to be high. See *Appendix D: Mechanical Information* for additional mechanical details.



#### 2.2.1 DIN-Rail Mounting

Attach the X-600M to the DIN-Rail by hooking the top hook on the back of the enclosure to the DIN-Rail and then snap the bottom hook into place. To remove the X-600M from the DIN-Rail, use a flat-head screwdriver. Insert the screw driver into the notch in the release tab and pry against the enclosure to release the bottom hook.

# **Section 3: Example Applications**

#### **Environmental Monitor**

The X-13s can be used for a broad range of temperature sensing applications. The web interface and the built-in control capabilities of the X-600M can be leveraged to operate alarms or provide input to process control or security systems. The X-600M can operate without being connected to a PC or server, it can operate alarms, equipment and controls in remote locations based on the temperature, event schedules or other inputs. The X-600M can display data from multiple X-13s expansion modules.

#### **Process Control**

Together with the X-600M controller, the X-13s may be suitable for process control applications where a PLC is traditionally used or to augment the capabilities of a PLC. Not only is the X-600M more economical than a PLC, the ease of programming reduces deployment and configuration maintenance costs. The Modbus/TCP interface can be used to transmit temperature data to other devices, including PLCs.

#### **Process Monitor**

The web page display can be customized to provide temperature data formatted for your needs. Email, SNMP, XML, and Modbus/TCP alerts can be generated automatically when a process' parameter limits are violated or interrupted.

### 3.1 Monitor the temperature of a generator

In the example below, thermocouples are used to monitor the engine coolant temperature and the ambient air temperature of a generator. If the temperature exceeds a user-specified threshold, an email or text notification is sent to the appropriate personnel notifying them of the alarm condition.



# Section 4: Configuration and Setup

### 4.1 Setup Example

#### The Quick Start Demo

After making the power and Ethernet connections, the X-600M can automatically scan for the presence of any ControlByWeb<sup>™</sup> Ethernet devices (on the same sub-net) and also for any expansion modules connected to the X-600M via the ribbon-cable connector. It also automatically creates a dashboard web page and populates it with all of the resources (components) supported by the Ethernet devices and expansion modules. This makes it easy to start experimenting with the web page's user interface and to try out the relays and sensors.

To quickly add a device do the following:

1. Click on the **Devices** menu tab to pull up the *Devices Overview* page. Then click on the **Find New Devices** button to scan the expansion bus and the local network for ControlByWeb devices and expansion modules.

⊖ ⊖ ⊖ ﷺ Setup	×	2
$\leftarrow$ $\rightarrow$ C $\square$ 192.168.1	.1.2/setup.html	☆ =
		Welcome: Administrator Commit Changes   Abandon Changes   Logout
🗲 System	E Devices	
Wetwork	Add, edit, and delete devices that are attached to the X-600M either through the expansion bus or throu	igh the Ethernet network. Devices must be added before setting up I/O,
Devices	Logic, or Dashboards	
<b>≵</b> vo		
Control/Logic	Device Lise Find New Devices	
Logging	Name ≑ Description ≑ Address ≑ Port ≑ Model	Add New Device     Serial Number
Edit Dashboards	device1 X600M (master unit) n/a X-600M	00:0c:c8:00:00:72
	Showing 1 - 1 of 1 Devices	
View Dashboards		

2. In this example we are going to add an *X-13s Thermocouple expansion module*. Click the **Add** button for the X-13s.

⊖ O Ø jig Setup	×							R.
← → C 🗋 192.168.1	.2/setup.html							್ಷ <b>=</b>
						Commit Chang	Welcome: / ges   Abandon Chang	Administrator jes   Logout
System System Network Devices	Devices   F List of automatic	Find Devices						
Control/Logic	New Devices Found	Rescan Back						
Logging	Show 10 \$ entries	s 						
Edit Dashboards	Model X-13S-K	Serial Number 0000005c	SERIAL	Address AUTO GENERATE	AUTO GENERATE	AUTO GENERATE	Add	
	X-15S	0000064	SERIAL	AUTO_GENERATE	AUTO_GENERATE	AUTO_GENERATE	Add	
View Dashboards	X-12S	0000054	SERIAL	AUTO_GENERATE	AUTO_GENERATE	AUTO_GENERATE	Add	
	X-11S	0000004f	SERIAL	AUTO_GENERATE	AUTO_GENERATE	AUTO_GENERATE	Add	
	Showing 1 to 4 of 4 ent	ries					Previou	ıs Next 🕨

3. In the *Select* column, click the checkboxes of the I/O components you would like to configure and select the **Create Device Widget** checkbox (This will display the status of the I/O on the Dashboard).

○ ○ ○ 👰 Setup	×				R <sub>M</sub>
← → C 🗋 192.168.1.	.2/setup.ht	000	X600M		<sub>≌<sup>ल</sup></sub>
CONTROLBYWEB	De	192.168.1.2/popup.php     Thermocouple T     Add I/O found on Therm	ype K Slave   Add I/O	e below the list for a description of each field.	Welcome: Administrator
Network	Lis	I/O List			
Devices		I/O Type	I/O Description	I/O Name Select	
<b>≵</b> vo		Thermocouple 1	AUTO_GENERATE	AUTO_GENERATE	
Control/Logic	New Devic	Thermocouple 2	AUTO_GENERATE	AUTO_GENERATE	
	Show 1 Model	Showing 1 to 2 of 2 entries		Select All Deselect All	Select
Edit Dashboards	X-15S		Add Checked I/O Create device widg	et on panel1	Add
	X-12S	Device I/O: This shows the typ	e and reference number of each input and ou	put on the device.	Add Add
View Dashboards	X-11S	I/O Description: Text can be e spaces and the maximum num	ntered here to identify the I/O in a format that ber of characters is ???. If nothing is entered	is easy to understand and recognize. It can include a description will be automatically generated.	Add
	Showing 1	<ul> <li>I/O Name: This is a unique nar must start with an alphabetic (r nothing is entred a name will a Select: Each I/O that is select optimal performance it is recon anytime under the I/O tab.</li> <li>Status: Ready.</li> </ul>	ne given to each I/O. This name is used to re tot a number) character and cannot include sp utomatically be generated. ed (checked) will be added to the X-600M dat imended that only I/O which will be used be s	ference the I/O when writing scripts. This name aces. The name can be up to ??? characters long. I ibase and can then be used by the X-600M. For elected. Note that I/O can be added and deleted at	f Previous Next >
Status: Ready			For product support go to www.ControlE	yWeb.com	Xytronix Research & Design, Inc.

Click **Add Checked I/O** to submit these changes.

4. Click Commit Settings - Once clicked, the X-600M begins to monitor the newly added device.

● ● ● ● 🖉 Setup	×							E <sup>R</sup>
← → C 🗋 192.168.1	.2/setup.html							☆ <b>=</b>
						Commit Chang	Welcome: Ad	dministrator s   Logout
🗲 System	Dovices	Find Dovisor						
Network	List of autom	atically detected new devices.						
Devices								
<b>≵</b> 1/0								
Control/Logic	New Devices Found	Rescan Back						
Logging	Show 10 \$ ent	ries						
Edit Dashboards	Model	Serial Number	Comm Type	Address	Description	Name	Select	
	X-155	0000064	SERIAL	AUTO_GENERATE	AUTO_GENERATE	AUTO_GENERATE	Add	
	X-12S	0000054	SERIAL	AUTO_GENERATE	AUTO_GENERATE	AUTO_GENERATE	Add	
View Dashboards	X-11S	0000004f	SERIAL	AUTO_GENERATE	AUTO_GENERATE	AUTO_GENERATE	Add	
	Showing 1 to 3 of 3	entries					Previous	Next 🕨

5. On the main menu, click the **View Dashboards** menu tab. The **View Dashboards** page shows a display similar to what users will see when accessing the X-600M's control page. A temperature readout should be shown for both sensor channels. Use this page to test and debug the dashboards, panels, widgets and components in real time. A pull-down menu allows access to other dashboards. Within minutes you can experience the power and flexibility of the dashboard's user interface and experiment/test the buttons, sliders, and data entry boxes to meet your needs for your specific application.

⊖ ⊖ ⊖ ﷺ	×		e <sup>n</sup>
← → C 🗋 192.168.1	2/setup.html		tz] ≡
			Welcome: Administrator Commit Changes   Abandon Changes   Logout
🗲 System			
Network		X600M - Dashboard 1	
Devices	Thermocouple Type K Slave (0000005c)	φ	
<b>↓</b> vo	Thermocouple: 76.35 F		
Control/Logic	Thermocouple: 89.75 F		
Logging			
Edit Dashboards			

# **Appendix A: Specifications**

#### **Power Requirements**

Input Voltage: 9-28 VDC (power is supplied via the X-600M controller, 24V recommended) Current: See table below for typical values at 25°C

Power Supply	Open Thermocouple	Good Thermocouple
9 VDC	49 mA	17 mA
12 VDC	37 mA	13 mA
24 VDC	20 mA	8 mA

#### **Thermocouple Inputs**

Number of channels:	2-channels
Thermocouple:	Туре-К
Linear Range:	-200° C to 1250°C
Operating Ambient:	-40° C to 85°C (internal cold junction compensation)
Resolution:	0.027°C
Accuracy:	+-0.5°C
Drift:	4ppm/°C typical, 15ppm/°C max
Туре:	Inputs are not isolated, only use ungrounded thermocouples
Input Current:	Differential, +-165nA max
Error Detection:	Detects sensor breakage or disconnection of lead wire

#### **Thermocouple Connectors**

Туре:	Miniature size, Omega PCC-SMP Series, Type-K
Mating Connector:	Miniature size, SMP

#### **Expansion Connector:**

Connector:	Ribbon cable, 2x5-position, polarized 0.100" pitch
Communications:	RS-485

#### LED Indicators

Green:	Power On
Yellow:	"Open Thermocouple" Channel-1
Yellow:	"Open Thermocouple" Channel-2

#### Environmental

Indoor use or NEMA-4 protected location	
Altitude:	up to 2000m
Operating Temperature:	-40°C to 65.5°C (-40°F to 150°F)
Storage Temperature:	-40°C to 85°C (-40°F to 185°F)
Humidity:	5-95%, non-condensing

#### Mechanical

Size:	1.41 x 3.88 x 3.1 in. (35.7 x 98.5 x 78 mm), (not including connector)
Weight:	4.8 oz (136 g)

#### **Electromagnetic Compliance**

IEC CISPR 22, CISPR 24 FCC 47CFR15 (Class B) EN55024 ITE Immunity (2010) EN55022 Emissions (2010)

#### **Product Safety Compliance**

UL 61010-1 (Electrical Equipment for Measurement, Control, and Laboratory Use)



## **Appendix B: Trademark and Copyright Information**

This document is Copyright ©2014 by Xytronix Research & Design, Inc. All rights reserved.

X-600M<sup>™</sup>, WebRelay<sup>™</sup>, ControlByWeb<sup>™</sup>, and Xytronix Research & Design<sup>™</sup> are trademarks of Xytronix Research & Design<sup>™</sup>, Inc. 2005-2014.

All other trademarks are the property of their respective owners.

All parts of this product and design including but not limited to firmware, hardware design, schematics, PCB layout, concept, graphics, users manual, etc., are property of Xytronix Research & Design, Inc. ©2005-2014. X-600M may not be opened, disassembled, copied or reverse-engineered.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying or scanning, for any purpose other than the personal use by the purchaser of this product. Xytronix Research & Design, Inc., assumes no responsibility for any errors that may appear in this document.

Whereas reasonable effort has been made to make the information in this document as useful and accurate as possible, Xytronix Research & Design, Inc. assumes no responsibility for the application, usefulness, or completeness of the information contained herein. Under no circumstance will Xytronix Research & Design, Inc. be responsible or liable for any damages or losses including direct, indirect, special, incidental, or consequential damages or losses arising from either the use of any information contained within this manual or the use of any products or services referenced in this manual.

Xytronix Research & Design, Inc. reserves the right to change any product's features, specifications, documentation, warranties, fee schedules, and conditions at any time and without notice.

# **Appendix C: Warranty**

This Xytronix Research & Design, Inc. product has a warranty against defects in material and workmanship for a period of one year from the date of shipment. During the warranty period, Xytronix Research & Design, Inc. will, at its option, either repair or replace products that prove to be defective. This warranty is extended to the original purchaser of the equipment only.

For warranty service or repair, the product must be properly packaged, and returned to Xytronix Research & Design, Inc. The purchaser shall prepay all charges for shipping to Xytronix Research & Design, Inc., and Xytronix Research & Design, Inc. will pay the shipping charges to return the product to the purchaser as long as the product is shipped within the United States. If the product is shipped outside of the United States, the purchaser shall pay all shipping charges, duties, and taxes.

#### Limitation

The foregoing warranty shall not apply to defects or damage resulting from improper use or misuse, unauthorized repair, tampering, modification, improper connection, or operation outside the electrical/environmental specifications for the product. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes, and tornadoes. This warranty does not cover damage to property, equipment, direct, indirect, consequential, or incidental damage (including damage for loss of business profit, business interruption, loss of data, and the like) arising out of the use or misuse of this product.

UNDER NO CIRCUMSTANCES WILL THE LIABILITY OF XYTRONIX RESEARCH & DESIGN, INC. TO THE PURCHASER OR ANY OTHER PARTY EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT, REGARDLESS OF THE FORM OF THE CLAIM. No other warranty is expressed or implied. Xytronix Research & Design, Inc. specifically disclaims the implied warranties or merchantability and fitness for a particular purpose. Some jurisdictions may not allow the exclusion of limitation of liability for consequential or incidental damage.

# **Appendix D: FCC Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

#### Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. There is no guarantee, however, that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a relay on a circuit different from where the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Notice

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# **Appendix E: Mechanical Dimensions**



