



# User's Guide



*Shop online at*

**omega.com®**

OMEGA®

*omega.com*

*e-mail: info@omega.com*

*For latest product manuals:*

*omegamanual.info*

ISO 9001  
CERTIFIED  
CORPORATE QUALITY

STAMFORD, CT

ISO 9001  
CERTIFIED  
CORPORATE QUALITY

MANCHESTER, UK

# HH502

## Digital Thermometer

**omega.com**<sup>®</sup>

ΩOMEGA<sup>®</sup>

OMEGAnet<sup>®</sup> On-Line Service  
omega.com

Internet e-mail  
info@omega.com

## Servicing North America:

### U.S.A.: ISO 9001 Certified

OMEGA Engineering, Inc.

One Omega Drive, P.O. Box 4047

Stamford, CT 06907-0047 USA

Toll-Free: 1-800-826-6342 TEL: (203) 359-1660

FAX: (203) 359-7700 e-mail: info@omega.com

### Canada:

976 Bergar

Laval (Quebec), Canada H7L 5A1

Toll-Free: 1-800-826-6342 TEL: (514) 856-6928

FAX: (514) 856-6886 e-mail: info@omega.ca

## For immediate technical or application assistance:

### U.S.A. and Canada:

Sales Service: 1-800-826-6342/1-800-TC-OMEGA<sup>®</sup>

Customer Service: 1-800-622-2378/1-800-622-BEST<sup>®</sup>

Engineering Service: 1-800-872-9436/1-800-USA-WHEN<sup>®</sup>

### Mexico:

En Español: 001 (203) 359-7803

FAX: (001) 203-359-7807

info@omega.com.mx

e-mail: espanol@omega.com

## Servicing Europe:

### Benelux:

Managed by the United Kingdom Office

Toll-Free: 0800 099 3344 TEL: +31 20 347 21 21

FAX: +31 20 643 46 43 e-mail: sales@omega.nl

### Czech Republic:

Frystatska 184, 733 01 Karviná, Czech Republic

Toll-Free: 0800-1-66342 TEL: +420-59-6311899

FAX: +420-59-6311114 e-mail: info@omegashop.cz

### France:

Managed by the United Kingdom Office

Toll-Free: 0800 466 342 TEL: +33 (0) 161 37 29 00

FAX: +33 (0) 130 57 54 27 e-mail: sales@omega.fr

### Germany/Austria:

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany

Toll-Free: 0 800 6397678 TEL: +49 (0) 7059 9398-0

FAX: +49 (0) 7056 9398-29 e-mail: info@omega.de

### United Kingdom:

ISO 9001 Certified

OMEGA Engineering Ltd.

One Omega Drive, River Bend Technology Centre

Northbank, Irlam, Manchester M44 5BD England

Toll-Free: 0800-488-488 TEL: +44 (0)161 777-6611

FAX: +44 (0)161 777-6622

e-mail: sales@omega.co.uk

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification. The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

**WARNING:** These products are not designed for use in, and should not be used for, human applications.

# INTRODUCTION

This instrument is a 4½ digit, compact-sized portable digital thermometer designed to use external K-type and J-type thermocouples as temperature sensor. Temperature indication follows Reference Temperature/Voltage Tables (N.I.S.T. Monograph 175 Revised to ITS-90) for K-type and J-type thermocouples. Two K-type thermocouple are supplied with the thermometer.

## SAFETY INFORMATION

It is recommended that you read the safety and operation instructions before using the thermometer.

### **WARNING**


To avoid electrical shock, do not use this instrument when working voltages at the measurement surface over 24V AC or DC.

### **WARNING**

To avoid damage or burns, do not make temperature measurement in microwave ovens.

### **CAUTION**

Repeated sharp flexing can break the thermocouple leads. To prolong lead life, avoid sharp bends in the leads, especially near the connector.

The  symbol on the instrument indicates that the operator must refer to an explanation in this manual.

# SPECIFICATIONS

## ELECTRICAL

**Temperature Scale:** Celsius or Fahrenheit user-selectable.

**Measurement Range:**

J-TYPE -200°C to 1050°C, (-328°F to 1922°F)

K-TYPE -200°C to 1370°C, (-328°F to 2498°F)

**Resolution:** 0.1°C or 0.2°F.

**Accuracy:** Accuracy is specified for operating temperatures over the range of 18°C to 28°C (64°F to 82°F), for 1 year, not including thermocouple error.

$\pm(0.05\% \text{ rdg} + 0.3^\circ\text{C})$  -50°C to 1370°C

$\pm(0.05\% \text{ rdg} + 0.7^\circ\text{C})$  -50°C to -200°C

$\pm(0.05\% \text{ rdg} + 0.6^\circ\text{F})$  -58°F to 2498°F

$\pm(0.05\% \text{ rdg} + 1.4^\circ\text{F})$  -58°F to -328°F

**Temperature Coefficient:** 0.1 times the applicable accuracy specification per °C from 0°C to 18°C and 28°C to 50°C (32°F to 64°F and 82°F to 122°F).

**Input Protection:** 24V dc or 24V ac rms maximum input voltage on any combination of input pins.

**Maximum Differential Common Mode Voltage (Maximum Voltage between T1 and T2 during measurement):** 1volt.

**Reading Rate:** one time per second.

**Input Connector:** Accepts SMP male miniature thermocouple connectors.

## **ENVIRONMENTAL**

**Ambient Operating Ranges:** 0°C to 50°C (32°F to 122°F) <80% R.H.

**Storage Temperature:** -20°C to 60°C (-4°F to 140°F) <70% R.H.

## **GENERAL**

**Display:** 4½ digit liquid crystal display (LCD) with maximum reading of 19999.

**Overload:** "----.-" is display.

**Battery:** Standard 9V battery.

**Battery Life:** 100 hours typical.

**Auto power off:** The meter key switch inactive for more than 30 minutes,  
press power key to resume operation.

**Dimensions:** 192mm(H) x 91mm(W) x 52.5mm(D).

**Weight:** 365g.

# OPERATING INSTRUCTIONS

## ① ① Power Switch

The ① key turns the thermometer on or off. In the data SET mode, can not power off, must leave data SET mode then power off.

## ② °C/°F Selecting the Temperature Scale

Readings are dual displayed in either degrees Celsius(°C) or degrees Fahrenheit(°F). When the thermometer is turned on, it is set to the temperature scale that was in use when the thermometer was last turned off. To change the temperature scale, press the °C/°F key.

## ③ HOLD Mode (only Main display)

Pressing the HOLD key to enter the Data Hold mode, the "HOLD" annunciator is displayed. When HOLD mode is selected, the thermometer held the present readings and stops all further measurements.

Pressing the HOLD key again to cancel HOLD mode causing thermometer to resume taking measurements.

In the MIN/MAX recording mode, press HOLD key to stop the recording. Press HOLD key again to resume recording. (Previously recorded reading are not erased).

#### ④ **T1 /T2/T1-T2 Main display Input Selection**

The input selection indicates which input is selected for main display; T1 thermocouple, T2 thermocouple or the difference between the two thermocouples (T1-T2), when the thermometer is turned on, it is set to T1, When main display input selected T1, then T1 input can select alternate of thermocouple by pressing K/J key switch.

#### ⑤ **K/J T1 Input Thermocouple Type Select (Main display)**

The K/J key switch the T1 input selects the K-type or J-type thermocouple as input, when main display input selected T1.

When the thermometer is turned on, it is set to the type selected that was in use when the thermometer was last turned off.

#### ⑥ **MIN MAX with Time record Mode (only Main display)**

Press MIN MAX key to enter the MIN MAX Recording mode, (displays the Maximum reading with time, Minimum reading with time and Average reading stored in record mode). In the this mode the automatic power-off feature is disabled and ①key, °C/°F key, REL key, SET key, Hi/Lo LIMITS key and main display T1 T2 T1-T2 key, K/J key are disabled.

The beeper emits a tone when a new minimum or maximum value is recorded.

Push MIN MAX key to cycle through the MAX, MIN and AVG readings.

If an overload is recorded, the averaging function is stopped and average value display"----.-".

In the this mode, press HOLD key to stop the recording of readings, all values are frozen, press again to restart recording.

To prevent accidental loss of MIN, MAX and AVG data, in this mode can only be cancelled by pressing and hold down the MIN MAX key for 2 seconds to exit and erased recorded readings.

#### WARNING

MIN, MAX and AVG readings can be recorded for a period of up to 20 hours maximum. If this 20 hours period is exceeded the unit readings will not be accurate.

#### ⑦ REL Relative mode (only Main display)

Pressing REL key to enter the Relative mode, zero the display, and store the displayed Reading as a reference value and annunciator REL is displayed. Press REL key again to exit the relative mode.

The relative value can also be entered by the user. (See "SET mode" later in this manual.)

When the desired Relative value has been entered, press REL key to enter the Relative mode, press SET key use set Relative value as a reference value. Press REL key again to exit the relative mode.

In the Relative mode, the value (can not  $\geq \pm 3000.0$  counts) shown on the LCD is always the difference between the stored reference and the present reading.



## ⑧ **Sec. Minu. Selecting the Time scale**


Reading the third displayed (Time) in either second or minute. When the thermometer turned on, it is set to second. To change the Time scale, press sec. Minu. key.

Maximum Time reading is 100 hours. If 100 hours is exceeded, reset Time to zero and restart.

## ⑨ **SET mode (Relative value set, Time set and Hi/Lo Limits value set)**

1. Press SET key to enter Relative value SET mode (Press ENTER key can escape relative value set mode), REL set mode. = = = =. is displayed in main display.

Relative value is entered via overlay numbers, then press overlay ENTER key, stored the relative value, enter Time set mode.

2. Time set mode, (Press ENTER key can escape Time set mode) =. = = =. is displayed in second and third display. Time (hours, minutes, seconds) value is entered via overlay numbers, then press overlay ENTER key. Time start from set time value, enter Hi/Lo Limits value set mode.
3. Hi Limit value set mode,  is displayed (Press ENTER key can escape Hi Limit value set mode), = = = =. is displayed in main display, Hi Limit value is entered via overlay numbers, then press overlay ENTER key, stored the Hi Limit value, enter Lo Limit value set mode (Press ENTER key can escape Lo Limit value set mode). = = = =. is displayed in main display, Lo Limit value is entered via overlay numbers, then press overlay ENTER key, stored the Lo Limit value and exit SET mode.

4. When the thermometer is turned on. The Relative set value and Hi/Lo Limits set value that was in use when thermometer was last turned off set values.

#### ⑩ **T1/T2/T1-T2 second display Input Selection**


The input selection indicates which input is selected for second display; T1 thermocouple, T2 thermocouple or the difference between the two thermocouples (T1-T2), when the thermometer is turn on, it is set to T2 input can select alternate of thermocouple by second display K/J key switch.

#### ⑪ **K/J T2 Input thermocouple type select (second display)**

The K/J key switch the T2 input selects the K-type or J-type thermocouple as input, when second display input selected T2.

When the thermometer is turned on, it is set to the type selected that was in use when the thermometer was last turned off.

#### ⑫ **Hi/Lo Limits mode (only Main display)**


Press Hi/Lo Limits key to enter the Hi/Lo Limits comparative mode,  is displayed, when input temperature value exceed Hi or Lo Limits value. The beeper emits a continuity pulse tone. Press Hi/Lo Limits key again to exit the Hi/Lo Limits mode.

# OPERATOR MAINTENANCE

## WARNING

To avoid possible electrical shock, disconnect the thermocouple connectors from the thermometer before removing the cover.

### Battery Replacement

Power is supplied by a 9 volt "transistor" battery. The " " appears on the LCD display when replacement is needed. To replace the battery, remove the two screws from the back of the meter and lift off the battery cover. Remove the battery from battery contacts.

# CALIBRATION PROCEDURE

**Note:** The following calibration procedures should be performed only by qualified technicians who have access to the following:

Equipment: The class of calibration should be 10 times greater than the measured meter.

Step 1: Short the J3 with jumper.

Step 2: Apply 65 mV to the T1 input from Volts Calibrator and wait till the reading becomes stable, then press the SET key until the display shows 0.1.

Step 3: Apply Type K 0°C to the input T2 and wait till the reading becomes stable, then press the SET key until the meter shuts off by itself.

Step 4: Remove the jumper from J3.

**NOTES:**

**NOTES:**

## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence. The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering. OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2008 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

# Where Do I Find Everything I Need for Process Measurement and Control?

## OMEGA...Of Course!

*Shop online at [omega.com](http://omega.com)<sup>sm</sup>*

### TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

### PRESSURE, STRAIN AND FORCE

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

### FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

### pH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

### DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Datalogging Systems
- ☑ Recorders, Printers & Plotters

### HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

### ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments

M2807/1008