

Troubleshooting

Problem	Possible Solution
Hard drive malfunction – screen locks up or goes blank	 Turn off the IPW computer processor, then turn it back on. If the operating system does not start up, refer to your computer manufacturer's user manual.
DLS System Software malfunction – screen locks up or closes down	A system may appear to lock up due to orders being processed in the background. If this is not the case, do the following:
	 Record any error messages that appear. Turn off the IPW computer processor, then turn it back on. If the DLS System Software does not start up, record any error messages that appear and note what function the software was performing when the problem occurred.
Notwork	3 Contact your service provider.
disconnect – unable to upload orders to the Internet	current.
	2 Make sure your hub, router, and modem connections are secure.
	3 If you are unable to re-establish the network connection, contact your Internet service provider.
Network disconnect – unable to receive incoming orders from network devices such as KODAK Picture Preview Center	1 Check for loose connections to the incoming network device.
	2 Make sure the incoming network device is turned on
	3 Check to see if you are configured to receive network orders
	 4 If you are unable to re-establish the network connection, contact your service provider.

Errors reported through the software

If the status icon is red or yellow, click the status icon, then click the inner tab icon showing a light other than green to view the errors in the appropriate status screen.

For more information, refer to the DLS System Software Help under "Troubleshooting."

Kodak is a trademark of Eastman Kodak Company.

Eastman Kodak Company Rochester, NY 14650



KODAK DLS System Management Software 3.0 LA

System Startup

Important: Perform the steps in the order listed.

- **1** Turn on the flatbed scanner and the other peripheral devices.
- **2** Turn on the film scanner. A 3-minute warm-up period is required before the film scanner scans film. A 30-minute warm-up period is recommended.
- **3** Switch the printer to Operation mode.
- **4** Turn on the IPW computer and monitor. The KODAK DLS System Management Software (DLS System Software) starts automatically.
- **5** Run Scanner Corrections (optional).

Note: For directions on running Scanner Corrections, see the DLS System Software Help.

System Shutdown

Important: Perform the steps in the order listed.

- **1** Wait for processing orders to complete.
- **2** Run the printer Close Down Checks.
- **3** From the **File** menu, select **Shutdown**, and then click **OK**. The DLS System Software and the WINDOWS 2000 Operating System shut down.

Note: If orders are being processed when you select Shutdown, a dialog box appears. Delete the processing orders and proceed with the shutdown, or continue processing the orders (in this case the system is not shut down).

- **4** When the DLS System Software shuts down and the Restart button appears, turn off the IPW computer and monitor.
- **5** Turn off the flatbed scanner and the other peripheral devices.
- 6 Turn off the film scanner.

Note: Turning off the film scanner while the DLS System Software is shutting down can cause scanner failure during startup.

7 Install the manual gate in the film scanner to keep dust off the lens.





P/N 6B6808_EN 3/2002 © Eastman Kodak Company, 2002

