


# *Ultrastab 866R*

## *Six-Channel Current Transducer*

### *User Manual*



Distributed by:

GMW Associates

955 Industrial Road, San Carlos, CA 94070 USA

Tel: (650) 802-8292 Fax: (650) 802-8298

Email: [sales@gmw.com](mailto:sales@gmw.com)

Website: <http://www.gmw.com>

Manufactured by:

Danfysik A/S

Mollehaven 31

DK 4040 Jyllinge

Denmark

Tel: +45 46 76 81 50 Fax: 45 46 73 15 51

Email: [danfysik@danfysik.dk](mailto:danfysik@danfysik.dk)

24 April 2006

## TABLE OF CONTENTS

PAGE

### 1. INTRODUCTION AND SPECIFICATIONS.

1.1	Introduction.....	2
1.1.1	Working principle.....	3
1.2	Warranty.....	4

### 2. RECEIVING AND UNPACKING.

2.1	Receiving the goods.....	5
2.2	Instructions for unpacking.....	5

### 3. INSTALLATIONS.

3.1	Installation.....	6
3.2	Interlock circuit.....	6

### 4. OPERATING INSTRUCTIONS.

4.1	Switching ON and Operating Instructions.....	7
-----	--	---

### 5. THEORY OF OPERATION.

5.1	General description of the Electronics.....	8
5.2	Current transducer 866 & 867.....	8
5.3	Programming of the output voltage.....	9

6.	MAINTENANCE.....	9
----	------------------	---

APPENDIX A - SALES REPRESENTATIVE AND SERVICE.....	10
--	----

APPENDIX B – VOLTAGE OUTPUT MODULES.....	11
--	----

APPENDIX C – SPECIFICATIONS 866R- 09A03.....	14
--	----

APPENDIX D – DRAWINGS 88729B & 88201G & 89111.....	15
--	----

APPENDIX E – DRAWINGS 21908-0001-OA, 866R Outline.....	
--	--

APPENDIX – DRAWINGS 13908-0000-OA, 866R Schematic.....	
--	--

## 1.1 INTRODUCTION.

The ULTRASTAB 866R system is based on the very proven 866-600 precision current transducer technology. In this new configuration, named Model 866R, we have packaged the modules into a 3 to 6 channel system with a measuring capacity of up to 600A DC or 425A AC (RMS). The system can be used either as a stand-alone system or as a current range extender on high performance Power Analysers.


The system is delivered as a complete system, including auxiliary power supply, mounted in a 19" rack mount cabinet, transducer heads type 866-600 or 867-400 or a combinations of both types and connecting cables.

The basic version is equipped with 3 channels, but can be extended up to totally 6 channels.

The 866R system has a standard analog output of +/- 1V and an analog current output that is depending on the chosen type of transducer, and the selected maximum primary current, when the instrument was ordered, please refer to chapter 5.3.



Front view of the Ultrastab 866R with LED status information for the individual channels.



Rear view of the Ultrastab 866R with connectors for the individual Transducers/ channels and 25 pole female D-sub socket for interlock connections. The grounding option is located in the left side of the cabinet.

### 1.1.1 Working principle.

The DANFYSIK ULTRASTAB 866R Current Transducer system is a unique design, based on the zero-flux principle for galvanic isolated precision current measurement.

With the primary current conductor through the transducer head center hole and current flowing, the electronics will generate a current in the built-in compensation winding, counter-balancing the primary ampere-turns.

A very sensitive and extremely low noise detector circuit will detect when zero-flux is obtained, and an analog 0 – max.  $\pm 400\text{mA}$  or 0 -  $\pm 1\text{V}$  signal will be generated at the output terminals in direct proportion to the primary current.

The front panels of the modules are equipped with LED's giving you the information:

- Power
- Normal operation
- Transducer connected

## 1.2 Warranty

DANFYSIK A/S warrants the equipment delivered from the company to be free from any defects in materials and workmanship for a period of:

**12 Months from the date of installation or max. 18 months from the date of shipment. Whichever is shortest.**

Within this warranty period DANFYSIK A/S will repair or replace any defective parts free of charge either on the customers site or at our factory at our choice.

DANFYSIK A/S will pay or reimburse the lowest two-way freight charges on any items returned to DANFYSIK A/S or our designated agent/representative provided DANFYSIK A/S has given prior written authorisation for such return.

This warranty shall not apply to any equipment which our inspection shows to our satisfaction, to have become defective or unworkable due to mishandling, improper maintenance, incorrect use, or any other circumstances, not generally acceptable for equipment of a similar type.

DANFYSIK A/S reserves the right on standard products to make changes in design without incurring any obligation to modify previously manufactured units.

The foregoing is the full extent of the warranty and no other warranty is expressed or implied. If no event Danfysik shall be liable for special damage arising from the delivery, late delivery, or use of the equipment.

If any fault develops the following steps should be taken:

Notify DANFYSIK A/S giving full details of the problems and include Model, Type, Serial number, and Order number.

On receipt of this information DANFYSIK A/S will send you either service information or instructions for shipping.

All shipments of DANFYSIK A/S equipment should be made according to our instructions and shipped in the original or a similar package.

For smaller parts a cardboard carton will be sufficient, providing the parts are wrapped in plastic or paper and surrounded with at least 10 centimetres of shock-absorbing material.

## **2. RECEIVING AND UNPACKING.**

### **2.1. RECEIVING THE GOODS**

The shipping package and the ULTRASTAB should be thoroughly inspected for signs of obvious physical damage immediately upon receipt.

All materials in the package should be checked against the enclosed packing list and the list of standard delivery below. DANFYSIK A/S will not be responsible for any shortages unless notified immediately.

ULTRASTAB 866R. Standard Delivery:

- Electronics 19 inch crate
- Three Transducer heads type 866-600A or three type 867-400
- Three Connections cables 5m
- AC power cable
- Manual.

### **2.2. INSTRUCTIONS FOR UNPACKING**

The ULTRASTAB is shipped in a cardboard carton.

If the equipment is damaged in any way, a claim should be filed with the shipping agent, and a full report of the damage should be forwarded to Danfysik A/S or our local agent/representative immediately upon arrival.

Upon receipt of this report, Danfysik will forward instructions concerning the repair, replacement or return shipment.

Please include the Type No., Serial No., and Order No. for the ULTRASTAB 866R on any communication with DANFYSIK or our representative.

### **3. INSTALLATION**


1. Check that the specified AC voltage and current are available and that the ambient temperature is within the range specified in this manual.
2. Establish the Ground connection according to the local authority regulations and the requirements of the equipment via the AC power plug.
3. Connection cables:  
Mount the provided connection cables between the Electronics crate rear side sockets and the Transducer Heads. Use channel 1 to 3 as default.
4. Concerning Output terminals on the rear side of the cabinet:  
If the Voltage output shall be used, the shorting clamp on the Current output must always be mounted. The value of the internal shunt is written on a label.  
If output current is used - i.e. for connecting an external shunt - the shortening clamp must be opened.  
The grounding clamp shall normally be mounted to obtain best noise performance.
5. Check that all cables terminated in plugs are pushed fully home.
6. Transducer head.  
The transducer head may be installed in any orientation, but be careful to keep it away from power transformers, and other units producing significant magnetic stray fields. Please refer to the "busbar free zone" in the technical specifications of the 866R  
  
If above checkpoints are fulfilled the system is ready for use.

#### **3.2 INTERLOCK CIRCUIT**

The interlock circuit is present at a 25 pole D-Sub socket at the rear side of the cabinet. The output signal can be used in any general safety interlock set up circuit. There is an Opto coupler output for each channel which are ON at NORMAL OPERATION.

Interlock plug:

Channel 1: pin 12 Collector & pin 11 Emitter  
 Channel 2: pin 10 Collector & pin 9 Emitter  
 Channel 3: pin 8 Collector & pin 7 Emitter  
 Channel 4: pin 6 Collector & pin 5 Emitter  
 Channel 5: pin 4 Collector & pin 3 Emitter  
 Channel 6: pin 2 Collector & pin 1 Emitter



One example of the interlock output

#### **4. SWITCHING ON AND OPERATING INSTRUCTIONS**

When the instructions for installation in pos. 3.1 have been completed, the ULTRASTAB 866R Electronics can be switched ON.

Please note:

If two voltage output is connected to the same instrument e.g. an oscilloscope, the output will not be valid, due to the internal shorting of the two channels GND.

Any instrument connected to the Voltage output MUST have a differential input to avoid a grounding loop via power ground.

1. Switch ON the AC power and the green LED – Control Power will be on.  
The Green LED - NORMAL OPERATION on the units connected will be "ON"
- 2 The total assembly is in NORMAL OPERATION, and an analogue current/voltage proportional to the measured current will be generated by the electronics circuitry and presented at the output terminals.  
NORMAL OPERATION means: Cable connected, measured current is within 115 % of programmed maximum current and internal aux. power supplies are working.
3. If the Green LED - NORMAL OPERATION is not "ON", please recheck that all connections are properly made and secured by the screws.
4. If any problem should occur during this operation, please contact our local representative or Danfysik direct.
5. All performance data refers to max. Current for the type 866-600 or 867-400 transducer head. In order to obtain maximum accuracy of the instrument, lower currents can be measured by applying more primary turns through the transducer head and divide the output signal with the number of turns or program to a lower maximum current. For high sensitivity measurements it is important to distribute the turns with even space all around on the transducer head.
6. In order to avoid excessive saturation of the iron core in the transducer head, this unit must be switched on before the actual primary current source is applied.



## 7. THEORY OF OPERATION.

### 5.1 GENERAL DESCRIPTION OF THE ELECTRONICS

The ULTRASTAB 866R electronic crate is equipped with a switch mode power supply delivering the +/-15V to the transducer heads. This power supply covers the following range of mains input voltages: 85 – 264Vac / 47-63Hz .

The build in interlock and Voltage Output module( VOM ) receives the compensation current from the transducer heads and make it possible to measure the current or the voltage on the internal precision resistors.

### 5.2 ULTRASTAB 866-600 & 867-400 CURRENT TRANSDUCERS

The transducers have an arrow sticker on the side face. With the main current flowing in the direction of the arrow, a positive voltage will be developed across an internal or external Burden resistor.

The transducers can be mounted in any orientation, and the influence from external stray fields is very low.

Please note: The transducer contains fragile materials in the zero detector assembly, and care should be taken in handling.



### **5.3 Programming the output Voltage**

The output voltage is factory programmed to match the ordered number of channels and the maximum current to be measured.

If a need for more channels or other current values is desired, please contact Danfysik or our representative.

For information on how to field install new Voltage Output modules, please see appendix B.

The output voltage is always +/- 1V at maximum primary current, provided that the correct primary current has been selected when ordering. The value of the internal shunt is indicated on a label for each channel.

The configuration of your system is labelled on the lid of the 866R unit and shown in appendix B in this manual.

### **6.0 MAINTENANCE**

The ULTRASTAB 866R assembly does not require any maintenance under normal operation.

Please note:

Faults within the calibrated components and the zero flux detector can only be repaired by returning the ULTRASTAB 866R assembly to Danfysik A/S direct or via our local representative.

Failing to follow this procedure will make the warranty null and void.

**APPENDIX A. - SALES REPRESENTATIVE AND SERVICE.****DANFYSIK A/S,**

Moellehaven 31,

DK-4040 Jyllinge

**DENMARK.**

Phone No.: +45 46 78 81 50

Fax No.: +45 46 73 15 51

E-mail: sales@danfysik.dk

[www.danfysik.dk](http://www.danfysik.dk)**DISTRIBUTORS****EUROPE:**

SIGNALTEC GmbH

Dr. Carlo-Schmid-Straße 112

D-90491 Nürnberg

Germany

Telephone: +49 911 5971919

Fax: +49 911 5971920

Email: [info@signaltec.com](mailto:info@signaltec.com)Web: [www.signaltec.com](http://www.signaltec.com) ([www.signaltec.de](http://www.signaltec.de))**USA:****GMW ASSOCIATES,**

955 Industrial Road

San Carlos

CA 94070

P.O. Box 2578

Redwood City

CA 94064

Phone No.: (650) 802-8292

Fax No.: (650) 802-8298

E-mail: sales@gmw.com

[www.gmw.com](http://www.gmw.com)**INDIA:****TRANSACT INDIA CORPORATION**

5/1A, Grants Building

Arthur Bunder Road

Colaba

Mumbai - 400 005

Phone No.: (22) 285 5261

Fax No.: (22) 285 2326

E-mail: trans@vsnl.com


## **APPENDIX B: Installation of Voltage Output Modules ( VOM ):**

If there is a need for adding more channels or changing the maximum current value of the Ultrastab 866R the following should be done:

Remove the mains power cable from the unit

The lid is removed by unscrewing the two screws on the side of the cabinet.


The new VOM module can now be installed between the ribbon cable and the main circuit board, please see photo.



List of available VOM's:

Product	Description	Part No.
866-VOM75	Voltage Output Module with $\pm 10V$ analog output for $\pm 75A$	81088903
866-VOM150	Voltage Output Module with $\pm 10V$ analog output for $\pm 150A$	81088904
866-VOM300	Voltage Output Module with $\pm 10V$ analog output for $\pm 300A$	81088905
866-VOM600	Voltage Output Module with $\pm 10V$ analog output for $\pm 600A$	81088906

Programming label for *ULTRASTAB 866R*



Transducer type	Primary current		Output Current
<b>866-600</b>	A	600A (425A RMS)	400mA
	B	300A (210A RMS)	200mA
	C	150A (105a RMS)	100mA
	D	75A (52A RMS)	50mA
<b>867-400</b>	A	Not used	Not used
	B	400A (280A RMS)	200mA
	C	200A (140A RMS)	100mA
	D	100A (70A RMS)	50mA

## ULTRASTAB 866R

### 3 – 6 Channel Current Transducer System

<b>BASIC SPECIFICATION FOR A SINGLE CHANNEL</b>	
Primary current I (max.)	600ADC / 425A RMS
Polarity	Bipolar
Output at max. primary current: - Current output (screw terminals) - Voltage output (BNC)	$\pm 400\text{mA}$ *) $\pm 1\text{V}$
Load capacity: - Normal load - Overload (basic function maintained) - Overload (fault)	0 – 100% 0 – 110% 500% (0.1 s)
Transfer ratio accuracy: - Current I(max) / 400mA - Voltage I(max)/1V	< 2 ppm < 0,01%
Linearity: - Current mode - Voltage mode	< 1 ppm < 25 ppm
Measuring / ratio stability: Current mode: - v.s. temperature - v.s. time  Voltage mode: - v.s. temperature - v.s. time	<0,3 ppm/°C 1 ppm/month  <3 ppm/°C 10 ppm/month
Offset: - Initial - Drift v.s. temperature - Drift v.s. time	< 25 ppm < 0,3 ppm/°C < 2 ppm/month
Noise feedback to main conductor DC – 50 kHz (RMS) (Measured on the primary current cable – one turn)	< 10 $\mu\text{V}$
Output noise (RMS): DC – 10 Hz DC – 10 kHz DC – 50 kHz	< 1 ppm < 10 ppm < 30 ppm
Slew rate (10-90%)	$\geq 10\text{kA} / \text{ms}$


<b>BASIC SPECIFICATION FOR A SINGLE CHANNEL</b>	
Channel separation at max nominal current, and slew rate at 40kA/ms	0.05% / $\pm$ 66dB
Bandwidth (small signal 0.5%) 3 dB	DC to 100 kHz
Busbar free zone to be within linearity specification: Cylinder shape (diameter x length)	$\varnothing$ 150 x 150 mm
Test voltage transducer head	5 kV AC (RMS)
Cable length electronics measuring head	5 m
Operating temperature	10 – 50°C
Storage temperature	0 – 60°C
Input power requirement	85 - 260V, AC, 50/60Hz max. 100V A
Emission complying standard	EN 50081-2
Immunity complying standard	EN 50082-2-1995
Operating humidity	20 – 80%
Mechanical dimensions: A. Electronics Weight	483 x 88 x 250 mm Approx. 4 kg
B. Transducer (dwg. 88312) Hole for conductor Weight (each transducer)	122 x 98 x 65 mm $\varnothing$ 26 mm 1 kg

All ppm figures refer to max. output.  
Specifications are subject to change without notice.

- \*) Optional output data:  
The 866R can be delivered factory programmed for:  
 $\pm$  200mA /  $\pm$  1V at 300A primary current - or  
 $\pm$  100mA /  $\pm$  1V at 150A primary current - or  
 $\pm$  50mA /  $\pm$  1V at 75A primary current

**DANFYSIK A/S · DK-4040 Jyllinge · Denmark · Tel.: +45 46 79 00 00 · Fax: +45 46 79 00 01**  
Web: [www.danfysik.dk](http://www.danfysik.dk) – e-mail: sales@danfysik.dk






Projection:	Dimensions without tolerance indication:	Scale:	Customer:	Size:
EN 22768-mk	EN 22768-mk	1:1	CURRENT TRANSDUCER	<b>A3</b>
Pro. Eng.	Date:	Name:	Assembly:	AutoCAD
TS	TS	88729B	Ultraslab 200/4001	Mechanical
Des. App.	Date:	Name:	Drawing No.:	2002
			88729B	
			CAD File Type:	AutoCAD Mechanical 2002


**DANFYSIK**  
 DK-4040 Jyllinge, Denmark  
 Homepage: www.danfysik.dk  
 e-mail: danfysik@danfysik.dk  
 Phone: +45 4679 0000 Fax: +45 4679 0001

Important: Measurements and test data are confidential information which is the property of DANFYSIK A/S. It is submitted to you in confidence that it will not be disclosed or transmitted to others or used for manufacturing.






M6x10 FOR MOUNTING  
MAX RECOMMENDED TORQUE 0.2kgm.




D-SUB, 9 POLE  
POWER  
SIGNAL  
TEST




TOLERANCE: ±0.3		SURFACE TREATMENT: -		MATERIAL: -	
SCALE: 1:1		MACHINING: -		DRAWN BY: KP 11.03.97	
CURRENT TRANSDUCER 150/600A ULTRASTAB 866		DESIGN APP.:		PROD.APP. TS	
		PROJ.ENGR. TS		DWG.NO.:	
		88201G		REVISION: G SHEET 1 OF 1	
CUSTOMER: .		PROJECT NO.:		DATE: MK 20.03.01 SIZE: A3	
FILE:		PROJECT NO.:		DATE: MK 20.03.01 SIZE: A3	

IMPORTANT!  
This document contains information which is the property of Danfysik A/S, Denmark. It is submitted to you in confidence that it will not be disclosed or transmitted to others without Danfysik's authorization.








# Ultrastab 866R main blockdiagram

## SCHEMATIC

DRAWN BY: JB  
 DESIGN APP.  
 PROD APP.  
 PROJ. ENGR.  
 DWG.NO.: **(820) 89111**

FILE: T:\PROJEKTER\IGANG\PC STYRET TEST SYSTEM\TEST BOX\866R MAIN SCHEMATIC.DSN


CUSTOMER	ORDER NO.	REV. 1	SHEET. 1 OF 1
MØLLEHAVEN 31 DK-4000 LILLINGE DENMARK	09:22:39		SIZE A4
Modified: Friday, September 26, 2003	Created: Wednesday, September 24, 2003 10:17:53		
TELEPHONE: +45 46 79 00 00	TELEFAX: +45 46 79 00 01		
			
E-MAIL: DANFYSIK@DANFYSIK.DK			



H G F E T D C B A

REV	DESCRIPTION	DATE	APPROVED
A	RELEASE	18 APR 81	M. DUFFY

1 2 3 4 5 6 7 8



H G F E T D C B A

**PROCEDURE:**  
 1. Turn on the power to the system.  
 2. Check the status LEDs on the front panel.  
 3. Verify the output voltage on the transducers.  
 4. Check the current through the transducers.  
 5. Verify the accuracy of the transducers.  
 6. Turn off the power to the system.

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	866-000	ULTRASTAB 866 R CURRENT TRANSDUCER SYSTEM
2	1	866-400	TRANSFORMER 1
3	1	866-400	TRANSFORMER 2
4	1	866-400	TRANSFORMER 3
5	1	866-400	TRANSFORMER 4
6	1	866-400	TRANSFORMER 5
7	1	866-400	TRANSFORMER 6

**DO NOT SCALE**  
 FROM DRAWING  
 TO OTHER DRAWING  
 FROM PHOTO  
 TO OTHER PHOTO  
 FROM MODEL  
 TO OTHER MODEL  
 FROM FIELD  
 TO OTHER FIELD  
 FROM OTHER  
 TO THIS DRAWING

**SCALE:** 1:1

**DATE:** 18 APR 81  
**BY:** M. DUFFY  
**APP'D:** M. DUFFY

**DESCRIPTION:**  
 CMTV  
 Danfysik 866R  
 Outline Drawing

**PROJECT:** A0 21908-0001-0 A  
**SCALE:** 1:1  
**SHEET:** 1 OF 1

**WARNING!**  
 Do not touch the terminals with power on.

**TRANSFORMER 1**  
 866-400  
 Not in use  
 A  
 B

**TRANSFORMER 2**  
 866-400  
 Not in use  
 A  
 B

**TRANSFORMER 3**  
 866-400  
 Not in use  
 A  
 B

**TRANSFORMER 4**  
 866-400  
 Not in use  
 A  
 B

**TRANSFORMER 5**  
 866-400  
 Not in use  
 A  
 B

**TRANSFORMER 6**  
 866-400  
 Not in use  
 A  
 B

**CONTROL POWER**

**1 NORMAL OPERATION**  
 866 POWERED

**2 NORMAL OPERATION**  
 866 POWERED

**3 NORMAL OPERATION**  
 866 POWERED

**4 NORMAL OPERATION**  
 866 POWERED


**5 NORMAL OPERATION**  
 866 POWERED

**6 NORMAL OPERATION**  
 866 POWERED

**DANFYSIK**







STATUS / INTERLOCK (DB25 CONNECTOR)	PIN 12	COLLECTOR	PIN 11	EMITTER
CHANNEL 1	PIN 12	COLLECTOR	PIN 11	EMITTER
CHANNEL 2	PIN 10	COLLECTOR	PIN 9	EMITTER
CHANNEL 3	PIN 8	COLLECTOR	PIN 7	EMITTER
CHANNEL 4	PIN 6	COLLECTOR	PIN 5	EMITTER
CHANNEL 5	PIN 4	COLLECTOR	PIN 3	EMITTER
CHANNEL 6	PIN 2	COLLECTOR	PIN 1	EMITTER

VOM BURDEN RESISTOR	TRANSJUCER	FS	CURRENT	RB
866-600	600A	2.50Ω	5.00Ω	
	300A	10.00Ω	20.00Ω	
	150A	40.00Ω	5.00Ω	
	75A	200A	10.00Ω	
867-400	400A	5.00Ω	10.00Ω	
	200A	10.00Ω	20.00Ω	
	100A	20.00Ω	20.00Ω	

NOTE:  
 1. 'ON' UNDER NORMAL OPERATING CONDITIONS  
 2. 5mA MAXIMUM CURRENT

FORM	REV.	DATE	NUMBER	DESCRIPTION

**GMW**  
 G. M. Durfy, Inc.  
 955 Industrial Rd., San Carlos, CA 94070  
 Telephone: (415) 965-7000  
 Telex: (650) 907-8292 Fax: (650) 907-8298

TITLE: DANFYSIK 866R SYSTEM SCHEMATIC  
 DRAWING NO.: AO 13908-0000-01 A  
 SHEET 1 OF 1

