



Qpets Remote Training System

User Manual

Model: SP 101

Please read this guide before using



Strap Length: 12 inches---20 inches



Thank you for choosing Qpets. Our mission is to make happy pet owners by providing quality pet products, the latest tools and techniques to successfully train your pet. If you have any questions or comments, please contact the our Customer Support Center at 1-909-923-8743 or visit our website at www.lavasat.com

Table of Contents

Components.....	2
Quick Start Guide.....	2
Step-1 Prepare the Remote Transmitter.....	2
Step-2 Pair transmitter with the collar receiver...3	3
Step-3 Install the electrodes for the receiver.....3	3
Step-4 Adjust the collar to fit your pet.....3	3
How to check the static shock function.....	4
How to use the transmitter	4
How to change the battery.....	4
How to re-set/re-pair receiver with transmitter.....	4
Important Tips.....	5
Customer Support Center.....	6



Thank you for choosing Qpets. Our mission is to make happy pet owners by providing quality pet products, the latest tools and techniques to successfully train your pet. If you have any questions or comments, please contact the our Customer Support Center at 1-909-923-8743 or visit our website at www.lavasat.com

Table of Contents

Components.....	2
Quick Start Guide.....	2
Step-1 Prepare the Remote Transmitter.....	2
Step-2 Pair transmitter with the collar receiver...3	3
Step-3 Install the electrodes for the receiver.....3	3
Step-4 Adjust the collar to fit your pet.....3	3
How to check the static shock function.....	4
How to use the transmitter	4
How to change the battery.....	4
How to re-set/re-pair receiver with transmitter.....	4
Important Tips.....	5
Customer Support Center.....	6



Customer Support Center

Tel: 1-909-923-8743

Monday – Friday 8:30AM – 5:00 PM Pacific Time

Email: smartpets@lavasat.com

Add: LAVA Electronics Inc. 2580 E Philadelphia ST #D, Ontario, CA 91761

This product has a limited Manufacturer Warranty. Details of the warranty can be found on www.lavasat.com or by calling our Customer Support Center.



Made in China











3. Use a paper clip to double click the tiny button which inside of the re-set hole on the Receiver, you can see it after you take the battery cover out from receiver. The LED indicated light which on the Receiver will start blinking.
4. Hold the Vibration Button (located in the middle of transmitter) until the receiver starts vibrating. The Red LED indicated light will stay on after pair the Receiver successfully with transmitter.

Important Tips: (Please Read)

1. The valid distance of remote control means the straight-line distance between the transmitter and the receiver without obstacles in between. If there are interference signals or signal screening around, the actual remote control distance may vary.
2. The lifetime of the batteries varies according to how often you use the product. Your first battery may not last as long as you expect.
3. This product is for pet training. Good effect can only be achieved after a period of training.
4. This product is a wireless transmitting device; you **MUST NOT** use the remote control system in places like petrol stations or hospitals where mobile phones are prohibited. Patients using heart pacemakers are forbidden to use this product.
5. The Electrodes have to directly touch pet's skin as it is very important to effective training.
6. This product is only for Pet Training, It is not a **Regular Pet Collar**. Please remove it from your pet at least 8 hours out of every 24 hours.
7. The Device does not design only for water resistant, not fully waterproof.
8. If you do not use the transmitter or Receiver, please take the battery out for saving battery life.











Components:			
1 x Transmitter with Antenna		1 x Receiver	
1 x 9V 6F22 Battery		1 x Adjustable strap	
1 x Pair of Rubber Electrodes and 1 x Metal Electrodes (for Receiver)		1 x Test Light (for testing Shock Function)	
2 x 6V 4LR44 Batteries (for each receiver)		1 x User Manual	

Quick start Guide

Step 1: Prepare the Remote Transmitter

1. Screw the antenna into place before using. Do not operate the remote trainer without a transmitter antenna.
2. Follow the Positive (+) and Negative (-) signs inside of transmitter. Insert the 9V 6F22 battery into the transmitter correctly.



Components:			
1 x Transmitter with Antenna		1 x Receiver	
1 x 9V 6F22 Battery		1 x Adjustable strap	
1 x Pair of Rubber Electrodes and 1 x Metal Electrodes (for Receiver)		1 x Test Light (for testing Shock Function)	
2 x 6V 4LR44 Batteries (for each receiver)		1 x User Manual	

Quick start Guide

Step 1: Prepare the Remote Transmitter

1. Screw the antenna into place before using. Do not operate the remote trainer without a transmitter antenna.
2. Follow the Positive (+) and Negative (-) signs inside of transmitter. Insert the 9V 6F22 battery into the transmitter correctly.



Step 2: Prepare the Collar Receiver

1. Follow the Positive (+) and Negative (-) signs inside of receiver. Insert the 1 x 6V 4LR44 Battery for Receiver.
2. The **Red Indicated Light** will stay on for 2 second and start blinking.
3. Press the **Vibration Button** (in the middle of the transmitter), the Receiver will vibrate.

Note:

- Please always install the transmitter's battery **BEFORE** install the battery of receiver. As it is a wireless training system. The transmitter has to be power on then the receivers are able to receive the code from transmitter.

Step 3: Install the Electrodes for the Receiver.

Randomly pick one pair of electrodes and screw for receiver. (Please pick the same size electrodes for the receiver.)

Step 4: Adjust the collar to fit your pet.

To ensure a proper fit, please follow the steps below:

1. Put the strap on the receiver.
2. With your pet standing, center of collar receiver where contact points are **underneath your pet's neck, touching the skin.**
3. The collar receiver should fit snugly, yet loose enough to allow one finger to fit between the strap and your pet's neck. If the strap is too long for your pet, cut off the excess length.
4. Allow your pet to wear the collar for several minutes and then re-check the fit. Check the fit again as your pet becomes more comfortable wearing the collar receiver.

We recommend you to use the vibration function first before starting the static shock and always start from the lowest level of static shock.



How to test the shock function

1. Use the **TEST LIGHT** attach on the both side of Electrodes (Metal).
2. Press Shock Button, the **TEST LIGHT** will blink or keeps on.



How to use the transmitter

- Press **Vibration Button** on the transmitter (located in the middle of the transmitter), the Orange and Red LED Indicated Light on the transmitter will stay on.
- **Button 1- 6** are Shock Button for the Receiver. (Decrease in static shock which the **1 Button is the strongest static shock**). The Orange Indicated Light will on when you press the Button 1-3, the Red Indicated Light will on when you press the Button 4-6.
- The receiver will get into the **SAVE MODE** if you do not use it for 2 minutes and there is no LED light on the receiver. Please **gently** shack it, it will be back to the **STANDBY MODE**.

How to change the battery

- Please replace the battery when there is no LED Indicated light on the transmitter when you press any button on the transmitter.
- Please replace the battery when there is no LED Indicated light on the Receiver.

How to re-set/re-pair Receiver with Transmitter

The Training System might stop working if the receiver lost the code with Transmitter. Please re-set/re-pair the receiver with transmitter.

1. Make sure the transmitter is power on
2. Put the battery into the receiver.



3. Use a paper clip to double click the tiny button which inside of the re-set hole on the Receiver, you can see it after you take the battery cover out from receiver. The LED indicated light which on the Receiver will start blinking.
4. Hold the Vibration Button (located in the middle of transmitter) until the receiver starts vibrating. The Red LED indicated light will stay on after pair the Receiver successfully with transmitter.

Important Tips: (Please Read)

1. The valid distance of remote control means the straight-line distance between the transmitter and the receiver without obstacles in between. If there are interference signals or signal screening around, the actual remote control distance may vary.
2. The lifetime of the batteries varies according to how often you use the product. Your first battery may not last as long as you expect.
3. This product is for pet training. Good effect can only be achieved after a period of training.
4. This product is a wireless transmitting device; you **MUST NOT** use the remote control system in places like petrol stations or hospitals where mobile phones are prohibited. Patients using heart pacemakers are forbidden to use this product.
5. The Electrodes have to directly touch pet's skin as it is very important to effective training.
6. This product is only for Pet Training, It is not a **Regular Pet Collar**. Please remove it from your pet at least 8 hours out of every 24 hours.
7. The Device does not design only for water resistant, not fully waterproof.
8. If you do not use the transmitter or Receiver, please take the battery out for saving battery life.



Customer Support Center

Tel: 1-909-923-8743

Monday – Friday 8:30AM – 5:00 PM Pacific Time

Email: smartpets@lavasat.com

Add: LAVA Electronics Inc. 2580 E Philadelphia ST #D, Ontario, CA 91761

This product has a limited Manufacturer Warranty. Details of the warranty can be found on www.lavasat.com or by calling our Customer Support Center.



Made in China



LAVA Electronics Inc
2580 E Philadelphia St #D
Ontario, CA 91761, USA
1-909-923-8743

www.lavasat.com

Email: qpets@lavasat.com

Copyright © LAVA Electronics Inc. 2010. All rights reserved.