

Appliance Documentation

SBSes 7273 from Index 20 PremiumPlus

comprising:

SKBes 4212 from Index 20 PremiumPlus

SGNes 3012 from Index 20 PremiumPlus

Side by Side combined
BioFresh refrigerator and NoFrost freezer
with dispensing unit through the door



Contents

1.0	Operating and control elements	4
2.0	Functions at a glance.....	5
3.0	Description of appliance.....	6
3.1	Sensor positions, schematic diagrams.....	7
3.1.1	SKBes 4212 filter, water tank and air flaps.....	7
3.1.2	SKBes 4212 fan, evaporator, sensors and heater.....	8
3.1.3	SGNes 3012 fan, sensors.....	9
3.1.4	SGNes 3012 feed screw, crusher.....	10
3.1.5	Water circuit.....	11
4.0	Main components and their functions.....	12
4.1	Electrical components and functions.....	12
4.1.1	General.....	12
4.1.2	SKBes refrigerator with BioFresh.....	12
4.1.3	SGNes NoFrost freezer.....	15
4.2	Refrigeration components and functions.....	18
4.2.1	SKBes refrigerator with BioFresh.....	18
4.2.2	SGNes Freezer.....	18
5.0	Assembly instructions / replacement of parts.....	19
5.1	General.....	19
5.1.1	Electronic control panel.....	19
5.1.2	Dispensing unit.....	20
5.1.3	Electronic power module.....	21
5.2	SKBes refrigerator with BioFresh.....	23
5.2.1	Top door hinge.....	23
5.2.2	Bottom door hinge.....	23
5.2.3	Bottom soft stop mechanism.....	24
5.2.4	Reed relay-door recognition.....	25
5.2.5	Magnet-door recognition.....	25
5.2.6	Horizontal separating plate.....	26
5.2.7	BioFresh control panel.....	26
5.2.8	Vertical separating plate.....	27
5.2.9	Fan.....	28
5.2.10	Water tank.....	28
5.2.11	Refrigerator compartment air sensor/air flap.....	29
5.2.12	BioFreshPlus and BioFresh air sensor/air flap.....	29
5.2.13	Evaporator sensor.....	30
5.2.14	Refrigerator compartment LED lighting.....	31
5.2.15	BioFresh LED lighting.....	32
5.2.16	BioFresh pull-out rails.....	33
5.3	SGNes freezer.....	34
5.3.1	Top door hinge.....	34
5.3.2	Bottom door hinge.....	35
5.3.3	Bottom soft stop mechanism.....	36
5.3.4	Reed relay-door recognition.....	37
5.3.5	Magnet-door recognition.....	37
5.3.6	LED interior light.....	38
5.3.7	Evaporator module.....	39
5.3.8	Evaporator sensor.....	40
5.3.9	Air sensor.....	40
5.3.10	Temperature fuse.....	41
5.3.11	Fan.....	41
5.3.12	IceMaker.....	42
5.3.13	Crusher module housing.....	44
5.3.14	Crusher module connection.....	45
5.3.15	Solenoid valves.....	46

6.0	Technical data	48
6.1	General	48
6.2	Refrigerator- BioFresh appliance	48
6.3	Freezer	49
7.0	Service menu	50
7.1	Brief survey of service menu	50
7.2	Manual defrosting	54
7.3	Demo mode	54
7.4	Panel test	55
7.5	Sensor test (display of temperature) and door contact test	56
7.5.1	Freezer compartment	56
7.5.2	IceMaker	57
7.5.3	Dispensing unit	58
7.5.4	Water intake	59
7.5.5	Refrigerator-BioFresh compartment	60
7.6	Service mode	61
7.6.1	Freezer compartment	61
7.6.2	IceMaker	62
7.6.3	Dispensing unit	63
7.6.4	Water intake	64
7.6.5	Refrigerator-BioFresh compartment	66
8.0	Error code, troubleshooting	67
8.1	Table of error codes	67
8.2	Troubleshooting VCC compressor / inverter	68
8.2.1	Checking the inverter and the frequency signal	68
8.2.2	Checking the compressor	69

1.0 Operating and control elements



Freezer compartment


- 1 **ON/OFF** ON/OFF button for appliance
- 2 **SuperFrost** SuperFrost function
- 3 **Alarm** Alarm OFF button for audible alarm
- 4 **Up** Setting button temperature higher
- 5 **Down** Setting button temperature lower

Refrigerator-BioFresh compartment

- 6 **Up** Setting button temperature higher
- 7 **Down** Setting button temperature lower
- 8 **SuperCool** SuperCool function
- 9 **Holiday** Holiday function, display indicates: Ho
- 10 **ON/OFF** ON/OFF button for refrigerator BioFresh compartment

Dispensing unit

- 11 **ON/OFF** ON/OFF button for dispensing unit
- 12 **Ice Cubes** Ice-cube dispensing function
- 13 **Crushed Ice** Crushed ice dispensing function
- 14 **Filter** Filter change display
- 15 **Child Lock** Child proofing
- 16 **Light** Illumination



BioFreshPlus

- 1 **0°C** button (normal BioFresh)
- 2 **Temperature display** BioFreshPlus
- 3 **-2°C** button (fish and seafood)
- 4 **6°C** button (tropical fruits)

2.0 Functions at a glance

Control:	Electronic	
Temperature display:	Refrigerator compartment: BioFreshPlus: Freezer compartment:	Actual value Set value Actual value
Temperature range:	Refrigerator compartment: BioFreshPlus: Freezer compartment:	+2°C to +9°C +6°C / 0°C / -2°C -14°C to -28°C
Temperature alarm:	Refrigerator compartment: BioFresh compartment: Freezer compartment:	Not present Not present Visual and audible
Door alarm:	Refrigerator compartment: Freezer compartment:	Audible Audible
Fan:	Refrigerator compartment: Freezer compartment:	Present Present
Defrosting:	Refrigerator compartment: Freezer compartment:	Automatic Automatic
Interior light:	Refrigerator compartment: BioFresh compartment: Freezer compartment:	Present Present Present
Service menu:	Present	
Compressor:	Refrigerator compartment: Freezer compartment:	Standard VCC
Solenoid valve refrigeration circuit:	Not present	

3.0 Description of appliance

The **SBSes 7273** is a Side by Side combined appliance consisting of a **SKBes 4212** and a **SGNes 3012**.

SKBes 4212:

Refrigerator compartment and BioFresh compartment are cooled by way of a common evaporator. The freely suspended evaporator is thermally sealed off by an insulated, vertical separating plate.

A DC fan is used for temperature balance between the refrigerator compartment, BioFreshPlus and BioFresh compartment. In conjunction with the air flap in each case, the fan provides for the supply of cold air needed. The fan is integrated in the vertical separating plate.

If the refrigerator, BioFreshPlus or BioFresh compartment needs cooling (detection by the respective air sensor), the fan is switched on and the associated air flap is opened. The fan takes in the warm air from the front and blows it down past the evaporator.

When it is sufficiently cold in one of the compartments, the respective air flap is closed. The compressor and the fan continue running only until such time as the other compartments have reached the switch-off value and the air flaps close.

This appliance has a water tank for the supply of cold water (11°C to 15°C) in the dispensing unit.

The **SKBes** does not have a control panel as it is controlled using the control panel in the dispensing unit of the **SGN**.

SGNes 3012:

The appliance has a lamellar evaporator with fan and integrated defrost heater. Two sensors, an air sensor and an evaporator sensor, see to the control and automatic defrosting. A safety temperature limiter protects the appliance against excessively high temperatures during the defrosting phase.

A dispensing unit integrated in the door supplies ice cubes, crushed ice and chilled water.

3.1 Sensor positions, schematic diagrams

3.1.1 SKBes 4212 filter, water tank and air flaps




Fig. 3.1.1 / 1

Fig. 3.1.1 / 2

3.1.2 SKBes 4212 fan, evaporator, sensors and heater




Fig. 3.1.2 / 1

Fig. 3.1.2 / 2

3.1.3 SGNes 3012 fan, sensors




Fig. 3.1.3 / 1

Interior light
Air sensor
Fan
Evaporator sensor




Fig. 3.1.3 / 2

3.1.4 SGNes 3012 feed screw, crusher




Fig. 3.1.4 / 1

IceMaker
Feed screw
Ice crusher knives




Fig. 3.1.4 / 2

3.1.5 Water circuit




Fig. 3.1.5 / 1

4.0 Main components and their functions

4.1 Electrical components and functions

4.1.1 General

Electronic control system	
Type:	Series 6 electronic control system
Components:	1x control panel 2x power module (1 power module per appliance)

4.1.2 SKBes refrigerator with BioFresh

Electronic control system (operation using SGNes)	
Setting range:	Refrigerator compartment: +2°C to +9°C BioFreshPlus: +6°C / 0°C / -2°C , U0 to U9 (U0: coldest setting) BioFresh compartment: b0 to b9 (b0: coldest setting; 0.8K per step)

Display range: 2°C to 49°C (actual value display)
temperatures equal to and lower than +2°C are displayed with 2°C.

Functions	
SuperCool:	ON: Refrigerator compartment sets itself to +2°C for 6 hours. BioFresh temperature remains unchanged.
	OFF: The refrigerator compartment sets itself to the set value.
Holiday	ON: Press button for 3 seconds. Refrigerator and BioFresh compartment sets itself to +15°C. Ho appears in the display.
	OFF: The refrigerator and BioFresh compartment sets itself to the set value.
	Info: Remove all food from the refrigerator and BioFresh compartment. This function prevents odour when the refrigerator compartment door is closed.
Defrosting:	Automatic during compressor standstill phase.

Door alarm:
When: If door is open, after 60 seconds.
Audible: 3 beeps.

Sensors	
Refrigerator compartment air sensor:	Position: Behind refrigerator compartment air flap cover. Function: - Compressor ON/OFF - Fan ON. (Condition: Evaporator sensor is 1K colder) - Refrigerator compartment air flap open/closed. - Generates the display value.
Evaporator sensor:	Position: In sensor pocket on the back of the evaporator. Function: - Fan ON enable. (During start-up from +8°C and colder; in operation from +4.8°C and colder) - Compressor ON enable (from +5°C and warmer). - Ends the defrosting phase (from +5°C and warmer).
BioFreshPlus air sensor:	Position: Behind BioFreshPlus air flap cover. Function: - Compressor ON/OFF - Fan ON.

(Condition: Evaporator sensor is 1K colder)
 - BioFreshPlus air flap open/closed.

BioFresh air sensor: Position: Behind BioFresh air flap cover.
 Function: - Compressor ON/OFF
 - Fan ON.
 (Condition: Evaporator sensor is 1K colder)
 - BioFresh air flap open/closed.

Ambient air sensor: Position: On the power PCB.
 Function: Affects the switch-off value of the BioFresh air sensor. Therefore temperature fluctuations in the BioFresh compartment are minimised.
 Info: An ambient air sensor error is displayed only in the service menu. In case of fault, the switch-off value of the BioFresh air sensor is not affected.
 In case of a defect the power PCB has to be replaced.

Switch

Door switch: Position: In front panel.
 Type: Reed PCB
 Contact type: Make contact
 Function: Activation via:
 Magnet in the door, magnet is replaceable.

Switching signal when:

door closed: interior light OFF
door open: fan OFF
 interior light ON
 door alarm ON after 60 seconds

Loads

Fan: Position: Centre of liner ceiling, behind vertical separating plate.
 Function:

Compressor	Door	Fan
OFF	CLOSE D	ON low speed
ON	CLOSE D	ON high speed
ON/OFF	Up	OFF
Evaporator sensor from +5°C and warmer	CLOSE D	OFF

e.g. if the refrigeration is OFF **and** the door is CLOSED and the evaporator sensor is colder than +5°C, **then** the fan is **ON, low speed**.

Control: Low speed 6 V/DC
 High speed 9 V/DC

During start-up the fan switches ON only from +8°C at the evaporator sensor.

BioFreshPlus heater: Position: Foamed-in, inside right and left, directly above the pull-out rail for BioFreshPlus.
 Function: Switches ON as soon as the BioFreshPlus air sensor has reached the switch-on value for the heater.

Refrigerator compartment interior light:	Position:	Inside right and left.
	Function:	- Shines as soon as the door is opened. - Is switched OFF after door has been open for 15 minutes.
BioFresh compartment interior light:	Position:	Inside left.
	Function:	- Shines as soon as the door is opened. - Is switched OFF after door has been open for 15 minutes.
Compressor:	Type:	Standard compressor
	Function:	<p>ON: Refrigerator compartment evaporator sensor switch-on value (equal to or warmer than +5°C) and refrigerator compartment, BioFreshPlus or BioFresh air sensor switch-on value <u>Note:</u> On-delay time (8 minutes) must have elapsed.</p> <p>OFF: Refrigerator compartment, BioFreshPlus and BioFresh-air sensor switch-off value.</p>

4.1.3 SGNes NoFrost freezer

Electronic control system

Setting range: -14°C to -28°C

Display range: 0°C to -49°C
Values outside the range are indicated by a cross bar

Functions

Temperature alarm:

Alarm value:	4K warmer than set value.
Warmest alarm value:	-10 °C
Coldest alarm value:	-20 °C
Delay:	20 minutes
Visual:	Flashing alarm LED
Audible:	4 beeps (suppressed during start-up)
During start-up: value is reached,	The temperature display flashes until the switch-off the audible alarm is switched OFF.

(e.g. given a set value of -18°C, a temperature of -14°C must be present for at least 20 minutes, then a temperature alarm is raised.)

When the defrosting phase begins, the temperature alarm is suppressed for 1.5 hrs.

Defrosting:

ON:	- During start-up after 3 hours cumulative compressor running time. - After a cumulative compressor running time of 10 to 60 hours maximum, depending on the number/duration of the door openings.
	When the defrosting phase begins, the compressor and the fan are switched OFF and the defrost heater is switched ON.
Duration:	The defrost heater remains switched ON until - the freezer compartment evaporator sensor has reached +22°C or - a max. defrosting time of 50 minutes has been reached.
Info:	After the end of the heating phase the compressor is switched ON with a 10-minute delay. Fan ON, from -25°C. If the SuperFrost function is activated during the defrosting phase, this will not interrupt defrosting.

Door alarm:

When:	If door is open, after 60 seconds.
Audible:	3 beeps.

SuperFrost:

ON:	Freezer compartment sets itself to -36 °C (quantity-controlled, min. 30 hrs., max. 65 hrs.)
	The appliance sets itself to -36°C for at least 30 hours. In the following 35 hours cooling by 8K to the set value must have been reached or a total time of 65 hours must have elapsed in order that SuperFrost is automatically ended.

OFF: The freezer compartment sets itself to the set value.

Note: If SuperFrost is actuated during a defrosting phase, the SuperFrost function is not performed before the defrosting phase has run.

Sensors

- Air sensor:** Position: Behind the front panel of the evaporator module.
 Function: - Switches the compressor ON/OFF.
 - Generates the display value.
- Evaporator sensor:** Position: Slipped into the lamellar evaporator.
 Function: - Switches the defrost heater OFF (ends the defrosting phase).
 - Switches the fan ON/OFF.

Switch

- Door switch:** Position: In door panel
 Type: Reed contact
 Contact type: Make contact
 Function: Activation via:
 Magnet in the front panel, magnet is replaceable.
- Switching signal when:**
- | | | |
|---------------------|----------------|---------------------|
| door closed: | interior light | OFF |
| door open: | interior light | ON |
| | fan | OFF |
| | door alarm | ON after 60 seconds |

Loads

- Fan:** Position: In the evaporator module, at the back centre.
 Function:

Evaporator sensor	Compressor	Door	Fan
Switch-on value	OFF	CLOSED	OFF
Switch-on value	ON	CLOSED	ON
Switch-on value	OFF/ON	UP	OFF
Switch-off value	OFF/ON	CLOSED/OPEN	OFF

e.g. If the evaporator sensor has reached the switch-on value for the fan **and** the compressor is ON **and** the door is CLOSED, **then** the fan is **ON**.

- Switch-on value evaporator sensor:
- During start-up: -25°C
 - In the normal mode 2K colder than air sensor

- Defrost heater:** Position: Clipped into lamellar evaporator
 Function: Keeps the evaporator free from ice. Activation via electronic control system.

Defrost heater ON:

- Depending on the number and duration of door openings, the electronic system calculates the defrost cycles between 10-60 hours cumulative compressor running time.
- Upon start-up after 3 hours cumulative compressor running time.

Defrost heater OFF:

- When the evaporator sensor has reached +22°C
- When max. time of 50 minutes is exceeded.

Heater cannot be replaced →only complete evaporator module!

Interior light: Position: In front panel
 Function: - Shines as soon as door is opened.
 - Is switched OFF after door has been open for 15 minutes.

Compressor: Type: VCC compressor, frequency-controlled.
 Function: **ON:** Air sensor switch-on value
 Note: On-delay time (8 minutes) must have elapsed.
OFF: Air sensor switch-off value.

VCC compressor, frequency-controlled.

- Compressor with 4 different speeds (1600 / 1900 / 3000 / 3600 rpm).
- The inverter electronic control is fitted directly on the compressor. The inverter electronic control controls the compressor with a pulse-width modulated square-wave voltage.
- For speed value input, the inverter electronic module receives a square wave frequency signal from the power PCB.
 This frequency signal is output with 56, 71, 87, 100 or 117 Hz, depending on the speed at which the compressor is to run.

Frequency in Hz	Speed in rpm	Operation
56	Compressor OFF	Compressor OFF
71	1600	Ideal case
87	1900	Control mode
100, 0 (signal interruption), other values than the defined frequencies	3000	Start-up, signal interruption, signal fault
117	3600	SuperFrost

- **Runtime longer than 70 minutes:**
 Speed increase by one step during compressor operation.
- **Runtime shorter than 40 minutes:**
 Speed reduction on next start-up.

For troubleshooting, see section 8.2 Troubleshooting VCC compressor / inverter

4.2 Refrigeration components and functions

4.2.1 SKBes refrigerator with BioFresh

Compressor	
Compressor:	Standard.
Evaporator	
Type:	Rear wall evaporator
Type of installation:	Suspended freely.
Injection point:	Top centre
Flow sequence:	Top to bottom

4.2.2 SGNes Freezer

Compressor	
Compressor:	VCC, frequency-controlled
Frame heater	
Position:	Foamed-in in the housing, in the contact area of the magnetic door seal.
Evaporator	
Type:	Lamellar evaporator
Type of installation:	In evaporator module on appliance ceiling
Injection point:	Front centre
Flow sequence:	Front to back

5.0 Assembly instructions / replacement of parts

5.1 General

5.1.1 Electronic control panel

- Front casing:
- Remove drip plate.
 - Detach the front housing from the door, starting at the bottom with the plastic frame.
 - Disconnect the bus connector and the connector to the dispensing unit (Fig. 5.1.1/ 4 and 5).



Fig. 5.1.1 / 1



Fig. 5.1.1 / 2



Fig. 5.1.1 / 3




Fig. 5.1.1 / 4



Fig. 5.1.1 / 5

5.1.2 Dispensing unit

- Undo fastening screws (Fig. 5.1.2/ 1).
- Release hose clip.
- Disconnect heater connector
(foamed-in heater in dispensing unit to prevent condensate).
- Draw dispensing unit forwards for removal (Fig. 5.1.2/ 2).




Fig. 5.1.2 / 1




Fig. 5.1.2/ 2 Dispensing unit connections




Fig. 5.1.2/ 3 Dispensing unit



Fig. 5.1.2 / 4

5.1.3 Electronic power module

Note: Pull out the mains plug!

- Electronic power module cover:**
- Disengage marked retaining clips.
 - Swing out the cover at the bottom and lift for removal.




Fig. 5.1.3 / 1

- Cable clip:**
- Disengage the cable clip (transparent plastic clip) at the marked location.




Fig. 5.1.3 / 2

- Detach front PCB edge connector
- Release strain relief of supply cable.
- Disengage plug-in module at the right and left clip.




Fig. 5.1.3 / 3

Plug-in module:

- Pull out the plug-in module forwards.
- Detach rear PCB edge connectors.




Fig. 5.1.3 / 4

Electronic power module:

- Disengage the locking hooks at the "holder for capacitors".
- Disengage electronic power module at the marked locations (Fig. 5.1.3/ 6).




Fig. 5.1.3 / 5




Fig. 5.1.3 / 6

5.2 SKBes refrigerator with BioFresh

5.2.1 Top door hinge

It is not possible for the hinges of this appliance to be changed over!

Turn hinge cover: Disengage the cover in the marked direction and raise it for removal (Fig. 5.2.1/ 1).

Turn hinge: Undo the marked screws and remove the turn hinge Fig. 5.2.1/ 2).



Fig. 5.2.1 / 1




Fig. 5.2.1 / 2

5.2.2 Bottom door hinge

Turn hinge cover locking device: Disengage the cover in the marked direction and draw it forwards for removal (Fig. 5.2.2/ 1).

Bearing pin: Retract the adjustable foot and press the bearing pin downwards. Then swing out the door at the bottom and draw it out of the upper bearing pin (Fig. 5.2.2/ 2). Notch has to point forwards for re-assembly.

Turn hinge: Undo the screws (Fig. 5.2.2/ 3) and remove the turn hinges.




Fig. 5.2.2/ 1 Turn hinge cover locking device




Fig. 5.2.2/ 2 Bearing pin




Fig. 5.2.2/ 3 Turn hinge

5.2.3 Bottom soft stop mechanism

Turn hinge cover: On the right-hand side, lever it forwards off the turn hinge (**Fig. 5.2.3/ 1**), push the hinge pin up and out (**Fig. 5.2.3/ 2**).




Fig. 5.2.3 / 1




Fig. 5.2.3 / 2

Cover Soft stop mechanism: Disengage cover of the soft stop mechanism at the marked locations (see **Fig. 5.2.3/ 3**).



Fig. 5.2.3 / 3

Soft stop unit: Undo the screws fastening the soft stop unit (see **Fig. 5.2.3/ 4**).



Fig. 5.2.3 / 4

Safety device soft stop unit: Fit the safety device for the soft stop unit. **Danger of crushing in the area indicated** (see **Fig. 5.2.3/ 5**).




Fig. 5.2.3 / 5

5.2.4 Reed relay-door recognition

- Reed relay:**
- Remove the cover of the front panel at the left and right.
 - Disengage and remove the front panel (**Fig. 5.2.4/ 1**).
 - Reed relay is clipped into place at the rear (**Fig. 5.2.4/ 2**).



Fig. 5.2.4 / 1




Fig. 5.2.4 / 2

5.2.5 Magnet-door recognition

- Magnet:**
- Slightly depress the locking lug of the magnet holder and lever the magnet holder out (**Fig. 5.2.5/ 2**).




Fig. 5.2.5/ 1 Door panel




Fig. 5.2.5/ 2 Magnet holder



Fig. 5.2.5/ 3 Magnet holder

5.2.6 Horizontal separating plate

- Remove BioFresh drawers and insulation plate of BioFreshPlus.
- Remove cable duct panel (see **Fig. 5.2.6/ 1**)
- Disconnect and detach cable.
- Undo fastening screws (see **Fig. 5.2.6/ 2**)
- Pull out the separating plate forwards.




Fig. 5.2.6 / 1




Fig. 5.2.6 / 2

5.2.7 BioFresh control panel

- Remove cable duct panel, disconnect cable.
- Disengage control panel at marked locking lugs.




Fig. 5.2.7 / 1

5.2.8 Vertical separating plate

- For disassembly of the horizontal separating plate (see **5.2.6 Horizontal separating plate**).
- Remove glass shelves.
- Using a screwdriver, disengage clips at the right and left at the marked location (**Fig. 5.2.8/ 1**) and press in the direction of the separating plate (**Fig. 5.2.8/ 2**). Remove clip.
- Undo screws (**Fig. 5.2.8/ 4**) fastening the separating plate.
- Disconnect fan cable (**Fig. 5.2.8/ 5**).




Fig. 5.2.8 / 1



Fig. 5.2.8 / 2



Fig. 5.2.8 / 3




Fig. 5.2.8 / 4




Fig. 5.2.8 / 5

During assembly pay attention that the locking lugs of the vertical separating plate are slipped into the grooves of the compartment liner for fixing the separating plate at the top.



Fig. 5.2.8 / 6




Fig. 5.2.8 / 7

5.2.9 Fan

- For disassembly of the horizontal separating plate (see **5.2.6 Horizontal separating plate**).
- For disassembly of the vertical separating plate (see **5.2.8 Vertical separating plate**).
- Undo the fastening screw of the water tank.
- Undo fan connector.
- Press up holding clips to unlock fan with rubber mount.




Fig. 5.2.9 / 1

5.2.10 Water tank

- For disassembly of the horizontal separating plate (see **5.2.6 Horizontal separating plate**).
- For disassembly of the vertical separating plate (see **5.2.8 Vertical separating plate**).
- Undo the fastening screws of the water tank.
- Undo the fastening screws of the filter holder.



Fig. 5.2.10 / 1




Fig. 5.2.10 / 2

5.2.11 Refrigerator compartment air sensor/air flap

- Disengage cover of the refrigerator compartment air flap and raise it (**Figs. 5.2.11/1 and 2**).
- Refrigerator compartment air sensor is attached to the BioFreshPlus PCB in the horizontal separating plate.
- The refrigerator compartment air flap is only slipped into place, it is not interlocked or screw-fitted.




Fig. 5.2.11 / 1




Fig. 5.2.11 / 2




Fig. 5.2.11 / 3

5.2.12 BioFreshPlus and BioFresh air sensor/air flap

- Disengage and remove cover of BioFresh air flaps (**Fig. 5.2.12/1**).
- BioFreshPlus and BioFresh air sensors are attached to the BioFreshPlus PCB in the horizontal separating plate.
- BioFresh air flaps are only slipped into place, they are not interlocked or screw-fitted.



Fig. 5.2.12 / 1




Fig. 5.2.12 / 2

5.2.13 Evaporator sensor

- For disassembly of the horizontal separating plate (see **5.2.6 Horizontal separating plate**).
- For disassembly of the vertical separating plate (see **5.2.8 Vertical separating plate**).
- Undo screws holding the evaporator.
- Draw the evaporator sensor out of the sensor pocket at the back of the evaporator (**Fig. 5.2.13/ 1**).




Fig. 5.2.13 / 1

5.2.14 Refrigerator compartment LED lighting

LED light column:

- Using a small screwdriver, turn the slot in the cap downwards.
- Insert a screwdriver in the slot and remove the cap.
- Undo screws of light column.




Fig. 5.2.14 / 1




Fig. 5.2.14 / 2

LED PCB:

- Unlock and pull off connector (Fig. 5.2.14/ 3).
- Unlock PCB and connector socket at the marked locations (Fig. 5.2.14/ 4).
- Lift PCB at an angle from the light cover.




Fig. 5.2.14 / 3



Fig. 5.2.14 / 4

INFO

One LED group comprising 3 LEDs is used for each illuminated support rib. If a single LED of an LED group is defective, the entire LED group is inoperative. All the other LEDs continue to shine.




Fig. 5.2.14 / 5

5.2.15 BioFresh LED lighting

- Disengage light unit (Fig. 5.2.15/ 2).
- Unlock and pull off connector (Fig. 5.2.15/ 3).
- Disengage and remove LED PCB (Fig. 5.2.15/ 4).



Fig. 5.2.15 / 1



Fig. 5.2.15 / 2



Fig. 5.2.15 / 3




Fig. 5.2.15 / 4

5.2.16 BioFresh pull-out rails

Pull-out rail:

- Press in lock and press rail to the rear (**Fig. 5.2.16 / 1**).
- Support is replaceable (**Fig. 5.2.16/ 3**).




Fig. 5.2.16 / 1



Fig. 5.2.16 / 2




Fig. 5.2.16 / 3

5.3 SGNes freezer

5.3.1 Top door hinge

It is not possible for the hinges of this appliance to be changed over!

Turn hinge cover: Disengage the cover in the marked direction and raise it for removal (**Fig. 5.3.1/ 1**).

Door turn hinge:

- Undo the marked screws (**Fig. 5.3.1/ 2**).
- Position the door turn hinge as illustrated (**Fig. 5.3.1/ 3**), so that the holes for the template are in a line.
- Fit the template, which safeguards against twisting of the cable (**Fig. 5.3.1/ 3**).
- Remove the top door panel and lever out the cable feedthrough using a screwdriver (**Fig. 5.3.1/ 4**)
- Disconnect the bus connector on the reed PCB (**Fig. 5.3.1/ 4**) and remove the turn hinge together with cable.




Fig. 5.3.1 / 1




Fig. 5.3.1 / 2




Fig. 5.3.1 / 3




Fig. 5.3.1 / 4



Fig. 5.3.1 / 5

5.3.2 Bottom door hinge

Turn hinge cover locking device:

Disengage the cover in the marked direction and draw it forwards for removal (Fig. 5.3.2/ 1).

Bearing pin:

Retract the adjustable foot and press the bearing pin downwards (Fig. 5.3.2/ 2). Notch has to point forwards for re-assembly.




Fig. 5.3.2/ 1 Turn hinge cover locking device




Fig. 5.3.2/ 2 Bearing pin

Bottom turn hinges:

Undo screws (Fig. 5.3.2/ 3).




Fig. 5.3.2/ 3 Turn hinge

5.3.3 Bottom soft stop mechanism

Turn hinge cover: On the right-hand side, lever it forwards off the turn hinge (Fig. 5.3.3/ 1). Push the pin up and out (Fig. 5.3.3/ 2).




Fig. 5.3.3 / 1




Fig. 5.3.3 / 2

Cover Soft stop mechanism: Disengage cover of the soft stop mechanism at the marked locations (see Fig. 5.3.3/ 3).



Fig. 5.3.3 / 3

Soft stop unit: Undo the screws fastening the soft stop unit (see Fig. 5.3.3/ 4).



Fig. 5.3.3 / 4

Safety device soft stop unit: Fit the safety device for the soft stop unit. **Danger of crushing in the area indicated** (see Fig. 5.3.3/ 5).




Fig. 5.3.3 / 5

5.3.4 Reed relay-door recognition

- Reed relay:**
- Disengage and remove the door panel (**Fig. 5.3.4/ 1**).
 - Reed relay is clipped into place at the rear (**Fig. 5.3.4/ 2**).




Fig. 5.3.4/ 1 Door panel



Fig. 5.3.4/ 2 Reed PCB

5.3.5 Magnet-door recognition

- Magnet:**
- Disengage the front panel (**Fig. 5.3.5/ 1**).
 - Unclip the magnet off the holder (**Fig. 5.3.5/ 2**).



Fig. 5.3.5/ 1 Front panel



Abb. 5.3.5/ 2 Inside the front panel

5.3.6 LED interior light

LED interior light: The interior light is behind the front panel and is directed downwards, towards the drawers.

- Unlock and pull off the connector (**Fig. 5.3.6/ 1**).
- Disengage the LED unit (**Fig. 5.3.6/ 2**).
- LED unit comprising LED with heat-sink and light cover (**Fig. 5.3.6/ 3**).




Fig. 5.3.6/ 1 Connector




Fig. 5.3.6/ 2 LED unit




Fig. 5.3.6 / 3

5.3.7 Evaporator module




Fig. 5.3.7/ 1 Evaporator module

Locking parts: Are snapped into place at the right and left for locking the evaporator module. Lever off by applying a screwdriver between the locking part and the compartment liner (Fig. 5.3.7/ 2).

Transit support: Remove the adhesive tape as transit support of the "top polystyrene moulding", it is no longer needed for assembly (Fig. 5.3.7/ 3).

Top polystyrene moulding: Lift off the polystyrene moulding first at the front, then at the back. Draw the "top polystyrene moulding" forwards for removal.




Fig. 5.3.7/ 2 Remove locking part



Fig. 5.3.7/ 3 Remove adhesive tape

5.3.8 Evaporator sensor

Evaporator module: Dismantle the evaporator module as described below under **5.3.7 Evaporator module**.

Evaporator sensor: Is slipped inbetween the lamellas and in case of defect it has to be cut off and repaired with the repair kit (Art. No. 9590 062).




Fig. 5.3.8/ 1 Evaporator module folded down

5.3.9 Air sensor

Evaporator module: Dismantle the evaporator module as described below under **5.3.7 Evaporator module**.

Front polystyrene moulding: Is situated behind the front panel of the evaporator module. Acts as an air seal of the air sensor in the direction of the lamellar evaporator.

Air sensor: Is engaged behind the front panel of the evaporator module and in case of defect it has to be cut off and repaired with the repair kit (Art. No. 9590 062).



Fig. 5.3.9/ 1 Removal of the polystyrene




Fig. 5.3.9/ 2 Air sensor

5.3.10 Temperature fuse

Evaporator module: Dismantle the evaporator module as described below under **5.3.7 Evaporator module**.

Temperature fuse: Fastened by screw (see **Fig. 5.3.8/ 1 Evaporator module lowered**).
To be noted for replacement:
- Cut off only at the coloured wires (not heater wire!)
- Fix the wires in such a way that they do not touch the heater.

5.3.11 Fan

Evaporator module: Dismantle the evaporator module as described below under **5.3.7 Evaporator module**.

Safety plate Lift out of the guide.

Fan: Safety plate is used for support in transit to prevent the fan from becoming detached.

Fan blade: Press the fan blade off the fan shaft using your thumbs.

Fan: Swing the fan out of the seat.
Take care: As the fan is swung out, the lower clip of the fan housing may get caught in the rubber mount and break.




Fig. 5.3.11/ 1 Safety plate, fan



Fig. 5.3.11/ 2 Dismantling fan blade

5.3.12 IceMaker

Ice storage container with crushing unit:

- Raise the ice storage container a little and remove it.
- The ice storage container composes a module together with the feed screw and crusher. Therefore these components are not singly available as spare parts.



Fig. 5.3.12 / 1




Fig. 5.3.12 / 2

Magnet holder:

- Clipped into the ice storage container, the reed contact is situated in the IceMaker. For recognition that the ice storage container is slid into place.




Fig. 5.3.12 / 3




Fig. 5.3.12 / 4

IceMaker:

- Disengage the locking lugs on the upper side of the housing of the crusher module (Fig. 5.3.12/ 6)
- Press the IceMaker backwards.
- Disconnect the connector.




Fig. 5.3.12 / 5




Fig. 5.3.12 / 6




Fig. 5.3.12 / 7



Fig. 5.3.12 / 8

5.3.13 Crusher module housing

- Press the left and right retaining clips of the crosspiece in the direction shown and release them (Figs. 5.3.13/ 1 to 3).
- Detach the housing from the support ribs by turning it a little (Fig. 5.3.13/ 4).
- Tip the housing forwards (Fig. 5.3.13/ 5)
- Disengage the crosspiece from the housing and push it out to the right (Fig. 5.3.13/ 5).




Fig. 5.3.13 / 1




Fig. 5.3.13/ 2 Right retaining clip




Fig. 5.3.13/ 3 Left retaining clip



Fig. 5.3.13 / 4




Fig. 5.3.13 / 5

5.3.14 Crusher module connection

- Using a screwdriver, disengage the cover at the marked locations and remove it (Fig. 5.3.14/ 1).
- Connections for the feed screw motor and for the magnet-operated switch of the ice flap are accessible (Fig. 5.3.14/ 3).



Fig. 5.3.14 / 1




Fig. 5.3.14 / 2




Fig. 5.3.14 / 3

5.3.15 Solenoid valves

Water connections: Press the elbow in the direction of the solenoid valve, keep the black outer ring depressed and detach the elbow (Fig. 5.3.15/ 1).

Solenoid valve group: Disengage it at the sides and press it downwards (Fig. 5.3.15/ 2).




Fig. 5.3.15 / 1




Fig. 5.3.15 / 2

Electrical connections:

- Detach the marked PCB edge connectors for control of the solenoid valves and attach the connectors to the cable slots in the unit carrier (Fig. 5.3.15/ 3). In this way the individual connectors cannot be inadvertently drawn under the unit carrier when pulling out the solenoid valve group.
- Detach connectors on the solenoid valve (Fig. 5.3.15/ 3).

Note: The connectors have to be inserted in such a way that the text "OBEN" (TOP) points upwards. (splash-proof)




Fig. 5.3.15 / 3




Fig. 5.3.15 / 4

Water connections at the rear:

Undo the screw fittings (**Fig. 5.3.15/ 5**).

Note: The hose will be entrained!
The hose has to be pretensioned in the opposite direction before screwing the parts together.




Fig. 5.3.15 / 5




Fig. 5.3.15 / 6

Seal of water connections:

The screw fittings are sealed with a paper washer (**Fig. 5.3.15/ 7**).

Since the screw action leaves a score (**Fig. 5.3.15/ 7**) in the washer, the washer has to be replaced once the screw fitting has been undone.

Note:
Replace washer (xxxx xxx) once the screw fitting has been undone!




Fig. 5.3.15 / 7



Fig. 5.3.15 / 8

6.0 Technical data

6.1 General

Sensor values:	Refrigerator compartment:	Air and evaporator sensor
	BioFreshPlus:	Air sensor
	BioFresh compartment:	Air sensor
	Freezer compartment:	Air and evaporator sensor

Temperature °C	Resistance value kOhm
+35	3.1
+30	3.8
+25	4.7
+20	5.9
+15	7.3
+10	9.3
+5	11.9
0	15.3
-5	19.8
-10	25.9
-15	34.1
-20	45.3
-25	60.8
-30	82.3
-35	112.8

6.2 Refrigerator- BioFresh appliance

Interior light: SKBes 4210	<u>Refrigerator compartment:</u>	
	Wattage:	approx. 3 watts
	Voltage:	approx. 13 volts/DC, with LED lighting connected. approx 13 volts/DC, with LED lighting disconnected
	Current:	350 mA
	<u>BioFresh compartment:</u>	
	Wattage:	approx. 1 watt
	Voltage:	approx. 13 volts/DC, with LED lighting connected. approx. 13 volts/DC, with LED lighting disconnected.
	Current:	350 mA

Fan:	Wattage:	1.6	watts
	Voltage:	12	volts/DC
			- 6V
			- 9V
	Speed:	2300	rpm
	Direction of rotation:	left (viewed from the front onto the fitted fan)	

BioFreshPlus heater:	Wattage:	7	watts
	Voltage:	230	volts/AC

Air flaps: Non-verifiable.

Water tank: Capacity: 0.75 litres

Water filter: Capacity: 0.25 litres
Filter change: 200 days

6.3 Freezer

Motor of feed screw/ crusher:	Wattage:	75 watts
	Voltage:	230 volts
Magnet-operated switch of ice flap:	Wattage:	60 watts
	Voltage:	230 volts
Heater dispensing chute:	Wattage:	2.6 watts
	Voltage:	13.3 volts
LED interior light:	Wattage:	2 watts
	Voltage:	230 volts
Fan:	Wattage:	1.9 watts
	Voltage:	230 volts
	Speed:	2100 rpm
	Direction of rotation:	right (as viewed onto shaft), left (as viewed in the direction of the evaporator module)
Defrost heater:	Wattage:	259 watts
	Voltage:	230 volts
Temperature fuse:	Tripping temperature:	93°C (Is faulty after tripping and has to be replaced)

7.0 Service menu

The service menu may be used by service technicians only.



Activation of service menu: Press "Up" + „ON/OFF" simultaneously for about 5 seconds (only with freezer buttons!)













If the service menu is activated, then "MENU" flashes in the display.

7.1 Brief survey of service menu








Service menu	Menu	Operation	Submenu	Operation	Selection of functional part
Manual defrosting	H	1x SF	H I	1x SF	R : Defrost heater ON
Demo mode	D	1x SF	D 0	1x SF	Demo mode ON ----- Demo mode OFF
Panel test	P	1x SF	P I	1x SF	Press sensor buttons, door sensor
Sensor test	E -	1x SF	Up or Down button E -	1x SF	Up/ Down button ↓/↑ Freezer compartment : Sensors IceMaker : Sensors Dispensing unit : Sensors Water intake : Sensors Refrigerator-BioFresh compartment : Sensors
Service mode	E -	1x SF	Up or Down button E -	1x SF	Up/ Down button ↓/↑ Freezer compartment : Electric loads IceMaker : Electric loads Dispensing unit : Electric loads Water intake : Electric loads Refrigerator-BioFresh compartment : Electric loads

Service menu	Menu	Operation	Sub-menu	Operation	Selection of functional part	
Sensor test	E -	1x SF	Up or Down button	E0	1x SF	Up/Down button ↓/↑ 103 104 10A Freezer compartment : Air sensor : Evaporator sensor : Door contact
				E1	1x SF	Up/Down button ↓/↑ 101 10A IceMaker : Sensor ice-cube tray : Contact IceMaker drawer
				E0	1x SF	Up/Down button ↓/↑ 00A 00B 00C Dispensing unit : Left pedal : Right pedal : Ice flap dispensing unit
				E0	1x SF	Up/Down button ↓/↑ 00A Water intake : Double solenoid valve, main valve
				E1	1x SF	Up/Down button ↓/↑ 101 102 103 104 10A Refrigerator-BioFresh compartment : Air sensor : Evaporator sensor : BioFresh air sensor : BioFreshPlus air sensor : Ambient air sensor : Door contact















Service menu	Menu	Operation	Submenu	Operation	Selection of functional part
Service menu	L	1x SF	L0	1x SF	<p>Freezer compartment</p> <p>L0 : All OFF L1 : Compressor ON, low speed L2 : Compressor ON, high speed L3 : Fan ON L4 : Defrost heater ON L5 : Light ON</p>
				1x SF	<p>IceMaker</p> <p>L0 : All OFF L2 : All OFF Press SuperFrost L2 - : - Ice-cube tray moves to emptying position and back. - 3 seconds activation water intake valve. Press ON/OFF button on IceMaker. L3 : All OFF Press SuperFrost L3 - : - Ice-cube tray moves to emptying position. - 25 seconds activation water intake valve.</p>
				1x SF	<p>Dispensing unit</p> <p>L0 : All OFF L1 : IceCrusher flap Open L2 : Dispensing unit ice flap Open/Closed L3 : Heater dispensing chute L4 : Light left pedal ON L5 : Light right pedal ON L6 : Light dispensing unit ON L7 : Button LEDs</p>
				1x SF	<p>Water intake</p> <p>L0 : All OFF L1 : All OFF Press SuperFrost L2 : Double solenoid valve, main valve : All OFF Press SuperFrost L3 : Solenoid valve IceMaker : All OFF Press SuperFrost L3 : Solenoid valve dispensing unit : Not assigned</p>

				1x SF	Up/ Down button ↓/↑	<p><u>Refrigerator-BioFresh compartment</u></p> <ul style="list-style-type: none">  0 : All OFF  1 : Compressor ON  5 : Light ON  7 : Fan, low speed  8 : Fan, high speed  9 : BioFreshPlus heater ON  h : Refrigerator compartment air flap Open  l : Refrigerator compartment air flap Closed  n : BioFreshPlus air flap Open  o : BioFreshPlus air flap Closed  p : BioFresh air flap Open
--	--	--	---	-------	------------------------------	---

7.2 Manual defrosting







Step	Display	Operation	Display following operation	Testing option / Info
Start service menu --Manual defrosting--				SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	 flashes	Service menu active, Manual defrosting selected
2	 flashes	Press "SF" once	  Static	Manual defrosting ON selected
3	  Static	Press "SF" once	 Static	Manual defrosting ON activated
Manual defrosting is ended by: <ul style="list-style-type: none"> - Switching appliance ON/OFF - Automatic after the defrost parameters are reached 				

7.3 Demo mode

Step	Display	Operation	Display following operation	Testing option / Info
Start service menu -- Demo mode ON --				SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	 flashes	Service menu active
2	 flashes	Press "Up" once	 flashes	Demo mode selected
3	 flashes	Press "SF" once	  Static	Demo mode ON selected
4	  Static	Press "SF" once	Set value and " Demo "	Demo mode ON
Start service menu -- Demo mode OFF--				SF = SuperFrost
1	Actual value and " Demo "	Press "Up" and "ON/OFF" simultaneously for 5 seconds	 flashes and " Demo "	Service menu active
2	 flashes and " Demo "	Press "SF" once	  static and " Demo "	Demo mode OFF selected
3	  static and " Demo "	Press "SF" once	Actual value	Demo mode OFF
<p>The text "Demo" in the display informs of the activated demo mode.</p> <p>Demo mode can be deactivated only via service menu, not by OFF/ON or disconnection from the supply.</p> <p>Operation switches to the mode wanted, demo mode or normal mode, as soon as "SuperFrost" has been actuated.</p>				

7.4 Panel test



Step	Display	Operation	Display following operation	Testing option / Info
Service menu start				SC = SuperCool
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	 flashes	Service menu active
Panel test -- test of sensor buttons, display elements, door sensor and beep --				
2	 flashes	Press "Up" once	 flashes	Panel test selected
3	 flashes	Press "SC" once	 Static	Panel test activated
4	 Static	Press "SC" once	All symbols/segments	Display elements/ More symbols are displayed than the respective electronic control system uses!
5	All symbols/segments	Door closed/open and press all buttons one after the other (each operation is confirmed by beep)	- Beep for 2 seconds - Appliance switches OFF → display dark	After the last button has been pressed, a beep sounds for 2 seconds, provided the test was successful.
End	Panel test cannot be ended in step 2, for example, it has to be performed in full. Should a button/reed contact be defective, no 2-second beep sounds and the appliance does not switch OFF . The appliance then has to be unplugged and plugged back in again.			

7.5 Sensor test (display of temperature) and door contact test



































7.5.1 Freezer compartment



Step	Display	Operation	Display following operation	Testing option / Info
Service menu start				SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	H flashes	Service menu active
Sensor test and door contact test (sensor values without offset, appliance in control mode)				
2	H flashes	Press "Up" three times	E- flashes	Sensor test mode selected
3	E- flashes	Press "SF" once	E8 Static	Sensor test mode Freezer compartment selected
6 → 4	E8 Static	Press "SF" once	83 flashes alternately with sensor temperature	Sensor test mode Freezer compartment activated Freezer compartment air sensor
5	83 flashes alternately with sensor temperature	Press "Up" once	84 flashes alternately with sensor temperature	Freezer compartment evaporator sensor
4 ← 6	84 flashes alternately with sensor temperature	Press "Up" once	8A flashes alternately with oP or cL	Freezer compartment door contact (oP =door open, cL =door closed)
End	Press "ON/OFF" once: Return to level 2 E1 . Points: E1, E-, E0, E^, E, selectable Press "ON/OFF" twice: Return to level 1 E- . Points: d, P, E-, L selectable Press "ON/OFF" three times: Return to normal/control mode			

































7.5.3 Dispensing unit

Step	Display	Operation	Display following operation	Testing option / Info
Service menu start				SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	 flashes	Service menu active
Sensor test and door contact test (sensor values without offset, appliance in control mode)				
2	 flashes	Press "Up" three times	 flashes	Sensor test mode selected
3	 flashes	Press "SF" once	 Static	Sensor test mode Freezer compartment selected
4	 Static	Press "Up" twice	 Static	Sensor test mode Dispensing unit selected
7 → 5	 Static	Press "SF" once	 flashes alternately with  or 	Sensor test mode Dispensing unit activated Left pedal (cL = actuated)
6	 flashes alternately with  or 	Press "Up" once	 flashes alternately with  or 	Right pedal (cL = actuated)
5 ← 7	 flashes alternately with sensor temperature	Press "Up" once	 flashes alternately with  or 	Ice flap dispensing unit (oP=ice flap closed, cL=ice flap open) <i>Only when dispensing unit ON and left pedal is actuated!</i>
End	Press "ON/OFF" once: Return to level 2  . Points:  ,  ,  ,  ,  selectable Press "ON/OFF" twice: Return to level 1  . Points:  ,  ,  ,  selectable Press "ON/OFF" three times: Return to normal/control mode			

7.5.4 Water intake **E0**

Step	Display	Operation	Display following operation	Testing option / Info
Service menu start				SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	H flashes	Service menu active
Sensor test and door contact test (sensor values without offset, appliance in control mode)				
2	H flashes	Press "Up" three times	E- flashes	Sensor test mode selected
3	E- flashes	Press "SF" once	E0 Static	Sensor test mode Freezer compartment selected
4	E0 Static	Press "Up" three times	E0 Static	Sensor test mode Water intake selected
5	E0 Static	Press "SF" once	oP flashes alternately with cL	Sensor test mode Water intake activated Double solenoid valve, main valve (oP = open, cL = closed)
End	Press "ON/OFF" once: Return to level 2 E0 . Points: E1, E2, E0, E0, E1 selectable Press "ON/OFF" twice: Return to level 1 E- . Points: d, p, E-, L selectable Press "ON/OFF" three times: Return to normal/control mode			

7.5.5 Refrigerator-BioFresh compartment

Step	Display	Operation	Display following operation	Testing option / Info
Service menu start				SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	 flashes	Service menu active
Sensor test and door contact test (sensor values without offset, appliance in control mode)				
2	 flashes	Press "Up" three times	 flashes	Sensor test mode selected
3	 flashes	Press "SF" once	 Static	Sensor test mode Freezer compartment selected
9 → 4	 Static	Press "Up" four times	 Static	Sensor test mode Refrigerator-BioFresh compartment selected
10 → 5	 Static	Press "SF" once	 flashes alternately with sensor temperature	Refrigerator compartment air sensor
6	 flashes alternately with sensor temperature	Press "Up" once	 flashes alternately with sensor temperature	Refrigerator compartment evaporator sensor
7	 flashes alternately with sensor temperature	Press "Up" once	 flashes alternately with sensor temperature	BioFresh air sensor
8	 flashes alternately with sensor temperature	Press "Up" once	 flashes alternately with sensor temperature	BioFreshPlus air sensor
9	 flashes alternately with sensor temperature	Press "Up" once	 flashes alternately with sensor temperature	Ambient air sensor
5 ← 10	 flashes alternately with sensor temperature	Press "Up" once	 flashes alternately with  or 	Refrigerator compartment door contact (oP=door open, cL=door closed)
End	Press "ON/OFF" once: Return to level 2  . Points:  ,  ,  ,  ,  selectable Press "ON/OFF" twice: Return to level 1  . Points:  ,  ,  ,  selectable Press "ON/OFF" three times: Return to normal/control mode			

7.6 Service mode



7.6.1 Freezer compartment



Step	Display	Operation	Display following operation	Testing option / Info	
Service menu start					SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	H flashes	Service menu active	
Service mode -- testing electric loads--					Power input 1)
2	H flashes	Press "Up" four times	L flashes	Service mode selected	
3	L flashes	Press "SF" once	L9 Static	Service mode Freezer compartment activated	
9 → 4	L9 Static	Press "SF" once	80 Static	All OFF	--
5	80 Static	Press "Up" once	81 Static	- Freezer compartment compressor ON, low speed	--
6	81 Static	Press "Up" once	82 Static	- Freezer compartment compressor ON, high speed	--
7	82 Static	Press "Up" once	83 Static	Freezer compartment fan ON	1.9 watts
8	83 Static	Press "Up" once	84 Static	Freezer compartment defrost heater ON	259 watts
4 ← 9	84 Static	Press "Up" once	85 Static	Freezer compartment light ON	2 watts
End	Press "ON/OFF" once: Return to level 2 : L' Items: L', L', L', L', L' selectable. Press "ON/OFF" twice: Return to normal/control mode				

1) Power input = power input of the load in the respective test step!






























7.6.2 IceMaker



Step	Display	Operation	Display following operation	Testing option / Info	
Service menu start				SF = SuperFrost	
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	H flashes	Service menu active	
Service mode -- testing electric loads--				Power input 1)	
2	H flashes	Press "Up" four times	U flashes	Service mode selected	
3	U flashes	Press "SF" once	U8 Static	Service mode Freezer compartment selected	
4	U8 flashes	Press "Up" once	U8 Static	Service mode IceMaker activated	
11 → 5	U8 Static	Press "SF" once	00 Static	All OFF	--
6	00 Static	Press "Up" once	02 flashes alternately with -0	All OFF	--
7	02 flashes alternately with -0	Press "SF" once	02 flashes alternately with -1	- Ice-cube tray emptied, back to home position - 3 seconds activation water intake valve	3 watts
8	02 flashes alternately with -1	IceMaker Press ON/OFF button	02 flashes alternately with -0	All OFF	--
9	02 flashes alternately with -0	Press "Up" once	03 flashes alternately with -0	All OFF	--
10	03 flashes alternately with -0	Press "SF" once	03 flashes alternately with -1 → -0	- Ice-cube tray emptied - 25 seconds activation water intake valve After 25 seconds have elapsed, 03 again flashes alternately with -0	3 watts
5 ← 11	03 flashes alternately with -0	- Press IceMaker ON/OFF button (→ switch ON) - Close drawer	03 flashes alternately with -0	Ice-cube tray returns to home position	--
End	Press "ON/OFF" once: Return to level 2 : U8 Items: U, U, U0, U1, U1 selectable. Press "ON/OFF" twice: Return to normal/control mode				

1) Power input = power input of the load in the respective test step!

7.6.3 Dispensing unit 







Step	Display	Operation	Display following operation	Testing option / Info	
Service menu start				SF = SuperFrost	
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	 flashes	Service menu active	
Service mode -- testing electric loads--				Power input 1)	
2	 flashes	Press "Up" four times	 flashes	Service mode selected	
3	 flashes	Press "SF" once	 Static	Service mode Freezer compartment selected	
4	 Static	Press "Up" twice	 Static	Service mode Dispensing unit activated	
9 → 4	 Static	Press "SF" once	 Static	All OFF	--
5	 Static	Press "Up" once	 Static	IceCrusher flap open/closed	--
6	 Static	Press "Up" once	 Static	Dispensing unit ice flap open/closed	--
7	 Static	Press "Up" once	 Static	Heater dispensing chute	2.6 watts
8	 Static	Press "Up" once	 Static	Light left pedal ON	--
4 ← 9	 Static	Press "Up" once	 Static	Light right pedal ON	--
4 ← 9	 Static	Press "Up" once	 Static	Light dispensing unit ON	--
4 ← 9	 Static	Press "Up" once	 Static	Button LEDs dispensing unit	--
End	Press "ON/OFF" once: Return to level 2  Items:  ,  ,  ,  ,  selectable. Press "ON/OFF" twice: Return to normal/control mode				

1) Power input = power input of the load in the respective test step!

7.6.4 Water intake



Step	Display	Operation	Display following operation	Testing option / Info	
Service menu start				SF = SuperFrost	
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	H flashes	Service menu active	
Service mode -- testing electric loads--				Power input 1)	
2	H flashes	Press "Up" four times	0 flashes	Service mode selected	
3	0 flashes	Press "SF" once	00 Static	Service mode Freezer compartment selected	
4	00 flashes	Press "Up" three times	00 Static	Service mode Water intake activated	
12 → 5	00 Static	Press "SF" once	00 Static	All OFF	--
6	00 Static	Press "Up" once	01 flashes alternately with -0	All OFF	--
7	01 flashes alternately with -0	Press "SF" once	01 flashes alternately with -1	Double solenoid valve, main valve	--
8	01 flashes alternately with -0	Press "Up" once	02 flashes alternately with -0	All OFF	--
9	02 flashes alternately with -0	Press "SF" once	02 flashes alternately with -1	Solenoid valve, IceMaker	--
10	02 flashes alternately with -0	Press "Up" once	03 flashes alternately with -0	All OFF	--
11	03 flashes alternately with -0	Press "SF" once	03 flashes alternately with -1	Solenoid valve dispensing unit	--
5 ← 12	03 flashes alternately with -0	Press "Up" once	04 Static	Not assigned	--

End	Press " ON/OFF " once: Return to level 2 :  Items:  ,  ,  ,  ,  selectable. Press " ON/OFF " twice: Return to normal/control mode
------------	---

1) Power input = power input of the load in the respective test step!

7.6.5 Refrigerator-BioFresh compartment

Step	Display	Operation	Display following operation	Testing option / Info	
Service menu start					SF = SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	H flashes	Service menu active	
Service mode -- testing electric loads--					Power input 1)
2	H flashes	Press "Up" four times	L flashes	Service mode selected	
3	L flashes	Press "SF" once	LF Static	Service mode Freezer compartment selected	
4	LF Static	Press "SF" once	LI Static	Service mode Refrigerator-BioFresh compartment activated	
9 → 4	LI Static	Press "SF" once	LO Static	All OFF	--
5	LO Static	Press "Up" once	LI Static	Compressor ON	--
6	LI Static	Press "Up" once	LS Static	Light ON	4 watts
7	LS Static	Press "Up" once	LT Static	Fan, low speed	1.6 watts
8	LT Static	Press "Up" once	LU Static	Fan, high speed	--
8	LU Static	Press "Up" once	LD Static	BioFreshPlus heater ON	7 watts
8	LD Static	Press "Up" once	LH Static	Refrigerator compartment air flap open	--
8	LH Static	Press "Up" once	LL Static	- Refrigerator compartment air flap closed - BioFreshPlus air flap open	--
4 ← 9	LL Static	Press "Up" once	LH Static	- BioFreshPlus air flap closed - BioFresh air flap open	--
End	Press "ON/OFF" once: Return to level 2 LL Items: L, LF, LO, LN, LI selectable. Press "ON/OFF" twice: Return to normal/control mode				

1) Power input = power input of the load in the respective test step!


8.0 Error code, troubleshooting

8.1 Table of error codes

Error code	Defective component	Emergency mode
F0	BioFresh air sensor	Compressor 10 minutes ON and 40 minutes OFF.
F1	Refrigerator compartment air sensor	Compressor 10 minutes ON and 40 minutes OFF.
F2	Refrigerator compartment evaporator sensor	Compressor 10 minutes ON and 40 minutes OFF.
F3	Freezer compartment air sensor	Compressor continuous operation
F4	Freezer compartment evaporator sensor	Compressor continuous operation
F6	BioFreshPlus air sensor	Compressor 10 minutes ON and 40 minutes OFF.
F7	Ambient air sensor	Ambient temperature of +25°C is preset Sensor error can be queried only in the service menu under the sensor test step "E".
nC (not Connected)	<ul style="list-style-type: none"> - SKBes not connected to mains. - Connecting module not connected. - Bus connector on SKBes power PCB, no contact. - Bus connector on SKBes horizontal separating plate, no contact. 	--

8.2 Troubleshooting VCC compressor / inverter

8.2.1 Checking the inverter and the frequency signal



Attention: In case of interruption of the frequency signal, the compressor starts only after 90 seconds!!

8.2.2 Checking the compressor

Fault profile: Compressor does not run (not even after a waiting time of 90 secs)

Select step 5 (low speed) or step 6 (high speed) in the service menu under "7.6.1 Service mode Freezer compartment". If the compressor now starts there was probably an operator error. Otherwise proceed as described below.
 At the inverter, line voltage (230V) must be applied between N and 1/C.

