Frigidaire

Use & Care Manual

# Freezer



| Product Registration2            |  |  |
|----------------------------------|--|--|
| Energy Saving Ideas 2            |  |  |
| Important Safety Instructions2-3 |  |  |
| First Steps                      |  |  |
| Setting the Temperature Control  |  |  |
|                                  |  |  |
| Freezer Optional Features 4 - 6  |  |  |
| Care and Cleaning7 - 8           |  |  |
| Power Failure/Freezer Failure8   |  |  |
| Avoid Service Checklist9 - 10    |  |  |
| Warranty11                       |  |  |



#### A WARNING Electrical Information

These guidelines must be followed to ensure that safety mechanisms in the design of this freezer will operate properly.



- Refer to the serial plate for correct electrical rating. The power cord of the freezer is equipped with a three-prong grounding plug for protection against shock hazards. It must be plugged directly into its own properly grounded three-prong receptacle, protected with a 15 amp time delay fuse or circuit breaker. The receptacle must be installed in accordance with the local codes and ordinances. Consult a qualified electrician. Receptacles with Ground Fault Circuit Interrupters (GFCI) are NOT RECOMMENDED. DO NOT USE AN EXTENSION CORD OR AN ADAPTER PLUG.
- If the voltage varies by 10 percent or more, freezer performance may be affected. Operating the freezer with insufficient power can damage the motor. Such damage is not covered under the warranty. If you suspect your voltage is high or low, consult your power company for testing.
- To prevent the freezer from being turned off accidentally, do not plug the unit into an outlet controlled by a wall switch or pull cord.
- Do not pinch, knot, or bend the power cord in any manner.

#### WARNING

- **Other Precautions** • To defrost, always unplug unit first.
- Never unplug the freezer by pulling on the power cord. Always grip the plug firmly and pull straight out from the receptacle.
- Turning the control to "OFF" turns off the compressor but does not disconnect power to other electrical components.

#### First Steps

Before starting the freezer, follow these important first steps.

#### Installation / Freezer Placement

- Choose a place that is near a grounded electrical outlet.
- The freezer should be located where surrounding temperature will not exceed 110°F (43°C). Temperatures of 32°F (0°C) and below will NOT affect freezer operation. Additional compressor heaters are not recommended.
- Allow space around the unit for good air circulation. Leave a 3 inch (75mm) space on all sides of the freezer for adequate circulation.



#### Leveling

The freezer must have all bottom corners resting firmly on a solid floor. The floor must be strong enough to support a fully loaded freezer. It is VERY IMPORTANT for your freezer to be level in order to function properly. If the freezer is not leveled during installation, the door/lid may be misaligned and not close or seal properly, causing cooling, frost or moisture problems.

#### To level Upright Units:

After discarding crating screws and wood base, use a carpenter's level to level the freezer from front to back. Adjust the plastic leveling feet in front, 1/2 bubble higher, so that the door closes easily when left halfway open.

#### **To level Chest Units:**

If needed, add metal or wood shims between feet pads and floor.



#### **Door Removal (Upright Models)**

- Unplug the unit
- Gently lay freezer on its back, on a rug or blanket.
- Remove two base screws and base panel. Remove wire from clips on bottom of cabinet, if required.
- Unplug connector, if required, by holding the cabinet connector in place and pulling the door connector out.
- Remove the bottom hinge screws.
- Remove the plastic top hinge cover.
- Remove the screws from the top hinge.
- Remove the top hinge from the cabinet.
- Remove the door and bottom hinge from the cabinet.
- To replace door, reverse the above procedures and securely tighten all screws to prevent hinge slippage.



#### Lid Removal (Chest Models)

• See lid removal instructions on the back of the cabinet.

#### Setting the Temperature Control

#### **Cool Down Period**

- For safe food storage, allow four (4) hours for freezer to cool down completely. The freezer will run continuously for the first several hours. Foods that are already frozen may be placed in the freezer after the first few hours of operation. Unfrozen foods should **NOT** be loaded into the freezer until freezer has operated for four (4) hours.
- When loading freezer, freeze only three (3) pounds of fresh food per cubic foot of freezer space at one time. Distribute packages to be frozen evenly throughout the freezer. It is not necessary to turn the control knob to a colder setting while freezing food.

## Electromechanical Temperature Control (Chest and Some Upright Models)

The electromechanical temperature control is located inside the freezer on upright models, and on the left exterior wall on chest models (see figure 1). The temperature is factory preset to provide satisfactory food storage temperatures. However, the temperature control is adjustable to provide a range of temperatures for your personal satisfaction. To adjust the temperature setting, turn the temperature control knob clockwise or counter clockwise. Allow several hours for the temperature to stabilize between adjustments.



## Standard Electronic Temperature Control (Some Upright Frost Free Models)

The standard electronic temperature control is located inside the freezer on upright models (see Figure 2). Temperature is factory preset to provide satisfactory food storage temperatures. To adjust the temperature setting, move the UP ( $\blacktriangle$ ) button for warmer temperature and DOWN ( $\heartsuit$ ) button for colder temperature on the control panel. Allow several hours for the temperature to stabilize between adjustments.



Standard Electronic Temperature Control Figure 2

### Deluxe Electronic Temperature Control (Some Upright Frost Free Models)

Refer to the Electronics Control Guide supplied when you purchase a deluxe electronic upright model. See Figure 3 for deluxe electronics control panel.



Deluxe Electronic Temperature Contro Figure 3

#### **Freezer Optional Features**

Your freezer may have some or all of the features listed below. Become familiar with these features and their use and care.

#### **Power On Light**

The power on light indicates that the freezer is properly connected to an electrical power. The light glows even when the temperature control is turned to "OFF". If the light goes out, refer to "Freezer does not run" in the Avoid Service Checklist section.

#### Electromechanical Temperature Alarm (Audible Only or Slide-Out Basket (Some Upright Models) Audible with Warning Light)

This feature is designed to provide a warning of a possible malfunction. If the temperature of the food rises to a level unsafe for long-term storage, the buzzer will sound. The red light, if equipped, will also glow. The Temp Alarm feature operates on household electricity. If power fails, the alarm will not function. An ON/OFF switch allows you to deactivate the Temp Alarm when not wanted. The freezer is shipped with the Temp Alarm in the "OFF" position (if equipped). After the freezer has run approximately four (4) hours, the red light, if equipped, will go off. Then you may activate the Temp Alarm without the alarm sounding.

Press the "ON" switch to activate the Temp Alarm feature. To deactivate, press the "OFF" switch.

If the alarm sounds, be sure freezer is properly leveled, and the door/lid closes freely and seals properly. If you suspect a technical malfunction, call an authorized service personnel immediately.

#### **Electronic Temperature Alarm (Some Electronic Chest** Models)

This feature is designed to provide a warning if the inside temperature reaches an unsafe level. The Temp Alarm feature operates on household electricity. It will not function if household electricity is interrupted.

When the freezer is initially plugged in, the red Temp Alarm indicator light blinks. The indicator light will continue to blink until the freezer has reached a safe freezing temperature. If a malfunction causes an unsafe temperature inside the freezer, the red light will blink and the buzzer will sound. To silence the buzzer, press the ALARM OFF button. The indicator light will continue to blink until a safe freezing temperature is again reached. If the problem is not solved within twelve (12) hours, the buzzer will turn on again. If the ALARM OFF button is not pressed, the buzzer will turn itself off automatically after 48 hours, but the red Temp Alarm light will continue to blink.



#### **Electronic Temperature Alarm (Some Electronic** Upright Models)

Refer to the Electronics Control Guide supplied when you purchase a deluxe electronic upright model.



The slide-out basket, located at the bottom of the freezer provides separate storage space for items that are difficult to store on freezer shelves. To remove the basket, pull out and lift up.

#### Security Lock with Pop-out Key

This security lock fastens the door/lid snugly, ensuring that stored food is secure. To lock or unlock the freezer, push the key into the lock and turn. The key pops out of the lock after it has been turned.

#### Interior Light

The light comes on automatically when the door/lid is opened. To replace the light bulb, turn the temperature control to "OFF" and unplug the electrical cord. Replace the old bulb with a bulb of the same type and wattage.

#### Adjustable Shelf (Some Upright Models)

This shelf can be moved to one of two positions. Lift the shelf up and out to move to the desired position.

#### Slide-Aside Basket (Chest Models)

This basket helps organize odd-shaped items. To reach other packages in the freezer, slide the basket aside or lift out.



Slide-Aside Basket

#### Fast Freezing Shelves (Manual Defrost Upright Models)

These shelves contain cooling coils to freeze foods quickly and allow cold air to constantly circulate throughout the freezer. Do not use sharp metal objects such as ice picks or scrapers to clean the shelves. This could damage the shelves and reduce their cooling ability. These shelves are not adjustable.

#### Tilt-Out Shelf (Some Upright Models)

This shelf is located inside on the freezer door and provides additional storage space. To access an item, tilt the top of the "basket" shelf down.



Tilt-Out Shelf

#### **Care and Cleaning**

- Damp objects stick to cold metal surfaces. DO NOT touch interior metal surfaces with wet or damp hands.
- The freezer must be unplugged (to avoid electrical hazard) from power source when defrosting the unit.

Some upright and chest freezers are frost free and defrost automatically, but should be cleaned occasionally.

#### **Between Defrostings**

To avoid frequent defrosting, occasionally use a plastic scraper to remove frost. Scrape with pulling motion. **NEVER** use a metal instrument to remove frost.

#### Defrosting

It is important to defrost and clean the freezer when 1/4 to 1/2 inch of frost has accumulated. Frost may tend to accumulate faster on the upper part of the freezer due to warm, moist air entering the freezer when the door/lid is opened. Remove food and leave the door/lid open when defrosting the freezer.

#### To Defrost Upright Models with Defrost Drain:

- Remove the drain plug on the inside floor of the freezer by pulling it straight out.
- To access external drain tube on models with a base panel, first remove the two screws from the base panel. Locate the drain tube near the left center under the freezer.
- Place a shallow pan under the drain tube. Defrost water will drain out. Check the pan occasionally so water does not overflow (see figure 1).
- A ½ inch garden hose adapter can be used to drain the freezer directly into a floor drain. If your model is not equipped with an adapter, one can be purchased at most hardware stores.
- Replace the drain plug when defrosting and cleaning are completed. If the drain is left open, warm air may enter the freezer.

#### To Defrost Chest Models with Defrost Drain:

- Place a shallow pan or the Divider/Drain Pan (if equipped) beneath the drain outlet. Pull out the outside drain plug (see figure 2). A ½ inch garden hose adapter can be used to drain the freezer directly into a floor drain (see figure 3). If your model is not equipped with an adapter, one can be purchased at most hardware stores.
- Pull out the drain plug inside the freezer (see figure 4). Defrost water will drain out. Check pan occasionally so water does not overflow.
- Replace the drain plugs when defrosting and cleaning are completed. If the drain is left open, warm air may enter the freezer.

#### To Defrost Models without Defrost Drain:

- Place towels or newspapers on the freezer bottom to catch the frost. The frost will loosen and fall.
- Remove the towels and/or newspapers.
- If the frost is soft, remove it by using a plastic scraper. If the frost is glazed and hard, fill deep pans with hot water and place them on the freezer bottom.

- Close the freezer door/lid. Frost should soften in about fifteen (15) minutes.
- Repeat this procedure is necessary.



#### Cleaning The Inside

After defrosting, wash inside surfaces of the freezer with a solution of two (2) tablespoons of baking soda in one (1) quart (1.136 liters) warm water. Rinse and dry. Wring excess water out of the sponge or cloth when cleaning in the area of the controls, or any electrical parts.

Wash the removable parts with the baking soda solution mentioned above, or mild detergent and warm water. Rinse and dry. **NEVER** use metallic scouring pads, brushes, abrasive cleaners or alkaline solutions on any surface. **DO NOT** wash removable parts in a dishwasher.

#### **Cleaning The Outside**

Wash the cabinet with warm water and mild liquid detergent. Rinse well and wipe dry with a clean soft cloth. Replace parts and food.

Do not use razor blades or other sharp instruments, which can scratch the freezer surface when removing adhesive labels. Any glue left from the tape can be removed with a mixture of warm water and mild detergent, or touch the residue with the sticky side of the tape already removed. **DO NOT REMOVE THE SERIAL PLATE**.

### Power Failure / Freezer Failure

#### AWARNING Risk of Child Entrapment

If leaving the freezer door/lid open while on vacation, make certain that children cannot get into the freezer and become entrapped. **DO NOT** open freezer door/lid unnecessarily if freezer is off for several hours.

#### Vacation and Moving Tips

#### Short Vacations:

• Leave the freezer operating during periods of non-use of less than three (3) weeks.

#### Long Vacations:

If the freezer will not be used for several months:

- Remove all food and unplug the power cord.
- Clean and dry the interior thoroughly.
- Leave the freezer door/lid open slightly, blocking it open if necessary, to prevent odor and mold growth.

#### Moving:

When moving the freezer, follow these guidelines to prevent damage:

- Disconnect the power cord plug from the wall outlet.
- Remove foods, then defrost, and clean the freezer.
- Secure all loose items such as base panel, baskets, and shelves by taping them securely in place to prevent damage.
- In the moving vehicle, secure freezer in an upright position to prevent movement. Also, protect outside of freezer with a blanket or similar item.

#### IF A POWER FAILURE OCCURS:

Frozen foods will stay frozen for at least 24 hours if the freezer is kept closed. If the power failure continues, pack seven or eight pounds of dry ice into the freezer every 24 hours. Look in the Yellow Pages under "Dry Ice", "Dairies", or "Ice Cream Manufacturers" for local dry ice suppliers. Always wear gloves and use caution when handling dry ice.

If the freezer has stopped operating, see the "Freezer does not run" section in the Avoid Service Checklist section of this use and care guide. If you cannot solve the problem, call an authorized service personnel immediately.

If the freezer remains off for several hours, follow the directions above for the use of dry ice during a power failure. If necessary, take the food to a local locker plant until the freezer is ready to operate. Look in the Yellow Pages under "Frozen Food Locker Plants".

| AVOID SERVICE   |   | st. It may save you time and expense. This list includes   |  |
|---|---|--|--|
| CHECKLIST   | common occurrences that are not the result of defective workmanship or materials in this appliance.   |  |  |
| PROBLEM   | CAUSE   | CORRECTION   |  |
| FREEZER DOES NOT RUN                                      | Ι.  |  |  |
| Freezer does not run.                                     | * Freezer is plugged into a circuit that  | * Use another circuit. If you are unsure about the outlet  |  |
|   | has a ground fault interrupt.   | have it checked by a certified technician.   |  |
|   | <ul> <li>Temperature control is in the "OFF"<br/>position.</li> </ul>   | * See Thermostat Setting.  |  |
|   | <ul> <li>Freezer may not be plugged in, or<br/>plug may be loose.</li> </ul>  | <ul> <li>* Ensure plug is tightly pushed into outlet.</li> </ul>   |  |
|   | * House fuse blown or tripped circuit breaker.  | * Check/replace fuse with a 15 amp time delay fuse.<br>Reset circuit breaker.  |  |
| _   | * Power outage  | * Check house lights. Call local Electric Company.   |  |
| Freezer runs too much or<br>too long.                     | * Room or outside weather is hot.   | * It's normal for the freezer to work harder under these conditions.   |  |
|   | <ul> <li>Freezer has recently been<br/>disconnected for a period of time.</li> </ul>  | <ul> <li>It takes 24 hours for the freezer to cool down<br/>completely.</li> </ul>   |  |
|   | * Large amount of warm or hot food have been stored recently.   | <ul> <li>Warm food will cause freezer to run more until the<br/>desired temperature is reached.</li> </ul>   |  |
|   | <ul> <li>Door/lid is opened too frequently or<br/>kept open too long.</li> </ul>  | * Warm air entering the freezer causes it to run more.<br>Open the door/lid less often.  |  |
|   | <ul> <li>Freezer door/lid may be slightly<br/>open.</li> </ul>  | * See "Door/lid Problems".   |  |
|   | * Temperature control is set too low.   | <ul> <li>* Turn control knob to a warmer setting. Allow several<br/>hours for the temperature to stabilize.</li> </ul>                                   |  |
|   | <ul> <li>Freezer gaskets are dirty, worn,<br/>cracked or poorly fitted.</li> </ul>  | <ul> <li>Clean or change gasket. Leaks in the door/lid seal wil<br/>cause freezer to run longer in order to maintain<br/>desired temperature.</li> </ul> |  |
| Interior freezer temperature is too cold.                 | * Temperature control is set too low.   | * Turn control knob to a warmer setting. Allow several hours for the temperature to stabilize.   |  |
| Interior freezer temperature                              |   | * Turn control knob to a colder setting. Allow several   |  |
| is too warm.  | warm.   | hours for the temperature to stabilize.  |  |
|   | * Door/lid is opened too frequently or kept open too long.  | * Warm air entering the freezer causes it to run more.<br>Open the door/lid less often.  |  |
|   | <ul> <li>Freezer door/lid may be slightly<br/>open.</li> </ul>  | * See "Door/lid Problems".   |  |
|   | <ul> <li>* Large amount of warm or hot food<br/>have been stored recently.</li> </ul>   | <ul> <li>Wait until the freezer has had a chance to reach its<br/>selected temperature.</li> </ul>   |  |
|   | <ul> <li>Freezer has recently been<br/>disconnected for a period of time.</li> </ul>  | * Freezer requires 24 hours to cool down completely.   |  |
| Freezer external surface temperature is warm.             | <ul> <li>The external freezer walls can be<br/>as much as 30°F warmer than room<br/>temperature.</li> </ul>   | <ul> <li>This is normal while the compressor works to transfer<br/>heat from inside the freezer cabinet.</li> </ul>                                      |  |
| SOUND AND NOISE   |   |  |  |
| Louder sound levels whenever freezer is on.               | <ul> <li>Modern freezers have increased<br/>storage capacity and more stable<br/>temperatures. They require high<br/>efficiency compressors.</li> </ul> | * This is normal. When the surrounding noise level is low, you might hear the compressor running while it cools the interior.                            |  |
| Louder sound levels when<br>compressor comes on.          | <ul> <li>Freezer operates at higher<br/>pressures during the start of the ON<br/>cycle.</li> </ul>  | <ul> <li>* This is normal. Sound will level off or disappear as<br/>freezer continues to run.</li> </ul>   |  |
| Popping or cracking sound<br>when compressor comes<br>on. | <ul> <li>Metal parts undergo expansion and<br/>contraction, as in hot water pipes.</li> </ul>   | <ul> <li>* This is normal. Sound will level off or disappear as<br/>freezer continues to run.</li> </ul>   |  |

| PROBLEM                                    | CAUSE   | CORRECTION   |  |
|--|---|--|--|
| SOUND AND NOISE (Cont.                     | )   | •  |  |
| Bubbling or gurgling sound,                | * Refrigerant (used to cool freezer) is circulating throughout the system.                              | * This is normal.  |  |
| Vibrating or rattling noise.               | <ul> <li>Freezer is not level. It rocks on the<br/>floor when it is moved slightly.</li> </ul>          | <ul> <li>Level the freezer by putting wood or metal shims<br/>under part of the freezer.</li> </ul>  |  |
|  | * Floor is uneven or weak.  | * Ensure floor can adequately support freezer. Level<br>the freezer by putting wood or metal shims under part<br>of the freezer.                     |  |
|  | * Freezer is touching the wall.   | * Re-level freezer or move freezer slightly.   |  |
| WATER / MOISTURE / FRO                     | OST INSIDE FREEZER  |  |  |
| Moisture forms on inside<br>freezer walls. | <ul> <li>Weather is hot and humid, which<br/>increases internal rate of frost build-<br/>up.</li> </ul> | * This is normal.  |  |
|  | * Door/lid is slightly open.  | * See "Door/lid Problems".   |  |
|  | <ul> <li>Door/lid is kept open too long or is<br/>opened too frequently.</li> </ul>                     | * Open the door/lid less often.  |  |
| WATER / MOISTURE / FRO                     | OST OUTSIDE FREEZER   |  |  |
| Moisture forms on outside freezer walls.   | * Door/lid is slightly open.  | * See "Door/lid Problems".   |  |
| ODOR IN FREEZER                            |   | •  |  |
| Odors in freezer.                          | * Interior needs to be cleaned.   | * Clean interior with sponge, warm water, and baking soda.   |  |
|  | * Foods with strong odors are in the freezer.   | * Cover the food tightly.  |  |
| DOOR/LID PROBLEMS                          |   | ·  |  |
| Door/lid will not close.                   | * Freezer is not level. It rocks on the floor when it is moved slightly.                                | * Level the freezer by putting wood or metal shims under part of the freezer.  |  |
|  | * Floor is uneven or weak.  | <ul> <li>Ensure floor can adequately support freezer. Level<br/>the freezer by putting wood or metal shims under part<br/>of the freezer.</li> </ul> |  |
| LIGHT BULB IS NOT ON                       |   |  |  |
| Light bulb is not on.                      | * The fluorescent lamp or light bulb is<br>burned out.  | * See "Fluorescent Lamp" or "Interior Light" on<br>Features Section.   |  |
|  | <ul> <li>No electric current is reaching the<br/>appliance.</li> </ul>                                  | * See "Freezer Does Not Run".  |  |
| AUTOMATIC ICE MAKER I                      | NOT WORKING (IF EQUIPPED)   |  |  |
| Automatic ice maker not                    | * Ensure the Wire Signal Arm is not in the "UP" position.   |  |  |
| working (some models).                     | * Ice maker should produce 4 to 5 pounds of ice in a 24 hour period.                                    |  |  |
|  | * Water supply is turned off.   |  |  |
|  | * Water pressure is too low.  |  |  |
|  | * The freezer is not cold enough.   |  |  |

### **Compact Appliance Warranty Information**

Your appliance is covered by a one year limited warranty. For one year from your original date of purchase, Electrolux will pay all costs for repairing or replacing any parts of this appliance that prove to be defective in materials or workmanship when such appliance is installed, used and maintained in accordance with the provided instructions.

#### Exclusions This warranty does not cover the following:

- 1. Products with original serial numbers that have been removed, altered or cannot be readily determined.
- 2. Product that has been transferred from its original owner to another party or removed outside the USA or Canada.
- 3. Rust on the interior or exterior of the unit.
- 4. Products purchased "as-is" are not covered by this warranty.
- 5. Food loss due to any refrigerator or freezer failures.
- 6. Products used in a commercial setting.
- 7. Service calls which do not involve malfunction or defects in materials or workmanship, or for appliances not in ordinary household use or used other than in accordance with the provided instructions.
- 8. Service calls to correct the installation of your appliance or to instruct you how to use your appliance.
- 9. Expenses for making the appliance accessible for servicing, such as removal of trim, cupboards, shelves, etc., which are not a part of the appliance when it is shipped from the factory.
- 10. Service calls to repair or replace appliance light bulbs, air filters, water filters, other consumables, or knobs, handles, or other cosmetic parts.
- 11. Surcharges including, but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas, including the state of Alaska.
- 12. Damages to the finish of appliance or home incurred during installation, including but not limited to floors, cabinets, walls, etc.
- 13. Damages caused by: services performed by unauthorized service companies; use of parts other than genuine Electrolux parts or parts obtained from persons other than authorized service companies; or external causes such as abuse, misuse, inadequate power supply, accidents, fires, or acts of God.
- 14. Labor costs after ninety (90) days from your original date of purchase incurred for product repair or replacement as provided herein for carry-in appliances.

#### DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES

CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR OR REPLACEMENT AS PROVIDED HEREIN. CLAIMS BASED ON IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW, BUT NOT LESS THAN ONE YEAR. ELECTROLUX SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN LIMITED WARRANTY OR ANY IMPLIED WARRANTY. SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THESE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WRITTEN WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

If You Need Service Keep your receipt, delivery slip, or some other appropriate payment record to establish the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts. Service under this warranty must be obtained by contacting Electrolux at the addresses or phone numbers below.

This warranty only applies in the USA and Canada. In the USA, your appliance is warranted by Electrolux Major Appliances North America, a division of Electrolux Home Products, Inc. In Canada, your appliance is warranted by Electrolux Canada Corp. Electrolux authorizes no person to change or add to any obligations under this warranty. Obligations for service and parts under this warranty must be performed by Electrolux or an authorized service company. Product features or specifications as described or illustrated are subject to change without notice.

USA 1.800.944.9044 Electrolux Major Appliances North America P.O. Box 212378 Augusta, GA 30907



Canada 1.800.668.4606 Electrolux Canada Corp. 5855 Terry Fox Way Mississauga, Ontario, Canada L5V 3E4