TECHNICAL MANUAL (Ver.2.0)

MULTI PROJECTION UNIT

RM-V4000V/V5000V

PROJECTION SCREEN KIT

RMS-V4011/V5011

PROJECTION FRAME

RMF-V4011/V5011

PROJECTION CABINET

RMF-V4011R

ACaution

This symbol refers to a hazard or unsafe practice which can result in personal injury or property damage.

Notes:

- Pioneer will not be liable for any loss caused by defects of the parts supplied other than by Pioneer.
- An damage during shipping will be compensated for only in the case where Pioneer's specific packing materials for shipping are used.
- The guarantee of performance is applicable only when the assembly and adjustment described in this technical manual and the adjustment described by the system manual of RM-V2000 have been carried out.





PIONEER RM-V4000 / 5000 MANUAL.

This Acrobat (IE: a PDF file) version of the Pioneer RM-V4000 / 5000 manual was made from the original digital document and scanning an existing manual. Because of this, there are many less then perfect pages and hand written comments.

As Pioneer is constantly working towards providing the best possible documentation for our products, there may be an improved version of this document available. Please contact your Pioneer representative for additional information.

Josh Kairoff Pioneer New Media Technology. October 27, 1997.

CONTENTS

CHAPTER 1. FEATURES OF PROJECTION CUBE SYSTEM	4
1. FEATURES OF SYSTEM	4
2. FEATURES OF MULTI PROJECTION UNIT (RM-V4000V/V5000V)	4
3. FEATURES OF FRAME TYPE	5
4. FEATURES OF CABINET TYPE	5
CHAPTER 2 . GENERAL SPECIFICATIONS	6
1. SPECIFICATIONS	6
(1) Multi Projection Unit (RM-V4000V/V5000V)	6
(2) Projection Screen Kit(RMS-V4011/V5011)Product Weight:11.0kg/14.0kg	13
(3) Projection Frame (RMF-V4011/V5011)Product Weight:26.8kg/28.8kg	14
(4) Projection Cabinet(RMF-V4011R)	15
(5) Projection Install Table (RM-V112/RMA-V5010)	16
(6) Munting Unit (RMA-V2050/2060)	17
(7) Multi Video Processor(RMD-V3216/3109,RMD-V2170)	18
(8) Adjustment Control Unit (RU-V107)*Option	20
(9) Projection Cabinet (RMF-V4011R) Accessories	
2. SYSTEM DIMENSIONS	
(1) 160-inch (40-inch 4×4screens)For RMF-V4011	
(2) 150-inch (50-inch 3×3screens)For RMF-V5011	
(3) 160-inch (40-inch 4×4 screens)For RMF-V4011R	24
CHAPTER 3. INSTALLATION AND ASSEMBLY	. 25
1. INSTALLATION CONDITIONS	25
(1) Installing Ground	25
(2) Ceiling	26
(3) Front Space	26
(4) Rear Space	26
(5) Number of Units Stacked Up	26
(6) Prevention of Tilting	26
(7) Calculating the Heat Quantity	
(8) Temperature and Humidity	
(9) Condensation	
(10) Visible Angle	
(11) Lighting	
(12) Effects of Earth Magnetism	
(13) Connection with a Power Supply	
(14) Cabes Used(15) Semi-outdoor Installation	
(16) Precautions for Use of User-Obtained Parts	
2. INSTALLATION AND ASSEMBLY	
(2) Opening the Packaging	
(3) Carrying the Units After Opening Packaging	
3. PRECAUTIONS FOR TRANSPORTATION	
4. ASSEMBLING THE SYSTEM	
(1) Assembling the Projection Frame (RMF-V4011/V5011)	
(2) Assembling the System	
5. SPECIAL INSTALLATION	
(1) Wall inset	
(2) Diagonal installation	
(3) Architrave processing	
(4) Upside down installation	
(5) Hanging from ceiling	53
CHAPTER 4. ADJUSTMENTS	. 54
1. ADJUSTMENT PREPARATIONS	
(1) Wiring	
(2) Wiring Handling	
(3) Aging	54

(4) Adjustment Signals	55
(5) Equipment Required for Adjustments	55
2. BEFORE ADJUSTMENTS	56
(1) Convergence Adjustment Memory	56
(2) TV System	56
(3) White Balance Adjustment Memory	58
(4) Combined Use of Remote Control and Personal Computer	58
(5) Memory of Adjustment Data and Settings	58
(6) Giving IDs	59
3. EXAMPLES OF MAIN USES OF CUBE SYSTEM	61
(1) Expansion/Individual Switching at Multi Video Processor Side-General example of RM-V2000 series	61
(2) When Switching the Cube Input Function-Display example expected on RM-V4000V system	61
(3) When Switching Source Inputs to Multi Video Processor (1)-When using Pioneer's new Multi Video Processor	62
(4) When Switching Source Inputs to Multi Video Processor (2)-When using Pioneer's Multi Video Processor	
(5) When Using Two Multi Video Processors without Frame Adjusting Function	
(6) When Single Screen is Used	63
(7) When Switching the Source Input to the Multi Video Processor	
4. SCREEN ADJUSTMENTS	
(1) Adjustment Flowchart	
(2) Convergence Adjustment Flowchart	66
(3) Convergence Adjustment Contents	
(4) White Balance Adjustment Flowchart	
(5) White Balance Adjustment	87
(6) External Control by RS-232C	94
(7) Adjustments by Remote Control	106
CHAPTER 5. OPERATIONS · MAINTENANCE	
1. MAINTENANCE	118
(1) Re-adjustments After 3 months	118
(2) Periodic Maintenance	118
(3) Replacement of Parts	118
2. PRECAUTIONS FOR PLAYING	123
3. SERVICE SYSTEM	123
4. PRECAUTIONS FOR ASSEMBLING AND MAINTENANCE	124
CHAPTER 6. PRECAUTIONS	125
1. PRECAUTIONS ON FUNCTION AND PERFORMANCE OF SYSTEM	125

WARNING 🗥

- To prevent injuries and physical damages, always read and observe this manual and all labels on the unit before assembly, construction, and adjustments.
- \cdot Do not use the unit outdoors to prevent fire hazards and electric shocks caused by water entering the unit.
- To prevent injuries, take note of the sharp edges of this unit.
- When performing setup work at high places, to prevent the falling down of the unit and damages caused by falling objects, set the Keep Out area.
- To prevent fire hazards and electric shocks, do not place foreign objects in the unit nor remodel it.
- To prevent fire hazards, observe the following using environment.

Temperature :5 to 35 °C

Humidity:20 to 80%

*The above temperature and humidity are conditions for the multi-projection unit and screen separately, and not those of the system.

Perform ventilation with the fan etc. and observe the operating environment conditions even after completing assembly.

· Never install the system tilted.

CHAPTER 1. FEATURES OF PROJECTION CUBE SYSTEM

1. FEATURES OF SYSTEM

Free combination of cubes

By combining cubic style projection cubes, various layouts can be realized. Combine the cubes as desired (four-screens, nine-screens, vertically in one row, horizontally in one row, etc.) according to the purpose of exhibition and installation location.

• Huge screen without reflection (Frame type screen)

Improved image contrast and vertical visible angle with new tint screen.

Reduced reflection of external light.

No discomfort even when viewed in brightly lit event halls and show rooms.

Ouse in bright places

Realizing a high-luminance of 600ft-L (For white peak, RM-V5000V:420ft-L) for the screen brightness, it can be used adequately in lobbies and open spaces with external light.

Oultra-thin mullion (approx. 3mm) when combined (40-inch type).

The width of the Pioneer cube gap is only about 3 mm (about 4 mm 50-inch type) even when combined. Thinner and more easy-to-view than before, the problem of missing images and characters has been resolved to a large extent.

OHDTV, WS IMAGE

By adding equipment, the system can also receive HDTV the next generation video format. High quality live-like images can be shown on a huge screen to a large crowd of viewers such as at event halls and show rooms.

2. FEATURES OF MULTI PROJECTION UNIT (RM-V4000V/V5000V)

Variable scanning

Horizontal frequency:15 to 35 kHz.

Vertical frequency:50 to 150 Hz.

Corresponding automatically to the different pixel number,

and vertical/horizontal scan frequencies of different companies, the unit always displays the best computer images. In addition to NTSC, it can also display Personal Computer images for presentation and data display.

•Work station computer images can be displayed.

Using the special converter, several screens can be joined to display work station class computer images for display in a control center, CG, and simulation.

High quality image by double scan

Double scan signals of the special converters can be input to realize non-interlaced high quality image.

Improvement of adjusting method

- The convergence adjusting system has been changed form analog to digital. In addition to conventional adjusting methods, by adding the adjustment (point convergence) by points (25 points), adjustments have become more easy and accurate.
- By adding the linear white circuit, the white balance can be adjusted more precisely.
- ■The multi-projection unit can be mounted onto conventional cabinets (RM-V4000V) in addition to RMF-V4011R.

- •Incorporates functions such as multi-switch which aim at high quality image for enlarged images and solid screen.
 - Although peripheral light is given adequate luminance to construct the multi-screen, the multi switch is loaded to realize a
 huge screen with more consistent brightness by the peripheral light compensation circuit. It is also equipped with a function which performs contour correction during enlargement of images to provide natural and high quality enlarged images.
 - The incorporated auto white balance function and ABL (auto brightness limiter) link function control inconsistencies of color and brightness between the screens.
- •Wired remote control (RU-V107/Optional) for adjustments.

In the setting of the multi-screen system, using the wired remote control in convergence and white balance adjustments enables the images to be viewed at the same time. These adjustments are performed to obtain uniformity of the entire screen.

It is efficient for adjustments to be performed by several persons and in temporary adjustments.

Sticking-easing function

A contrast selection function for easing sticking is provided.

Memory function

Apart from the standard values set at shipment, up to 7 numbers can be memorized for the adjusting value.

Convenient "color mode selection switch" for camera-reexposure.

A convenient "color mode selection switch" which can set two types of white balance data is provided. For example, when using the system as a monitor for reexposing in broadcast station studios, etc., images exposed using the camera according to the lighting of the studio will come out with unnatural colors. By setting the temperature of one color to 3200 °K, natural color reproductions can be realized by one-touch operation.

On-screen function

In addition to adjusting values, maintenance data, etc., can be displayed on the screen.

●External control function

A RS-232C external control terminal is equipped. Using a Personal Computer, various adjustments can be performed from the front and a variety of images can be played. The daisy-chain for connecting the combination terminal by the link control cable (DIN 6-pin/provided) can be performed in the transmission of control signals to each unit. Complicated connections are not required. By giving IDs to each unit, each unit can be adjusted individually even after the system has been started.

Corresponds to both NTSC and PAL formats (automatic differentiation).

3. FEATURES OF FRAME TYPE

- By adopting an unique mullion structure, ultra-thin gap (about 3 mm) (about 4 mm for 50-inch type), when screens are combined, has been realized, thereby resolving the problem of missing images and characters.
 - Projectors can be connected and disconnected from the front
 - and rear even after installation. Therefore, checking, replacement, or maintenance can be performed easily.
- •Efficiency is the same as before. Up to five screens can be piled on top of each other without any reinforcement. Use of reinforcement enables the level to be increased.
- By adopting the frame structure, a mullion-less system can be realized.

4. FEATURES OF CABINET TYPE

- Outstanding durability due to its dynamic design using aluminum.
- •As the cabinet need to be piled up only in installation, setup time is very short. It therefore proves efficient in cases where time is limited, conditions are harsh, etc. such as events.
- ●By adopting an unique mullion- structure, ultra-thin mullion- (about 3 mm) (when screens are combined) has been realized, thereby resolving the problem of missing images and characters.
- The RM-V4000V or RMA-V2130 can be mounted.

CHAPTER 2. GENERAL SPECIFICATIONS

1. SPECIFICATIONS


(1) Multi Projection Unit (RM-V4000V/V5000V)


TV forma NTSC, PAL automatic selection
(Each mode provided)
Projection tube
Horizontal resolution600 TV lines (In video input mode)*1
Luminance (For white peak) 600ft-L(40-inch)*
420ft-L(50-inch)
Practical visible angleHorizontal direction 150 deg
Vertical direction 60 deg *1
Input signals:
Video input Standard input level (75 ohm load) 1 Vp-p
Input terminal:BNC connectorx1
Y/C separation inputStandard input level (75 ohm load)
Luminance (Y) signal 1 Vp-p (With sync signal)
Color (C) signal:286m Vp-p (Burst signal <ntsc>)</ntsc>
300m Vp-p (Burst signal <pal>)</pal>
Input terminal:BNC connector (Y and Cx1 each)
RGB input Analog R, G, B signals
Horizontal 15 kHz to 35 kHz (Automatic switching)
Vertical 50 Hz to 150 Hz (Automatic switching)
RGB-1:BNC connectorx5*3
RGB-2:D-Sub 9-pin connectorx1*3
R:Red input:0.7 Vp-p±2db, terminated at 75 ohm, posi-
tive polarity
G/G SYNC:Green input,0.7 Vp-p±2db, terminated at 75
ohm, positive polarity
Green input with SYNC:0.7 Vp-p±2db, terminated at 75
ohm, positive polarity
B:Blue input:0.7 Vp-p±2db, terminated at 75 ohm, posi-
tive polarity
SYNC/HD:Composite sync input:0.3Vp-p to 4Vp-p, ter-
minated at 75 ohm, positive/negative polarity
Horizontal sync input:0.3Vp-p to 4Vp-p, terminated at 75
ohm, positive/negative polarity
• • • • • • • • • • • • • • • • • • • •
VD:Vertical sync input:0.3Vp-p to 4 Vp-p, terminated at
75 ohm, positive/negative polarity
EXT control:BNC connector
Remote input:Mini jack
Linked input:6PIN DIN connector
Output signal
Video output Standard level (75 ohm load) 1 Vp-p
Outputs input signal from input terminal
Remote output 6PIN DIN connector

Computer control:
Method RS-232C (D-SUB 25PIN
Speed (1200), (2400), 4800, (9600
(19200) BPS*2
Power supply voltage AC100V to 120V, 50/60H;
Normal Consumption power about400VA*4
Maximum Consumption power450VA
AC outlet (Max. 10A, AC100V to 120V)x1
External dimensions 680 (W)x490 (H)x610 (D) mm
(excluding projection)
Weight50 kg (Main unit)
Accessories
Control cablex1
*Used for controlling several multi-projection units.
*1 Projection Screen Kit(RMS-V4011/V5011)
Projection Frame(RMF-V4011/V5011)
Specifications when installed as specified above.
*2 The RS-232C baud rate is set to 4800BPS before ship ment.

- *3 Either RGB1 or 2 is used by switch selection.
- *4 For NTSC COLOR BAR signal input.


Dimensions





(Fig.2-1)


Power Supply Panel



No.	Name	Туре	Function
1	AC outlet		Connects other multi-projection units. Not linked to main powerswitch. Note 1)
2	Main power switch	See-saw switch	Turns on and off the power supplied to the main unit. Sets into the standby state when turned on.
3	Fuse holder		Stores the fuse. No-one except serviceman should touch this part.

Note 1) Refer to page 32 (13) Connection with a power supply 1 power supply voltage.

Control Panel



No.	Name	Туре	Function	
1)	Control input terminal	BNC connector	ector Video input and Y/C input external switching control signal in put terminal	
2	Y (Luminance) input terminal	BNC connector	Luminance signal input terminal	
3	C (Color) input terminal	BNC connector	Color signal input terminal	
4	Video input terminal	BNC connector	Video signal input terminal	
(5)	Video output terminal	BNC connector	Video input terminal 4 through-out terminal	
6	TERMINATE switch	Slide switch	Terminates the video input terminal 4 at 75 ohm	
7	COMBINATION switch	Tact switch	Turns on when linked to ABL	
8	MULTI switch	Tact switch	Turns on when used on multi screen	
9	COLOR MODE switch	Tact switch	Switches the color temperature. 1:Normal use. 2:Re-exposure	
10	INPUT switch	Tact switch	Switches VIDEO input, Y/C input, RGB input. Switches VIDEO input and Y/C input with the external control signal 1 at VIDEO position	
11)	POWER switch	Tact switch	Power OFF:STANDBY (Red LED) lights up Power ON:ON (Green LED) lights up	
12	STATUS switch	Tact switch	Accumulated duty time:Switch which displays setting states of each switch on the screen.	
13	RS-232C port	D-sub 25 PIN (Female)	RS-232C communication connector	
(14)	emote control connection ter minal	Mini jack	Connected to adjusting remote control (optional)	
15)	Linked output terminal	DIN 6PIN	Output terminal of ABL signal, remote control signal, and RS-232C signal	
16	Linked input terminal	DIN 6PIN Input terminal of ABL signal, remote control signal a 232C signal		
17)	RGB input terminal	D-sub 9PIN (Male)	RGB signal input terminal	
18	RGB input select switch	Slide switch	Switches RGB signal input terminal type	
19	RGB input terminal (R)	BNC connector	RGB signal R input terminal	
20	RGB input terminal (G/composite sync)	BNC connector	RGB signal G and composite sync (Input signal G on sync) input terminal	
21)	RGB input terminal (B)	BNC connector	RGB signal B input terminal	
22	RGB input terminal (Horizontal sync/composite sync)	BNC connector RGB signal horizontal sync and composite sync (Or signal H/V sync) input terminal		
23	RGB input terminal (Vertical sync)	BNC connector	RGB signal vertical sync input terminal	

[•] To turn off the power, use the POWER switch ① of the unit, the RS-232C control, or wired remote control (optional). (If turned off using the main POWER switch or by disconnecting the power cable from the outlet, the settings of the above ⑦ to ① switches and the state of the TV SYSTEM and convergence memory will not be recorded on the memory.)

Consequently when starting up or stopping the whole system by AC ON/OFF in setup conditions for a demonstration, it is necessary to turn off the power using the above method to record each setting in the memory.

^{*:} Counts only when the power is ON and signal has been input to the input function selected. If the main POWER switch is turned off or the power cable is pulled out of the outlet while the power is on before one hour has passed, errors will occur in the count.

CONTROL PANEL MODE Switches

●COMBINATION switch



Position	Function	
OFF	ABL link is off	
ON	ABL link is on	

[·] Turns on or off each time it is pressed. The LED lights up when turned on.


MULTI switch



Position	Function	
OFF	Changes to a picture quality suitable for single screen	
ON	Changes to a picture quality suitable for multiple screens	

[·] Turns on or off each time it is pressed. The LED lights up when turned on.


COLOR MODE switch



Position	Function	
MODE1	Sets the normal use color temperature. MODE1 LED lights up when selected.	
MODE2	Sets the re-expose color temperature. MODE2 LED lights up when selected.	

[·] Sets to MODE1/MODE2 each time it is pressed.


●INPUT SELECT switch




- The input switches each time this switch is pressed.
- When switched to a signal with different frequency, it will take several seconds (1 to 2) before the image is output properly. If switched at intervals shorter than the above, power may be cut to protect the internal circuits. In such cases, turn off the main POWER switch once and turn it on again.

Position	Function	
VIDEO	The VIDEO input terminal is selected. When selected, the VIDEO LED lights up. When switching to VIDEO or Y/C input by inputting the control signal to the EXT.CONTROL terminal, select this position. <ext. control=""> The VIDEO or Y/C input is selected when the control signal is input to the EXT.CONTROL terminal (BNC). In this case, the VIDEO LED remains lit. Control signals High:VIDEO Low:Y/C The High state is set when the control input terminal is released (normal state). The VIDEO input signal will be selected.</ext.>	
Y/C	The Y/C input terminal is selected. When selected, the Y/C LED lights up.	
RGB	The RGB input terminal is selected. When selected, the RGB LED lights up.	

OSTATUS switch



The display changes cyclically each time it is pressed.
 The settings can be checked.



Display Example)

STATUS display page 1

1.HOUR 1000H
2.INPUT VIDEO
3.MULTI ON
4.COLOR MODE 1
5.COMBI. ON
6.INFORM. ON
7.BAUD RATE 4800BPS

STATUS display page 2

9.TV SYSTEM A.CONV. (COMP)	AUTO MODE-1	


- 1:Displays the accumulated duty time. (Refer to the note on page 9.)
- 2:Displays the input state. Note)
- 3:Displays the MULTI ON/OFF state.
- 4:Displays the COLOR MODE 1/2 state.
- 5:Displays the COMBINATION ON/OFF state.
- 6:Displays the INFORMATION MODE ON/OFF state.

 Note)Downs the CONTRAST adjustment value 20 at ON state for the relaxation of the CRT burn.
- 7:Displays the communication speed in computer control.

9:Displays the TV SYSTEM state.

A:Displays the memory area of the convergence selected.

[RGB-2 Terminal]



Analog RGB

: 0.7Vp-p (75ohm)

Sync signal

: 0.3Vp-p to 4Vp-p (750hm)

Connector

: 9-pin D SUB Connector (Male)

Pin Assignment 1: R

6: GND

2: G/Sync on G

7: VD

3: B

8: NC

4: Signal GND

9: NC


5: HD/Sync

[VIDEO input]

The video output terminal is the input through-out terminal. When connecting to other units, terminate the terminal of the unit to be connected at 75 ohm, and turn off the 75 ohm TERMINATE switch of the main unit. When not connecting other units, always turn on this switch.

POWER SUPPLY outlet \triangle

- Power supply outlet (No-switch linkage:Below 10A)
 For multi-projection unit expansion. Do not use for other purposes.
- Power supply outlet power consumption
 Up to two multi-projection units can be connected to one multi-projection unit.




Focus Adjustment

Adjustment	Input Signal	Adjusting Point	Adjusting Method
Focus adjustment	Cross hatch	Focus control (VR1) of lens assembly attached to the replaced CRT assembly and the focus variable resistor	Move the lens assembly left and right and optimize the focus. Rotate the focus VR and optimize the focus. Adjust the lens assembly and focus VR repeatedly. Note:Perform the following adjustment again only when the blue focus has been adjusted. Rotate the blue focus VR in the clock wise direction and enlarge the blue color vertically until it barely project out of its area. Rotate the focus VR by about 10 des (approximate for your reference).

Note) ASK our servicemen if the Focus VR needs to be adjusted.

(2) Projection Screen Kit (RMS-V4011/V5011) Product Weight: 11.0 kg/14.0kg




(Fig.2-2)

Unit:mm

The number in parentheses is the dimentsion for RMS-V5011

(3) Projection Frame (RMF-V4011/V5011) Product Weight: 26.8kg/28.8kg




(Fig.2-3)

Unit:mm The number in parentheses is the dimension for RMS-V5011

Accessories

Metal fixture (R)	1
Metal fixture (L)	1
Stopper	2
Screw M5x10	. 38+2
Screw M5x35	6
Screw M5x50	4
Hexagon head bolt (with washer) M8x45	8
Shield	1
Rivet	2

(4) Projection Cabinet(RMF-V4011R)



(Fig.2-4)

Specifications

Exter	al dimensions 845 (W)×670 (H)×1259 (D)mn
Neigl	t56.0kg
Scree	n size
Comp	onent parts (RM-V4000V fittings)
Fr	me R [BNG1207]
Fr	me L [BNG1208]
H	lder (R) [BNG1150]
He	lder (L) [BNG1151]
Αı	achment (R) [BNG1173]
Αŧ	achment (L) [BNG1174]
Re	ar holder R [BNG1205]
Re	ar holder L [BNG1206]
Re	ar panel R (upper) [BMR1069]
Re	ar panel L (upper) [BMR1070]1
	ar panel R (lower) [BMR1071]
Re	ar panel L (lower) [BMR1072]1


Cushion A [BMR1106]	1
Cushion B [BMR1107]	2
Hinder panel [BMR1075]	2
Adjuster (BEF1011)	2
Cover [BNE1012]	1
Screw (M5×15)[PMB50P150FZB]	18 (spare×2)
Screw (MS×50) [PMB50P500FZB]	4
Screw (M5×20) [PMB60P200FZB]	
Screw (3×12) [ABA1167]	4
Screw (3×8) [BBZ30P080FZK]	10
Nut (M8) [NA80FZK]	2

(5) Projection Install Table (RM-V112/RMA-V5010)

① Projection Install Table(RM-V112)...For only RMF-V4011

Base weight: 61.2kg Integrated weight: 62kg

Dimension [Include packing] (WXHXD): 920X1370X795mm



(Fig.2-5)


2 Projection Install Table(RMA-V5010)...For only RMF-V5011 (with Munting Unit) Making inquiries separately.

(6) Munting Unit (RMA-V2050/V2060)

① Double munting unit (RM-V2050)

Base weight : 34.0kg Integrated weight : 70kg

Dimension [Include packing] (WXHXD) : $1850\times340\times1460$ mm





(Fig.2-6)

(7) Multi Video Processor (RMD-V3216/V3109, RMD-V2170)


1) Multi Video Processor (RMD-V3216/V3109)







Front View



Side View

(Fig.2-7)

Main Specifications of Multi Video Processor (RMD-V3216/V3109)

Input signal

Input video signal (Can be expanded up to four systems) 2-line (RMD-V3216), 1-line (RMD-V3109) ... BNC terminal

- ① Composite video signal 1.0 Vp-p (75ohm terminated) 2 Y/C separation signal

 - Y (With sync) 1.0Vp-p (75ohm)
- *1 or 2 signal format can be selected
- *Only 1 has a terminate switch, throughout

Input standard sync signal BNC terminal

- ① Composite sync signal 0.286 to 4.0 Vp-p
- ② Composite video signal Video level 0 to 0.714 Vp-p (75ohm)
- *Terminate switch, throughout

RS-232C control input 25-pin D-SUB

Output signal

Output video signal

16-line (RMD-V3216), 9-line (RMD-V3109) .. BNC terminal

- ① Composite sync signal 1.0 Vp-p (75ohm)
- 2 Y/C separation signal
 - Y (With sync) 1.0Vp-p (75ohm)
 - C (With burst) Burst level 0.286 Vp-p (75ohm)
- *1) and 2) signal formats are output simultaneously.

③ RGB s	signal
---------	--------

	Green (Sync on Green)	1.0	Vp-p
	SYNC	0.3	Vp-p
	B.R	0.7	Vp-p
١.	itnut reference composite sync signal BNC	tori	minal

Output reference composite sync signal BNC terminal

(Or input reference sync signal throughout)

Others

Power supply AC100 to 120V (50/60 Hz)
Power consumption
(RMD-V3216, RMD-V3109) 350W, 700VA
Operating temperature and humidity range
5 °C to 35 °C
Below 85% (No condensation)
External dimensions (RMD-V3216, RMD-V3109)
482.6 (Width)x420 (Depth)x314 (Height) (mm)
(Excluding handle)


Weight

RMD-V3216	. 22.5 kg
RMD-V3109	. 22.0 kg

Accessories

Rack mounting screw M5	8
Rack mounting washer	8

2 Multi Video Processor (RMD-V2170)




(Fig.2-8)

Main Specifications of Multi Video Processor (RMD-V2170)

Input video signalNTSC format Ou	ıtput
Input signal band Above 4.2 MHz	Video output
Input	Output signal
Video input	NTSC composite video signal (BNC)
Input signal	Output system16-line
NTSC composite video signal (BNC)	Standard output level
Input system 4-line	Y/C separation output
Standard input level	Output signal NTSC Y/C separation signal (BNC)
Y/C separation	Output system16-line
Input signal NTSC Y/C separation signal (BNC)	Standard output level
Input system 4-line	C286 mVp-p (75 Ω load, burst signal)
Standard input levelY:1 Vp-p (75 Ω load)	st signal output
C:286 mVp-p (75 Ω load burst signal)	Output signal
*The video input or Y/C separation input is to be	NTSC composite video signal (BNC)
selected by the switch on the rear panel.	Standard output level
Reference sync signal input	Sync signal outputTTL level (BNC)
Input signalComposite sync (BNC)	
Standard input level Pow	wer supply voltage 100 to 120V, 50/60 Hz
Composite sync 0.3 to 4 Vp-p	wer consumption 300W/500VA
Control input Ext	ernal dimensions 483 (W)x314 (H)x469 (D) mm
Input signal Conforms to RS-232C (25-pin, D-sub)	eight33 kg

^{*}Line up series of RMD-V2110 with 9 OUTPUT CIRCUITS.

(7) Adjustment Control Unit (RU-V107)*Option



(Fig.2-9)

Ac	cessories	
	AA dry battery (IEC R6P)	. 2
	Cable (5m)	2


(8) Projection Cabinet (RMF-V4011R) Accessories

To attach the multi-projection unit (RM-V4000V) to the conventional RM-V2000A, the RMF-V4011R accessories (metal fixtures) are required. The following lists the required parts. For details of attaching the multi-projection unit, refer to Chapter 3. "4-(2)Assembling the System".

Frame R (BNG1207)	1
Frame L (BNG1208)	1
Holder (R) (BNG1150)	1
Holder (L) (BNG1151)	1
Attachment (R) (BNG1173)	2
Attachment (L) (BNG1174)	2
Rear holder R (BNG1205)	1
Rear holder L (BNG1206)	1
Rear panel R (upper) (BMR1069)	1
Rear panel L (upper) (BMR1070)	1
Rear panel R (lower) (BMR1071)	1
Rear panel L (lower) (BMR1072)	1
Cushion A (BMR1106)	1
Cushion B (BMR1107)	2
Hinder panel (BMR1075)	2
Adjuster (BEF1011)	2
Cover (BNE1012)	1
Screw (M5x15) (PMB50P150FZB) 18 (Spar	e 2)
Screw (M5x50) (PMB50P500FZB)	4
Screw (M6x20) (PMB60P200FZB)	4
Screw (3x12) (ABA1167)	4
Screw (3x8) (BBZ30P080FZK)	. 10
Nut (M8) (NA80FZK)	2

2. SYSTEM DIMENSIONS

(1) 160-inch (40-inch 4×4screens)...For RMF-V4011




(Fig.2-10)

Refer to Fig. 3-30 for the position of the bolts.

As the plate thickness and screw head height are added, external dimensions will increase when cabinets and side boards, etc. are used.

(2) 150-inch (50-inch 3×3screens)...For RMF-V5011




(Fig.2-11)

Refer to Fig. 3-30 for the position of the bolts.

As the plate thickness and screw head height are added, external dimensions will increase when cabinets and side boards, etc. are used.

(3) 160-inch (40-inch 4×4screens)...For RMF-V4011R



(Fig.2-12)

Refer to Fig. 3-30 for the position of the bolts.

As the plate thickness and screw head height are added, external dimensions will increase when cabinets and side boards, etc. are used.

CHAPTER 3. INSTALLATION AND ASSEMBLY

1. INSTALLATION CONDITIONS

(1) Installing Ground


(1) Ground

The ground must be flat and horizontal. It should be able to bear the weight of the system.

For wooden floors, if the part receiving the weight of the system lies at the center between the reinforcement beams below the floor, the floor may become deformed or may curve inwards. In such cases, lay a more than 12 mm thick board below the system to distribute the weight of the system on the floor.

For concrete floors, it may not be possible to install the system horizontally due to the roughness of the floor. In such cases, do the same as above.

When installing the system on a installation table, always place the screen unit and cabinet on the same level of the installation table. The screen should also be more than 15 mm inside the edges of the installation table.



2 How to culculate weight

Example: 40-inch Cube × 16screens

RM-V4000V (Multi-Projection Unit) 50kg \times 16 = 800kg RMS-V4011 (Projection Screen Kit) 11kg \times 16 = 176kg RMF-V4011 (Projection Frame) 27kg \times 16 = 432kg RMS-V112 (Projectin Install Table) 54kg \times 4 = 216kg

Total: 1744 kg + α (screw, others)

Note) Other than the above weights, the weight of the person installing the system are also added. For 16 screens, about 3 to 4 persons=240 kg (15% of total weight).

(2) Ceiling


The distance from the top of the system to the ceiling must be about the length of one screwdriver (about 30cm).
 The ceiling above the system has air-conditioner vents or light bulbs, take note that problems caused by dusts, temperature and humidity, and water droplets may result.

(3) Front Space

Finger and hand prints form easily on the face of the screen. Therefore make sure viewers cannot touch it directly.
 Also leave adequate space in front of the system so that the screen can be replaced and maintenance can be performed from the front.

(4) Rear Space

When removing and installing the projection unit from the back, at least 1m must be left open at the back. When removing
and installing from the front, leave a space of at least 70 cm so that wires and the control assembly can be pulled out.



At installing locations where the projection unit has to be removed from the front, take note of how the unit is to be installed.(Refer to Chapter 3 4-(2)-3. Installation.)

(5) Number of Units Stacked Up

- Up to 4 to 5 units can be stacked up on top of each other. But do not use the casters of the installation table (RM-V112) for the 4th level and upwards.
 - *For 16 screens, all casters must be installed.
 - When using the installation table, always secure it to the floor using the provided floor leveler after installation.
- · Use a reinforcement when stacking more than 5 units (from the 6th level).
 - Example 1: Remove the casters, and place weights on the installation table to stabilize it.
 - 2 :Secure using anchor bolts.
 - (Use chemical anchor bolts if possible.)
 - 3 :Secure with wires.

(6) Prevention of Tilting

 The method of securing to floors and walls differ according to their materials. Always have a construction specialist or Pioneer dealer perform the procedure for you.

(7) Calculating the Heat Quantity

The maximum power consumption of each multi-projection unit is 500VA. As most of the power consumed changes to heat, power consumed is taken to be the heat produced.

① Convert to calories

(VA)x1.163 (kcal/h)

Heat produced/multi-projection unit

500x1.163=582 (kcal/h)

② Convert to B.t.u

[VA]x0.293=[B.t.u]
Heat produced/multi-projection unit 500x0.293=147 [B.t.u/h]

No. of Screens	Calories(kcal/h)	8.t.u/h
11	582	147
4	2326	586
9	5234	1319
12	6978	1758
16	9304	2344

(8) Temperature and Humidity

· Closely observe the following conditions on the temperature and humidity of the location of installation.

(1)Operating temperature

: 5 to 35 degC (No condensation)

(2)Operating humidity

: 20 % to 80 %

(3)Storing temperature

: -10 to 45 degC

- The lenticular sheet will stretch and consequently the center of the screen will rise if the humidity is relatively high. In this
 case, the focus may slightly change and therefore readjustments in the installing conditions of the location must be performed when your system arrives.
- Avoid wetting the system at all times. Due to the shape of the product, it is easily affected by external conditions. Especially
 to be avoided is wetting the multi-projection unit and screen. Thorough water-proof measures must be taken when installing them in locations where there is a high level of moisture in the air such as near air-conditioning vents and water sprays.
 - Take note that in new buildings, moisture is frequently produced from the concrete and the humidity level subsequently
 rises.
- Generally, electronic equipment such as the multi-projection unit should not be installed in high humidity environments.
 Follow the precautions below when high humidity is expected.
 - · Never install the multi-projection unit and screen in locations that do not meet their respective specifications.
 - · Ground the units.
 - Ensure that there is no condensation.
 - . Install the units where no one can touch them.
 - . Ensure that water droplets do not fall onto the units.

(9) Condensation


One problem that occurs in the winter season is "Condensation". When the temperature of the room in which the RM-V4000V/5000V system is installed rises suddenly, condensation occurs on the screen and lens, thereby the system cannot display its best performance. In such cases, turn off the power once, leave the system off for one hour, and turn on the power again. Increasing the room temperature gradually is another method.

(10) Visible Angle

<Obtaining the Appropriate Visible Angle>

First decide the range actually viewed, and next decide the position of the projection system referring to the figure below.

Example) When installing 40-inch 16 screens at the 8m center in the range where the height is more than 3m while standing and more than 4m while seated.



* 40° (Vertical), 84° (Horizontal)

The vertical 40° and horizontal 84° position is the angle at which the luminance drops by 1/3 against the front. Pioneer recommends that the screen be positioned at this angle because images will not appear dark at this angle.

<Explanation>

The point of intersection of the line projecting down 3m from the screen and the lower line from the 4th projection system is about 2.1 m from the floor. (Black lines in Fig. 3-3.)

The point of intersection of the line projecting down 4m from the screen and the lower line from the 4th projection system is about 1.8 m from the floor. (Dotted lines in Fig. 3-3.)

To allow the user seated 4m away to view the screen (the eyes is fixed at 1.2m):

1.8 - 1.2 = 0.6 m (600 mm)


This means that as the bottom of the first projection unit to the floor is 716.5 mm, it needs to be placed 600mm below the current position without using the installation table.

As for as the standing position, the line projecting down 3m from the screen and the line from the 4th projection unit intersect at the following point:


6100 - 600 = 1500 = 1.5 m

As the position of the eye is about 1.6m high when standing, it can be covered sufficiently at 3m from the screen. For the horizontal direction, the area shaded diagonally is the visible range when 4m from the center as shown in Fig. 3-4.


40-inch Vertical Visible Angle




50-inch Vertical Visible Angle



40-inch Horizontal Visible Angle



50-inch Horizontal Visible Angle



(Fig. 3-6)

(11) Lighting

- The projection screen kit (RMS-V4011/V5011) will not reflect like TV screens when exposed to external light, but may reflect
 if directly exposed to strong lights such as spotlight. Therefore, make sure that the screens are not exposed to direct
 spotlight.
- For certain installation location conditions, a glass sheet may have to be attached to the screen surface. In this case, as there will be reflection by external light, consider the installation position, etc. carefully.
- As the actual intended images of the system may not be obtained in very bright locations, consider the position of lighting and direction of sunlight when installing the system.

(12) Effects of Earth Magnetism

- Due to effects of earth magnetism, the position of the image displayed will differ according to the installed direction. Difference is about several mm in the up/down/left/right directions, but the degree of change varies according to the strength of the earth magnetism of each area.
- Misconvergence may also occur due to slight rotations.
- Therefore, when performing adjustments before bringing the system into the installing location. Perform the adjustments in the same direction and angle as installation, perform adjustments again at the final location decided.
- If the system is used at a fixed position, adjust it at the final position used.
- The system is not only affected by earth magnetism but by the following magnetisms generated by various items in its surrounding as well.
 - · Steel frame of building
 - · Power cables on the floor
 - · Large speaker systems
 - · Special equipment (Those generating magnetic force)
 - · Metallic installation table, frames, etc.

(13) Connection with a Power Supply A

① Power supply voitage

The guaranteed voltage of this unit is ±10% of the rated voltage.

But if the impedance of the power wires is high, the voltage waveform will become distorted and show the same symptoms as when voltage drops abnormally. As the following must be noted even if the voltage is within the allowable range, check the power wiring again.

- · The voltage drop from the distributor to the multi projection unit is great.
- · The voltage changes greatly when the power of the unit is turned on and off (Roughly 5% of the rated voltage)

2 Power supply capacity


Calculate the power consumption of one unit as 500VA with allowance.

Multi-Projection	' l	Current Capacity	
Unit Screens		100V	120V
1 screen	500VA	5A	4.2A
4 screens	2000VA	20A	16.7A
9 screens	4500VA	45A	37.5A
12 screens	6000VA	60A	50.0A
16 screens	8000VA	80A	66.7A


The current increases when the voltage decreases. Referring to "3" Connection", design the system slightly greater than the above figures. When connecting the distributor to other equipment, also take note of the power consumption of the equipment and make sure the capacity of the distributor is not exceeded.

3 Connection

 An AC OUTLET is provided on the unit. Up to two multi-projection units can be connected to a multi-projection unit. Do not connect other types of equipment.



· Connect the equipment so that the current capacity of the distributor is not exceeded. Set slightly greater.



3P Plug

The power cord of this unit has a 3P plug. This is to prevent electric shocks caused by leaked currents. Always connect it to a 3P outlet.

⑤ Leak Breaker

The unit is incorporated with the power line filter to reduce noise. Therefore a 0.5 mA leakage current will flow with each unit. If a leak breaker is equipped, check that its sensitive level is above the total leakage current of the system.

Also calculate each unit such as image transmission unit, etc. as 0.5 mA.

It is extremely dangerous to supply power from existing wall outlets, etc.

Position the final outlet connected to each unit of this system as near as possible to the system.

Set the current capacity slightly greater-about more than 25% of the total consumption power.

The power supply voltage should be above 100V (102V to 105V) when there is no load. The power circuit should be controlled so that the voltage will not fall below 96V when all load is set.

(14) Cables Used

Use coaxial cables. Normally use a 3C-2V for less than 20m long. Use 5C-2V for greater lengths. 5C-2V is recommended for high-vision.

Adjust the length of the cables. The distance between the transmission system and multi-projection unit should be as short as possible. When the distance is great, consider the thickness of the cable and electrical compensation carefully.

The limit is as shown when using the cables to connect the transmission final output terminal and the system.

3C-2V: 15m

5C-2V: 30m

To use a longer cable, the VIDEO signal must be corrected.

(15) Semi-outdoor Installation

This system is basically designed for use indoors. However, if it has to be installed outdoors, take note of the following.

- · Waterproof and rustproof measures
- · Temperature difference and humidity difference
- Light on the screen (So that it is not exposed to direct sunlight.)
- · Wind containing salt

(16) Precautions for Use of User-Obtained Parts

It is recommended that Pioneer products be used for the projection stand, mount unit, etc. Users obtaining these parts separately by themselves should take note of the following.

- When obtaining stands and mount units separately, make sure that the system can be installed horizontally. Also calculate
 strength properly and take adequate measures against tilting of the screen. If the recommended stand and mount unit are
 not used, Pioneer will bear no responsibility whatsoever for accidents and injuries incurred due to incomplete connections
 and mounting, natural disasters, etc.
- When mounting top board, side board, rear panel obtained separately, use the holes for mounting the Pioneer stand and projection frame. (Refer to Fig. 3-30)

2. INSTALLATION AND ASSEMBLY

(1) Confirmation

1) Decide the position for installing the system according to the installation conditions in Chapter 3.

Check Items

- [1] Dimensions of installing position, space at the back, distance to the ceiling
- [2] Floor flatness, strength, roughness
- [3] Position of power supply
- [4] Installing location

Necessity ti strengthen the floor, wall, etc.(reinforcement cover, sheet, plank, etc.), path used to transport the system, width of passage, if elevator is available, its size and maximum bearing weight, etc.

- [5] Position, specifications, and structure of a transmission equipment, and image type
- [6] Model number of equipment used, and their quantity (perform according to list).

Check if there is enough equipment for each unit

(2) Opening the Packaging

① Packaging specifications

[1] Multi Projection Unit	(RM-V4000V/V5000V)	: $769(W) \times 690(H) \times 738(D)$	61.0kg
[2] Projection Screen Kit	(RMS-V4011)	: $940(W) \times 230(H) \times 730(D)$	15.7kg
	(RMS-V5011)	: 1126(W) \times 230(H) \times 879(D)	20.2kg
[3] Projection Frame	(RMF-V4011)	: 950(W) \times 180(H) \times 1300(D)	31.2kg
	(RMF-V5011)	: 1160(W) \times 250(H) \times 1475(D)	35.4kg
[4] Projection Cabinet	(RMF-V4011R)	: 1006(W) × 859(H) × 1454(D)	68.0kg

2 Opening the packaging

Open from the big ones first and put the small packagings inside the empty big packagings. Also dispose or store the packagings.

Do not mix up the opened items with those still in the packaging.

Move the empty packagings somewhere else so that they will not come in the way. Next, obtain an assembly space that is as wide as possible.


* Turn down the opened packagings upside down to differentiate them from those not opened.


Do not lose accessories, the warranty card, etc.


^{*}These procedures must be performed by only one person.

③ Multi Projection Unit (RM-V4000V/V5000V)

- [1] Open the upper carton, and remove the ABL cable and instruction manual provided.
- [2] Remove the upper carton (the pad will be connected to the upper carton).
- [3] Remove the upper pad.
- [4] Take out the unit (must be taken out by two persons).








(Fig.3-7)

4 Projection Screen Kit (RMS-V4011/V5011)


- * Projection screen kit is double-packaged to maintain its performance. After removing the middle cover protecting its screen, make sure the screen does not get scratched or dirty.
 - [1] Remove the top cover.
 - [2] Remove the band securing the middle cover and remove the middle cover.
 - [3] Gently peel off the black tape pasted at the four sides of the screen. Be careful not to damage the lenticular sheet.
 - [4] Take out the screen unit from the box and stand it on a flat floor, paying attention to its top and bottom.
 - [5] Remove the eight screws for transportation (gold), four protection panels, white sheet at the back of the screen, and the bag containing accessories attached to the top of the frame.
 - * The protection panel is attached with the transportation screws. Keep the removed panel if required. When storing the system, do not remove the outermost protection panel.
 - [6] When opening the packagings of several units first, after opening them, place them in a different place to protect them from damage, and place a sheet over them to protect them from dusts.



(Fig.3-8)


⑤ Projection Frame (RMF-V4011/V5011)

- [1] Open the upper carton and cut the PP bands (eight) securing the internal parts.
- [2] Remove the two horizontal frame assemblies (packaged in a card box), fixtures (R) and (L).
- [3] Remove the H-shape frame assembly (L).
- [4] Remove the base assembly.
- [5] Remove the H-shape frame assembly (R).
- [6] Remove the shield attached to the under carton, bag containing accessories, and instruction manual.



6 Projection Cabinet (RMF-V4011R)


- [1] Open the upper carton and remove packings B and C, and the instruction manual.
- [2] Remove the upper carton.
- [3] Remove the top sheet B and peel off the front and back sheets B.
- [4] Remove the cabinet. (Hold the handle of the cabinet by two persons.)
- [5] Remove sheet B.
- [6] Remove the parts from the under carton.



(Fig. 3-10)

(3) Carrying the Units After Opening Packaging

To carry the screen unit and multi-projection unit after opening the packaging, hold them by the parts shown in the figure, and lift and move them.



- Never drag the system along the floor when moving the units.
- The lenticular sheet damages very easily as it is very thin. Therefore move it gently and do not apply excessive shock or vibration to it.
- As the panels supporting the screen are very thin and deform easily, be careful that they do not hit or get hooked onto surrounding objects when moving them.

3. PRECAUTIONS FOR TRANSPORTATION

Do not stack the units on their sides or backs when transporting them.


Always place them upright. If they are stacked on their sides or backs, vibration and shock may cause damage or fire hazards.

■Precautions for Transporting RMS-V4011/V5011

- * As RMS-V4011 must always be installed, it will not need to be re-packed and transported. Packaging instructions are provided for your reference just in case it has to be transported again.
- · Pack it properly according to the packaging specifications. Also check the following conditions,
 - [1]The protection panel has been properly attached by the transportation screws (eight).
 - *Use the protection screws (gold) provided with the unit.
 - [2]The protection tapes are pasted to the four corners of the protection panels.
 - *Paste the protection tape on the protection panel.
 - *Use a relatively weak tape about 20mm to 30mm in width.
 - <Recommended Tape>

Name

:Acetate cloth adhesive tape (25 mm width)



(Fig.3-12)


- When transporting or storing the units in the packaged state, always face them up.
- The number of units that can be stacked in storage is 16.
- As the screen is at the top, be careful not to step, and place heavy objects on this top side, nor hit it with sharp objects.

4. ASSEMBLING THE SYSTEM

(1) Assembling the Projection Frame (RMF-V4011/V5011)

Assemble the projection frame as follows.

- [1] Mount the stopper onto the base assembly and tighten the screws (M5 \times 35). (2 \times 2 points)
- [2] Mount the H-shape frame assemblies (R) and (L), and tighten the screws (M5 \times 10). (4 \times 4 points)
- [3] Mount the horizontal frame assemblies (two) and tighten the screws (M5 \times 10). (4 \times 4 points)
 - * As for the positions for tightening the screws in steps 2 and 3, push the frame against the corner fixtures in the two directions indicated by the arrow.
- [4] Mount the shield onto the H-shape frame assembly (L) using the rivets, peel off the paper on the shield and paste a magic tape on the H-shape frame assembly (L).
- [5] Attach the fixtures (R) and (L) and tighten the screws (M5 \times 10). (3 \times 2 points)
- [6] Place the projection unit on the base assembly, and secure the fixtures (R) and (L) and projection unit to each other with the screws (M5 \times 10). (2 \times 2 points)
- [7] Secure the movable part of the base assembly with the two screws (M5 \times 35).



(Fig. 3-13)

(2) Assembling the System

The basic procedure for assembling the system is as follows.

- ① Assemble the projection stand (RM-V112/RMA-V5010).
- 2 Mount a one-link mount unit . (40-inch only)
- 3 Assemble the projection frame (RMF-V4011/V5011).
- 4 Mount the multi-projection unit (RM-V4000V/V5000V).
- Mount the projection screen kit (RMS-V4011/V5011).
- 6 Mount the top board , side board , rear panel.

The basic procedure for assembling the system for rental-use is as follows.

- 1) Assemble the projection stand (RM-V112).
- ② Mount the 2-link/3-link mount unit (RMA-V2050/V2060).
- 3) Mount the multi-projection unit (RM-V4000V) to the projection cabinet (RMF-V4011R).
- (4) Mount the projection cabinet (RMF-V4011R).

The above procedure is recommended. It is explained below.

1) Projection Install Tables (RM-V112/RMA-V5010)

Place the installation tables (RM-V112) at the specified position and link them together with the bolts and nuts specified.

First tighten the bolts and nuts temporarily, and after all have been linked, check their height differences and if they are horizontal before tightening the nuts and bolts firmly.

Do not tighten the adjusters at the legs as their final positions have to be adjusted after assembling all units.

To install at a height greater than the installation table when not using this table, make sure the strength is greater than required.

2 Mount Unit (RMA-V2050/V2060)

Place the mount unit on the stand and join them using the specified bolts and nuts.

As the horizontality, difference in level, etc. of the mount units form the basis of the whole system assembled, assemble them accurately.

If gaps are formed between the mount unit and the stand due to the difference in height, use the floor leveler of the stand to adjust the height, or place spacers between the mount unit and stand (metal plates about 1 to 2 mm thick).

When using several mount units, adjust their height, horizontality, etc.

In the case of the system for rental-use, mount the conventional mount units (RMA-V2050/V2060) using the conventional method. For details, refer to the RM-V2000A technical manual.

③ Projection Frame(RMF-V4011/V5011)

Assemble the frames from the bottom. (Assembling them vertically will make it difficult to adjust their left and right positions.)(fig. 3-14)

Position them while aligning their front and back sides. (fig.3-15)

From the second level, the stopper pins will go into the units below as the cabinet approach these units and the position is fixed.

Next, adjust the front/back/left/right positions to the units below, and tighten the hexagon head bolts in the vertical and horizontal directions.


△During the above procedure, the table holding the projection units will not be secure.

Take note that as a result, the table may project out when the cabinet is tilted.


7	8	9
4	5	6
1	2	3
	\bigcirc	


3	6	9
2	5	8
1	4	7
	X	

(Fig. 3-14)




Adjust it with the front as a reference. (Fig. 3-15)





4 Multi Projection Unit (RM-V4000V/V5000V)

The Multi-Projection Unit is designed to be mounted from the back of the cabinet normally. If sufficient space cannot be left at the back, it can be mounted from the front.



Mount from back


(Fig.3-18)


a When mounting from the back

[1] Pull the table of the cabinet to the back. (Fig. 3-19)


- [2] Insert the (M5 \times 35) into the holes (Fig. 3-20) on the table. (To prevent the table from moving when placing the projection unit.)
- [3] Place the multi-projection unit on the table and decide the position.

 The position should be so that the front of the multi-projection unit will touch the metal fixtures while the sides touch the guide fixtures (right side as viewed from the screen side). (Fig. 3-21)
- [4] Secure the multi-projection unit to the metal fixtures of the cabinet with the four (M5 \times 50). (Fig. 3-22)
- [5] Remove the inserted into the table at step 2, and push in until the table touches the stopper.






(Fig. 3-21)



(Fig. 3-20)






(Fig. 3-22)


b When mounting from the front

- [1] Remove the two stoppers and two metal fixtures from the cabinet. (Fig. 3-23)
- [2] Pull the table to the front.
- [3] Insert the screws (M5 \times 35) into the holes on the table.
- [4] Place the multi-projection unit on the table.
- [5] Attach the metal fixtures to the table.
- [6] Decide the position of the multi-projection unit and attach it to the metal fixture with the four (M5 \times 10). (Fig. 3-24)
- [7] Remove the screws inserted into the table at step [3], and push in until the stopper can be attached.

 *As there are no stoppers at the back, be careful not to push the table in excessively.
- [8] Re-tighten the stopper at the initial position.
- [9] Pull out the table until it touches the stopper.
- [10] Secure the cabinet table to the cabinet with the two (M5 \times 35).










5 Projection Screen Kit (RMS-V4011/V5011)

[1] Mount the screen unit serving as the reference. Basically, mount from the center unit at the bottom.

ⓐ If the number of units arranged are odd (E.g.: $3 \times 3=9$ screens)


- Adjust the screen unit to the cabinet at the center of the bottom level and temporarily tighten the linking bolts. (Do not tighten tightly.)
- · Adjust the left and right balance with your hand and tighten the linking bolts tightly so that the two centers coincide.



(Fig. 3-25)


(b) If the number of units arranged are even (E.g.: $4 \times 4=16$ screens)

- Adjust the screen unit to the right cabinet (or left cabinet) at the center two cabinets of the bottom level and temporarily tighten the linking bolts. (Do not tighten tightly.)
- Adjust the left side of the screen unit attached and left side of the cabinet (rights sides if the screen unit was attached to the left cabinet at the center) so that they are aligned precisely with your hand, and tighten the linking bolts.
- Join the left side (or right side) screen unit to the unit mounted first as closely as possible.



(Fig.3-26)

- [2] Join the next screen beside the screen mounted as the reference and mount the remaining screens in order. (Stack them from the bottom to the top.)
- [3] If necessary, attach the screw rivet (BEC1082) provided as the accessory of RMS-V4011. (Fig. 3-27)




(Fig. 3-27)

* This part is used to shield the light leaking from the big hole (ø 8) on the outermost side of the left and bottom projection units (diagonally shaded part in Fig. 3-28) after installing the system. Use it if necessary.

Screen units with this rivet cannot be attached outside the area indicated by the standing lines in fig. 3-28.

(It will not connect to the adjoining units.)




(Fig. 3-28)

<Note>

- Do not mistake the top and bottom of the screen unit. The side with the longer screw projecting out (side with transportation screw) is the top and the side with the 8 mm hole is the bottom.
- Before mounting the screen unit to the cabinet, check that the transportation screw, protection panel, and black tape have been removed. (Do not remove the protection panel on the outer-most side when installing the system.)
- · Always tighten the linking bolts of the cabinet and screen unit with your hands, and tighten them as firmly as possible.
- Put on gloves when stacking the screen units for protection and perform in twos.
- To prevent the lenticular sheet from damage, mount the screen unit gently and do not subject it to vibration and shock.
- When the screen units are stacked, the head of the panel fixing screws and 8 mm holes will engage. When stacking the upper screen unit, make sure that it does not brush the lower screen unit as it has panel screws projecting out.


(6) Top panel, Side panel, Rear panel

As this system is of the rear projection type, it must be enclosed to avoid exposure to external light. (Fig.3-29)




Installing the Enclosure

The panels can be attached easily by using the linking holes of the unit. (See Fig. 3-30)




 As shown in Fig. 3-31, attach the top panels and side panels starting from the top panels at the center outwards. Attach the side panels from the top downwards. The rear panels can be attached in any order.




(3) Attaching the Multi Projection Unit (RM-V4000V) to the Projection Cabinet (RMF-V4011R)


The figure shows the assembling procedure of the left attachment. Assemble the right attachment in the same way. The parts on the right side of the screen are R and those on the left side are L from the view point against the screen.

(1) Attach the attachments R and L (BNG1173, 1174) to the front of frames R and L (BNG1207, 1208) using the screw (M5 \times 15).




(2) Insert the claws of holders R and L (BNG1150, 1151) into the slits of frames R and L, rotate them as shown in the figure, and attach using the screws (M5 \times 15). (2 pieces \times 2 locations).







*Drop the screw-lock fluid to screws so as not to loosen.(Right and left)




(4) Attach the parts assembled at steps (1) and (2) onto the multi-projection unit. Attach the attachments R and L to frajmes R and L. using the screw (M5 \times 15) as shown in the figure, and attach the attachments R and L to the rear of the projection unit using the screws (M5 \times 50). (2 screws \times 2 locations).



(5) Paste spacer A (BMR1073) to the top board of the multi-projection unit and spacers B (BMR1074) to the two sides at the position shown in the figure after peeling off the seal.




(7) Attach the attachments R and L to the unit through the top board of the unit using the screws (M6 \times 20) and then attach attachments R and L to the unit from the back using screws (M6 \times 20). (2 screws \times 2 locations).



*Drop the screw-lock fluid to screws so as not to loosen. (4 points)


(8) Check the Focus and reajust if necessary.

- - (9) Attach the cover (BNE1012) to the top board of the unit using the four screws (M5 \times 15).




(6) Insert the multi-projection unit from the rear of the


unit in this state.




(10) Attach the adjuster (BEF1011) attached with a nut (M8) to the rear holders R and L (BNG1205 and 1206).




- (11) While tilting the parts assembled at step 10, insert it into the holes on the shoulder of the multi-projection unit and attach with the screws (3 \times 12). (2 screws \times 2 locations). Furthermore, pull up the adjuster to the top of the unit while rotating it, and pull down the nut to the rear holders R and L while rotating it to secure the projection unit.
- * Tighten the nuts tightly.



(12) Attach each rear panel (BMR1069, 1070, 1071, 1072) to the unit and the rear holders R and L using the screws (3 \times 8). Furthermore, to cover up the gap at the top of the projection unit, paste the hinder panel (BMR1075) over the top board and projection unit.



[After Completion]




4' Mounting the Projection Cabinet (RMF-V4011R)

Projection cabinet can mount to use the conventional method. For details, refer to the RM-V2000A technical manual.

5. SPECIAL INSTALLATION

(1) Wall inset

• If removing the screen after installing the system, the person must go behind the screen (diagonally shaded part of the figure). Therefore when insetting the unit in the wall, careful take this into account before installation.




• When fixing the screen into the wall, space for placing your hand inside the wall at the top, bottom, right, and left will be required in addition to the above in order to attach and remove the screen.

(2) Diagonal installation

• This system cannot be placed facing upwards or downwards and diagonally. Always place it horizontally. However, Multiprojection unit (RM-V4000V/V5000V) alone can be tilted at the top, bottom, left, and right up to 90 deg. Installation of special order screens and cabinets should also become possible in the near future.

(3) Architrave processing

- When enclosing the screen with a frame, etc., add 15 mm to the dimensions of the assembled screen at the top, bottom, left, and right.
 - * Perform framing constructions after assembling the screen.



- If light leaks from the rear space after constructions, place a blind plate over the rear.
- No one should climb onto the top board.

(4) Upside down installation

· Not possible

(5) Hanging from ceiling

· Not possible

CHAPTER 4. ADJUSTMENTS

1. ADJUSTMENT PREPARATIONS

(1) Wiring

1) Connection of Power Supply


- The power supply can be connected to up to 3 units in a series using the AC outlets of Multi projection units. Connect the three units as one system to the external outlet.
- The AC plug of Multi projection unit is a 3P with a ground pin. When connecting it to a normal outlet, use an exclusive 3P AC adapter.
- The AC plug of Multi projection unit is a 3P with a ground pin. To prevent electric shocks, connect the ground pin to the ground when connecting the power supply.

2 Connection of signal cable

Use coaxial cables. Normally, if less than 15m, use 3C-2V. If less than 30m, use 5C-2V.
 The signal transmission equipment and Multi projection units should be as close as possible to each other.

③ Connection of ABL link cable

• By connecting the ABL link cables in cascade form, control signals (RS-232C, remote control signal) can be transmitted to all the units.



(2) Wiring Handling

- Except for short-term installations such as events, etc., in normal long-term installations, adjust the length of the wiring appropriately taking into consideration the overall route to be wired.
- Make sure the connection terminals are not subjected to direct weight and force. Tie the wires up in short-term use and bind them up properly in long-term use.

(3) Aging

 After turning on the power, input the 100% white signal or moving images, and perform aging until Multi projection unit stabilizes (about 1 hour). If adjustments are performed without performing aging, as Multi projection unit will warm up and stabilize, convergence and white balance will become incorrect.

(4) Adjustment Signals

 Use the composite video signal for adjustments created in the multi video processor. When converters not creating the signals for adjustment are used, supply the signals for adjustment from equivalent signal sources (signal generator, LD player, etc.)

Especially for RGB input signals, adjust them by connecting the model (PC, etc.) actually used.

©Generally Required Signals

Adjustment	Signal Name
Screen center Screen size adjustment	Monoscope
Convergence adjustment	Crosshatch Tilted crosshatch
White balance adjustment	White signal (Can be linearly varied between 0% and 100%) Or window step
Linear white adjustment	Window step
Total adjustment (Color, tint, etc.)	Moving image (scenery, faces) Color-bar, etc.

(5) Equipment Required for Adjustments

The following are required for the adjustments performed during the set-up of Multi projection unit.

Equipment	Role	Required Function	Recommended Model	Remarks	
Personal Com- puter	For adjusting	RS232C communication function		Pioneer can provide adjustment soft- ware for NEC 98 or PC/AT windows.	
Adjusting re- mote control	For adjusting		Pioneer RU-V107	Prepare a Personal Computer or this remote control for adjustment.	
Signal genera- tor	For generating white balance and color tint adjusting signals	Gray scale White (% variable)		Especially white (% variable) is important. (Cannot replace with LD, etc.) Use signal generators of this class at the least.	
Adjusting LD	Total image quality adjust- ment	1	LD demonstration 2 (Not for sale)	Perform color, or final and overall adjustments with the actual images.	
LD player	For playing adjusting LD	With still function	Pioneer LD-V4400		
Cable	For connecting RS-232C	D-Sub 25-pin (male) straight cable		The length differs according to the place adjustment is performed at, but prepare at least 10 m.	
	For connecting video			Sur propara di todoi vo	
Adjusting LD	For generating signals for adjusting size, convergence	Monoscope Crosshatch	Test disc GGV series	Use for adjusting screen size and center.	

2. BEFORE ADJUSTMENTS

(1) Convergence Adjustment Memory

Multi projection unit incorporates altogether 8 convergence adjustment memories.

There are two types of convergence memories. They are as follows;

- . Memory automatically selected according to the signal input (MEMORY 1 TO 4)
- Memory that can be set manually using external computers or remote control (MEMORIES 5 TO 7).

The memory selected automatically is set according to the setting of the TV SYSTEM described in the next section.

	Memory Area	Standard Adjustment Mode				Manual Mode			
Input Function	Input Signal	1	2	3	4	5	6	7	FACTORY
VIDEO Y/C	NTSC	Ç	×	×	×	С	0	0	
RGB	PAL	×	0	×	×	C	<u> </u>		
RGB	20kHz <fh≦28khz< th=""><th>×</th><th>×</th><th>\circ</th><th>×</th><th>0</th><th>0</th><th>0</th><th></th></fh≦28khz<>	×	×	\circ	×	0	0	0	
	28kHz <fh≦35khz< th=""><th>×</th><th>×</th><th>×</th><th>0</th><th>0</th><th>0_</th><th>0</th><th>) •</th></fh≦35khz<>	×	×	×	0	0	0_	0) •

fH: Horizontal sync frequency of the input signal. (errar: ±2kHz)

: Enable to select.

X : Disable to select.

: Disable to select. Only possible to read out to the memory area enable to select.

There are altogether 7 memories (MEMORY 1 to 7) which can be adjusted.

The FACTORY memory stores the convergence adjustment data when the NTSC signal was input.

(2) TV System

The TV system determines the control of the whole unit (convergence, deflection) according to the signal input. Set it according to the signal input.

The convergence adjustment memory is determined according to the setting of the TV SYSTEM. The contents are as follows.

TV SYSTEM	VIDEO Input Y/C Input		RGB I	nput	
NTSC	MEMORY-1		MEMO	RY-1	
PAL	MEMORY-2		MEMORY-2		
AUTO	NTSC Input	MEMORY-1	NTSC Input	MEMORY-1	
	PAL Input	MEMORY-2	PAL Input	MEMORY-2	
			*20k to 28k Input	MEMORY-3	
		-	*28k to 35k PAL Input	MEMORY-4	

Apart from the above memories, memories 5 to 7 can be set manually and using the remote control.

The horizontal input frequency has a ±2 kHz error.

When TV SYSTEM=AUTO

<VIDEO, Y/C Input)

- Selects the convergence memory from MEMORY-1 or MEMORY-2 automatically according to the signals input (NTSC/PAL). <RGB Input>
- · Automatically selects the convergence memory as follows.

For NTSC input:MEMORY 1

For PAL input: MEMORY 2

Horizontal frequency 20 kHz to 28 kHz input:MEMORY 3

Horizontal frequency 28 kHz to 35 kHz input :MEMORY 4

When TV SYSTEM=NTSC

• The convergence memory is always set to MEMORY 1 regardless of the input signal.

When TV SYSTEM=PAL

• The convergence memory is always set to MEMORY 2 regardless of the input signal.

In standard settings, MEMORIES 1 to 4 are selected as described above, but MEMORIES 5 to 7 can be selected if preset using the remote control or commands of the Personal Computer.

When the input signal is NTSC only or PAL only, by setting the TV SYSTEM to NTSC or PAL, smooth input switching (no image distortion) will be possible.

Normally, no problems will be encountered with the above method. But if two or more types of signals are input to the same input function, convergence adjustment has to be performed according to the respective input source. (For example, when there is signal phase difference in each input source, when connecting several PCs and switching from outside, etc.). In such cases, use convergence adjustment memories 5 to 7 (MANUAL 1 to 3). The 5 to 7 convergence adjustment memories can be switched from outside using the Personal Computer.

Finally, examples of main uses by the system of these units are provided below.

For details of how to set the convergence memory (specific example), refer to "3. Examples of Main Uses of Cube System".

(3) White Balance Adjustment Memory

ADJUSTMENTS has altogether six white balance adjustment memories.

Color mode 1 (Normal)	VIDEO, Y/C input memory RGB input memory Factory shipment memory
Color mode 2 (Re-expose)	VIDEO, Y/C input memory RGB input memory Factory shipment memory

Four memories can be actually adjusted except the factory shipment memory. The factory shipment memory contains the normal white balance adjustment data and re-expose white balance adjustment data.

By setting to color mode 1 using the rear panel switch, etc., the white balance adjustment data can be switched by synchronizing with input switching. This is the same for color mode 2. If it is necessary to change color modes 1 and 2 using the input function, connect the PC and switch each time it is necessary.

(4) Combined Use of Remote Control and Personal Computer

Although it is possible to connect both the remote control (RU-V107) and Personal Computer, adjustments cannot be performed using both at the same time.

Remote control, Personal Computer commands and rear panel switches operated the latest are given priority. When the adjustment mode is set by the Personal Computer while adjusting with the remote control, the adjustment mode will be set by the Personal Computer, disabling adjustments to be performed using the remote control. If the adjustment mode is set by the remote control using adjustments by the Personal Computer, adjustments by the Personal Computer will be disabled. Furthermore, if the rear panel switches are operated when the adjustment mode is set by the remote control or Personal Computer, the adjustment mode is exited and the rear panel switches operations are started.

(5) Memory of Adjustment Data and Settings

When adjustments are ended in the adjustment mode such as convergence, white balance, etc., always exit the adjustment mode (AJN for Personal Computer, ADJ OUT key for remote control). If the power is turned off (AC OFF) without exiting the adjustment mode, a part of the adjustment data will not be preserved in the memory.

The input function, MULTI ON/OFF (peripheral light amount switching), COMBINATION ON/OFF (ABL link switching), COLOR MODE 1/2 (white balance switching), TV SYSTEM setting, and convergence memory state setting will be preserved in the memory only when the power is turned off using the remote control, command of a Personal Computer (POF) or the rear panel tact switch. The AC ON/OFF will not allow data to be preserved in the memory.)

When starting or stopping the system by AC ON/OFF in an installation condition for demonstration, use this method to preserve the conditions in the memory first.

(6) Giving IDs


When several Multi projection units are used to compose the 9 screens or 16 screens (multi-screen), the ID is used to differentiate between Multi projection units. When the units are given IDs, by connecting the ABL link cable, commands can be transmitted by specifying the ID, and it is possible to operate only Multi projection unit corresponding to that ID by remote control operations.

<Giving IDs using Personal Computer>

Commands: IDC (IDC CLEAR) ;Clears the ID given IDS (ID SET) ;Gives an ID

The IDS is valid only when no ID has been given. It will be valid from units nearest to the personal computer (remote control).

(Example) 4 screens • When giving IDs first using Personal Computer.



By sending commands in this order, IDs can be given to each Multi Projection Unit.

The characters that can be used for the IDs are 0 to 9 and A to F, and * (capital and small letters are not differentiated). The * can be used in the following way.

**IDC :Clears IDs given to all units

*1AJY :Only units which have IDs whose 2nd digit is 1 enter the adjustment mode.

2*IN1 :The input function of only units which have IDs whose 1st digit is 2 is set to VIDEO.

ADJUSTMENTS


<givir [1]</givir 	ng IDs Using the Remote Control> Enter the adjustment mode.
[2]	The main menu will be displayed. Press the 1 key. Select "1. ID CLEAR/SET/SELECT"
[3]	Check that the ID display at the top left of the screen is "" and press the 1 key. Select "1.ID SET".
	If an ID has already been given, press the key, select "0. ID CLEAR" of the main menu, return to "[1] Enter the adjustment mode." and give the ID.
[4]	As the ID input standby state is set, press the O to 9, A to F keys, and input the ID.
[5]	To use the multi-screen unit, return to "[1] Enter the adjustment mode." and given an ID to the next unit.
<preca< td=""><td>autions for Giving IDs using the Remote Control and Personal Computer></td></preca<>	autions for Giving IDs using the Remote Control and Personal Computer>
clea	nmunication cannot be performed with units connected using the ABL link cable, after units whose IDs have been ared. When the command "** IDC" shown in the figure on the previous page is performed, only the first unit can be trolled. Using the command "11 IDS" will enable the 2nd unit and onwards to be controlled.

When IDs are set as this, the unit connected next can be controlled.

3. EXAMPLES OF MAIN USES OF CUBE SYSTEM


(1) Expansion/Individual Switching at Multi Video Processor Side-

General example of RM-V2000 series



Input Function) Fixed mainly at RGB
TV SYSTEM) Fixed at NTSC or PAL
Converter data required at display) One

(2) When Switching the Cube Input Function-Display example expected on RM-V4000V system



Input Function) By switching Y/C↔RGB, switches

expansion/individual (video distortion is great)


TV SYSTEM) Composite or Y/C signal system Fixed at NTSC

RGB AUTO

Converter data required for display) Composite signal system-One RGB-One

(3) When Switching Source Inputs to Multi Video Processor (1)-

When using Pioneer's new Multi Video Processor




Input Function) RGB TV SYSTEM) AUTO

Converter data required for display) One

- *The phase difference of each input source can be adjusted at the Multi Video Processor side.
- *When switching between the same NTSC, it is needed to switch by CUBE side.

(4) When Switching Source Inputs to Multi Video Processor (2)-

When using Pioneer's Multi Video Processor




Input Function) Y/C

TV SYSTEM) Fixed at NTSC

Converter data required for display) Two

* For example, adjust LDP-1 with MEMORY1 and LDP-2 with MEMORY 5 (or 6 or 7) and switch data when switching LDP

(5) When Using Two Multi Video Processors without Frame Adjusting Function



Input Function) RGB TV SYSTEM) AUTO


(Or synchronize with the switching of Multi Video Processor 1/2 and switch NTSC

fixing/PAL fixing)

The converter data required for display) Two

* MEMORY1/2 is automatically switched by the microprocessor

(6) When Single Screen is Used




Input Function) RGB TV SYSTEM) AUTO

Converter data required for display) Two

* For example, adjust VGA with MEMORY4 and MAC with MEMORY 5 (or 6 or 7), and switch the signal selection data

(7) When Switching the Source Input to the Multi Video Processor



Input Function: RGB TV SYSTEM: AUTO

Converter data required for playing: Three


For example, set as follows, and switch the data to input using RS-232C.

Expanded NTSC:MEMORY 4
Personal computer 1:MEMORY 5
Personal computer 2:MEMORY 6

4. SCREEN ADJUSTMENTS

(1) Adjustment Flowchart

The following shows the order for performing the adjustments generally required in the setup of the multi-projection system. For details, see the descriptions on the next page and later.



(2) Convergence Adjustment Flowchart Find the center of the screen (P.67) NOTE Do not adjust center using convergence such as GH STATIC GV STATIC Input the adjustment signal (P.67) Green POINT CONVER MODE ,etc. Considerable load will be imposed on the adjustment Using only green, adjust the circuit, causing malfunctions. 2 (P.68) center of V PHASE H PHASE SIZE, H-BLK R, H BLK L adjustment required is the setting OK to Hori-NO zontal 92% and Vertical (1) 93% with NTSC input? (2) RGB others YES Is horizontal fre-NO quency of input signal above 20 kHz? SIZE adjustment not required YES Perform rough ad-Turn on RGB justment in dynamic convergence adjustment Adjust color deviation at RGB (P.71) right side of screen using H BLK R If familiar with H-BLK convergence ad-Adjust color deviation at observe iustment left side of screen using H BLK L here Adjust joining of peripheral screens in green point conver-(P.75)Finely adjust center position using gence mode (P.68) H PHASE H-BLK 12 Adjust linearity of green Adjust horizontal size at (P.75) point convergence mode (P.74) right side of screen using H SIZE obse Adjust green, red, blue color de-13 Adjust vertical size using V SIZE viation in point convergence (P.75) mode V LINEARITY H SIZE Enter point convergence mode adjust horizontal size of (P.76)left side of screen of green observe here When color deviates at both sides of screen Adjust left side of screen of red in (P.76) the same way Adjust left side of screen of blue (P.76) in the same way observe

here


POINT CONVER ADJ

(3) Convergence Adjustment Contents

☐ Measurement of screen center

The center can be found easily by pasting threads in the spaces of the protection panels at the screen frame.

The $\hfill\square$ numbers correspond to the numbers in the flow-chart.



2 Adjustment signal input


For adjusting size...Monoscope, etc.(EX.LD Test disc GGV1013, FRAME NO. 18001)

For screen joining, linearity, color adjustment...Use adjustment signals such as , cross-hatch, etc.

(EX.LD Test disc GGV1013, FRAME NO. 14401)

If signals are created in the multi video processor, use them.

For RGB inputs, generate the adjustment signals conforming to the above using the models actually used (PC, etc.), and check them via the expander actually used.



Note


Depending on the user memory used, the image may become distorted as shown in the figure on the right. In this case, before adjusting the center, adjust HBLKR and HBLKL first.

3,4,7 center adjustment

Set to only green and adjust the center with V PHASE H PHASE.

When MULTI ON, as V PHASE does not move, adjust it at the splitter side.

If not possible, adjust with V STATIC





NOTE

Do not adjust the center using convergence such as GH STATIC | GV STATIC

Green POINT CONVER MODE , etc.

Considerable load will be imposed on the adjustment circuit, causing malfunctions.







The center adjustment by H PHASE V PHASE adjusts the timing for displaying video signals and therefore current is not supplied to the deflection york.

Current is on the other hand supplied to the convergence york in the center adjustment by convergence such as GH STATIC GV STATIC GREEN POINT CONVER MODE, etc. and therefore imposes load on the circuit.

Current is also supplied to the vertical deflection york with V STATIC. If supplied excessively, distortion will occur as shown in the right figure.





No distortion occurs in adjustments by V PHASE.




Explanation of H BLK L and H BLK R Adjustments

H BLK L and H BLK R adjustments are performed to obtain the optimum convergence adjustment wave form when the display range changes due to changes in the H SIZE and frequency.







When size is increased with H BLK L and H BLK R not adjusted.







Image after H BLK L and H BLK R has been adjusted.

5 H BLK R Adjustment

Output all three colors R,G,B, observe the right side of the screen, and adjust with HBLK R so that the color stops deviating.









When $\ensuremath{\boxed{\mbox{H BLK R}}}$ adjustment is not properly performed

- NOTE -

When HBLKR is adjusted so that the three colors R,G,B do not deviate, if the horizontal line distortion shown in the right figure occurs, move HBLKR until the distortion disappears with color deviation maintained.




6 H BLK L adjustment



NOTE


There are points at which the screen does not move even though the HBLK L value changes. This is not a malfunction.

After adjusting HBLK L, the left side of the screen may be smaller than the right side of the screen. As the DOINT CONV, MODE of the procedure will be performed later, ignore it now.



9 V SIZE adjustment


Do not observe the bottom part of the screen.



8 H SIZE adjustment

Set to only green, observe the right side of the screen, and adjust the data amount in the horizontal direction using H SIZE.

Do not observe the left side of the screen.




9' V SIZE LINEARITY Adjustment

Those familiar with the convergence adjustment can adjust the bottom part of the screen in addition to the top part of the screen using V SIZE and V LINEARITY.


Reference Information

The horizontal 92% and vertical 93% positions in NTSC inputs are the positions shown in right figure, for Laser Disc test disc GGV1013 monoscope signal (frame No. 14401).



 $\underline{10}$, $\underline{11}$ point convergence adjustment

12, 13




OIn point convergence adjustment, the 25 points set on the screen can be adjusted individually. In addition, the area of the four sides of the screen can be adjusted.


NOTES

- The adjusting points set by the circuit are fixed at the positions shown in the figure. In some cases, the OSD display may
 deviate. But the actual adjusting points are as shown in the figure.
- Deviation between two adjusting points will naturally be corrected when the deviation of each point is corrected.


Movement of screen by point convergence adjustment




In addition, there are three other area adjustments.




In adjustment step 111, observe the external part of the screen, adjust the 16 adjusting points there, taking note of linearity in the peripheral area such as joining with other screens, crosshatch, etc.
(Ignore the distortion inside the screen.)







In adjustment step 12, adjust the inside of the screen and produce linearity.





The following are examples of adjusting points in point convergence adjustments and their movements on the screen.

Displayed OSD Movement on screen L











NOTE

If only one point is moved greatly in the point convergence mode, it may not move in areas smaller than the desired adjusting area.

In this case, adjust while moving the other points slowly.






11 Dynamic convergence

In addition to the point convergence mode, conventional convergence adjustments can also be performed.

V • Convergence adjustment



8


() STATIC

111 Dynamic convergence

H • Convergence adjustment


8

() STATIC



(4) White Balance Adjustment Flowchart

When adjusting the expanded screen: Multi on, Comb on ABL off)
ABL switch setting



(5) White Balance Adjustment

1 Before Adjusting White Balance

Adjusting the white balance means to adjust the color tone. This adjustment is necessary for the screen to become white when the white signal is input, and black when the black signal is input. In the actual adjustment, the bias and gain of the CRTs for the three colors (R, G, and B) are adjusted so that the screen becomes the same color tone.


Before performing the white balance adjustment, complete the convergence adjustment first. If not performed properly especially where the screens join each other, the colors of the screens may not join. When performing the adjustment, take into account the position and height of the sets, height of the eyes of those viewing the screens, and distance to the screens. There are two types of screen white balance data-video, Y/C input and RGB input. The data is switched when the screens are switched. For RGB input, COLOR, TINT, and SHARPNESS cannot be adjusted. When the ABL is off, ABL LEVEL cannot be adjusted.

② ABL switch Setting


In ABL setting, when the luminance of units completely match the unit which ABL voltage is controlled the most and luminance is lowest, the luminance of the whole multi-screen becomes low.

The ABL switch is able to switch the amount of ABL control voltage when ABL is on.


This switch has three modes-ABL1, ABL2, and ABL3.




Recommended Usage of Modes




At shipment, the ABL switch will be set to ABL3.



Remove the ⓐ panel of the rear panel shown in the left figure. When this panel is removed, there will be two printed circuit boards as shown in Fig. 4-1.




The ABL switch is at the bottom right of the board below the two printed circuit boards.




Note

The position of the switch differs according to the product lot. If the switch is not located at the position shown in the above figure, it will be located at the position in the figure below.



Remove the six screws 8 to 6 of the rear panel in the left figure.



-Note

It is hazardous to open the rear panel because electric shocks may be caused by the high voltage circuits, etc. inside. As the rear panel must be opened to use the ABL switch, contact our servicemen if the switch needs to be operated.

3 Adjustment Flow

Single screen

[1]Perform the adjustment using the full white (variable by %) signal generator.

[2]Perform the COLOR, TINT, and SHARPNESS adjustments.

[3]Note down or memorize in the PC memory the data after the rough adjustment.

[4] Check the joining of the screens using the animated images.

[5]If the screens are not joined properly, adjust. (Check with animated images.)

[6]If not joined properly, return to the data in (2) and perform the adjustment again.

4 Initial Settings

CONTRAST 1

LUNIRASI IV

BRIGHTNESS Depends on auto W/8

ABL GAIN 255

ABL LEVEL 128

LINEAR WHITE 200

R,G,B,HIGH LIGHT

R,G,B,LOW LIGHT

#SHARPNESS

#TINT

#COLOR

Data at shipment

#Must be set only for VIDEO and Y/C screen.

TINT adjustment cannot be performed for PAL inputs

CONTRAST, LINEAR WHITE, ABL LEVEL, ABL GAIN adjustment values considerably affect the ABL operation.

Basically, fix the CONTRAST level to 170, if the ABL function feature well.

⑤ Rough Adjustments

(1) Black level adjustment

Signal:White 10%

Adjust R LOW, G LOW, and B LOW to the point where the CRT starts lighting up.

(2) HI LIGHT adjustment

Signal:White 50%

Adjust R HI, G HI, and B HI so that the CRT becomes white. First, adjust so that the brightness of R, G, and B becomes the same, and while maintaining that brightness, balance R, G, and B, and adjust so that the CRT becomes white.

(3) LOW LIGHT adjustment

Signal:White 20%


Adjust R LOW, G LOW, and B LOW so that the CRT becomes gray.

(4) Convergence adjustment

Signal:White 50%, 20%

Repeat (2) to (3) and converge the light. If the HI LIGHT of

R, G, and B is moved, their LOW LIGHT will change greatly. Therefore, pay special attention to the value of the LOW LIGHT.




6 LINEAR WHITE adjustment

When white peak signals such as WINDOW are input, due to the characteristics of the Blue CRT, there is a tendency for the peak to become yellow compared to other colors. The linear white adjustment is performed to correct this tendency.

Blue becomes weak when data is set to UP and strong when set to DOWN. If Linear White is added excessively, the ABL voltage becomes unbalanced and the medium luminance of blue may be erased, etc.

Also make sure that the blue is not blur when MULTI ON is set because the top left and bottom left of the screen are affected first.



ABL GAIN adjustment (White 100%)

The ABL GAIN adjustment adjusts the white 100% luminance of a unit to other units after low luminance and medium luminance have been adjusted.

Normally, when white 100% is input, ABL is imposed and the current is controlled so that the current flowing in the CRT does not exceed a certain level. Even if the current flowing in the CRT of each unit is the same, the difference in the characteristics of each CRT will cause their luminance to become inconsistent. The ABL GAIN adjustment converges this inconsistency. It adjusts the ABL current flowing virtually.

In white 100% inputs, as the ABL works efficiently, the luminance drops, when the ABL GAIN of a unit with high luminance is decreased, use this adjustment to adjust its luminance to the other units.

Turn off ABL in the adjustment.

Normally set ABL GAIN to maximum.

ABL LEVEL adjustment (White 100%)

The ABL LEVEL adjustment controls the inconsistency of the ABL control voltage of each unit when ABL is on.

- [1] Set the ABL of all units to ON.
- [2] Turn on and off the ABL of each unit to change the luminance.
- [3] For units whose luminance becomes dark, turn UP the ABL level and turn on and off the ABL until the luminance stops changing.
- [4] For units whose luminance does not change, turn DOWN the ABL level to the point just before the luminance becomes dark.
- [5] Perform steps (2) to (4) for all the units, change white from 0 to 100% and check that the ABL does not work abnormally.

Adjustment Using Moving Images

The adjustment using images adjusts the overall joining of the screens by loading discs used by users (for actual performance) and discs always used for adjustments. View the overall screen and adjust the screen with the greatest difference to the other screens. The specific method is; at first, focus on the brightness, make the brightness the same, and correct the differences in R, G, and B. Pay the attention that changing the HI LIGHT value affects the balance of the LOW LIGHT considerably. Strictly speaking, as W/B deviation cannot be checked using moving images and W/B cannot be corrected just by performing fine adjustments, check using rough adjustments.

If the DEMONSTRATION-II LD can be used, correct the following points.

[1] Dark images (Almost black image:FRAME No. 32300 to 33200)

Check that the brightness of the screens appears the same.

Check that black is not blur or emphasized.

[2] Bright images (Almost white image:FRAME NO. 7400 to 8100)

Focus on where the brightness is the same, especially the white peak, and check in the same way as for dark images in (1).

[3] Skin color images (FRAME NO. 26900)

Check if the skin color of a face image is the same as in the other screens.

[4] Colored images (FRAME NO.19100)

Use when performing adjustments during VIDEO input or Y/C input. Adjust so that the colors of vegetables, fruits, etc. are of the same brightness and same depth.

If consistency cannot be adjusted with animated images, re-input the rough adjustment data and re-adjust.

➡ View the moving images. If a screen is darker than the others due to excessive ABL, increase the contrast and decrease the R, G, B High Light so that ABL is suppressed.

[5] White peak images (FRAME NO.08272)

Readjust the Linear White adjustment, if the whiteness on the white peak screen differed on each screen.

Confirm the moving images

View the moving images. If W/B is incorrect, set to rough adjustment. If the luminance of the multi-screen is dark or inconsistent, set the ABL switch.

1 Precautions

1 Avoid adjusting with images with high tube radiation (FRAME NO. 13590)

If only one spot is bright in a very dark image, the screen will look bright due to the spot.

Refer to the separate sheet for precautions on white balance.

2 Precautions on screen hue

If the hue of the screens is green or yellow, images will not be displayed clearly. The white parts of bright images especially will appear yellow. These images can be made clear by adjusting so that they appear slightly bluish.

However, if made bluish excessively, brightness may appear insufficient due to the CRT characteristics.

3 Color Adjustment (White Balance)

(a)Effects of brightness

- · Take note of dark images which have some high luminance parts.
- The reflected light overlap with surrounding dark parts at the face of the CRT and surface of projection lens, and luminance and hue become different from the adjoining screen.

(b) Differences caused by visual points

- Although the joined parts of multiple screens are improved by peripheral light amount correction, the image may not be natural at some points. (Adjustment of vertical direction using the installation table)
- Due to the layout of the red, green, and blue CRTs, when the screens are viewed diagonally, they may appear reddish or bluish (Color shift).
- For multiple screens, as the angles of the left and right screens are different to a viewer, they may appear to have different colors.
- © Before adjustments, have the user check the visual point, and adjust at that point.

(c)

· As the white balance of high light (drive) and low light (cutoff) is adjusted, the color balance at the center points will differ.

(6) External Control by RS-232C

As Multi projection unit is equipped with a RS-232C port, various controls and, white balance and convergence adjustments can be performed by an external computer.

① Interface

1]Connector D-sub 25-pin 2]Pin assignment

PIN No.	Symbo;	Signal Name
1	FG	Frame Ground
2	RXD	Received Data
3	TXD	Transmitted Data
5	CTS	Clear To Send
7	GND	Signal Ground

[3]Baud rate

4800 bps (1200, 2400, 9600, 19200 bps can also be selected)

[4]Data format

Start: 1-bit


Data:8-bit

Parity:0 (No parity)

Stop:1-bit


[5]Connection

DB25



P 0Q

COMPUTER



[6]Protocol

Multi projection unit from computer

ID: 2-Byte(ASC II)COMMAND: 3-Byte(ASC II)

stx ID COMMAND etx

				· · · · · · · · · · · · · · · · · · ·	
stx	ΙD	COMMAND	COMMAND	COMMAND	etx

stx=02h etx=03h

Up to 3 commands possible

stx	ID	COMMAND	ARGUMENT	etx

ARGUMENT: 3-Byte(ASC II)

② RS-232C Commands Table

	C o m mand	Name	Normal Valid	Number Direct	UP/DWN Command	Function
A	ABL	ABL LEVEL	×	0	0	ABL operation link level adjustment (Note 1)
1	AJN	ADJUST NO	×	×	×	Adjustment mode exit
1	AJY	ADJUST YES	0	×	×	Adjustment mode start-up
	AOF	ALL OFF)	×	×	R,G,B all color off
	AON	ALL ON		×	×	R,G,B all color on
	ABG	ABL GAIN	×	0	0	ABL gain adjustment
В	800	BLUE 00	×	0	0	Adjusts BV STATIC
	B01	BLUE 01	×	0	0	Adjusts BV SIZE
	B02	BLUE 02	×	0	0	Adjusts BV LINEARITY
]	B03	BLUE 03	×	0	0	Adjusts MID SIZE
]]	B04	BLUE 04	×	0	0	Adjusts MID LIN
	B06	BLUE 06	×	\circ	0	Adjusts BV SKEW
	B07	BLUE 07	×		0	Adjusts BV KEY
	B08	BLUE 08	×	0000	0	Adjusts BV SUB KEY
	809	BLUE 09	×		0	Adjusts BV MID KEY
	B10	BLUE 10	×	0000	0	Adjusts BV MID S-KEY
	B11	BLUE 11	×	2	0	Adjusts BV 5D SKEW
]]	B12	BLUE 12	X		0	Adjusts BV BOW
i i	B13	BLUE 13	×	0	0	Adjusts BV PIN
	B14	BLUE 14	×)	0	Adjusts BV SUB PIN
	B15	BLUE 15	×) i	0	Adjusts BV MID PIN
1	B16	BLUE 16	×	00000000	0	Adjusts BV MID S-PIN
	B17	BLUE 17	×	9	0	Adjusts BV 6D BOW
1	B18	BLUE 18	×	9	9	Adjusts 8V 3D SKEW
	B19	BLUE 19	×	5	0	Adjusts BV 3D KEY
	B20	BLUE 20	×		0	Adjusts BV 3D SUB KEY
	B21	BLUE 21	×		0	Adjusts BV MID 3D KEY
	B22	BLUE 22	×	5	0	Adjusts BV MID 3D S-KEY
	B23	BLUE 23	×	0	0	Adjusts BV 5D SIZE
1 1	B24	BLUE 24	×	2	<u> </u>	Adjusts BV 4D BOW
	B25	BLUE 25	×			Adjusts BV 4D PIN
	B26	BLUE 26	×	<u> </u>	0	Adjusts BV 4D SUB PIN
	B27	BLUE 27	×)	0	Adjusts BV MID 4D PIN
	B28	BLUE 28	X	~	0	Adjusts BV MID 4D S-PIN
	B29	BLUE 29	×	0	0	Adjusts BV 6D LIN
	B30	BLUE 30	×	0	0	Adjusts BH STATIC
	B31	BLUE 31	×	0	0	Adjusts BH SKEW
	B32	BLUE 32	×	0	0	Adjusts BH BOW
	B33	BLUE 33	×	00	00	Adjusts BH 3D SKEW Adjusts BH 4D BOW
4	B34	BLUE 34				•
	B36	BLUE 36	×) (00	Adjusts BH SIZE Adjusts BH KEY
	B37 B38	BLUE 37	×	000	00	Adjusts BH PIN
		BLUE 38				
- 1			<u> </u>			

Com- mand	Name	Normal Valid	Number Direct	UP/DWN Command	Function
B39	BLUE 39	×	Ĵ	0	Adjusts BH 3D KEY
B40	BLUÉ 40	×	0	0	Adjusts BH 4D PIN
B41	BLUE 41	×	0		Adjusts BH 5D SIZE
B42	BLUE 42	×	-		Adjusts BH LINEARITY
B43	BLUE 43	×	0	0	Adjusts BH SUB KEY
B44	BLUE 44	×	Ĵ	0	Adjusts BH SUB PIN
B45	BLUE 45	× [()	0	Adjusts BH 3D S-KEY
B46	BLUE 46	×	()	0	Adjusts BH 4D S-PIN
B47	BLUE 47	×	0	0	Adjusts BH 6D LIN
B48	BLUE 48	×	0	0	Adjusts BH MID SIZE
B49	BLUE 49	×	2	0	Adjusts BH MID KEY
B50	BLUE 50	×	3	0	Adjusts BH MID PIN
851	BLUE 51	×	0	0	Adjusts BH MID 3D KEY
B52	BLUE 52	×	0	0	Adjusts BH MID 4D PIN
B53	BLUE 53	×	3	Ö	Adjusts BH 5D SKEW
B54	BLUE 54	×	0000000000000000	ŏ	Adjusts BH MID LIN
B55	BLUE 55	l ×	Ö	0	Adjusts BH MID SUB KEY
856	BLUE 56	×		ŏ l	Adjusts BH MID SUB PIN
B57	BLUE 57	×	000	o l	Adjusts BH MID 3D S-KEY
B58	BLUE 58	×	5	ō	Adjusts BH MID 4D S-PIN
B59	BLUE 59	×	ŝ	ō	Adjusts BH 6D BOW
361	P-CONV. ADJ 61	×	×	(Note 2)	Adjusts BLUE point convergence
362	P-CONV. ADJ 62	×	×	(Note 2)	Adjusts BLUE point convergence
363	P-CONV. ADJ 63	×	×	(Note 2)	Adjusts BLUE point convergence
364	P-CONV. ADJ 64	×	×	(Note 2)	Adjusts BLUE point convergence
365	P-CONV. ADJ 65	×	×	(Note 2)	Adjusts BLUE point convergence
371	P-CONV. ADJ 71	×	×	(Note 2)	Adjusts BLUE point convergence
372	P-CONV. ADJ 72	×	×	(Note 2)	Adjusts BLUE point convergence
373	P-CONV. ADJ 73	×	×	(Note 2)	Adjusts BLUE point convergence
374	P-CONV. ADJ 74	1 ×	×	(Note 2)	Adjusts BLUE point convergence
375	P-CONV. ADJ 75	×	×	(Note 2)	Adjusts BLUE point convergence
181	P-CONV. ADJ 81	×	×	(Note 2)	Adjusts BLUE point convergence
182	P-CONV. ADJ 82	×	×	(Note 2)	Adjusts BLUE point convergence
83	P-CONV. ADJ 83	×	×	(Note 2)	Adjusts BLUE point convergence
84	P-CONV. ADJ 84	×	×		Adjusts BLUE point convergence
85	P-CONV. ADJ 85	×	×		Adjusts BLUE point convergence
91	P-CONV. ADJ 91	×	×		Adjusts BLUE point convergence
92	P-CONV. ADJ 92	×	$\hat{\mathbf{x}}$	1	Adjusts BLUE point convergence
93	P-CONV. ADJ 93	×	x		Adjusts BLUE point convergence
94	P-CONV. ADJ 94	×	$\hat{\mathbf{x}}$	(Adjusts BLUE point convergence
95	P-CONV. ADJ 95	×	×		Adjusts BLUE point convergence
A1	P-CONV. ADJ A1	×	×		Adjusts BLUE point convergence
A2	P-CONV. ADJ A2	l ×	×		Adjusts BLUE point convergence
A3	P-CONV. ADJ A3	×	×		Adjusts BLUE point convergence
A4	P-CONV. ADJ A4	×	×	1	Adjusts BLUE point convergence
A5.	P-CONV. ADJ A5	×	×		Adjusts BLUE point convergence
P1	P-CONV. ADJ P1	×	×	1	Adjusts BLUE point convergence

	Com- mand	Name	Normai Valid	Number Direct	UP/DWN Command	Function
В	BP2	P-CONV. ADJ P2	×	×	(Note 2)	Adjusts BLUE point convergence
ĺ	ВР3	P-CONV. ADJ P3	×	×	(Note 2)	Adjusts BLUE point convergence
	BP4	P-CONV. ADJ P4	×	×	(Note 2)	Adjusts BLUE point convergence
1	вні	BLUE HIGH LIGHT	×			Adjusts BLUE HIGH-LIGHT
1	BLW	BLUE LOW LIGHT	×			Adjusts BLUE LOW-LIGHT
	BOF	BLUE OFF	×	×	_ ×	Turns OFF BLUE
	BON	BLUE ON	×	×	×	Turns ON BLUE
	BRT	BRIGHTNESS	×	С		Adjusts BRIGHTNESS
С	CBN	COMBINATION NO	000	×	×	Turns OFF ABL operation link
	CBY	COMBINATION YES	9	×	×	Turns ON ABL operation link
}	CM1	COLOR MODE 1		×	×	Sets white balance data to color mode 1
i l	CM2	COLOR MODE 2	0	×	×	Sets white balance data to color mode 2
	CNT	CONTRAST	×	0		Adjusts CONTRAST
	COL	COLOR	×	\circ	0	Adjusts COLOR
	COF	COLOR OFF	×	×	×	Turns OFF COLOR
	CON	COLOR ON .	×	×	×	Turns ON COLOR
٥	DOF	DISPLAY OFF	×	×	×	Turns OFF OSD display
	DW0	DOWN 10	×	×	×	Decreases adjusting value by 10
	DWn	DOWN n	×	×	×	Decreases adjusting value by n
	DWF	DOWN FULL	×	×	×	Minimizes adjusting value
	DIY	OSD DISP. YES	×	×	×	Enables OSD display
	DIN	OSD DISP. NO	×	×	×	Disables OSD display
G	G00	GREEN 00	×	0	0	GREEN convergence adjustment (Same as BLUE)
	G59	GREEN 59		_		
	G61	P-CONV. ADJ 61	×	0		GREEN point convergence adjustment (Same as BLUE)
Ì	GP4	P-CONV. ADJ P4				
	GHI	GREEN HIGH-LIGHT	×	5	0	Adjusts GREEN HIGH-LIGHT
	GLW	GREEN LOW-LIGHT	×	0	0	Adjusts GREEN LOW-LIGHT

	Com-	Name	Normal Valid	Number Direct	UP/DWN Command	Function
G	GON	GREEN ON	×	×	×	Turns ON GREEN
1	GOF	GREEN OFF	×	×	×	Turns OFF GREEN
	GGH	GET GH CONV DATA	×	×	×	Calls GH convergence adjusting data
	1			i		(For each mode)
ŀ	GGV	GET GV CONV DATA	×	×	×	Calls GV convergence adjusting data
						(For each mode)
	GRH	GET RH CONV DATA	×	×	×	Calls RH convergence adjusting data
						(For each mode)
!	GRV	GET RV CONV DATA	×	×	×	Calls RV convergence adjusting data
]			i		(For each mode)
	GBH	GET BH CONV DATA	×	×	×	Calls BH convergence adjusting data
						(For each mode)
	GBV	GET BV CONV DATA	×	×	X	Calls BV convergence adjusting data
				i		(For each mode)
	GDD	GET DEFL DATA	×	×	×	Calls the main deflection adjusting data for
				ł	ŀ	each mode
	GWB	GET W/B DATA	×	×	×	Calls the white balance adjusting data for
						each mode
	GUS	GET CNV SEL DATA	×	×	×	Calls the current state of the convergence
1					ľ	data
	GST	GET STATUS DATA	×	×	×	Calls the various setting states
н	нен	H PHASE	x	0	0	Adjusts H deflection PHASE
	HSI	H SIZE	1 × 1	0	Ö	Adjusts H deflection SIZE
	HBL	H BLK-L	×	ŏ	ŏ	BLK width adjustment for forming conver-
į				<u> </u>	~	
ı	HBR	H BLK-R	×	0	0	gence correction waveform (Left)
		TI DECOTE			_	BLK width adjustment for forming conver- gence correction waveform (Right)
	IDS	ID SET	×	×	×	Sets ID
1	IDC	ID CLEAR	×	â		Clears ID
	IN1	INPUT 1		x		Selects video input
	IN2	INPUT 2		x l	į.	·
ŀ	IN3	INPUT 3	000	x	1	Selects Y/C input
- 1	IMY	INFO.MODE ON	×	â l		Selects RGB input
- 1	IMN	INFO.MODE OFF	l x	â l		Turns ON information mode
	IIVII	INFO.MODE OFF	^	^	^	Turns OFF information mode
L I	LOR	LIGHT ONLY RED	×	×	×	Displays only RED
	LOG	LIGHT ONLY GREEN	×	×	- ×	Displays only GREEN
	LOB	LIGHT ONLY BLUE	×	×	×	Displays only BLUE
ĺ	LWT	LINEAR WHITE	×	0	_ 1	Adjusts LINEAR WHITE
мП	MLY	MULTIYES		×	×	Turns ON peripheral light amount correction
1	MLN	MULTI NO		×	×	Turns OFF peripheral light amount correction
N r	NTS	TV SYSTEM NTSC	0	×	×	Sets TV SYSTEM to NTSC (Note 4)

	Com- mand	Name	Normat Valid	Number Direct	UP/DWN Command	Function
P	PON	POWER ON	0	×	×	Turns ON power
	POF	POWER OFF		×	×	Turns OFF power
	POC	POWER ON(MUTE)	0	×	×	Turns ON power with the convergence DAC muted
	PAL	TV SYSTEM PAL	0	×	×	Sets TV SYSTEM to PAL (Note 4)
R	R00	RED 00-59	×	0	0	RED convergence adjustment (Same as BLUE)
	R59 R61	P-CONV. ADJ 61	×	0 -	0	RED point convergence adjustment (Same as BLUE)
	RP4	P-CONV. ADJ P4				
	RHI	RED HIGH LIGHT	×	0	0	RED HIGH-LIGHT adjustment
	RLW	RED LOW LIGHT	×	0	0	RED LOW-LIGHT adjustment
i !	RON	RED ON	×	×	×	Turns ON RED
	ROF	RED OFF	×	×	×	Turns OFF RED
s	SHP	SHARPNESS	×	С	0	Adjusts SHARPNESS (Note 6)
٦	STD	STD W/B DATA		×	×	Re-writes white balance adjusting data in
		015 1115 5A1A			, ,	factory memory
	STC	STD W/B DATA	×	×	×	Re-writes convergence adjusting data in factory memory
	SW1	SWITCH MENU 1		×	×	Displays various settings in OSD
	SW2	SWITCH MENU 2	00	×	×	Displays convergence data switching in OSD Adjusts TINT (Note 5)
[_ [TAIT	TIME	×	0	0	Displays test cross (Pattern 1)
l ⊤ l	TNT	TINT	l â	×	×	Displays cross hatch
i i	TS1	TEST CROSS 1		×	×	Sets TV SYSTEM mode to auto mode (Note 4)
	TS5	TEST CROSS 5	×	×	×	Increases adjusting value by 10
	TVA	TV SYSTEM AUTO		^		mcreases adjusting value by 10
U	UP0	UP 10	×	×	×	Increases adjusting value by n
	UPn	UPn	×	×	×	Maximizes adjusting value
l	UPF	UP FULL	×	×	×	Switches convergence adjusting data to
	US5	USER 5	5	×	×	user 5 (Note 4)
	US6	USER 6	0	×	×	Switches convergence adjusting data to user 6 (Note 4)
	US7	USER 7	5	×	×	Switches convergence adjusting data to user 7 (Note 4)
	USR	USER DATA RESET	0	×	×	Reset TV SYSTEM setting data (Note 4)

ADJUSTMENTS

	Com- mand	Name	Normal Valid	Number Direct	UP/DWN Command	Function
v	VPH	V PHASE	×	0	0	Adjusts V deflection PHASE
	VSI	V SIZE	0	×	×	Adjusts V deflection SIZE
- 1	VLI]	V LINEARITY		×	×	Adjusts V deflection LIN
- 1	vst	V STATIC)	×	×	Adjusts V deflection STATIC
-	VMS	V MID SIZE		×	×	Adjusts V deflection MID SIZE
-	VML	V MID LINEARITY		×	×	Adjusts V deflection MID LIN

Note 1: The ABL command is valid only in the ABL combination ON (CBY) state.

Note 2: The UP/DOWN commands that can be used for the point convergence adjustment are;

Move up→UP1

Move down→DW1

Move to right→RI1

Move to left→LE1

effective for the following only.

Note 3: The COL, CON, and COF commands are not valid during RGB input.

Note 4: The TV SYSTEM related commands can be set separately for the input function (VIDEO, Y/C, and RGB)

Note 5: The TNT commands are not valid during RGB input. Neither valid during PAL input besides RGB.

Note6: The SHP commands are not valid during RGB input.

· Normal valid

Command which can be used only when the adjustment mode is set using a command.

· Number direct

Command which can directly be specified as the adjusting value when added with 000 to 255.

· UP/DWN command

Command which can manipulate the adjusting value for the number added when UPn/DWn (n is any number from 0 to 9) to it.

③ LIST OF GET COMMANDS

What are GET Commands?

- · Commands which output adjustment data, etc. from Multi projection unit microprocessor to the PC.
- · The adjustment data is output for every mode.

Example 1)When <GGH> command is set when CONV.DATA MEMO-1 is

selected, the GREEN horizontal convergence data of MEMO-1 will be get. In the same way, when <GGH> command is set when CONV.DATA MEMO 2 to 7 are selected, the GREEN horizontal convergence data of MEMO-2 to 7 will be get.

Example 2)When <GWB> command is set when COLOR MODE =1 and at the same time, INPUT=RGB, the W/B DATA for COLOR MODE=1 and INPUT=RGB will be get.

- * Only valid for one ID. (Invalid for ID=**, 1*, *1, etc.)
- The adjustment data, etc. is output in ASCII codes.

Note)< > indicates the command name.

[1] <GRH> (GET RH CONV.DATA)=RED horizontal convergence data is output. <GGH> (GET GH CONV.DATA)=GREEN horizontal convergence data is output. <GBH> (GET BH CONV.DATA)=BLUE horizontal convergence data is output.

Format:Output in the following order.

OCTY (ASU)

①\$TX (02H)		
②<□30>/□H STATIC	adjustment data	(3 BYTE)
③< □31>/□H SKEW	adjustment data	(3 BYTE)
④< □32>/□H BOW	adjustment data	(3 BYTE)
⑤<匚36>/□H SIZE	adjustment data	(3 BYTE)
⑥<□42>/□H LINEARITY	adjustment data	(3 BYTE)
⑦<□37>/□H KEY	adjustment data	(3 BYTE)
®<□43>/□H SUB KEY	adjustment data	(3 BYTE)
⑨< □38>/□H PIN	adjustment data	(3 BYTE)
10< □44>/□H SUB PIN	adjustment data	(3 BYTE)
①<□33>/□H 3D SKEW	adjustment data	(3 BYTE)
®<⊑34>/⊑H 4D BOW	adjustment data	(3 BYTE)
⅓< _53>/□H 5D SKEW	adjustment data	(3 BYTE)
⊕<⊏59>/□H 6D BOW	adjustment data	(3 BYTE)
⑤<□48>/□H MID SIZE	adjustment data	(3 BYTE)
ઉ•<⊑54>/⊡H MID LIN	adjustment data	(3 BYTE)
⊕< ⊑44>/⊟H 5D SIZE	adjustment data	(3 BYTE)
յ8<⊑47>/⊡H 6D LIN	adjustment data	(3 BYTE)
®<⊏44>/⊑H 3D KEY	adjustment data	(3 BYTE)
భ<⊏45>/□H 3D S-KEY	adjustment data	(3 BYTE)
②< <u>□40>/</u> □H 4D PIN	adjustment data	(3 BYTE)
23<□46>/□H 4D S-PIN	adjustment data	(3 BYTE)
않<□49>/□H MID KEY	adjustment data	(3 BYTE)
2∳<□55>/□H MID S-KEY	adjustment data	(3 BYTE)
含<□50>/□H MID PIN	adjustment data	(3 BYTE)
為<匚56>/□H MID S-PIN	adjustment data	(3 BYTE)
ಭ<⊑51>/⊟H MID 3D KEY	adjustment data	(3 BYTE)
இ<⊏57>/⊡H MID 3D S-KEY	adjustment data	(3 BYTE)
29<⊏52>/□H MID 4D PIN	adjustment data	(3 BYTE)
છે<⊑58>/⊑H MID 4D S-PIN	adjustment data	(3 BYTE)
③ETX (03H)		

Note □:R or G or B

[2] <GRV> (GET RV CONV.DATA)=RED horizontal convergence data is output. <GGV> (GET GV CONV.DATA)=GREEN horizontal convergence data is output. <GBV> (GET BV CONV.DATA)=BLUE horizontal convergence data is output.

Format:Output in the following order.

①STX (02H)		
②<□00>/□H STATIC	adjustment data	(3 BYTE)
③<□06>/□H SKEW	adjustment data	(3 BYTE)
④< □12>/□H BOW	adjustment data	(3 BYTE)
S<□01>/□H SIZE	adjustment data	(3 BYTE)
⑥<□02>/□H LINEARITY	adjustment data	(3 BYTE)
⑦<□07>/□H KEY	adjustment data	(3 BYTE)
®<□08>/□H SUB KEY	adjustment data	(3 BYTE)
⑨< □13>/□H PIN	adjustment data	(3 BYTE)
®<⊡14>/⊡H \$UB PIN	adjustment data	(3 BYTE)
10< 18>/□H 3D SKEW	adjustment data	(3 BYTE)
ઉ< □24>/□H 4D BOW	adjustment data	(3 BYTE)
⊕<□11>/□H 5D SKEW	adjustment data	(3 BYTE)
⊕<□17>/□H 6D 8OW	adjustment data	(3 BYTE)
®<□03>/□H MID SIZE	adjustment data	(3 BYTE)
%< □04>/□H MID LIN	adjustment data	(3 BYTE)
⊕< □23>/□H 5D SIZE	adjustment data	(3 BYTE)
®<□29>/□H 6D LIN	adjustment data	(3 BYTE)
③<□19>/□H 3D KEY	adjustment data	(3 BYTE)
ॐ<⊡20>/⊡H 3D S-KEY	adjustment data	(3 BYTE)
②<□25>/□H 4D PIN	adjustment data	(3 BYTE)
②<□26>/□H 4D S-PIN	adjustment data	(3 BYTE)
왕<□09>/□H MID KEY	adjustment data	(3 BYTE)
&<□10>/□H MID S-KEY	adjustment data	(3 BYTE)
ॐ< □15>/□H MID PIN	adjustment data	(3 BYTE)
ळ<⊡16>/⊡H MID S-P!N	adjustment data	(3 BYTE)
②<□21>/□H MID 3D KEY	adjustment data	(3 BYTE)
28<□22>/□H MID 3D S-KEY	adjustment data	(3 BYTE)
ঞ্জ<□27>/□H MID 4D PIN	adjustment data	(3 BYTE)
ॐ<⊡28>/⊡H MID 4D S-PIN	adjustment data	(3 BYTE)
③ETX (03H)		

Note ☐:R or G or B

[3] <GDD> (GET DEFLECTION DATA>-Deflection adjusting data is output.

Format:Output in the following order.

①STX (02H)		
② <hph>/ H PHASE</hph>	adjustment data	(3 BYTE)
③ <hsi>/ H SIZE</hsi>	adjustment data	(3 BYTE)
∢VPH>/ H PHASE	adjustment data	(3 BYTE)
⑤ <vst>/ V STATIC</vst>	adjustment data	(3 BYTE)
⑥ <vsi>/ V SIZE</vsi>	adjustment data	(3 BYTE)
② <vli>/ V LINEARITY</vli>	adjustment data	(3 BYTE)
<pre>®<vms>/ V MID SIZE</vms></pre>	adjustment data	(3 BYTE)
⑨<vml>/ H MID LINEARITY</vml>	adjustment data	(3 BYTE)
® <hbl>/ H BLK-L</hbl>	adjustment data	(3 BYTE)
① <hbr>/ H BLK-R</hbr>	adjustment data	(3 BYTE)
②ETX (03H)	adjustment data	(3 BYTE)

[4] <GWB> (GET W/B DATA)-White balance adjustment data is output.

Format:Output in the following order.

①STX (02H)			
② <lwt>/ LINEAR WHITE</lwt>	adjustment data	(3 BYTE)	
3 <cnt>/CONTRAST</cnt>	adjustment data	(3 BYTE)	
<pre>@<brt>/BRIGHTNESS</brt></pre>	adjustment data	(3 BYTE)	
③ <col/> /COLOR	adjustment data	(3 BYTE)	Note 1)
<pre>⑤<tnt>/TINT</tnt></pre>	adjustment data	(3 BYTE)	Note 1) and Note 3)
⑦ <blw>/BLUE LOW-LIGHT</blw>	adjustment data	(3 BYTE)	
<pre> ®<glw>/GREEN LOW-LIGHT</glw></pre>	adjustment data	(3 BYTE)	
<pre> 9<rlw>/RED LOW-LIGHT</rlw></pre>	adjustment data	(3 BYTE)	
® <bhi>/BLUE HIGH-LIGHT</bhi>	adjustment data	(3 BYTE)	
① <ghi>/GREEN HIGH-LIGHT</ghi>	adjustment data	(3 BYTE)	
② <rhi>/RED HIGH-LIGHT</rhi>	adjustment data	(3 BYTE)	
<pre>I3<shp>/SHARPNESS</shp></pre>	adjustment data	(3 BYTE)	Note 1) and Note 5)
⊕ <abl>/ABL LEVEL</abl>	adjustment data	(3 BYTE)	Note 2) and Note 4)
® <abg>/ABL GAIN</abg>	adjustment data	(3 BYTE)	Note 2)
®ETX (03H)			

Note 1)Dummy when INPUT=RGB

Note 2)No dependent on mode. (Has one data.)

Note 3)Dummy when PAL signal is input. (INPUT=VIDEO or Y/C)

Note 4)Dummy when COMBINATION=OFF (Data is output when COMBINATION=ON)

Example)US 4:Indicates CONV.MEMO-4 is selected.

Note 5)SHARPNESS data for OFF is output when MULTI MODE=OFF, and SHARPNESS data for ON is output when MULTI MODE=ON.

[5] <GUS> (GET CONV. USER DATA)=Deflection and convergence data memory area setting state is output.

①STX (02H)	
②Memory area selected when INPUT=VIDEO or Y/C & input signal=NTSC.	(3 BYTE)
Example)US 1:Indicates CONV.MEMO-1 is selected.	
③Memory area selected when INPUT≠VIDEO or Y/C & input signal≠PAL	
(Or other than NTSC, containing no signals).	(3 BYTE)
Example)US 2:Indicates CONV.MEMO-2 is selected.	
Memory area selected when INPUT=RGB & input signal=NTSC.	(3 BYTE)
Example) US 1:Indicates CONV.MEMO-1 is selected.	
Memory area selected when INPUT=RGB & input signal=PAL (or other than NTSC, contain	ining no signals). (
BYTE)	
Example)US 2:Indicates CONV.MEMO-2 is selected.	
©Memory area selected when INPUT=RGB & input signal=MID FREQ.	(3 BYTE)
Example)US 3:Indicates CONV.MEMO-3 is selected.	
∑Memory area selected when INPUT=RGB & input signal=HIGH FREQ.	(3 BYTE)

Note) MID FREQ.:Input horizontal frequency = 20 to 28 kHz HIGH FREQ:Input horizontal frequency = 28 to 35 kHz

@ETX (03H)

[6] <GST> (GET STATUS)-Various setting states are output.

①STX (02H)

2Version of microcomputer software

(5 BYTE)

Example)V1.01:Indicates VERSION 1.01.

3Input function state

(3 BYTE)-Output in command name.

Example)IN1:Indicates VIDEO input.

MULTI MODE state

(3 BYTE)-Output in command name.

Example)MLY:Indicates MULTI MODE=ON.

5COLOR MODE state

(3 BYTE)-Output in command name.

Example)CM1:Indicates COLOR MODE=1.

©COMBINATION state

(3 BYTE)-Output in command name.

Example)CMY:Indicates COMBINATION=ON.

②INFORMATION MODE state

(3 BYTE)-Output in command name.

Example)IMY:Indicates INFORMATION=ON.

®TV SYSTEM state

(3 BYTE)-Output in command name. (Note 1)

Example)TVA:Indicates TV SYSTEM=AUTO.

Deflection and convergence data memory area state

(3 BYTE) (Note 1)

US1:Indicates that CONV.MEMO-1 (for NTSC) is selected.

US2:Indicates that CONV.MEMO-2 (for PAL) is selected.

US3:Indicates that CONV.MEMO-3 (for MID.FREQ) is selected.

US4:Indicates that CONV.MEMO-4 (for HIGH FREQ) is selected.

US5:Indicates that CONV.MEMO-5 is selected.

US6:Indicates that CONV.MEMO-6 is selected.

US7:Indicates that CONV.MEMO-7 is selected.

®FLICKER FREE presence/absence

(3 BYTE):Normally, LU/CA MODEL=Absent, WGW MODEL=Present.

000:FLICKER FREE BOARD=Indicates absent.

111:FLICKER FREE BOARD=Indicates present.

1DFLICKER FREE ON/OFF state

(3 BYTE)-Output in command name. (Note 2)

Example)FFN:Indicates FLICKER FREE BOARD=OFF.

@OSD display, enable/disable setting state

(3 BYTE)-Output in command name.

Example)DIY:Indicates OSD display enabled.

BETX (03H)

Note 1) When INPUT=VIDEO or Y/C, the VIDEO or Y/C input setting is output.

When INPUT=RGB, the RGB input setting is output.

Note 2) When FLICKER FREE BOARD=absent, FFN is always output.

4 PRECAUTIONS

[1]The adjusted data is backed up by the AJN command.

After adjustments, always perform AJN. AJN will also exit the screen adjustment display.

[2]Contents of the INPUT FUNCTION, MULTI ON/OFF, COMBINATION ON/OFF, COLOR MODE 1/2, TV SYSTEM, CONV.MEMORY are memorized only when the power is turned OFF using the remote control, POF command, or the TACT switch on the rear panel.

(They will not be memorized by AC ON/OFF.)

When starting up/stopping the system by AC ON/OFF under the long term installation conditions, memorize the contents before executing AC ON/OFF.

[3]There is a limit to the RS-232C communication buffer in the unit. If too many commands are sent at once, it will not operate properly.

[4]The RS-232C command excecution time.

When sending RS-232C command, send the next command after minimum 500m sec. But send the following commands after respective time.


a) The assigned command of the POINT CONVERGENCE ADJUST POINT	1.5sec
b) FRC (Initialization of the CONVERGENCE DATA	2sec
c) IN1~3 (Input switching)	1sec
d) TVA,NTS,PAL (TV system setting)	1sec

If the next commands are sent before these time, they may not be received. Care when making programs like the direction.

(7) Adjustments by Remote Control

Multi projection unit adjustments can be performed using the remote control (RU-V107) besides the computerand software. All adjustments are performed only using the remote control.

D Remote control functions.



. Turns on/off the power of the unit.

2) 0

<Adjustment Mode>

- Selects ID CLEAR in the ID SET/CLEAR/SELECT MODE. Also selects "0" for ID SET and ID SELECT.
- Selects V STATIC in the DEFLECTION ADJUST MODE.
- Selects ABL GAIN in the WHITE BALANCE ADJUST MODE.

3, 4)

Starts up the adjustment mode when the two buttons are pressed simultaneously.

5) 1

<Adjustment Mode>

- Selects 1 (ID SET/SELECT/CLEAR MODE) of the main menu of the adjustment mode.
- Sets ID SET in the ID SET/CLEAR/SELECT MODE. Also selects "1" for ID SET and ID SELECT.
- · Selects V PHASE in the DEFLECTION ADJUST MODE.
- Selects STATIC in the CONVERGENCE ADJUST MODE.
- · Selects CONTRAST in the WHITE BALANCE ADJUST MODE.
- Returns the CONVERGENCE ADJUST DATA to the factory set data in the MEMORY READ MODE.

6) (2)

<Adjustment Mode>

- · Selects 2 (OPERATION MODE) of the main menu of the adjustment mode.
- Sets ID SELECT in the ID SET/CLEAR/SELECT MODE. Also selects "3" for ID SET and ID SELECT.
- Cyclically selects the input function in the OPERATION MODE in the following order.

- · Selects the V SIZE in the DEFLECTION ADJUST MODE.
- · Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

- Moves the point to be adjusted up in the POINT CONVER ADJUST MODE.
- · Selects BRIGHTNESS in the WHITE BALANCE ADJUST MODE.
- Returns the WHITE BALANCE ADJUST DATA to the factory set data in the MEMORY READ MODE.

7) 3

<Adjustment Mode>

- · Selects 3 (DEFLECTION ADJUST MODE) of the main menu of the adjustment mode.
- Selects "3" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- · Cyclically switches MULTI ON/OFF in the OPERATION MODE.
- · Selects V MID SIZE in the DEFLECTION ADJUST MODE.
- · Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

• Selects COLOR in the WHITE BALANCE ADJUST MODE.

8) 41

<Adjustment Mode>

- · Selects 4 (CONVERGENCE ADJUST MODE) of the main menu of the adjustment mode.
- Selects "4" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- Cyclically switches COLOR MODE 1/2 in the OPERATION MODE.
- · Selects V LINEARITY in the DEFLECTION ADJUST MODE.
- Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

- · Moves the point to be adjusted to the left in the POINT CONVER ADJUST MODE.
- · Selects TINT in the WHITE BALANCE ADJUST MODE.

9) 5

<Adjustment Mode>

- Selects 5 (POINT CONVERGENCE ADJUST MODE) of the main menu of the adjustment mode.
- . Selects "5" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- Cyclically switches ABL COMBINATION ON/OFF in the OPERATION MODE.
- · Selects H SIZE in the DEFLECTION ADJUST MODE.
- Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

· Selects SHARPNESS in the WHITE BALANCE ADJUST MODE.

10) 🔼

<Adjustment Mode>

- · Selects 6 (WHITE BALANCE ADJUST MODE) of the main menu of the adjustment mode.
- · Selects "6" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- Cyclically switches INFORMATION MODE ON/OFF in the OPERATION MODE.
- Selects V LINEARITY in the DEFLECTION ADJUST MODE.
- Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

- Moves the point to be adjusted to the right in the POINT CONVER ADJUST MODE.
- Selects LINEAR WHITE in the WHITE BALANCE ADJUST MODE.

11) 7

<Adjustment Mode>

- Selects 7 (MEMORY READ MODE) of the main menu of the adjustment mode.
- Selects "7" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- Selects H BLK-L in the DEFLECTION ADJUST MODE.
- Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

· Selects RED HIGHLIGHT in the WHITE BALANCE ADJUST MODE.

12) 📆

<Adjustment Mode>

- · Selects "8" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- Cyclically switches FLICKER FREE ON/OFF in the OPERATION MODE. (Only for RM-V4000VE and RM-V5000VE)
- · Selects H BLK-R in the DEFLECTION ADJUST MODE.
- · Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

PIN - MID PIN - 4D PIN - MID 4D PIN -

- · Moves the point to be adjusted down in the POINT CONVER ADJUST MODE.
- · Selects GREEN HIGH-LIGHT in the WHITE BALANCE ADJUST MODE.

13) 9

<Adjustment Mode>

- Selects "9" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- · Cyclically switches TV SYSTEM in the OPERATION MODE in the following order.

T AUTO → NTSC → PAL 7

- · Selects V MID LINEARITY in the DEFLECTION ADJUST MODE.
- · Cyclically selects the item to be adjusted in the CONVERGENCE ADJUST MODE in the following order.

F SUB PIN → MID SUB PIN → 4D SUB PIN → MID 4D SUB PIN →

• Selects BLUE HIGH-LIGHT in the WHITE BALANCE ADJUST MODE.

14) **A**

<Adjustment Mode>

- · Selects "A" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- · Switches the CONVERGENCE ADJUST DATA in the OPERATION MODE.
- · Selects V MID LINEARITY in the DEFLECTION ADJUST MODE.
- Subtracts 10 from the current CONTRAST adjusting value in the DEFLECTION ADJUST MODE, CONVERGENCE ADJUST MODE, and POINT CONVER ADJUST MODE.(Returns to the original adjusting value when the adjustment mode is exited.)
- · Selects RED LOW-LIGHT in the WHITE BALANCE ADJUST MODE.

15) **B**

<Adjustment Mode>

- Selects "B" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- · Selects GREEN LOW-LIGHT in the WHITE BALANCE ADJUST MODE.

16) **C**

- <Adjustment Mode>
- Selects "C" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- Adds 10 to the current CONTRAST adjusting value in the DEFLECTION ADJUST MODE, CONVERGENCE ADJUST MODE, and POINT CONVER ADJUST MODE.(Returns to the original adjusting value when the adjustment mode is exited.)
- · Selects BLUE LOW-LIGHT in the WHITE BALANCE ADJUST MODE.

17)

<Adjustment Mode>

- · Selects "D" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- · Selects ABL LEVEL in the WHITE BALANCE ADJUST MODE.

ADJUSTMENTS

18) E

<Adjustment Mode>

· Selects "E" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.

19) **F**

<Adjustment Mode>

- Selects "F" for ID SET and ID SELECT in the ID SET/CLEAR/SELECT MODE.
- Cyclically switches between the 1st page and 2nd page in the OPERATION MODE.

20) R (ADJ)

<Adjustment Mode>

- Cyclically switches the adjusting color and direction between RH and RV in the CONVERGENCE ADJUST MODE.
- Selects the adjusting color RED in the POINT CONVER ADJUST MODE.

21) G (ADJ)

<Adjustment Mode>

- Cyclically switches the adjusting color and direction between GH and GV in the CONVERGENCE ADJUST MODE.
- · Selects the adjusting color GREEN in the POINT CONVER ADJUST MODE.

22) B AN

<Adjustment Mode>

- Cyclically switches the adjusting color and direction between 8H and 8V in the CONVERGENCE ADJUST MODE.
- · Selects the adjusting color BLUE in the POINT CONVER ADJUST MODE.

23) R

<Adjustment Mode>

- Cyclically switches RED ON/OFF in the DEFLECTION ADJUST MODE, CONVERGENCE ADJUST MODE, and POINT CONVER ADJUST MODE.
- <Normal Mode>
- . Sets the input function to VIDEO.

24) G

- <Adjustment Mode>
- Cyclically switches GREEN ON/OFF in the DEFLECTION ADJUST MODE, CONVERGENCE ADJUST MODE, and POINT CONVER ADJUST MODE.
- <Normal Mode>
- Sets the input function to Y/C.

25)

- <Adjustment Mode>
- Cyclically switches BLUE ON/OFF in the DEFLECTION ADJUST MODE, CONVERGENCE ADJUST MODE, and POINT CONVER ADJUST MODE.
- <Normal Mode>
- Sets the input function to RGB.

26) NPUT SEL

<Normal Mode>

- Cyclically switches the input function in the following order.

27)

<Adjustment Mode>

• Moves the convergence up in the POINT CONVER ADJUST MODE.

28) MAN MENU

<Adjustment Mode>

· Returns the main menu of the adjustment mode.

29) 💶

<Adjustment Mode>

- · Decreases the adjusting value.
- · Moves the convergence to the left in the POINT CONVER ADJUST MODE.

30) +/>

<Adjustment Mode>

- · increases the adjusting value.
- Moves the convergence to the right in the POINT CONVER ADJUST MODE.

31) DISP CALL

<Adjustment Mode>

- Turns on and off the test cross mark in the DEFLECTION ADJUST MODE, and CONVERGENCE ADJUST MODE.
- <Normal Mode>
- Cyclically switches the status display in the following order.

32)

<Adjustment Mode>

· Moves the convergence down in the POINT CONVER ADJUST MODE.

33) AOJ OUT

<Adjustment Mode>

- · Exits the adjustment mode.
- 34) LED for Confirming Transmission

2 Performing Adjustments

Turn on the power switch and press the two keys of the remote control together. The adjustment mode will be set.

To exit this mode, press the set was a fine the remote control. The normal screen will return.

2) Using the adjustment mode

The following main menu will be displayed when the adjustment mode is entered.

ADJUST

1.ID CLEAR/SET/SELECT

2.OPERATION MODE

3.DEFLECTION ADJ

4.CONVERGENCE ADJ

5.POIT CONVER ADJ

6.WHITE BALANCE ADJ

7.MEMORY READ

- Main Menu

ID CLEAR/SET/SELECT mode
 Used for selecting, setting and clearing the ID.

2) OPERATION mode

Switches the setting such as input selection, ABL linkage ON/OFF, etc.

3) DEFLECTION ADJ mode

Adjusts the main deflection size, etc. (But all three colors RGB at once.)

4) CONVERGENCE ADJ mode

Adjusts the convergence. (R, G, and B can be adjusted individually.)

5) POINT CONVER ADJ mode

Adjusts the convergence by point convergence. (R,G,and B can be adjusted individually.)

6) WHITE BALANCE ADJ mode

Adjusts the white balance, color.

7) MEMORY READ mode

Adjusts the current value (both convergence and white balance) to the value set at shipment.

3 Adjustment Examples
[1] Setting the ID
1) Enter the adjustment mode.
2) The main menu will be displayed. Press the 1 key to select [1. ID CLEAR/SET/SELECT].
3) Check that the ID display at the top left of the screen is []. Press the 1 key to select [1. ID SET].
If an ID has already been set, press the Q key to select [0. ID CLEAR] of the main menu, return to step 1), and set
the iD.
4) The ID input standby state will be set. Use the O to 9 and A to F keys to input the ID.
5) If several units are used, return to step 1) and set the ID of the next unit.
[2] Entering the adjustment mode of certain units only.
1) Enter the adjustment mode.
2) Check that all the screens display the adjustment mode. Press the key to select [1. ID CLEAR/SET/SELECT] of
the main menu.
3) Another menu will be displayed. Press the A key to select [2. ID SELECT].
4) Input the ID of the unit to be adjusted.
5) Only the unit corresponding to the ID input will display the main menu. All other units will be in the standby state.
6) Per m the usual adjustments.
7) 🗟 Ending the adjustment mode
Figs the key and return to the NORMAL OPERATION MODE. Note)
Repeat the mentioned operation 1) to 7).
Note) Also press the key surely when the specific unit is time out and returns to the NORMAL MODE.
If the law is not present the units which do not receive ID SELECT signal and held an stand by state

[3] Adjusting the H PHASE	
1) Enter the adjustment mode.	
2) Press the 3 key to select [3, DEFLECTION ADJ].	
3) Press the 4 key to select [H PHASE] . Then use the 4— and +/> keys to adjust the H PHA	4SE.
The following can be adjusted using similar methods.	
key: V STATIC 5 key: H SIZE	
1 key : V PHASE By key : V LINEARITY	
key: V SIZE 7 key: H BLK-L	
3 key : V MID SIZE 87 key : H BLK-R	
key: H PHASE 9 key: V MID LINEARITY	
4) Adjusting the green horizontal size (GH SIZE)	
1) Enter the adjustment mode.	
2) Press the 41 key to select (4. CONVERGENCE ADJ).	
3) Press the GAD key until the OSD display becomes (GH).	
The following can be adjusted in the same way.	
R	
Ball	
key : BH BV	
4) Press the key until the OSD display becomes [SIZE].	
Then use the <a>/- and +/▶ keys to adjust the GH SIZE.	
The following can be adjusted in the same way.	
1 key : STATIC	
key : SIZE → MID SIZE → 5D SIZE →	
3 key : □ LINEARITY → MID LINEARITY → 6D LINEARITY	
key : → SKEW → 3D SKEW → 5D SKEW	
5 key : KEY → MID KEY → 3D KEY → MID 3D KEY →	
key : SUB KEY - MID SUB KEY - 3D SUB KEY - MID 3D SUB KEY	
7 key : → BOW → 4D BOW → 6D BOW →	
key : PIN - MID PIN - 4D PIN - MID 4D PIN -	
9 key : SUB PIN - MID SUB PIN - 4D SUB PIN - MID 4D SUB PIN -	

[7] T	Turning on the per	ipheral light amount correction (MULTI)
1)	Enter the adjustm	nent mode.
2)	Press the 🔼	key to select (2. OPERATION MODE).
3)	Press the 3	key to turn on/off the peripheral light amount correction (MULTI).
	The following car	n be performed in the same way.
		key : Input selection (→ VIDEO → Y/C → RGB →)
	3	key : Peripheral light amount correction (ON ← → OFF)
	4 1	key : Color mode (1 ← → 2)
	5	key : ABL linkage (ON ← → OFF)
	B	key : Burning reduction mode (ON ←→OFF)
4)	Furthermore, the	F key can be used to move onto the next page. The following can be performed using the similar
	method at step 3)	
		key : TV system selection (→ AUTO → NTSC → PAL →)
		key : Convergence memory selection area switching

4	Precautions	Upon	Use
----------	--------------------	------	-----

- · Always turn off the power with the power button after adjustments and settings. All adjusted values and settings will be memorized.
- The remote control adjustment mode will automatically be exited in the following.
 - 1. When no operations are performed for about 30 seconds.
 - 2. When the rear panel switch is pressed
 - 3. When the power is turned off
- · One multi-projection unit cannot be adjusted using the remote control unit and personal computer simultaneously. If using the remote control unit after the personal computer adjustment mode has been started up, start up the remote control unit adjustment mode or turn off the power once.
- · When operating several multi-projection units simultaneously, do not press the buttons quickly and continuously as some units may not synchronize with the other units.
- · Multi-projection units not assigned an ID cannot be operated using the remote control unit. To exit this state, perform one of the following.
 - 1. Start up the remote control adjustment mode using the _____ button.
 - 2. Exit the remote control adjustment mode using the word button.
 - 3. Turn off the power.
- . The remote control signal is output to the next unit via the link terminal only when a certain ID is set to the multi projection units. When operating several units, set this ID to all the units. Only units connected with the link cable located after the units to which the remote control unit is connected can be operated.
- · Up to 16 units can be operated using the remote control at one time using the link cable. To operate more than 16 units, use a personal computer as well or reconnect the remote control.
- Handle the wire carefully.

Warning for Use of Dry Batteries 🛆

- Using dry batteries incorrectly will result in battery liquid leakage, damage, etc. Take note of the following. (Also refer to precautions provided for dry batteries.)
- Load the \oplus and \ominus sides of the batteries correctly as shown on the battery case.
- · Do not use old and new batteries together.
- · Batteries of the same shape may have different voltages.
 - Do not use different batteries together.
- When not using the unit for a long period of time (one month), remove the batteries to prevent battery liquid leakage. If leakage occurs, wipe the liquid thoroughly and load new batteries.
- Do not charge, short-circuit, disassemble, nor throw into fire the dry batteries provided.

CHAPTER 5. OPERATIONS · MAINTENANCE

1. MAINTENANCE

(1) Re-adjustments After 3 months

Although the RM-V4000V/V5000V is adequately adjusted at the

time of installation, values slowly change as time goes by. When adjusted completely again, the values will more or less be stable. The time to perform the re-adjustments is about 3 months later. It is recommended that these adjustments be included in plans made when the unit arrives.

(2) Periodic Maintenance

For the unit to display its best performance stably for a long period of time, it is recommended that periodic maintenance be performed. There are mainly two types of periodic maintenance.

- Cleaning
 - Although this depends considerably on the environment used in, the CRT lens surface, screens, etc. are cleaned mainly.
- Re-adjustments
 - Re-adjustments must be performed if required.

Pioneer recommends that contracts on periodic maintenance be signed.

(3) Replacement of Parts

The replacement and addition of RM-V4000V/V5000V parts are as follows and must all be performed by Pioneer servicemen. Request for these services when required.

① CRT

The luminance of the RM-V4000V/V5000V decreases with the time used like other video equipment. How much it decreases depends on the images displayed and the using conditions. As an approximate, the decrease is about half for 10000 hours. Although this 10000 hours (four years with eight hours of use every day) is a rough approximate for replacing the CRT, decide according to the state of the unit.


2 Screen

If a screen needs to be replaced due to scratches, etc., purchase a service parts screen.


Replacing the Screen

The following describes the method for replacing the screen with the center unit of a 9-screen system as the example.

[1] To remove the unit to be replaced (diagonally shaded part in Fig. 6-1), remove the screen units that need to be removed. (Remove a, b, c units in this case.)





(Fig. 5-1)



(Fig. 5-2)


- [2] Remove the panels at the top and right side of the screen unit to be replaced. (Remove 12 screws.) The panels are made of polycarbonate. Adhesive double coated tapes are pasted to the frames. When removing the panels, do not pull the panels in directions which are difficult to pull, but pull straight as much as possible as shown in fig. 5-2 The panel will not deform in this way.
- [3] Peel off the black vinyl tape at the edges. The top and right sides of the screen will become free. Remove the screen by pulling in the top right direction. (fig. 5-4)
 - * The left side and bottom of the screen is fixed to the panel by adhesive double coated tape. The lenticular sheet can be removed relatively easily. The fresnel lens is fixed firmly and will not come off by just pulling in the top right direction. To remove, while pulling in the top right direction, remove it by opening it as if opening a door.






(Fig. 5-4)

[4] Re-paste the adhesive double coated tape on the panel. It can be peeled off easily by scratching it with your finger backwards. Then paste a new adhesive double coated tape according to the figure. It is recommended that the following adhesive double coated tape be used.



OPERATIONS

- [5] Attach a new screen. While paying attention to the front and back, attach the fresnel lens. (Flat side: The shiny side is for the projection unit side.)
- [6] In the same way, attach the lenticular sheet while paying attention to the front and back. (The shiny side is for the fresnel lens side.)
 - * When attaching the screen, past the adhesive double coated tape properly by rubbing the tape with your finger with force.
- [7] Paste a black vinyl tape around the edge of the screen. It can be pasted easily by placing the screen frame on its side. As shown in Fig. 5-6, paste the vinyl tape slightly protruding out on the edges of each screen and cut off the protruding parts. Be careful not to scratch the lenticular sheet at this time.
- [8] After peeling off all the adhesive double coated tape remaining on the back of the panel or the frame, paste the above adhesive double coated tape to the frame side. Make sure not to paste over the black vinyl tape.
- [9] Peel off the released paper of the adhesive double coated tape and paste the panel along the tapped holes. Tighten the 12 screws.
- [10] Finally, check that the screen will not come off from its front and back.



(Fig. 5-6)

Cleaning the screen

As dust adheres to the surface of the screen easily, it should be cleaned periodically. Use the following cleaning items for cleaning.

Name

No.

Cleaning cloth

GED-009

: Minimax

GEM1004 (This can be used for the CRT as well.) Cleaning solution: B4

As hand prints and finger prints stick easily to the screen, do not touch the screen with your bare hands, and put on gloves when working.

1. Slight dirt can be removed easily by blowing on the screen and wiping off with a soft cloth such as the specified cloth or

As the screen surface scratches easily, do not rub it with hard items nor dust with dusters.

2. If the lenticular sheet is very dirty, moisten the above specified cloth with the specified cleaning solution and wipe it. Note: As the black print on the surface of the lenticular sheet may peel off, never use alcohol, benzine, thinner, etc.

Note: The back of the fresnel lens (flat side) is sprayed with antistatic agent. Dust will not therefore stick to it easily. Dusts can be cleaned off easily by wiping with the above specified cloth (dry). Do not use any kind of cleaning solution or the antistatic agent will lose its effects.

Also clean off difficult-to-clean oil with a dry cloth. If cleaning solution must be used, bear in mind that the above antistatic effects will be lost. However, if these effects are lost only partially, the image quality will not be affected.

Note: It is recommended that antistatic agent be applied to the surface of the lenticular sheet. Use the following product. Antistatic agent: Nondust GYD1004

When spraying the antistatic agent, spray from as far as possible with the appropriate amount. If sprayed excessively, the spray will accumulate in the grooves on the lenticular sheet, and as a result, affect the images.

OPERATIONS

Notes

- To produce fine joint, the left side and bottom of the screen are secure with adhesive double coated tape. Make sure the
 replaced screen is attached closely to the left and bottom sides of the panel. If not attached closely, the screen will disconnect from the panels when it expands and contracts according to temperature and humidity changes, or in the worst case,
 drop off.
- · In replacements, make sure not to leave dust and dirt between the lenticular sheet and fresnel lens.
- · Take note of the front and back of the screen. Unnatural images will be produced when these sides are mistaken.
- · As dust and oil adhere easily to the screen, when replacing, always put on gloves (also protects against hazards).
- · As the lenticular sheet is very thin and tears easily, handle it with extreme care.
- The fresnel lens is such that convex lenses are arranged in flat. Do not expose it to direct sunlight to prevent fire hazards, burns, and loss of eyesight.
- · When performing replacements at high places, work very carefully as small mistakes may lead to serious accidents.

2. PRECAUTIONS FOR PLAYING

- The input function, MULTI ON/OFF (peripheral light amount selection), COMBINATION ON/OFF (ABL link selection), COLOR MODE 1/2 (white balance selection), TV system selection, and convergence memory state will be recorded in the memory only if the power is turned off using the remote control or tact SW on the rear panel. (They will not be recorded in the memory if the power is turned off using AC ON/OFF.) When starting or stopping the system by AC ON/OFF under setup conditions for a demonstration, perform the above operations beforehand, record the above in the memory, and then perform AC ON/OFF.
- When different horizontal frequency signals (for example NTSC and Personal Computer signals) are switched in this unit, the screen will distort temporarily (1 to 2 seconds). This occurs because the unit deals with various input signals (the multiscan display), if the distortion of images is disturbing when images are played, etc., the images can be turned off ("muting") when switching the signals. The procedure is described below.
- (1) Using an external Personal Computer commands

Example) When muting an image of the unit with ID = 11:

11 A OF \rightarrow 11 INO \rightarrow 11 A ON

(Image mute)(Input selection & Image must released)

OΓ

2→ For Y/C input

or

3→ For RGB input

(2) Set the switches in the unit.

Switch ON:Mutes the screen for several seconds when switching the input function (VIDEO, Y/C, RGB). Switch OFF:Will not mute the screen even when the input function is switched.

And when switching pictures, thin lines may appeare on upper side for an instant. It is not a failure but the signal for working the AUTO WHITE BALANCE CIRCUIT. If there is some trouble when directing, making inquiries separately.

It is hazardous to open the rear panel because electric shocks may be caused by the high voltage circuits, etc. inside. As the rear panel must be opened to use the ABL switch, contact our servicemen if the switch needs to be operated.

3. SERVICE SYSTEM

The service system of this unit is as follows.

- (1) Repairs will be provided free-of-charge for one year for natural malfunctions.
- (2) For systems directly sold and setup by Pioneer, the Pioneer service center will provide preliminary service calls to repairs. (For details, contact your Pioneer dealer.)
- (3) The service calls for this system by Pioneer is based on a reservation system.
 When service calls are required, always make the necessary reservations through the Pioneer Service Department regardless of whether your system was purchased from a dealer or directly from Pioneer. If reservations are not made, service calls cannot be provided in some cases. (For details, contact your Pioneer dealer.)
- (4) When products purchased at home are used in foreign countries, the guarantee will become ineffective and the products will not be eligible for servicing.

4. PRECAUTIONS FOR ASSEMBLING AND MAINTENANCE


- · Periodically clean the vent nets of the fan of the multi-projection unit to prevent it from clogging.
- In assemblies and maintenance, the service person must move in the cabinet. The following are precautions for this procedure.
- Do not place load on the screen unit.
 (in the procedure, always place weight on the cabinet.
- (2) Be careful not to hit your head when moving the unit.
- (3) Do not touch the lens.
- (4) AS changing the position of the multi-projection unit will change the convergence, do not touch the multi-projection , unit.

Work carried out at high places is extremely hazardous. If tools, etc. are dropped, it will cause not only damage to the equipment but also injuries to men as well. Therefore work carefully.

CHAPTER 6. PRECAUTIONS

1. PRECAUTIONS ON FUNCTION AND PERFORMANCE OF SYSTEM

- The power may turn off temporarily due to power discharge inside the CRT tube, but it will recover automatically after one
 second. In the new CRT, the very slight amount of impurities remaining inside (in vacuum) may occasionally evaporate
 when hit with electron beam. The screen may black out instantaneously at this time. This will not occur after the CRT has
 been used for 100 to 200 hours.
- When the power remains off for some time, it may indicate that a fault has occurred inside. (malfunction of parts). Turn off
 the main power switch of the multi-projection unit, and after several seconds, turn it on again.
 If the power goes off again, it indicates a fault. If it works normally, it indicates abnormal operations due to electrical
 discharge and will not affect operations thereafter.
- If the screen color and brightness is abnormal or the switches do not function, turn off the main power switch once and turn
 it on again several seconds later.
- In some cases, the screen from appear bluish when seen from the left and slightly reddish when seen from the right. This
 phenomenon called color shift is inevitable due to the structure of the projection system in which the R G, B tubes are lined
 up and light is projected from the rear.
- When the one image (still image and caption) is displayed for a long period of time, the image will stick onto the screen and
 cannot be removed. As this is inevitable due to the projection system, it must be resolved through software contents,
 displaying method, system structure, etc.
- When bright images are displayed in the dark, the light reflected on the lens will shine in the darkness slightly. This phenomenon called tube-inside reflection is inevitable due to the structure of the projection whose CRT light has been expanded using the lens. (Fig. 6-1.)



(fig.6-1)

PRECAUTIONS

- When the OSD is displayed at the same time the input signal is switched, the displayed characters may enlarge or reduce in size, not synchronize, etc. This is normal.
- When switching the VIDEO and Y/C input using the EXT-CONTROL terminal, the signal cannot be switched between different TV formats

EXample) VIDEO input, NTSC ,	Y/C input	 \	VIDEO input,	Y/C input	\ <u>\</u>
NTSC ,	PAL	Δ	VIDEO input, NTSC ,	NTSC	\rightarrow \bigcirc

- Take note that while no signals are input to the unit, the hour meter will not count. If the power is turned off before one hour
 of use, errors will occur in the count of the hour meter.
- · When the following signals are input, the image may be distorted.
 - · VTR signal which repeats copying.
 - · VTR signal with copy-guard.
 - Scrambled CATV signal.
 - · Signals whose sync width is below 100 nsec.
 - Signals whose sync signal and video signal phases are considerably different.
 (In some cases the centers of H and V cannot adjusted. If adjustments can be performed using the expansion equipment at a use it.)
 - Signal with extremely narrow feedback period (In some cases, the 100 % video period cannot be output.)
 - When the HDTV signal is input from the RGB input terminal, the signal must be 4 line type or 5 line type with the separate RGB and Synchronous signal.
 - 4 line type R.G.B. H/V SYNC
 - 5 line type R.G.B. HD,VD

(When the 3 line type [R.B SYNC ON G] is input, the SYNC may be unlocked for an instant for some input signals.)

PRELIMINARY

PIONEER CUBE SYSTEM TECHNICAL MANUAL (Additional version)

- Before Cube adjustment
- · Convergence adjustment
- · Hi-scan signal adjustment
- · White balance adjustment

This manual has been made for the purpose of explain more detail of adjustment procedure that is difficult to understand with the technical manual for the installation. This manual will be used with the technical manual for the RM-V4000V. The basic point of view is the same as the RM-V2400N.

1996 September

SHIZUOKA PLANT
System Engineering Department

Before Cube adjustment

- 1. It is important to set the Cube with a mechanic surely.
 - ① Screw on after placing the Cube unit on the right position.
 - ② Attach the slide table part and the base of the frame.
 - 3 Make sure no installation gap between the screens.
- 2. Before a multi-screen adjustment, make sure the condition of the adjustment on the menu display if the setting of all screens are same. SW position of the rear panel for each display should be same condition.
- 3. The adjustment in the field is to take out the difference of each screen mainly.
 - At the factory, a central position and a screen size have been adjusted by using the Monoscope signal, adjustment condition will be changed when different signal is used for it in the field.
 - → When there is no require of the image size specially, check the whole tendency and adjust the size of the average majority.
 - ... The know-how to complete the adjustment in the short time is not moving the size as much as possible because the miss-convergence comes out when moving.
 - The display has been adjusted White balance by using the Window signal at the factory, try to take out the color balance error of each display mainly after a decision of target of average white balance.
- 4. In case changing various data at the adjustment causes bad adjustment condition, it is better to try adjustment again after resetting the data to the factory standard.

In the case of the protection works at turning on a power due to odd data setting while convergence adjustment, heal with the following operation:

Leave the unit about 10 seconds with "STAND-BY" (Red LED lights up) mode, then turn OFF/ON the main power SW in order to reset the protection circuit. Next, turn ON the power by issuing a "POC" command by a computer, or turn the power ON by the remote controller within 3

seconds after entering the adjust mode while the unit is in STAND-BY mode. In this case, actual setting of convergence will not be changed though the convergence data on the on-screen-display changes since convergence output is muted internally. Correct the incorrect data which was set by mistake or reset to the factory default data. The mute function is released and convergence adjustment can be started again after normal power OFF/ON cycle.

Convergence adjustment

1. Center position adjustment

POINT
The difference of "PHASE" and "STATIC" adjustment

As the way of moving a display position, each of the deflection and the convergence has the function of "PHASE" and "STATIC".

- . "P $\dot{H}ASE$ " \cdots Any miss-convergence will not come out since it only changes the timing of the video signal in the position.
- "STATIC" The miss-convergence of R, G, B comes out due to movement of the projected position of the CRT beam, and re-adjustment of the convergence is necessary. The "STATIC" function causes more DC voltage against the output amplifiers to move the beam and the amplifiers' load may be increased. To fix a data value on "128" beforehand is an ideal. Adjust within 10 mm on the screen is recommended when using "STATIC" of the convergence.
 - \Rightarrow Adjust the center position with "PHASE" to the utmost.

According to the whole tendency, if the individual screens with the size 95% of the left, 90% of the right are many, it is better to unify to the size of majority. It becomes the same size 95% of the left, 90% of the right with the expanded multi-image. After this adjustment, the phase shift function of MVP (Multi-Video-Processor) can correct simply either side or center without changing the convergence.

CAUTION

Some of the RM-V4000V can not be adjusted "V PHASE" when "multi" function is ON because of the difference of firmware revision. In this case, the center position should be adjusted by the phase adjustment of the MVP before the Cube's adjustment. "V STATIC" of the deflection can be used to move the vertical position If it's impossible to move by the MVP, and do not use "GV STATIC" of the convergence as much as possible.

2. Size adjustment

- Two types of the size control are available. One is the deflection adjustment that can control three (RGB) colors simultaneously, and the other is the convergence adjustment that can control the three colors separately. However, the output amplifiers for the convergence adjustment do not have enough room, therefore, the image may have some distortion or power protection may work when a lot of size factors are added at the convergence adjustment.
- \Rightarrow It is recommended that set "GH SIZE" and "GV SIZE" of the convergence within 128 \pm 10 range, then picture size should be adjusted by the deflection "V SIZE" mainly.
- The size of all individual images must be equal for the length and the width.
 The screen size that is adjusted in the individual screens becomes the enlarged picture size finally.
- The miss-convergence occurs when changing an image size, in this case, adjust it by using "H.BLK_L" and "H.BLK_R" command in the deflection adjustment mode.
 - ⇒ Refer to the technical manual P73.

3. The adjustment of the high scan signal (Refer to the technical manual P56 for the memory allocation) When a high frequency signal is fed, some distortion of the image appear

When a high frequency signal is fed, some distortion of the image appear on the display because the data which has been stored at factory is adjusted with standard NTSC signal.

— POINT — — — — — — — — — — — — — — — — — — —	
Adjust by using the command "H.BLK_L" and "H.BLK_	_R"

- ① When high horizontal frequency signal is fed, the image may be distorted to bend the horizontal line since the blanking width is not proper for the convergence adjustment. It is the same distortion which appears when size is changed.
 - \Rightarrow Refer to the technical manual P73 \sim and adjust the horizontal line to fix straight.
- ② When a different frequency signal is fed, the linearity of the deflection changes too. After the adjustment ①, adjust the pitches of each line of the cross hatching signal to be equal.
 - ⇒ At first, adjust for the pitch of the each lines to be equal as the monochromatic green by the point convergence adjustment.
- ③ Check the value of "GH SIZE" after the adjustment ②. (A lot of value of the convergence data may be changed since combination of various kind of waves are used at the point convergence adjustment)
 - ⇒ Reset the original size by using "H SIZE" after resetting "GH SIZE" to "128".
- Adjust the color deviation of R and B (convergence for R and B signal)
- 4. The adjustment procedure of the point convergence
 - ① Adjust the center portion of the screen.
 - ② Adjust the center cross-line by the point convergence.
 - ③ Find out the biggest part of the color deviation, and make the difference small as much as possible. If the adjustment point is moved widely, the convergence may change not only the adjustment point but around it. (Refer to the technical manual.)

④ Adjust one by one from outside to inside of display.
Check outside once again if there is a difference after finished adjustment at inside of the display.


High scan signal adjustment

1. The RGB input accepts the following frequency signals:

Horizontal: $1.5 \text{ KHz} \sim 3.5 \text{ KHz}$ (Automatic) **Vertical**: $5.0 \text{ Hz} \sim 1.5.0 \text{ Hz}$ (Automatic)

VGA mode is applied for the RM-V4000V. (refer to Figure 1)

- 2. Especially becoming a high scan frequency, the rate of the blanking width is increased. The non-display period must be at least **6.3** μ **sec.** for the horizontal and **1.3 m sec.** for the vertical interval. All picture image can not be displayed and hard to reject picture distortion when blanking interval periods are short.
- 3. When horizontal frequency is high and the display area is wide (= blanking period is short), a vertical streak may be seen on the left side of the screen. To solve it, adjust "STATIC" of convergence to move left side for RGB signals (Max. is 10 mm), then adjust "PHASE" of deflection to move right side. In this case, miss-convergence may occur due to the adjustment of the "STATIC".
- 4. The convergence amplifiers will have more load than normal condition in the convergence adjustment mode when a high scan signal is fed. Once miss-adjustment occurs, it may results more high load against the amplifiers and the protection circuit may turn the cube OFF, even if convergence can be adjusted similarly on the screen.
- 5. The defective symptoms due to an overload of convergence are follows:
 - Power Down (the power supply P.D. or the convergence P.D.)
 - The vertical direction scan of the top portion of the screen is disordered.
 - The vertical line shakes with the cross hatching signal.
 - The brightness of the image changes during the convergence adjustment.



Display dot			640 * 350	640 * 400	640 * 480	640 * 480	
Clock frequency [MHz]			z]	25. 175			30. 240
	Frequency [kHz]				35. 0		
Scan time [μ S] 1 H				28. 57			
Н					21. 16		
	Non-display [μS] b 6. 356					7. 41	
		Front porch	С		2. 12		
		Back porch	d	1. 907			3. 17
		H. SYNC	е		2. 12		
	Frequency [Hz]		70. 08	70. 0 8	59. 94	66. 67	
			1 V	14. 268	14. 268	16. 683	15. 0
V	Display [mS] j		j	11. 123	12. 711	15. 254	13. 7
	Nor	n-display [mS]	k	3. 145	1. 557	1. 429	1. 3
		Front porch	1	1. 176	0. 381	0. 381	0. 086
		Back porch	m	1. 906	1. 112	1. 048	111
		V. SYNC	n	0. 064	0. 064	0. 064	0. 086

(Figure 1) Example of signal timing

White balance adjustment

1. White balance adjustment

As the difference with the RM-V2000 series model, the "Green Low" and the "Green High" adjustment are additional. By this, in case of the white balance adjustment for the RM-V4000V series model, the contrast and brightness for each display should be set to the same value. The ABL adjustment takes difficulty if the contrast and brightness value is different on each display.

2. The adjustment of the low light and the high light effect respectively as a brightness adjustment function to the signal of low and high level. But, they influence a mutual brightness each other. Even if the middle level is well balanced, the brightness doesn't match with the others screen in the point of the ABL operation level or the light starting the shine when the balance is collapsing for the low and the high adjustment.

3. ABL adjustment


ABL (Auto Brightness Limit) is the circuit which limits a beam current automatically to protect that the brightness of the monitor TV (Cube) becomes high too much to destroy the CRT. It detects a beam current level on the 2nd side of the FBT, it lowers a contrast and a brightness and makes not to rise above a certain level.

4. ABL-GAIN adjustment

"ABL-GAIN" reduces the difference of each ABL operating point when putting together the multi screen Cube. ABL works to limit the light when the total anode current which flows through the CRT of the RGB becomes 1.4 mA.

In case, A, B are two pieces of Cube like the Figure-2, ABL works at the point of ① in the light when the luminous efficiency of the set of A is bad even if both CRT begin to shine at the same time. On the other hand, as for B, ABL works at the point of ② which is lighter than A unit.

"ABL_GAIN" increases the ABL current in appearance by the control of the microprocessor and ABL works early timing. By decreasing the value of "ABL_GAIN" (default is MAX.) for B unit, the ABL current is increased in appearance then ABL works at the light which is the same brightness point as A unit. In this case, the whole image becomes dark because the "ABL_GAIN" means to uniform the light Cube to the dark one. This adjustment is required when old and new CRT are installed in a wall and there is a difference of substantial lighting ability among these units.



5. ABL-LEVEL adjustment

"ABL-LEVEL" works only when combination is ON and link cables are connected. It reduces the difference of each Cube's brightness in case of ABL operation. The ABL combination is the function to work ABL of all connected Cube uniformly. However, the change of the brightness will not be the same condition by only connecting the cables if the operating point on each cube is different. "ABL_LEVEL" reduces a difference with the ABL variation of each Cube when connected. The microprocessor controls the contrast and the brightness level when the combination is ON. The "ABL_LEVEL" should be adjusted not to produce a brightness change at combination mode ON/OFF cycle with condition of 100% white signal is fed. Adjustment can be done only when the combination mode is ON. The "ABL combination ratio" SW (For only US model) also effective only when the combination mode is ON.

Before adjusting "ABL_GAIN","ABL_LEVEL", the R, G, B LOW, and HIGH adjustment must be done.