## **Quick-Start Guide**

#### KeypadLinc<sup>™</sup> - INSTEON 8 Button Countdown Timer Model: #2484D

A Countdown Timer that Turns Itself Plus other INSTEON Devices off Automatically

#### Introduction

KeypadLinc INSTEON Countdown Timer is a general purpose, countdown timer with 7 or 8 timer durations. Like other countdown timers, it will turn the connected lights / circuit off when its timer expires. However, that's where the similarity ends. Countdown Timer can also turn other INSTEON devices off when its timer expires. Still further, when you Link other INSTEON devices (as a Controller) to Countdown Timer, it will automatically start its countdown timer for the amount of time you choose.

2 5 min min 10 15 min, min, 30 1 min, h, 2 OFF

SET

Button



Countdown Timer

#### Installation

Important: Installation should be performed only by a qualified electrician or by a homeowner who is familiar and comfortable with electrical circuitry. If there are any questions, consult an electrician. For setup questions contact Tech Support at SmartLabs for guidance. Tools required: Phillips screwdriver, slotted screwdriver and a wire cutter/stripper. Two or more properly installed INSTEON Access Points are strongly recommended for every home to ensure reliable communication. You will need to ID all your wires before beginning. For a wiring diagrams (including 3-way circuits), see the KeypadLinc Dimmer Owner's Manual at <a href="http://www.smarthome.com/2486D.pdf">http://www.smarthome.com/2486D.pdf</a>.

- 1) Disconnect power at the service panel
- 2) Remove trim plate and existing switch/dimmer
- 3) Connect Countdown Timer's copper wire to ground with a wire nut (or screw as appropriate)
- 4) Connect Countdown Timer's white wire to neutral with a wire nut
- 5) Connect Countdown Timer's black wire to hot wire with a wire nut
- 6) Connect Countdown Timer's red wire to the switch-leg with a wire nut (control of a local load is optional)
- 7) Carefully screw Countdown Timer into electrical box and replace trim plate
- 8) Restore power at the service panel
- 9) Test Countdown Timer will return to its last on / off state

Your lights will turn on, flash after 1 minute and turn off after 2 minutes

#### **Operation**

1) Tap the "5 min" button (this will turn your lights on for 5 minutes)

- Your lights will turn on and any INSTEON devices controlled by your Countdown Timer will also turn on 5 min. LED will turn on
  - After 3 minutes the 2 min. LED will turn on and the 5 min. LED will turn off
  - After 1 minute the "1 minute warning" will turn your lights off then back on, indicating 1 minute left
  - After 1 more minute your lights will turn off and any INSTEON devices linked to Countdown Timer will also be turned off
- To turn lights off at any time, tap the OFF button or the button whose LED is on
- Your lights will turn off and any INSTEON devices linked to Countdown Timer will also be turned off

#### **Creating Links to Control other INSTEON Devices from Countdown Timer**

- 1) Press & hold any button on Countdown Timer until its LED begins blinking
- 2) Press & hold the SET button on the INSTEON-compatible Responder you wish to control until its LED flashes
  - Note: for multi-button devices, press & hold the button of choice until LED / load flashes


Note: All the devices you link in this manner will be turned on when you turn Countdown Timer on and will turn Off when the timer expires.

#### **Removing Links to other INSTEON Devices from Countdown Timer**

- 1) Press & hold the corresponding button on Countdown Timer until its LED begins blinking
- 2) Press & hold the same button again hold it for 15 seconds
- 3) Press & hold the SET button on the INSTEON-compatible Responder you wish to remove from Countdown Timer until its LED flashes Note: for multi-button devices, press & hold the button of choice until LED / load flashes

# smartlabs

2)



- To turn OFF button back into an off-only button:
  - a) Tap the "30 min" button, release, then press & hold the SET button for 5 seconds three times LED will stop blinking
    - b) Tap the "2 hr" button, release, then press & hold the SET button for 5 seconds three times
      - LED will stop blinking

Note: Once you have programmed the 8<sup>th</sup> button, simply pop the OFF key cap off and replace with appropriate button key cap

### For <u>HELP</u> call our friendly tech support @ 866-243-8018

SmartLabs Limited Warranty – SmartLabs warrants to the original consumer of this product that, for a period of two years from the date of purchase, this product will be free from defects in material and workmanship and will perform in substantial conformity to the description of the product in the owner's manual. This warranty shall not apply to defects or errors caused by misuse or neglect. © Copyright 2007 SmartLabs, 16542 Millikan Ave., Irvine, CA 92606-5027 – 866-243-8018 www.smartlabsinc.com

