

Unistep LabMaster Series

SPI

**SERIAL PORT INTERFACE MODULE
USER MANUAL**



~~~~ SERIAL PORT INTERFACE ~~~~

USER MANUAL

Section 1 - Introduction	
Features	3
Package Contents	3
Installation	3
Section 2 - Circuit Description	
Circuit Diagram	4
Parts List and the Component Placement Diagram	4
I/O Pin Assignments	4
Power Input	4
Processor	4
Serial Port	5
Configuration	5
Indicators	6
Analog Input Port	6
Digital Input Port	6
Digital Output Port	6
Section 3 - Command Interpreter	
Command Structure	7
Command Set	7
Section 4 - Control Panel	
Installation	8
Serial Port Settings	8
SPI Exec	9
Digital Output Port	9
Digital Input Port	9
Analog Input Port	9
PWM Output	10
Stepper Output	10
Frame Display Boxes	11
Section 5 - Support	
Internet www	12
Contacts	12
Section 6 - Appendices	
Command Reference	13
Circuit Diagram	15
Parts List & Component Placement Diagram	16

1. INTRODUCTION

Thank you for purchasing the LabMaster SPI Module. This is a very capable circuit with powerful hardware and firmware features. We hope that you will find the SPI module very helpful for your serial port interfacing, automatic control, and digital experimentation needs.

1.1 Features

- 8+1 Channel digital output port (8 bit latched data + 1 clock)
- 8+1 Channel digital input port (8 bit buffered data + 1 clock)
- 5+1 Channel Analog input port
- 2 Stepper motor control outputs
- 2 PWM and DC motor control outputs
- LED indicators for digital outputs
- 16-Pin dual-row headers for all I/O channels
- 9-Pin D-Sub RS-232 Interface for communicating with the host PC
- Serial communication configuration switches
- MPU configuration and reset switches
- Auto-transmit mode for initial system checking
- Ready/Activity LED indicator
- DIP-switch selectable 1200, 9600, 19200, and 57600 Baud transmission speeds
- Parity enable/disable and parity type selection
- LED lamps indicators for Parity and Framing errors
- Transparent mode of operation for simple I/O needs
- Powerful SPI Exec Command Interpreter for sophisticated control functions
- LED lamp indicator for MPU command mode
- Support for external voltage reference input
- Fully configurable PWM output channel
- Reverse polarity input power protection
- Fully socketed IC's
- Vcc and Gnd power lines included in I/O headers for powering external circuits

1.2 Package Contents

Please make sure that you have the following items in the SPI package:

1. The SPI Module (1)
2. Flat ribbon cable segments with 16-Pin IDC connector at one end (3)
3. Software and Documentation CD (1)

1.3 Installation

No assembly is required, as the SPI module is shipped fully assembled and tested.

2. CIRCUIT DESCRIPTION

2.1 Circuit Diagram


Full circuit diagram is included at the end of this manual. You may find it useful to keep it open while reading the following sections about the circuit details.

2.2 Parts List and the Component Placement Diagram

At the end of this manual you will also find one page with the Parts List and Component Placement Diagram. These will be useful if you need to locate a component on the SPI board, or if you need to find replacement parts.

2.3 I/O Pin Assignments

All I/O lines of the SPI circuit are brought out on 16-Pin dual-row header strips. These pins are numbered as shown in the figures below. Pin #1 can be identified in two ways: **1)** Pin numbers 1,2,15, and 16 are printed on the board. **2)** On the solder side, pin number 1 has a square solder pad, instead of the usual oval pad. It is recommended that you connect the ribbon cables so that the colored marker conductor indicates circuit #1.



2.4 Power Input

This is the circuit built around the Q1 Power MOSFET. It does three functions: **a)** Reverse power polarity protection with Q1 and R1, **b)** "Power Good" indication with R2 and D12, and **c)** Power supply filtering and decoupling with C1, C2, and C10-C13.

2.5 Processor

U1 is a PIC16F74 MPU that manages the serial port, all host communications, and all I/O lines on board the SPI. It runs the **SPI Exec** control program that interprets and executes the commands received from the controller application running on the host computer. U1 runs at a clock frequency of 12 MHz, as determined by the X1 oscillator crystal. MPU reads the DIP switches S1-1 thru S1-6 for configuration information and provides status indicators with LED lamps D8-D11.

There are two indicators that display information about the processor:

MPU Mode (D11): Works in conjunction with S1-6 switch to indicate that the MPU is in the Command Interpreter Mode.


SPI Ready (D10): Steady ON - SPI is ready to accept commands
Blinking - A reset operation underway or commands are being executed

2.6 Serial Comm Port

All communication with the host PC takes place via the serial Port. J2 connector is a 9-Pin female socket that is wired as a DCE (Data Communication Equipment) interface so that a single **9-conductor M/F serial cable** can be used without requiring gender changers or null modem adapters. J2 provides null modem functionality by shorting RTS line with CTS and DSR line with DTR.


Figure 3

DCE wired DB-09 socket
connector pin assignments



2.7 Configuration

DIP Switch Bank S1 is used to set the SPI communication parameters as follows (**C** – Closed (ON), **O** – Open (OFF)):



Interpreter Mode	This is the "Normal" mode of operation. SPI Exec program receives commands from the host application through the serial port and executes the commands.
Transparent Mode	<p>In this mode SPI Exec treats all transmissions from the host application as binary data and writes them to the Digital Output Port. Each write operation is followed by a "negative" pulse on the Clko line.</p> <p>In this mode SPI Exec also continuously monitors the Clki line for any transitions. When a transition is detected, it reads the signals at the Digital Input Port and sends the data as a single byte to the host application.</p>
Normal Transmission	A transmission from the SPI Module to the host application takes place only as a response to a command received from the host application. The configuration switches control the serial transmission parameters.
Auto Count	In this transmission mode, SPI Exec configures the SPI Module for communication at 1200 BAUD, 8 Bits, No parity, and one stop bit (1200, N, 8, 1), and continuously transmits single byte characters that count up from 00h to FFh. The purpose of this mode is to provide a continuous stream of characters so that a terminal program can be used to confirm successful serial transmission between the host PC and the SPI Module.

Note: SPI Module needs to be reset to recognize any configuration changes, since these switches are only read during the initial power-up or when a **Reset** operation is initiated.

2.8 Indicators

Power, D12	On - Indicates that power is on and the polarity is right
MPU Mode, D11	<p>Off - MPU is in the Command Interpreter mode. It will receive commands from the host application, carry out the commands, and send a response back with a return code.</p> <p>On - MPU is in the Transparent Mode. Any character received by the SPI module will be written to the Digital Output Port, followed by a clock pulse on the CLK0 line. Also, the data at the Digital Input port will be read upon detection of a READ pulse on the CLKI line, and will be sent to the host application as a single byte.</p>
Ready, D10	<p>On - SPI has been initialized and the MPU is ready.</p> <p>Off - MPU is not running. Pressing the RESET button should start the MPU.</p> <p>Blink - Command has been received and processed by the MPU</p>
Parity Error, D9	On - Incorrect parity bit detected
Frame Error, D8	On - Invalid async frame received. (Usually indicates mismatch in BAUD rates).

2.9 Analog Input Port (Port A)

AN0 - AN4	Analog Input Channels
AN5/Vref	This input is the Analog Input Channel #5, AN5, at its default setting. It can also function as the external reference input, Vref, that will be used for A-to-D conversions. The function of this input can be selected with SPI Exec commands. MPU normally uses the Vcc supply voltage as its internal reference for the A-to-D converter. If more stability, accuracy, or a different input range is desired, this pin can be selected as the input for an external voltage reference source. When external reference is selected, MPU will use the voltage at this pin as the reference for all A-to-D conversion functions on all analog inputs.
PWM	Pulse-Width Modulator output

PDIR Pulse-Width Modulator Direction output when PWM signal is used for DC motor speed control. If required, this output can be used as a general-purpose digital output line.

2.10 Digital Input Port (Port B)

DI0 - DI7 Digital input lines for TTL compatible digital logic signals. An octal buffer circuit is used to buffer and isolate the input lines from the bi-directional MPU bus.

CLKI Clock line for clocked read operations. Can be read with a command and can also be used as a general-purpose digital input line.

2.11 Digital Output Port (Port C)

DO0 - DO7 Buffered Digital output lines. A bank of 8 LED lamps are used to show the status of each line. Lamp is ON when the corresponding digital output line is HIGH.

CLKO Clock output line. Can be set, reset, and pulsed with commands. Not buffered.

SDIR Direction control bit for the stepper motor control applications. Can be used as a general-purpose digital output line with stepper output commands. Not buffered.


STEP Step pulse for stepper motor control applications. Duration of the pulse and the pulse repetition period can be preset, and the pulse generation can be started and stopped with stepper commands. Not buffered.

3. COMMAND INTERPRETER

SPI MPU manages communications, controls all hardware resources on board, and also runs the SPI Exec command interpreter when the MPU MODE switch S1-6 is in closed position and the MPU Mode indicator is **OFF**. In this mode MPU always watches the serial port and immediately executes any commands received from the host. Except for the System Reset command, it also sends an acknowledgement response back to the host as soon as the command is executed. If errors were detected, an Error Response may be sent back.

3.1 Command Structure

Commands and responses are carried by **Command frames** and have identical structures. Command frames are made up of four sections as shown below:



For example, the following hex representation of a command will set the stepper pulse duration to 100 ms:

FE 54 64 EF

3.2 Command Set

The complete list all SPI Exec commands and responses can be found at the end of this manual. Please note that even though the list shows commands and responses as two-digit hex numbers, actual commands and any data carried within the frames are simply 8-bit binary numbers. The Mnemonic representations of the op-codes are only used for documentation purposes and can be handy for use as programming constants (literals).

4. SPI CONTROL PANEL

SPI Control Panel application is designed to facilitate functional testing of the SPI module, as well as to provide an easy-to-use interface that can be used as the "front end" for simple experiments and demo setups.

SPI Control Panel v 0.9

Device: SPI Exec v 1.0 ● **Reset**

Digital Output Port

0 ☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐

All **ON** **OFF**

ClkO ☐

Digital Input Port

0 ☐ 1 ☐ 2 ☐ 3 ☐ 4 ☐ 5 ☐ 6 ☐ 7 ☐

Read

ClkI ☐ **Read**

PWM

Pulse x1.3 us

Period x5.3 us

Start **Stop**

Stepper Motor

Pulse x1.0 ms

Period x1.0 ms

Start **Stop**

Analog Input Port

Count	Volts	Vref
Ch 0	<input type="text" value="56"/>	<input type="text" value="1.09"/>
Ch 1	<input type="text" value="84"/>	<input type="text" value="1.64"/>
Ch 2	<input type="text" value="112"/>	<input type="text" value="2.18"/>
Ch 3	<input type="text" value="140"/>	<input type="text" value="2.73"/>
Ch 4	<input type="text" value="168"/>	<input type="text" value="3.28"/>
Ch 5	<input type="text" value="196"/>	<input type="text" value="3.82"/>

Read

Serial Port

Comm Port

1 ☐ 2 ☐ 3 ☐ 4 ☐

Speed

1200 ☐ 9600 ☐ 19200 ☐ 57600 ☐

Parity

None ☐ Odd ☐ Even ☐

Comm Errors

Frame ☐ Parity ☐ **Clr**

Apply

Unistep Technologies Tx Rx **Exit**

4.1 Installation

The computer disk included with the SPI package has three directories at the root level

1. Control Panel
2. User manual
3. Data Sheets

The 'Control Panel' directory contains one .exe file and at least one .ocx file. The .exe file is the Control Panel program and can be copied to any directory of your choice. The .ocx file, however, needs to be copied to the windows system directory. For most PC installations and MS Windows versions, one common system directory is 'c:\windows\system'. If the .ocx file is copied into this directory, the main Control Panel program can be run from any location.

4.2 Serial Port Settings

Serial Port setup and configuration controls of the SPI Control Panel program are grouped on the right-hand side section. Remember that you need to push (=click on) the **Apply** button to activate any changes made to the serial port settings. (Of course, SPI settings also need to be matched to the control panel settings for any successful communication to take place!)

Comm Port	You can use any of the Comm Ports 1 - 4 to communicate with the SPI module, depending on which com port hardware is present on your computer.
Speed	You can select 1200, 9600, 19200, or 57600 BAUD.
Parity	Parity bit can be disabled or odd/even parity can be selected.
Comm Errors	Any communication errors in the transmissions received from the SPI module will be indicated by these error indicators. They can be cleared using the Clr button.

4.3 SPI Exec

When the SPI Control Program is run, it immediately carries out the following actions:

- Initialize the PC serial port and open the communication channel
- Initialize various internal parameters
- Contact the SPI module and get the SPI Exec version number
- Initialize the SPI module with the internal parameters
- Clear SPI digital output port bits and stop any PWM or Stepper activity
- Turn the red "Power" light next to the Reset button from red to green to indicate that all is well.

Once the "Power" indicator turns green, the SPI Control Panel is ready to communicate with the SPI Exec.

4.4 Digital Output Port

The status of the 8 buffered digital output lines can be viewed and changed with the Digital Output Port indicators. The dull red color indicates a logic LOW output. A bright red color indicates a logic HIGH output on that line.

The SPI Control Panel Digital Output Port data bit indicators and the ClkO line indicator can be clicked on with the mouse to turn the corresponding bit (and the associated LED lamp) on and off.

The "**All ON**" and "**All OFF**" buttons can turn all bits on and off, respectively, all at the same time.

4.5 Digital Input Port

The SPI Control Panel digital input port section has indicators to show the status of the 8 buffered digital input lines. A dull red color indicates a logic LOW and the bright red color indicates a logic HIGH.

Digital Input Port indicators are "display only" indicators, naturally, and can not be "clicked on". The upper **Read** button reads and displays all Digital Input Port data bits. The lower **Read** button is used only to read the input clock line, **ClkI**.

4.6 Analog Input Port

This section of the SPI Control Panel manages the analog input port configuration, and displays the values of the analog input signals.

- The reference voltage source selection defaults to "Int (**I**nternal)". This means that the SPI module will use the 5 V DC supply line (Vcc) as its voltage reference.
- If an external reference is used, the "Ext" button should be selected, and the exact voltage of the reference should be entered into the Vref text box.
- When "Ext" is selected as the reference source, Channel 5 (AN5) is no longer available as an analog input channel, and its corresponding "Count" and "Volts" text boxes show "---"
- The first column, "**Count**", of 6 text boxes show the 8-bit digital values read from each of the 6 Analog Input Lines.
- The "**Volts**" column shows the voltage reading that corresponds to the count value when the reference voltage has the value indicated in the Vref text box.

Analog inputs are polled **once** each time the "**Read**" button is pressed.

4.7 PWM Output

The PWM section of the SPI Control Panel is used to configure and control the PWM signals generated by the SPI Module. The period, duration of the "on" or "high" portion of the waveform, and a "Direction" signal can be precisely controlled to obtain the desired PWM operation.

- Pulse Duration** This parameter is shown in the text box named "Pulse". The value cannot be entered directly, but it can be incremented and decremented in steps of 1 and 10 using the buttons with the arrows. Each count represents a duration of 1.3 μ s, and can be between 0 and 255.
- Pulse Period** The text box named "Period" shows the pulse period of the PWM signal. Each count represents 5.3 μ s, and can be incremented and decremented in steps of 1 and 10 using the buttons with the blue arrows. The valid values are between 1 and 255.
- Direction** Even though a PWM signal has no "direction" associated with it, since a major class of applications for PWM involves DC motor control, the SPI module provides a direction signal for a DC motor that might be driven with the PWM output. Selecting the "H" or "L" controls the level of the PDIR signal, and can be utilized to provide direction control for the DC motor. For any application that does not require a direction output, this signal can be utilized as a general-purpose digital output.
- Start, Stop** Once the pulse configuration parameters are set, the PWM signal can be started and stopped with these buttons. The stop/start operations do not affect the configuration settings. Program will retain the configuration information until it is terminated.

Note: Even though the SPI Control Panel lets you individually and independently adjust the pulse duration and pulse period (therefore the frequency), it will not prevent you from entering invalid combinations. One such example is to enter a pulse duration that is longer than the period of the signal. **The behaviour of the SPI Module for such invalid data can be unpredictable.** Responsibility for ensuring the validity of the configuration data rests with the user.

4.8 Stepper Output

The Stepper Motor section of the SPI Control Panel is used to configure and control the Stepper Motor Control signals generated by the SPI Module, much like the PWM section. Duration of the step pulse, its repetition rate, and the direction signal can all be individually controlled.

- Pulse Duration** This parameter is shown in the text box named "Pulse". The value cannot be entered directly, but it can be incremented and decremented in steps of 1 and 10 using the buttons with the arrows. Each count represents a duration of 1.0 ms, and can be between 0 and 255.
- Pulse Period** The text box named "Period" shows the pulse period of the stepper signal. Each count represents 1.0 ms, and can be incremented and decremented in steps of 1 and 10 using the buttons with the blue arrows. The valid values are between 1 and 255.
- Direction** The SDIR signal level can be controlled with the direction buttons. Selecting the "H" or "L" buttons sets the SDIR signal to the "High" and "Low" levels, respectively. If this signal is not being used to control the direction of a stepper motor, it can serve perfectly as a general-purpose digital output.
- Start, Stop** Once the pulse configuration parameters are set, the stepper signal can be started and stopped with these buttons. The stop/start operations do not affect the configuration settings. Program will retain the configuration information until it is terminated.

Note: Even though the SPI Control Panel lets you individually and independently adjust the pulse duration and pulse period (therefore the repetition rate), it will not prevent you from entering invalid combinations. One such example is to enter a pulse duration that is longer than the period of the signal. **The behaviour of the SPI**

Module for such invalid data can be unpredictable. Responsibility for ensuring the validity of the configuration data rests with the user.

4.9 Frame Display Boxes

The "Tx" and "Rx" text boxes are provided as a visual confirmation of the command frames exchanged between the SPI Control Panel and the SPI Module. These also work well to illustrate the use of the command frames for various control actions.

- | | |
|---------------|---|
| Tx Box | The "Tx" text box at the bottom of the SPI Control Panel screen show the control frames transmitted to the SPI Module when on-screen controls are used to control the SPI Module. |
| Rx Box | The "Rx" text box at the bottom of the SPI Control Panel screen show the command frames received from the SPI Module. |

5. SUPPORT

We are here to help if you need assistance in using or troubleshooting the SPI Module or the SPI Control Panel. Please do not hesitate to contact Unistep Tech Support using any of the means listed below:

- | | |
|-----------------|--|
| Internet | Our web site www.unistep.ca has some support information and we are adding new material all the time. |
| E-Mail | Please use our e-mail support address support@unistep.ca for any questions, comments, or recommendations you may wish to send our way. We strive to reply within two days. |
| Phone | Please contact us at 416-619-9308 if you need immediate help. |

SPI Exec Command Summary v1.0

Function Group	Cmnd Resp	Op-Code Byte	Data Byte 1	Data Byte 2	Mnemonic	Command / Operation	Length
System & Config							
	C	01	--	--	RST	System Reset	1
	R	01	--	--	--	System Reset Proceeding	1
	C	02	--	--	SID	Report SPI Exec ID	1
	R	02	nn	mm	--	SPI Exec version follows, <nn.mm>	3
Digital Output							
	C	10	nn	--	OUB nn	Write Output Byte <nn>	2
	R	10	--	--	--	Byte written to Output Port	1
	C	11	nn	mm	OOW nn,mm	Write Output Word <mm nn>	3
	R	11	--	--	--	Word written to Output Port	1
	C	12	nn	--	SCD	Set Output Clock Duration to <nn> ms	2
	R	12	--	--	--	Output clock duration set	1
	C	13	--	--	CLP	Pulse Output Clock	1
	R	13	--	--	--	Output clock pulsed	1
	C	14	--	--	CLH	Set Output Clock to HIGH	1
	R	14	--	--	--	Output clock set to HIGH	1
	C	15	--	--	CLL	Clear Output Clock to LOW	1
	R	15	--	--	--	Output Clock set to LOW	1
Digital Input							
	C	20	--	--	INP	Read Digital Input Port	1
	R	20	nn	--	--	Read <nn> from Input Port	2
	C	21	--	--	INC	Read Input Clock Line	1
	R	21	nn	--	--	Read <nn> on input clock line	2
Analog Input							
	C	30	nn	--	RAC nn	Read Analog Channel <nn>	2
	R	30	nn	mm	--	Count <mm> read from Channel <nn>	3
	C	31	--	--	INV	Select Internal Vref	1
	R	31	--	--	--	ADC configured for internal Vref	1
	C	32	--	--	EXV	Select External Vref	1
	R	32	--	--	--	ADC configured for External Vref	1
PWM Output							
	C	40	--	--	PWO	Start PWM Output	1
	R	40	--	--	--	PWM output Started	1
	C	41	--	--	PWF	Stop PWM Output	1
	R	41	--	--	--	PWM output stopped	1
	C	42	--	--	PDH	Set PWM Direction Line to HIGH	1
	R	42	--	--	--	PWM Direction line set to HIGH	1
	C	43	--	--	PDL	Set PWM Direction Line to LOW	1
	R	43	--	--	--	PWM Direction Line cleared to LOW	1
	C	44	nn	--	PWD nn	Set PWM signal ON Duration to <nn>	2
	R	44	--	--	--	PWM signal ON duration set	1
	C	45	nn	--	PWP nn	Set PWM Period to <nn>	2
	R	45	--	--	--	PWM Period set	1

STEPPER Output							
	C	50	--	--	STO	Start Stepper Output	1
	R	50	--	--	--	Stepper started	1
	C	51	--	--	STF	Stop Stepper Output	1
	R	51	--	--	--	Stepper stopped	1
	C	52	--	--	SDH	Set Stepper Direction to HIGH	1
	R	52	--	--	--	Stepper direction set to HIGH	1
	C	53	--	--	SDL	Set Stepper Direction to LOW	1
	R	53	--	--	--	Stepper direction set to LOW	1
	C	54	nn	--	STD	Set Stepper Pulse Duration to <nn> ms	2
	R	54	--	--	--	Stepper pulse duration set	1
	C	55	nn	--	STP	Set Stepper Pulse Period to <nn> ms	2
	R	55	--	--	--	Stepper pulse period set	1
I ² C Port						NOT IMPLEMENTED IN VERSION 1.0	
	C	60	nn	--	DIC	Download I ² C Packet of <nn> bytes	nn+2
	R	60	--	--	--	I ² C packet downloaded	1
	C	61	--	--	TIC	Transmit I ² C Packet from Buffer	1
	R	61	--	--	--	I ² C Packet Transmitted	1
	C	62	--	--	RIC	Receive I ² C Packet	1
	R	62	--	--	--	I ² C Packet Received	1
	C	63	--	--	UIC	Upload I ² C Packet	1
	R	63	nn	--	--	Uploading I ² C packet of <nn> bytes	nn+2
ERROR Response							
	R	F0	--	--	CNR	Command not Recognized	1
	R	F1	--	--	CFE	Command Framing Error	1
	R	F2	--	--	CRE	Parameter Range Error	1
	R	F3	--	--	ETO	Event Time Out	1
	R	F4	--	--	OVR	Command Buffer Overrun	1

Command/Response Operation

Op-Codes indicated as "C" are the commands that would be sent to the SPI module to carry out the desired operation. SPI unit will always acknowledge the command with a response Op-Code. These response Op-Codes are the ones indicated with an "R" in the "Cmnd/Resp" column. It is up to the user application to make use of these response codes.