NOTE: Please read all instructions carefully before using this product

Table of Contents

Safety Notice

Hardware Pack

Assembly Instruction

Parts List

Warranty

Ordering Parts

Model H2502C

Retain This Manual for Reference

110624

ASSEMBLY & OWNER'S MANUAL



CLUB REVOLUTION CYCLE H2502C



2801 S. Towne Ave, Pomona, CA 91766 Tel: (800) 999-8899 Fax: (626) 961-9966

www.impex-fitness.com info@impex-fitness.com

TABLE OF CONTENTS

BEFORE YOU BEGIN	1
IMPORTANT SAFETY NOTICES	2
WARNING LABEL PLACEMENT	3
HARDWARE PACK	
ASSEMBLY INSTRUCTIONS	
EXPLODED DIAGRAM	
PARTS LIST	9
CARE, MAINTENANCE, AND STORAGE	10
OPERATING NOTES	11
EXERCISE GUIDELINES	
WARRANTY	13
ORDERING PARTS	13

BEFORE YOU BEGIN

Thank you for selecting the MARCY Club Revolution Cycle H2502C by IMPEX[®] INC. For your safety and benefit, read this manual carefully before using the bike. As a manufacturer, we are committed to provide you complete customer satisfaction. If you have any questions, or find there are missing or damaged parts, we guarantee you complete satisfaction through direct assistance from our factory. To avoid unnecessary delays, *please call our TOLL-FREE customer service number.* Our Customer Service Agents will provide immediate assistance to you.

Toll-Free Customer Service Number 1-800-999-8899 Mon. - Fri. 9 a.m. - 5 p.m. PST www.impex-fitness.com info@impex-fitness.com

IMPORTANT SAFETY NOTICE

PRECAUTIONS

This exercise bike is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your bike. In particular, note the following safety precautions:

- 1. Keep children and pets away from the exercise bike at all times. DO NOT leave children unattended in the same room with the bike.
- 2. Only one person at a time should use the bike.
- 3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY.
- 4. Position the bike on a clear, leveled surface. DO NOT use the bike near water or outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the bike. Running or aerobic shoes are also required when using the bike.
- 7. Use the bike only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- 8. Do not place any sharp object around the bike.
- 9. Disabled person should not use the bike without a qualified person or physician in attendance.
- 10. Before using the bike to exercise, always do stretching exercises to properly warm up.
- 11. Never operate the bike if it is not functioning properly.
- 12. Read all warnings posted on the exercise bike.
- 13. Inspect the exercise bike for worn or loose component prior to use. Tighten/replace any loose or wore components prior to use.
- 14. Care should be taken in mounting or dismounting the exercise bike.
- 15. This exercise bike is for consumer and home use only.

WARNING: BEFORE BEGINNING ANY EXERCISE PROGRAM, CONSULT YOUR PHYSICIAN. THIS IS ESPECIALLY IMPORTANT FOR INDIVIDUALS OVER THE AGE OF 35 OR PERSONS WITH PRE-EXISTING HEALTH PROBLEMS. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. IMPEX INC. ASSUMES NO RESPONSIBILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE SUSTAINED BY OR THROUGH THE USE OF THIS PRODUCT. SAVE THESE INSTRUCTIONS.

WARNING LABEL PLACEMENT



The Warning Labels and Caution Label shown here have been placed on the Rear Stabilizer, Main Frame. If the labels are missing or illegible, please call customer service at 1-800-999-8899 for replacement. Apply the labels in location shown.

HARDWARE PACK

NOTE: The following parts are not drawn to scale. Please use your own ruler to measure the size.

No.	Description	Identifier	Q'ty
8	Lever Knob		4
9	M8 x 5/8" Allen Bolt		4
16	M8 x 2 7/8" Carriage Bolt		4
17	Ø 7/8" Curved Washer	M	4
18	M8 Acorn Nut		4
19	Ø 5/8" x Ø 3/8" Flat Washer		4
20	Ø 1/2" x Ø 3/8" Lock Washer		4
	#6 Allen Wrench		1
	Crossing Wrench		1

COMPONENTS FOR ASSEMBLY





















NO.14



NO.15

ASSEMBLY INSTRUCTION

- Tools Required For Assembling the Bike: One Crossing Wrench and Allen Wrench, provided by manufacturer.
- NOTE: It is strongly recommended that two or more people assemble this bike to avoid possible injury.

STEP-1

- A.) Do not tighten Bolts until instructed to do so.
- B.) Thread two Level Adjustment Knobs (#8) each onto the Front & Rear Stabilizer (#2 & #3).
- C.) Attach the Front Stabilizer (#2) to the Main Frame (#1). Secure it with two M8 x 2 ³/₄" Carriage Bolts (#16), two Ø 5/8" Curved Washers (#17), and two M8 Acorn Nuts (#18).
- D.) Attach the Rear Stabilizer (#3) to the Main Frame (#1). Secure it with two M8 x 2 ³/₄" Carriage Bolts (#16), two Ø 5/8" Curved Washers (#17), and two M8 Acorn Nuts (#18).
- E.) Securely tighten all Bolts.
- F.) Adjust the Level Adjustment Knob to stabilize the Bike on floor.
- G.) Thread the Right Pedal (#15) clockwise onto the right Crank (#38).
- H.) Thread the Left Pedal (#14) counterclockwise onto the left Crank (#38)



STEP 2

- A.) Insert the Handle Post (#6) into the front opening on Main Frame (#1). Use the Lock Knob (#11) to hold the Handle Post at selected height.
- B.) Attach the Handle (#7) to the Handle. Secure them together with four M8 x 5/8" Allen Bolts (#9), four Ø 5/8" Lock Washers (#20), and four Ø 5/8" Flat Washers (#19).
- C.) Insert the Seat Post (#4) into the opening on Main Frame. Use the Lock Knob (#11) to hold the Seat Post at selected height.
- D.) Flip over the Seat Pad (#12). Insert the tube of the Seat Support into the open slot and securely fasten the two nuts to secure the Seat Pad to the tube.
- E.) Insert the Seat Support (#5) through the open slot on Seat Post. Use the Lock Knob (#11) to hold the Seat at selected position.



EXPLODED DIAGRAM



PARTS I	LIST		
PART			
NO.	DESCRIPTION	SPEC.	QUANTITY
1	Main Frame		1
2	Front Stabilizer		1
3	Rear Stabilizer		1
4	Vertical Seat Post		1
5	Seat Support		1
6	Handle Post		1
7	Handle		1
8	Level Adjustment Knob		4
9	Allen Bolt	M8 x 5/8"	4
10	Tension Adjustment Knob		1
11	Lock Knob		3
12	Seat Pad		1
13	Brake Handle		1
14	Left Pedal		1
15	Right Pedal		1
16	Carriage Bolt	M8 x 2 7/8"	4
17	Curved Washer	Ø 7/8"	4
18	Acorn Nut	M8	4
19	Flat Washer	Ø 5/8" x Ø 3/8"	4
20	Lock Washer	Ø ½" x Ø 3/8"	4
21	Handle Grip		2
22	Round End Cap	Ø 1"	2
23	Rectangle End Cap	7/8" x 2"	4
24	Sleeve		4
25	Bottle Rack		1
26	Philips Screw	M4 x ¾"	2
27	Brake Bracket		1
28	Brake Pad		1
29	Flywheel		1
30	Flywheel Axle		1
31	Flywheel Ball Bearing	6001	2
32	Stabilizer End Cap		4
33	Aircraft Nut	M8	2
34	Roller Wheel		2
35	Allen Bolt	M8 x 1 5/8"	2
36	Shroud		1
37	Chain Belt		1
38	Crank		1
39	Crank Axle		1
40	Crank Ball Bearing	6203	2

CARE, MAINTENANCE AND STORAGE

- 1. Inspect and tighten all parts each time you use the bike. Replace any worn parts immediately.
- 2. The bike can be cleaned using a damp cloth and mild non-abrasive detergent. Do not use solvents.
- 3. Store the bike IN-DOOR. Excess moisture and water would cause rust on the frame.
- 4. The Bike shall be placed at least 24 inches away from the wall or/and any other object such as furniture to provide safe access to and passage around the bike.
- 5. To avoid possible injury, the help of two or more people are needed when moving the bike around.
- 6. Disposal Instructions The equipment can be safely disassembled and disposed without unreasonable hazards. Call your local recycle agency regarding details of recycling.
- 7. The maximum user weight is 300 lbs.
- 8. Assembled Dimension: 51" x 20" x 41"

OPERATING NOTES

ADJUSTMENT

- 1. Use the Tension Adjustment Knob (#10) to adjust the resistance for exercise.
- The seat height adjustment is in approximately 1" increment.
 *The seat height can be adjusted for 6 different height ranges from 36" to 41".
- 3. Loosen and pull out the Lock Knob (#11). Slide the Seat/ Seat Post/ Handle bar to the desired position on the Seat Post, Seat Support, Handle Post, and then release the Lock Knob and securely fasten the Knob to lock the Seat Post, Seat Support, and Handle Post.

Stopping the Exercise

- 1. Press down on the Brake Handle to stop the fly wheel. ONLY when the flywheel has stopped, will it be safe to remove feet from pedals.\
- 2. DO NOT stop pedaling: doing so could result in serious injury.
- 3. DO NOT attempt to stop the Fly Wheel by hands, feet or any other device not indicated in this instruction.

TRANSPORT

The Bike has a pair Roller Wheels on Front Stabilizer. To move, carefully tilt the cycle forward, and then roll.

EXERCISE GUIDELINES

Using your **Bike** will provide you with several benefits, it will improve your physical fitness, tone muscle and in conjunction with calorie controlled diet help you lose weight.

1. The Warm Up Phase

This stage helps get the blood flowing around the body and the muscles working properly. It will also reduce the risk of cramp and muscle injury. It is advisable to do a few stretching exercises as shown below. Each stretch should be held for approximately 30 seconds, do not force or jerk your muscles into a stretch - if it hurts, STOP.



2. The Exercise Phase

This is the stage where you put the effort in. After regular use, the muscles in your legs will become more flexible. Work to your but it is very important to maintain a steady tempo throughout. The rate of work should be sufficient to raise your heartbeat into the target zone shown on the graph below.



This stage should last for a minimum of 12 minutes though most people start at about 15-20 minutes

© IMPEX INC.

3. The Cool Down Phase

This stage is to let your Cardio-vascular System and muscles wind down. This is a repeat of the warm up exercise e.g. reduce your tempo, continue for approximately 5 minutes. The stretching exercises should now be repeated, again remembering not to force or jerk your muscles into the stretch.

As you get fitter you may need to train longer and harder. It is advisable to train at least three times a week, and if possible space your workouts evenly throughout the week.

MUSCLE TONING

To tone muscle while on your **MAGNETIC BIKE** you will need to have the resistance set quite high. This will put more strain on our leg muscles and may mean you cannot train for as long as you would like. If you are also trying to improve your fitness you need to alter your training program. You should train as normal during the warm up and cool down phases, but towards the end of the exercise phase you should increase resistance making your legs work harder. You will have to reduce your speed to keep your heart rate in the target zone.

WEIGHT LOSS

The important factor here is the amount of effort you put in. The harder and longer you work the more calories you will burn. Effectively this is the same as if you were training to improve your fitness, the difference is the goal.



LIMITED WARRANTY

IMPEX Inc. ("IMPEX[®]") warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of two years on the Frame from the date of purchase. This warranty extends only to the original purchaser. IMPEX's obligation under this Warranty is limited to replacing or repairing, at IMPEX's option.

All returns must be pre-authorized by IMPEX. Pre-authorization may be obtained by calling IMPEX Customer Service Department at 1-800-999-8899. All freights for products return to IMPEX must be prepaid by the customer. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an IMPEX authorized service center or for products used for commercial or rental purposes. No other warranty beyond that specifically set forth above is authorized by IMPEX.

IMPEX is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or other damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyments or use, costs of removal, installation or other consequential damages or whatsoever natures. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you.

The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal right. You may also have other rights which vary from state to state. Register on-line www.impex-fitness.com

IMPEX[®] INC. 2801 S. Towne Ave. Pomona, CA 91766

ORDERING REPLACEMENT PARTS

Replacement parts can be ordered by calling our Customer Service Department toll-free at **1-800-999-8899** during our regular business hours: Monday through Friday, 9 am until 5 pm Pacific standard time.

info@impex-fitness.com

When ordering replacement part, always give the following information.

- 1. Model
- 2. Description of Parts
- 3. Part Number
- 4. Date of Purchase

© IMPEX INC.