

HT10V/MT10PKIT O-Ring Replacement Kit For HT10V Series High Temperature And MT10P Medium Temperature Liquid-Cooled Enclosures Installation Instructions C1955M (11/98)



1.0 INSTALLATION

O-RING REPLACEMENT (HT10V Series Enclosures)

1. Turn off power to the enclosure.
2. Disconnect the in and out hoses for fluid from the fittings on the front plate of the enclosure and allow the fluid to completely drain from the front plate.
3. Remove the V-groove hose clamp that attaches the enclosure front plate to the enclosure.
4. Remove the desiccant bags inside the enclosure and replace them with the two bags from the kit.
5. Remove the eight screws and lock washers from the enclosure front plate that attach the backup plate, window, O-ring retainer, and O-ring.
6. Remove the O-ring and discard.
7. Place the enclosure front plate on a flat surface with the inside surface facing upward.
8. Position the new O-ring in the groove on the enclosure front plate around the window opening.
9. Position the O-ring retainer on top of the O-ring, then position the window and the backup plate on top of the window. Align the screw holes in the backup plate with the holes in the enclosure front plate.
10. Reinstall the screws and lock washers finger tight, then tighten them in a star pattern. Ensure new O-ring remains in the correct position.
11. Place the enclosure front plate on the enclosure and reinstall the V-groove hose clamp.
12. Reconnect the in and out hoses for fluid to the fittings on the front plate of the enclosure.

O-RING REPLACEMENT (MT10P Enclosure)

1. Turn off power to the enclosure.
2. Remove the V-groove hose clamp that attaches the enclosure front plate to the enclosure.
3. Remove the desiccant bags inside the enclosure and replace them with the two bags from the kit.
4. Remove the eight screws and lock washers from the enclosure front plate that attach the backup plate, window, and O-ring.
5. Remove the O-ring and discard.
6. Place the enclosure front plate on a flat surface with the inside surface facing upward.
7. Position the new O-ring on the enclosure front plate around the window opening.
8. Position the window on top of the O-ring, then position the backup plate on top of the window. Align the screw holes in the backup plate with the holes in the enclosure front plate.
9. Reinstall the screws and lock washers finger tight, then tighten them in a star pattern until they are snug. **Do not over-tighten.** Ensure new O-ring remains in the correct position.
10. Place the enclosure front plate on the enclosure and reinstall the V-groove hose clamp.



CAUTION: *There is no groove for the O-ring on this model enclosure. Make sure the new O-ring remains in the correct position when reassembling the window and backup plate onto the enclosure front plate. Over-tightening the screws may cause the O-ring to displace.*

2.0 WARRANTY AND RETURN INFORMATION

WARRANTY

Pelco will repair or replace, without charge, any merchandise proved defective in material or workmanship for a period of one year after the date of shipment.

Exceptions to this warranty are as noted below:

- Five years on FT/FR8000 Series fiber optic products.
- Three years on Genex® Series products (multiplexers, server, and keyboard).
- Three years on Camclosure® and fixed camera models, except the CC3701H-2, CC3701H-2X, CC3751H-2, CC3651H-2X, MC3651H-2, and MC3651H-2X camera models, which have a five-year warranty.
- Two years on standard motorized or fixed focal length lenses.
- Two years on Legacy®, CM6700/CM6800/CM9700 Series matrix, and DF5/DF8 Series fixed dome products.
- Two years on Spectra®, Esprit®, ExSite™, and PS20 scanners, including when used in continuous motion applications.
- Two years on Esprit® and WW5700 Series window wiper (excluding wiper blades).
- Eighteen months on DX Series digital video recorders, NVR300 Series network video recorders, and Endura™ Series distributed network-based video products.
- One year (except video heads) on video cassette recorders (VCRs). Video heads will be covered for a period of six months.
- Six months on all pan and tilts, scanners or preset lenses used in continuous motion applications (that is, preset scan, tour and auto scan modes).

Pelco will warrant all replacement parts and repairs for 90 days from the date of Pelco shipment. All goods requiring warranty repair shall be sent freight prepaid to Pelco, Clovis, California. Repairs made necessary by reason of misuse, alteration, normal wear, or accident are not covered under this warranty.

Pelco assumes no risk and shall be subject to no liability for damages or loss resulting from the specific use or application made of the Products. Pelco's liability for any claim, whether based on breach of contract, negligence, infringement of any rights of any party or product liability, relating to the Products shall not exceed the price paid by the Dealer to Pelco for such Products. In no event will Pelco be liable for any special, incidental or consequential damages (including loss of use, loss of profit and claims of third parties) however caused, whether by the negligence of Pelco or otherwise.

The above warranty provides the Dealer with specific legal rights. The Dealer may also have additional rights, which are subject to variation from state to state.

If a warranty repair is required, the Dealer must contact Pelco at (800) 289-9100 or (559) 292-1981 to obtain a Repair Authorization number (RA), and provide the following information:

1. Model and serial number
2. Date of shipment, P.O. number, Sales Order number, or Pelco invoice number
3. Details of the defect or problem

If there is a dispute regarding the warranty of a product which does not fall under the warranty conditions stated above, please include a written explanation with the product when returned. Method of return shipment shall be the same or equal to the method by which the item was received by Pelco.

RETURNS

In order to expedite parts returned to the factory for repair or credit, please call the factory at (800) 289-9100 or (559) 292-1981 to obtain an authorization number (CA number if returned for credit, and RA number if returned for repair).

All merchandise returned for credit may be subject to a 20% restocking and refurbishing charge. Goods returned for repair or credit should be clearly identified with the assigned CA or RA number and freight should be prepaid. Ship to the appropriate address below.

If you are located within the continental U.S., Alaska, Hawaii or Puerto Rico, send goods to:

Service Department
Pelco
3500 Pelco Way
Clovis, CA 93612-5699

If you are located outside the continental U.S., Alaska, Hawaii or Puerto Rico and are instructed to return goods to the USA, you may do one of the following:

If the goods are to be sent by a COURIER SERVICE, send the goods to:

Pelco
3500 Pelco Way
Clovis, CA 93612-5699 USA

If the goods are to be sent by a FREIGHT FORWARDER, send the goods to:

Pelco c/o Expeditors
473 Eccles Avenue
South San Francisco, CA 94080 USA
Phone: 650-737-1700
Fax: 650-737-0933

Pelco, the Pelco logo, Camclosure, Esprit, Genex, Legacy, and Spectra are registered trademarks of Pelco.
Endura and ExSite are trademarks of Pelco.

© Copyright 1998, Pelco. All rights reserved.