


INSTALLATION INSTRUCTIONS FOR L1753 LAMPHOLDER FOR USE WITH HALO TRACK SYSTEMS ONLY

TO ADJUST HALO-2 SERIES LAMPHOLDER

Halo-2 lampholders can be used with Halo Miniature or Halo-2 Power-Trac systems. An adjustable contact allows you to select the circuit position. Use a narrow blade screwdriver, as shown, to adjust the contact. Lift or lower the contact until it touches the plastic stop of the contact assembly. For circuit #1 move contact to the down position. For circuit #2 move contact to the up position. (Figure 1)

FIGURE 1



TO USE HALO-2 LAMPHOLDER WITH MINIATURE POWER-TRAC

When using Halo-2 lampholder with the Miniature Power-Trac System (L650, L651, L652, L653) adjustable contact must be in #1 (DOWN) position. (Figure 2)

FIGURE 2





FIGURE 3



TO USE HALO-2 LAMPHOLDER WITH HALO-2 POWER-TRAC

When using Halo-2 Lampholder with the Halo-2 Power-Trac System (L640, L641, L642, L643) adjust the contact position of each lampholder to the desired circuit-Circuit #1 (DOWN) or to Circuit #2 (UP). (Figures 2 & 3)

TO INSTALL LAMPHOLDER

Hold lampholder by the mounting adapter. Insert contact head into Halo Power-Trac. Twist mounting adapter approximately $\frac{1}{4}$ " turn (90°) until mounting sleeve tab locks into Power-Trac opening. (Figure 4)

FIGURE 4






FIGURE 5



NOTE: Forcing mounting adapter in wrong direction may damage the contact assembly! If mounting adapter will not turn easily, twist adapter in opposite direction.

Polarity line on adapter must align with polarity line on Power-Trac for proper installation. (Figure 5)

FIGURE 6



TO REMOVE LAMPHOLDER

Pull down on mounting adapter sleeve until tab is free of Power-Trac channel opening. Twist mounting adapter $\frac{1}{4}$ " turn (90°) until contact head is free and remove lampholder from track. (Figure 6)

RE-LAMPING INSTRUCTIONS FOR L1753 LAMPHOLDER

WARNING Before working in Power-Trac fixture, be sure to turn off AC power or remove fixture from Power-Trac.

CAUTION Halogen cycle lamps operate at extremely high temperatures. Allow sufficient time for fixtures to cool before relamping or attempting any other work.

INSTALLING LAMP

STEP 1 Pull spring held cover from end opposite of socket and hold or hook over end of unit as shown. (Figure 1)

STEP 2 Install 250 watt frosted quartz lamp mini-candelabra base only by screwing into socket. Do not handle lamp with bare hand. Use a cloth to touch lamp.

STEP 3 Take lens and 2 Gasket pieces from packing, placing 1 gasket on each of long edge of lens. Slide lens into unit keeping gaskets with glass edges. (Figure 2)

STEP 4 Replace end cover of unit back securing it on end of housing.

TO RELAMP

STEP 1 Pull spring held cover from end opposite lamp and hold or hook over end of unit. (Figure 1)

STEP 2 Slide glass lens far enough to remove lamp. (Figure 2)

STEP 3 Replace lamp with 250 watt frosted quartz, mini-candelabra base lamp only.

STEP 4 Replace glass lens and center in unit. Glass must be in place during operation.

STEP 5 Replace spring held cover.

FIGURE 1




FIGURE 2

