
TI

Assembly Instructions



- Carefully remove the fixture out of the carton, and check that all parts are included referring to the above illustration. Make sure not to misplace any parts that are needed for the installation;
- Thread the nipple (2) into the coupling (1) tightly.
- Slide the spacer tube (3), tube cover (4), column (5), check ring (6), housing (7), cap (8), spacer tube (9) onto the nipple (2), then secure them with fixture loop (10).
- Install the ARM (11) onto the strap (13) and fix it by the ball screws (12).
- 5. Install the ARM (11) onto the housing (7) and fix it by the ball screws (12).
- 6. Thread the nipple (18) into the coupling (17) and secure it with hex nut.
- Slide the spacer tube (19), tube cover (20), rubber washer (21), glass shade (22), steel
 washer (23) onto the nipple (18), and secure them with hex nut (24).
- 8. Secure the cap (25) onto the nipple (18), then fix it by the finial (26).
- 9. Install proper bulb (not included).
- Install the glass panel (15) rubber washer (14) onto the round plate (16)
 (let the mounting hole aligned), then secure them with ball screws (19).