Installation Instructions


ERW20-1C Refrigeration Packages


NOTICE: This water cooler must be connected to the water supply using a dielectric coupling.

NOTE: It is important to insure proper ventilation. Allow a minimum clearance of 12 inches (305 mm) in front and 3 inches (76mm) in the rear of the unit. If unit is to be installed in an enclosure, allow the following clearances around unit - 1 inch (25mm) each side, 3 inches (76mm) in the rear, 3 inches (76mm) above wall.

This chiller has been designed for use with potable water and includes an o-ring seal on the drain plug. The fitting should be replaced if the unit is to be used with more aggressive fluids

For use with photo processing applications, adjust cold control to warmer settings.





LEGEND

A = 3/8" O.D. TUBE WATER OUT

B = 3/8" O.D. TUBE WATER INLET

C = 3/8" O.D. TUBE TANK DRAIN

ERW20-1C

ITEMIZED PARTS LIST		
ITEM NO.	PART NO.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17* 18 19 22 12 23 24 25 26 27 28 29 31	50196C 28180C 28101C 28104C 28178C 28179C 28089C 28175C 27957C 28176C 30235C 30768C 30812C 35895C 35891C 36074C 30234C 66625C 70772C 66204C 66629C 35845C 35845C 35846C 30560C 70482C 70483C	Grommet Panel Insulation Box (Rear) Panel End Box Insulation (Front) Terminal Box Grille Cover Terminal Box Rear Panel Cover Insulation Box Base Ass'y Terminal Cover Solenoid Valve Overload Cold Control Cold Control Cold Control Freeze Protect Capacitor Compressor Service Pak Overload Spring Clip Compressor Condenser Evaporator Drain Plug Drier Heat Exchanger Relay Cap-Capacitor End Bracket-Capacitor Terminal Cover Male Connector Fitting Elbow Fitting Compressor Mounting Sleeve

*INCLUDES RELAY & OVERLOAD. IF UNDER WARRANTY, REPLACE WITH SAME COMPRESSOR USED IN ORIGINAL ASSEMBLY.

NOTE: All correspondence pertaining to any of the above water cooler or orders for repair parts MUST include model number and serial number of cooler, name and part number of replacement part.

INSTALLATION

- Potable water inlet and outlet are 3/8" (9 mm) O.D. tube located on top of unit. Water cooled condenser inlet and outlet are 3/8" (9 mm) O.D. tube located on right front of unit. Installer to provide air gap at condenser water outlet to comply with local plumbing specifications. Contractor to supply connections as required.
- Connecting lines to be of copper, thoroughly flushed to remove all foreign matter before being connected to cooler. If flushing does not remove all particles, a water strainer should be installed in supply line
- 3. Connect cooler to building supply line with a shut-off valve and install a union connection between the valve and cooler.
- Electrical: Make sure power supply is identical in voltage, cycle, and phase to that specified on cooler serial plate. Never wire compressor directly to the power supply

START-UP

- 1. Open supply line valve.
- 2. Purge air from all water lines by operating bubbler valve of fountain.
- 3. Connect to electrical power.

TROUBLE SHOOTING & MAINTENANCE

Temperature Control: Factory set for 50° F water under normal conditions. To adjust water temperature, turn screw on Item No. 14 clockwise for colder, counter clockwise for warmer.

Ventilation: Cabinet louvers should be periodically cleaned with brush, air hose or vacuum cleaner. Excess dirt or poor ventilation can cause no cold water and compressor cycling on the compressor overload protector

Lubrication: Motors are lifetime lubricated.

