

WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product. Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the even of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.

Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period.

- Please activate my limited warranty for WAGAN Corp. EZ Grip Rechargeable Spotlight
- Enclosed copy of original sales receipt.

Name			
Mail Address			
City			
State, Zip Code			
Item Purchased	Rechargeable 1,500,000 Candle Spotlight		
Stores Name			
Date of Purchase			
Signature		Date	

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty. Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service
 WAGAN Corporation
 3589 Yale Way
 Fremont, CA 94538

© 2004 WAGAN Corp.



Item no. 2292

Rechargeable 1,500,000 Candle Spotlight™ With Adjustable Handle



User's Manual

Thank you for purchasing the Rechargeable 150,000,000 Candle Spotlight by Wagan Tech. With normal care and proper treatment it will provide years of reliable service. Please read all operating instructions carefully before use.

CHARGING THE INTERNAL BATTERY:

1. The internal battery will need an initial charge of approximately 12 hours before first use
2. The internal battery should only be charged with one of the accessories provided
3. The on/off button must be in the OFF position whilst charging.
4. Avoid charging the internal battery at temperatures below 4°C or above 40°C
5. The spotlight should be kept fully charged when not in use. If it is stored then it should be recharged every 6-8 weeks. Always ensure that the switch is in the OFF position when it is not in use
6. If the charge is very low the battery will take approximately 12 hours to reach maximum capacity when using the supplied mains adapter. However, a 4 hour charge will provide a useable amount of charge
7. The battery will also charge from the 12 volt cigarette lighter socket of your vehicle using the lead provided. It is recommended that it is not left in this mode of charging for longer than 3 hours. Charging should be done with the engine running to prevent running down the charge on your vehicles' battery
8. There is no indication that the battery is charging or is fully charged
9. Do not charge continuously for a period longer than 24 hours
10. It is advisable to recharge the spotlight after each use
11. The battery charge does not have to be fully depleted before recharging
12. The lifespan of the internal battery is dependent on how it is treated; the more it is used the longer it should last. It is not possible to predict how long the battery will last but approximately

40 charge and discharge cycles should be expected from a well maintained battery

CHANGING THE HALOGEN BULB:

To change the spotlight bulb unscrew the lens cover anti-clockwise. Remove the bulb by, first, disconnecting the spade connector. Then unclip the springclip and pull out the bulb.

Important: Do not touch the glass of the bulb, handle by base only. If necessary, clean the glass with methylated spirit and a soft cloth.

USING THE SPOTLIGHT:

To operate the spotlight, press the On/Off button. Under optimum conditions, with a fully charged battery, the spotlight can normally be used for 20-25 minutes. To turn the carry handle into the 'pistol-grip' position (and vice-versa), press and hold the button and turn the handle around until it clicks into the position. Release the button.

The stand is adjustable by pulling it away from the spotlight body until the desired angle is achieved.

BATTERY DISPOSAL:

- The lead acid battery in this spotlight has a normal service life of many years, when the battery does expire it should be removed from the spotlight for recycling. Please contact your local solid waste authority for recycling information. To remove the battery, unscrew the lens of the spotlight, to reveal the rear of the lens and the internal parts of the spotlight
- Remove the 4 cross head screws situated in the top four corners of the battery retainer
- Once these have been removed take out the switch assembly and battery retainer
- Remove the battery connections and slide the battery out

Rechargeable 150,000,000 Candle Spotlight by Wagan Tech

USER'S MANUAL — Please read before using this equipment.

SAFETY GUIDELINES:

- Keep out of reach of children
- Do not use in wet conditions
- Store in a clean, dry environment
- Do not use if this unit is damaged in any way
- Never short the terminals of the internal battery together
- Never attempt to change the bulb when the battery is charging
- Do not expose the battery to fire or high temperatures, the battery may explode
- Never look directly into the light
- Caution! The lens will become hot after prolonged use
- Do not attempt to disassemble battery or remove any parts from the battery terminals
- Before disposing, protect exposed terminals

SPECIFICATIONS:

Name	Description
Light	35 Watt halogen bulb
Bulb fitting	H3, 6 Volt
Battery	6V 4Ah maintenance free sealed lead acid rechargeable battery
DC adapter input: output:	240 Volt AC ~ 50 Hz DC 9 Volt 500 mA
Brightness	1,500,000 candlepower beam carries up to one mile
Dimensions	6.125 x 6.75 x 9.6 in
Net Weight	4 lb
AC adapter	Input Voltage: 220V AC Output Voltage: 12V DC Output Current: 0.5 A

