

## Seed Papilio User Manual

GB

**IMPORTANT! Read this manual carefully. Keep it for future use.**

### List of contents

Warnings  
General information  
When you unpack your Seed Papilio for the first time  
Guarantee and chassis number  
How to use your Seed Papilio  
The white handles  
Preparing the chassis  
Preparing for use as a pushchair  
Adjustment of handlebar  
Adjustment of lying position  
Preparing for use as a pram  
Harness and harness rings  
Hood  
Brake  
Folding the chassis together  
Accessories  
Service and maintenance  
Measurements, weights and washing instructions

Your child could be injured if the instructions in this user manual are not followed.

**WARNING!** Do not use a mattress that is thicker than 30 millimeters. No additional mattress shall be used. Check that the Seat box's fastening mechanisms is activated correctly.

Take care when the pram/stroller is used on staircases or escalators.

NEVER pull the pram on its handles over stairs.

Do not place the pram/stroller in the vicinity of open fire or other sources of heat.

The pram/stroller should only be used for children between 0-36 months with a maximum weight of 17 kg.

Do not place more than 5 kg in the goods basket.

**WARNING** Never leave your child unattended. **WARNING** Ensure that all the locking devices are engaged before use.

**WARNING** To avoid injury ensure that your child is kept away when unfolding and folding this product.

**WARNING** Do not let your child play with this product.

**WARNING** Use the restraint system as soon as your child can sit unaided.

**WARNING** Always use the restraint system.

**WARNING** Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use.

**WARNING** This product is not suitable for running or skating.

### General information

Seed has developed and constructed your pram/stroller in accordance with the strictest requirements, including the safety standards EN 1888:2012, AS 2088:2000 and ASTM F833-12. In a number of areas we have gone even further to ensure your child's safety and to give you and other users of the pram/stroller the greatest possible security.

**When you unpack your Seed Papilio for the first time**

It is important to us that you have received the correct product, that it is in good order, and that you are happy to use your Seed Papilio.

When you unpack your Seed Papilio for the first time, you should ensure that the product is undamaged and that nothing is missing.

If parts are missing, you should contact the dealer from whom you purchased your Seed Papilio.

In the package you will find:

- Chassis
- Seat and Frame
- Hood
- User manual

Any scratched or faulty metal, plastic or textile parts will not be replaced after the pram/stroller has been taken into use.

All complaints should be directed to the dealer.

Always keep your receipts carefully and find the chassis number of your Seed Papilio on the chassis.

### Proof of guarantee

Your receipt is the proof of guarantee for your purchase.

### Your Seed Papilio has a chassis number

You will find the chassis number on the chassis to the right of the brake pedal.

### How to use your Seed Papilio

Always be aware when you use your Seed Papilio Check the grips. Are they correctly locked? Check the brake.

Check that the seat is correctly fitted to the chassis. If the pram/stroller is to be used as a pushchair, you must ensure that the seat is correctly fitted and that the child is harnessed.

The pram/stroller is constructed to transport one child between the ages of 0-36 months, but with a maximum weight of 17 kg.

Read more at [www.seed.dk](http://www.seed.dk), where we also have additional instructions and tips.

**IMPORTANT!** Never use the pram for more than one child.

### The white handles

For a comfortable and easy use of your Seed Papilio, We have chosen to make white handles for adjustment.

When using your Seed Papilio pay attention to: Check the white handles, are they locked correctly?Check the brake.

Check to see the seat has been correctly attached to the frame.

When using as a stroller, use harness at all times.

### Preparing the chassis

Place the chassis on the edge with the wheels towards you and hold the handlebar.<sup>1</sup>

Your stroller is fitted with swivel wheels, the wheels must be in "locked" position. Take hold of the wheels and pull them outwards to each side.<sup>1</sup>

Pull the rear axle casing in towards yourself to the locked position, when you hear a clearly audible click from each side, the wheels are locked.<sup>2</sup>

Place the chassis so that it is standing on its wheels.<sup>3</sup>

Apply the brake.<sup>4</sup>

**WARNING!** Please be aware that after pulling out the handle to its maximum height you have to push it slightly back on both sides till you hear a "click" from the locking mechanism.<sup>3</sup>

Adjust the handlebar with the help of the grips on each side of the frame to the height that you require.<sup>3</sup>

Your stroller is fitted with swivel wheels, the wheels can now be unlocked.<sup>5</sup>

### Preparing for use as a pushchair

**WARNING!** This seat unit is not suitable for children under 6 months. For Children undeer 6 months, please use the Infat Insert (Accessory).

The seat is placed with the adjustment-grip facing the handlebar.

When you hear a clearly audible click from the fitting installations, the seat is locked onto the chassis.

Zip the hood onto the end where the adjustment-grip are situated.

Adjust the chassis to the sitting angle by releasing the adjustment-grip and tip the seat up.<sup>7</sup>

The seat can also be fitted to face the opposite direction so the child is facing the handlebar, by fitting it with the two comfort-grips facing away from the handlebar.<sup>6</sup>

**WARNING!** Check that the seat's securing mechanism is activated correctly.

**WARNING!** Check that all locking mechanisms are activated before use.

**How to adjust the height of the handlebar** Release the grip on the handlebar to adjust the height for maximum comfort.<sup>3</sup>

### How to adjust the lying position

With the help of the one grip handle, on top the frame, you can place the frame in a horizontal position and a good lying position for the child as a pram and adjust the sitting position when it is used as a pushchair. Comfort grip is released by lifting upwards.<sup>7</sup>

**Preparing for use as a pram** (Soft Part must be the Seed Papilio Carry Cot)

**WARNING!** Only horizontal position is allowed when using the Seed Papilio Carry Cot..

Place the seat frame with the adjustment-grip at the frame turned forward.

When you hear a clearly audible click from the assembly fittings on both sides, the seat will be locked onto the chassis.<sup>6</sup>

**WARNING!** Check that the seat securing mechanism is activated correctly.

### The Hood/Canopy

The hood is fitted by first zipping it on from the left side (seen from the pushing direction) and clicking the two plastic fasteners onto the seat's chassis. Fit the cover by zipping it on from the right side (seen from the pushing direction).

The reclining angle can be adjusted by using the

comfort grip at the frame.<sup>7</sup>

The lower part of the hood is divided into two parts where the central flap can be folded up to create further ventilation. The hood can be adjusted back and forth in stages.<sup>8</sup>

### Removing the seat

The seat/SeedPapilio Carry Cot can be released from the chassis by simultaneously pressing in the two safety buttons on the fitting installations and lifting up.<sup>6</sup>

**Use of harness and harness rings**

**WARNING!** Always use the harness when the child can sit independently, irrespective of whether the pram/stroller is used as a pram or a pushchair. When using as a pushchair, you must always use the built-in three-point harness. You secure the child by pulling the two shoulder-straps out over the child's arms and locking them with the buckle on the crutch-strap.

Adjust the length of the harness so that it fits closely around the child's shoulders and hips. If you use the pram/stroller as a pram, you should always use a harness for your child. It is fastened to the two metal rings on the insides of the seat.

Ask your dealer for advice if you do not have a harness for your pram of if you are in doubt.

### How to brake your Seed Papilio

When you press the brake pedal down which is located at the rear of the chassis you lock the rear wheels so that your Seed Papilio cannot move. When you want to release the wheels, press up on the underside of the pedal.<sup>4</sup>

**WARNING!** Never use the brake while the pram/stroller is moving.

### How to fold your Seed Papilio

Apply the brake.<sup>4</sup>

Your stroller is fitted with swivel wheels, the wheels must be in "locked" position.<sup>5</sup>

Remove the seat by pressing in the two safety buttons on the side of the assembly installation. The

chassis should be horizontal.<sup>6</sup>

Release the adjuster grip on the handlebar and push it in as far as it will go.<sup>3</sup>

Note that the handlebar is strongly pressed lightly after pulling out again on both sides down and audibly clicks into place.

Release the two white grips, and the two white triggers, at the same time and fold the diagonal tube

down to the bottom chassis.<sup>3</sup>

Stand the chassis on the edge with the wheels towards yourself.

Release the rear axle casing by pressing it forward. Pull the wheels in to the bottom chassis.

Now the pram/stroller is folded together.

Tie the safety strap behind the brake pedal at the rear of the chassis.

You can fix the seat onto the closed chassis by clicking it onto the two internal pegs on the inner side of the diagonal tube to the underside of the fitting installation.

### Accessories for your Seed Papilio

Important! Use only original Seed accessories and spare parts

You must always ensure that it is correctly fitted so that your child cannot pull it into the pram/stroller and suffer injury. Ask your dealer for advice if necessary.

### Service and maintenance

Your Seed Papilio must be regularly maintained to maximize its lifetime.

### Maintenance of the chassis

Brush off dust and dirt after use.

Wash the pram/stroller regularly. Use warm water for the rims and wheels and dry afterwards with a cloth.

After cleaning with water you should apply a thin layer of acid-free oil to the aluminum parts.

Acid-free oil can also be used for the general care of the aluminum parts of the pram/stroller. This will maximize its lifetime.

Not cleaning your pram/stroller can result in corrosion.

**IMPORTANT!** Never use steel wool or abrasives on the pram/stroller.

### Maintenance of seat

If the textile parts of the seat become wet, they must always be allowed to dry in a stretched-out position.

This will prevent the textile from becoming moldy and from possible discoloring.

The material can be wiped down with a damp cloth or sponge.

Weight and measurements  
Chassi: 9,8 kg  
Soft Shell: 2,4 kg

Goods declaration measured in cm	Length	Width	Height
<b>External measurements</b>	92	58	102

<b>Frame:</b> Internal measurements	78	34	18-24
Chassis folded incl. wheels	83	58	22

**Chassis**  
Aluminium, Magnesium, Nylon and ABS

**Textile parts**

Seat: Material: 100 % polyester  
Filling: 100 % polypropylene

Cover: Material: 100 % polyester  
Filling: 100 % polypropylene

Hood: Material: 100 % polyester

Net: 70 % PVC and 30 % PET

Mattress: (Only with the Seed Papilio Carry Cot)  
Material: 100 % Cotton

Filling: 100 % Polyurethane

Washing: Hand-wash only

More information and videos about the Seed Papilio, please visit our Youtube Channel: [https://www.youtube.com/channel/UCD3odc6YptKGR\\_sbHq5Dsgppapilio-bundle](https://www.youtube.com/channel/UCD3odc6YptKGR_sbHq5Dsgppapilio-bundle) or simply scan the QR code.



Please see more manual videos of our products on [www.seed-stroller.com/download](http://www.seed-stroller.com/download)

Produced by

**Seed**

info@seed-stroller.com  
www.seed-stroller.com



## Seed Papilio Gebrauchsanleitung

DE

### Garantienachweis

Ihr Kassenbon gilt als Garantienachweis für den Kauf.

**Ihr Seed Papilio hat eine Gestellnummer**  
Die Gestellnummer befindet sich rechts neben der Feststellbremse.

### So benutzen Sie Ihren Seed Papilio

Lassen Sie beim Gebrauch Ihres Seed Papilio immer Vorsicht walten!

Kontrollieren Sie alle Hebel. Sind sie ordnungsgemäß verriegelt?

Prüfen Sie die Bremse. Prüfen Sie, ob die Softschale korrekt auf dem Gestell angebracht ist.

Bei der Verwendung als Sportwagen müssen Sie sich vergewissern, dass die Softschale richtig angebracht ist und das Kind angegurlet ist.

Benutzen Sie den Wagen nur für jeweils ein Kind im Alter von 0-36 Monaten. Das Höchstgewicht beträgt 17 kg.

Lesen Sie mehr unter [www.seed.dk](http://www.seed.dk). Dort finden Sie weitere Informationen und Tipps.

**WICHTIG!** Benutzen Sie den Wagen jeweils nur für ein Kind!

### Die weißen Hebel

Für eine komfortable und einfache Bedienung Ihres Seed Papilio verwenden wir weiße Hebel zum Justieren. Wenn Sie Ihren Seed Papilio in Gebrauch haben beachten Sie bitte folgendes:

Überprüfen Sie alle weißen Hebel, ob diese korrekt eingerastet sind.

Überprüfen Sie die Bremse.

Überprüfen Sie ob der Sitz/Seed Papilio Carry Cot korrekt auf dem Gestell befestigt ist.

Verwenden Sie Ihren Sportwagen immer mit dem Rückhaltesystem.

### Aufstellen des Gestells

• Stellen Sie das Gestell hochkant wobei die Räder zu Ihnen gerichtet sind und halten dabei den Schiebebügel fest.<sup>1</sup>

• Ihr Kinderwagen ist mit Schwenkrädern ausgestattet. Zum Zusammenklappen müssen die Räder in „gesperrt“ Position stehen.<sup>3</sup>

• Fassen Sie die Räder und ziehen Sie sie zur Seite heraus.<sup>1</sup>

• Ziehen Sie die Radaufhängung auf jeder Seite zu sich heran, bis sie deutlich hörbar einrastet.<sup>2</sup>

• Stellen Sie das Gestell auf die Räder.<sup>3</sup>

• Bremsen Sie den Wagen, indem Sie die weiße Feststellbremse nach unten treten.<sup>4</sup>

• Ziehen Sie den Schiebebügel heraus, bis er an beiden Seiten deutlich hörbar einrastet.<sup>3</sup>

• Stellen Sie den Schiebebügel mit Hilfe des weißen Hebels auf die gewünschte Höhe ein.<sup>3</sup>

### Aufbau zum Sportwagen

**WARNING!** Diese Sitzeinheit ist für Kinder unter 6 Monaten nicht geeignet. Für Kinder unter 6 Monaten bitte Infant Insert nutzen (Zubehör). ▶

• Die Softschale wird so eingesetzt, dass der Bedienhebel in Richtung Schiebebügel zeigt.<sup>7</sup>

• Wenn Sie am Montagebeschlag an beiden Seiten ein deutliches Klicken hören ist die Softschale am Gestell fest eingerastet.<sup>6</sup>

**WARNING!** Kontrollieren Sie den richtigen und festen Sitz der Softschale.

• Befestigen Sie das Verdeck mittels Reißverschluss am Kopfen.

• Zum Einstellen des Rahmens auf Sitzwinkel lösen Sie den Bedienhebel und schwenken die Softschale nach oben.<sup>7</sup>

Die Softschale lässt sich auch in der anderen Richtung montieren, so dass das Kind in Richtung Schiebebügel sitzt.<sup>5</sup>

**WARNING!** Kontrollieren Sie vor jedem Gebrauch, ob alle Verriegelungen eingerastet sind.

**So stellen Sie die Höhe des Schiebebügels ein**  
Lösen Sie den weißen Hebel am Schiebebügel, um die passende Höhe einzustellen.<sup>3</sup>

**So stellen Sie die Liegestellung ein**  
Mit Hilfe des Bedienhebels können Sie die Softschale waagerecht und in eine für das Kind bequemere Liegestellung positionieren bzw. die Sitzposition beim Gebrauch als Sportwagen einstellen.<sup>7</sup>

**WARNING!** Kontrollieren Sie vor jedem Gebrauch, ob alle Verriegelungen eingerastet sind.

### Aufbau zum Kinderwagen

Als Textildeil muss der Seed Papilio Carry Cot verwendet werden.

**Warning!** Der Seed Papilio Carry Cot darf nur waagrecht eingesetzt und genutzt werden. Der Bedienhebel unter dem Rahmen muss in Fahrtrichtung zeigen und darf nicht geneigt werden.

• Wenn Sie ein deutliches Klicken vom Montagebeschlag auf beiden Seiten hören, ist der Seed Papilio Carry Cot am Gestell fest eingerastet.<sup>6</sup>

**WARNING!** Kontrollieren Sie den richtigen und festen Sitz der Softschale.

• Das Verdeck wird mittels Reißverschluss von der linken Seite beginnend (in Fahrtrichtung gesehen) angebracht. Anschließend werden die beiden Plastikhebel am Rahmen des Seed Papilio Carry Cots festgeklickt.

• Befestigen Sie die Abdeckung mittels Reißverschluss von der rechten Seite (in Fahrtrichtung gesehen) beginnend.

• Der Liegewinkel lässt sich durch Betätigen des Bedienhebels verstellen.

• Ihr Kinderwagen ist mit Schwenkrädern ausgestattet, die jetzt entsperrt werden können.<sup>3</sup>

**Abnehmen des Seed Papilio Carry Cots**  
Der Seed Papilio Carry Cot lässt sich vom Gestell lösen, indem man die beiden Sicherheitsknöpfe am Montagebeschlag gleichzeitig eindrückt und den Seed Papilio Carry Cot heraushebt.<sup>6</sup>

**Gebrauch von Gurt und Gurtingen**  
**WARNHINWEIS!** Schnallen Sie das Kind sowohl im Kinderwagen als auch im Sportwagen an, sobald es selbst sitzen kann.

Bei der Verwendung als Sportwagen ist der eingebaute Dreipunktgurt zu gebrauchen. Ziehen Sie dazu die beiden Schultergurte über die Arme des Kindes und stecken Sie sie in den Verschluss am Schrittgurt. Stellen Sie die Länge der Gurte so ein, so dass sie fest an Schultern und Hüfte des Kindes anliegen.

Bei der Verwendung als Kinderwagen sollten Sie für Ihr Kind stets einen Gurt gebrauchen. Zur Befestigung dienen die beiden Metallringe an den Innenseiten der Softschale.

Fragen Sie Ihren Händler um Rat, wenn Sie für den Kinderwagen keinen Gurt haben oder Sie unsicher sind.

**Texteile**

**Softschale:** Stoff: 100% Polyester  
Füllung: 100% Polypropylen

**Verdeck** Stoff: 100% Polyester  
Füllung: 100% Polypropylen

**Verdeck:** Stoff: 100 % Polyester  
Netz: 70 % PVC und 30 % PET

**Matratze**

**Seed Papilio Carry Cot:** Stoff: 100 % Baumwolle  
Füllung: 100 % Polyurethane

**Wäsche:** Nur Handwäsche

Das **Verdeck** Der untere Teil des Verdecks ist zweigeteilt, wobei sich die mittlere Klappe öffnen lässt um für zusätzliche Belüftung zu sorgen. Das Verdeck ist stufenweise vor und zurück einstellbar.<sup>8</sup>

**Parkposition**  
Zum Feststellen der Hinterräder treten Sie die Feststellbremse ganz nach unten – Ihr Seed Papilio kann nun nicht mehr fahren. Um die Räder freizugeben drücken Sie die Bremse von unten hoch.<sup>4</sup>

**WARNING!** Verwenden Sie die Feststellbremse niemals, während der Wagen in Bewegung ist.

**So klappen Sie Ihren Seed Papilio zusammen**

• Stellen Sie die Bremse fest.<sup>4</sup>

• Ihr Kinderwagen ist mit Schwenkrädern ausgestattet. Die Räder müssen in „gesperrt“ Position stehen.<sup>3</sup>

• Nehmen Sie die Softschale ab indem Sie die beiden Sicherheitsknöpfe an der Seite des Montagebeschlags eindrücken. Der Rahmen muss dazu waagrecht stehen.<sup>4</sup>

• Lösen Sie den weißen Einstellhebel am Schiebebügel und schieben diesen vollständig ein.<sup>3</sup>

Beachten Sie, dass die Lenkstange nach dem Herausziehen unbedingt nochmals auf beiden Seiten leicht nach unten gedrückt wird und deutlich hörbar einrastet.

• Lösen Sie die beiden weißen Kipphebel und die beiden weißen Zughebel gleichzeitig und klappen Sie die schräge Stütze ein.<sup>3</sup>

• Stellen Sie das Gestell hochkant, wobei die Räder in Ihre Richtung weisen.

• Lösen Sie die Radaufhängung indem Sie sie nach vorn drücken.

• Klappen Sie die Räder auf den Rahmen.

• Nun ist der Wagen zusammengelegt.

**Zubehör für Ihren Seed Papilio**

**WICHTIG!** Verwenden Sie nur Original Seed-Zubehör und Ersatzteile.

Vergewissern Sie sich, dass das Zubehör korrekt angebracht wurde, damit es Ihr Kind nicht in den Wagen ziehen kann und dadurch zu Schaden kommt. Fragen Sie bei Bedarf Ihren Händler um Rat.

### Pflege und Wartung

Zur Verlängerung der Lebensdauer Ihres Seed Papilio ist eine regelmäßige Pflege erforderlich.

### Pflege des Gestells

Befreien Sie den Wagen nach Gebrauch von Schmutz und Staub.

Reinigen Sie den Wagen regelmäßig. Verwenden Sie warmes Wasser für Felgen und Räder und trocknen Sie sie mit einem Tuch ab. Nach der Reinigung mit Wasser sollten Sie auf die Aluminiumteile eine dünne Schicht säurefreies Öl auftragen.

Säurefreies Öl lässt sich auch für die allgemeine Pflege der Aluminiumteile des Wagens verwenden. Dadurch verlängern Sie die Lebensdauer des Produkts.

Mangelnde Reinigung kann zu Korrosion führen.

**WICHTIG!** Verwenden Sie niemals Stahlwolle oder scheuernde Mittel.

**Pflege des Seed Papilio Carry Cots/Softschale**  
Werden die Textileile der Seed Papilio Carry Cots/ Softschale nass müssen sie stets im aufgespannten Zustand trocknen. Sie vermeiden dadurch Schimmelbildung und mögliche Verfärbungen. Der Stoff lässt sich mit einem feuchten Tuch oder einem weichen