


# User's Manual

Welcome to use our product, Please read this information first.

1. Power switch is ON/OFF(ENTER), the crust of battery's seat is anode.
2. It can store 6 messages(1 can store 512 characters, 2-6 can store 256 characters), there is only can display any one every time..
3. The power supply for product Is CR2032, please change battery when the brightness isn't enough or can't display(The battery can hold 20 hours).
4. easily input by hand

Notes: Page Up= P-U, Page Down = P-D



## Key-press Information:

In the natural display, When you press the P-U key, it shows you start to operate the badge and coming into the first grade menu, the key-press control procedure;

adjust "P-U" or "P-D" to select: the switch display info (SWITCH), the input text (INPUT), move-left speed (Speed), brightness control (LUM). Then press Enter key coming Into second grade menu:

A: SWITCH; Choice menu (Total 6 pages), choose the display Information.

(1) Enter choice menu, press "ENTER" when display SWITCH.

(2) The right of display show the current data(1-6), by "P-U" or "P-D" adjust the number between

1-6, press "ENTER" when you select, the display will exit the operation and begin to show the information you inputted.

B: INPUT: Input the content of the text (Input the text newly).

- (1) Enter choice menu, press "ENTER" when the display show INPUT\*\* by "P-U" or "P-O".
  - (2) The right show the character, Input character by "P-U" or "P-D", press "ENTER" after finish.
  - (3) If you need input continuous character, press "ENTER" once a character confirmed, (press P-U all along, the character will roll until you loosen the key-press).
  - (4) If you need add a space, please press "ENTER" again.
  - (5) If you need delete a character, press "ENTER" for 3 seconds the character is deleted when the display resume to still state.
  - (6) Press "P-D" for 3 seconds or wait for 10 seconds, the display will exit operation and show the message.
- C: SPEED: adjust the move speed( the number is larger, the speed is faster).

(1) Enter choice menu, show SPEED by P-U or P-D. then press ENTER

(2) The number on the right is for the speed, adjust the number by P-U or P-D, press "ENTER" to confirm.

D: LUM: Adjust the luminance (The number is larger, the luminance is higher).

(1) Enter choice menu, adjust menu by "P-D" or "P-U" when it show LUM, press "ENTER".

(2) The number on the right show the brightness grade, adjust the number between 1-9 by "P-U" of "P-D", press "ENTER" after finish adjusting.

