

7629661 BIN THERMOSTAT WATER SHIELD ASSY.

QM-30 Installation Instructions Only

IF USED ON A QM-20, REPLACEMENT BRACKET AND SHIELD ARE NOT USED. INSTALL BIN THERMOSTAT ONLY.

- 1. Remove back panel.
- 2. Remove the two screws holding the bin thermostat to the bracket. Drill out the rivets that hold the bracket to the cabinet. Remove and discard the bracket.
- 3. Drill new 9/64" [3.5mm] diameter holes in the cabinet exterior flange 1.25" [31.75mm] above the existing holes. Attach the thermostat to the shield using the M4 x 7 screws supplied. Attach the shield to the cabinet using the 8-32 x .500" screws supplied.
- 4. Press the shield firmly into the foam. Seal the top, left side, and right seams with RTV.
- 5. Locate and drill 3/16" [4.76mm] diameter holes in the lower back panel above the water inlet valve. Install the water inlet valve shield using two 10-24 x .500" hex head screws supplied.
- 6. Install the back panel.

