





# **Bumper-Ball Mk2 User Manual**

#### Welcome to your Bumper-Ball



- 1. Harnesses
- 2. Handles
- 3. Main Ball
- 4. Internal Strings
- 5. Inflation Valve

## Inflation

Do not over-inflate the Bumper-Ball! Over-inflation is the surest way to reduce the life span of your Bumper-Ball.

Once opening the valve, fill until all the suspension ropes have become taut.

The ball should be inflated but not firm, allow room for air movement during collisions.

## Deflation

Sucking the air using the reverse function on the air pump will aid in a guick deflation. Also leaving the valve open will allow the ball to completely deflate but over a longer period.

## Storage

Bumper-Balls are made from our own blend of 0.7mm TPU and therefore are suitable to bend, roll and even fold for storage purposes.

## Cleaning

A damp cloth can be used to clean the exterior and interior walls of the Bumper-Ball. The use of disinfectant is also possible. We recommend testing any cleaning product on a non-noticeable area before proceeding to clean an entire Bumper-Ball.

## Use(s)

The Bumper-Ball is one of the most versatile inflatable items. General usage involves running, rolling, falling and bumping or combinations of the above.

Make sure any area used for Bumper-Ball activities has been cleared of any debris and secured to avoid public interaction with those in Bumper-Balls.





Padding any sharp corners may also be required if no Bumper-Ball arena is being used. Users should be supervised in order to reduce the risk of injury, damage to equipment and to ensure all users have fun.

#### Maintenance

You should take care to keep an eye on the state of your product before, after and during any use. Detecting issues early is the best way to keep the cost of maintenance down and your Bumper-Balls in constant service.

#### General

Dirt, Grit and other Marks should be removed as soon as possible; they later may cause staining or mask leaks (see cleaning).

#### Straps

Straps should be adjusted to fit each user comfortably and securely before use. The Bumper-Ball should cover the whole of the user's torso and only leave the lower legs exposed to allow for running at all times. Ensure users do not use the straps or handles as leverage to gain entry to the Bumper-Ball as this puts excessive force on them decreasing the life span of the strap(s)/handle(s). Straps and handles should be checked for signs of wear before, after and during use.

#### **Punctures**

The majority of punctures can be fixed using our recommended patches/tape rolls. Simply clean and de-grease area needing repair and use tape to cover the damage.

## Troubleshooting

Puncture too big – take photo with size reference and send to <u>Support@Bumper-Balls.com</u> Strap(s) / handle(s) detached – try re-gluing them to ball using high pressure during curing process Faulty valve – contact <u>Support@Bumper-Balls.com</u>

If you have any questions you feel unanswered please feel free to contact us at: <u>Support@Bumper-Balls.com</u>