User's manual for GSM Touch Screen Wireless Alarm System

I. Foreword

Thank you for purchasing and using GSM LED wireless alarm system. This is a Hi-tech household security product. It will make your life safer and colorful.

Please read the below information carefully before using for a proper usage.

II. Brief introduction of the Product

A. Product components: This product is composed of alarm host, basic accessories and optional accessories.


Alarm Host	Basic Accessories	Wireless Optional Accessories
		Wireless digital sensor, wireless motion sensor,
GSM LED Alarm	remote, wireless door sensor, wireless	wireless gas alarm, smoke alarm, wireless
Host	wide-angle PIR sensor, , wired siren	indoor and outdoor siren, doorbell button,
		wireless LED keypad, wireless LCD keypad


III. Function Features

- 1. LED displays Date
- 2. GSM 2/4 Band Net trasmission, phone audible alarming and SMS alarming
- 3. 15 wireless zones (Each zone supports up to 4 sensors). Supports 8 more wired zones(Optional).
- 4. Can preset up to 6 phone numbers and dial in sequence.
- 5. Intelligent logic analysis technology, corresponding zone number can be ideitified from LED indicators.
- 6. Arm\ Disarm the system by 5 ways: SMS, Main Host(Keypad), Wireless Keypad, Keychain Remotes, or even remotely by phones.
- 7. Available in AC\DC with Low-voltage Indicators
- 8. Learning sensors to alarm host, very easy operation.
- 9. Non-volatile chip, information stored automatically when off power.
- 10. Check door\window status automatically (This is when the system is disarmed only, if a door is opened, it will sound fast "bi bi bi")
- 11. Support wireless "ding-dong" doorbell function (Optional)
- 12. Support CID uploading to CMS(Center monitoring Station), can user our GSM CID connector to have this function.
- 13. Disconnection alarm, auto priority to occupy the telephone and monitoring function to hear what is happening.
- 14. Built-in Li-lon backup battery, it will alert when low power or without external power supply.
- 15. Store up to 100 alarm records and 100 arm\disarm records

IV. Understanding of the Products

A. Understanding of the Alarm Host





1. Specifications:

- Working power: AC=100~230V, DC=12V 1A
- Static current:<50mA (when not charging) Alarm current:<500mA
- Built-in Li-Ion backup battery: 3.7V 800mAH(rechargeable),
- Standby: around 24 hours, Full charging time: 12 hours
- 2-Band GSM: GSM900/1800Mhz (4-Band is optional: 850/900/1800/1900Mhz)
- GSM transmit power: 2W
- Receiving and emitting frequency: 433MHz
- Working condition:

Temperature: -10°C ~ 50°C Humidity: <80%

Product dimension:150×107×26(mm)

2. Zone types and definitions

- Zone types: Perimeter zone, Motion zone, Emergency zone
- Definitions:

Perimeter zone: Detecting the space like doors, windows, etc., generally use wireless door magnet sensors and wireless curtain PIR sensors

Motion zone: Detecting the space like living room, aisles and bedrooms, etc., generally use wireless wide-angle PIR sensors.

Emergency zone: Detecting the space like Emergency area (such as emergency distress, medical rescue, gas leakage and

fire alarm, etc., this zone keep 24-hour monitoring status automatically. Generally use panic button, wireless gas sensors and

wireless smoke sensors.

3. Modes of arming

• "Away Arm" mode: Once any detectors in perimeter zones or motion zones get triggered, the host will alarm immediately and meantime dial "#" automatically.

"Home Arm" mode: Once any detectors in perimeter zones get triggered, the host will alarm immediately and meantime dial "#" automatically. It will not alarm after any detectors in the motion zone are triggered.

4. How to operate the alarm host

Preparation

- 1. Insert SIM card properly.
- 2. Fix the antenna
- 3. Connect the telephone cable: connect the telephone cable of telecommunication to "Tel in" port on the alarm host, thenuse the telephone cable attached in the package to connect "Tel out" port and telephone set
- 4. Connect power: connect the power adaptor to DC port of the alarm host first, then plug it to the AC socket.
- 5. Turn on the backup battery
- 6. Check and see if GSM signal is good enough

Туре	GSM Signal OK	Signal is not normal or SIM card not inserted properly	
2-Band (900/1800 MHZ)	Signal indicator keeps flash about every 2 seconds	Signal indicator keeps on	
4-Band	Signal indicator keeps flash about	Signal indicator keeps flash about	
(850/900/1800/900 MHZ)	every 3 seconds	every 1 seconds	

• How to program

Notes:

•

classification	To be	Cod	Setting	Operation Instruction	Default
(For users)	programmed	е	Setting	Operation instruction	Setting
	Start to		SET + XXXXXX+ ENT	"XXXXXX":6-digit program password	888888
	program		OLI I AAAAA LINI		000000
				"X":Group number of telephone	
Necessary to				numbers,includes1~6.	
know	Input phone		$0 + \mathbf{X} + \mathbf{ENT} + \mathbf{Tel}$	"1" for C ID protocol.	
KIIOW	numbers	0	number+ ENT+	"2" for XSJ protocol.	No number
	Humbers		Y+ENT	"3~6" for personal.12 digits at most.	
				"Y": 0 or 1. ("0": phone alarm; "1": SMS	
				alarm)	
May know	Exit delay	1	1 + X + ENT	"X": 0 or 1. ("0": 0 second; "1": 15	0
Way Kilow	LXII delay	ı I	I ' X ' LINI	seconds)	U
	Entry delay	2	2 + X + ENT	"X": 0 or 1. ("0": 0 second; "1": 15	0
		_		seconds)	
	Emergency	3	3 + X + ENT	" X ": 0 or 1. " 0 ": silent; "1": audiable;	1
	alarm sound		O · X · EIII	A. C. C. T. C. Cherk, T. Gadiable,	•
	Perimeter				
	zone, motion	4	4 + X + ENT	"X": 0 or 1. "0": silent; "1": audiable;	1
	zon alarm	-	T T T T T T T T T T T T T T T T T T T	A. O OF T. O. SHOTH, T. dadiable,	'
	sound				
	Program		7 + X +ENT+ Y Y +	"X": 0 or 1. ("0":add; "1": delete)	
	wireless	7	ENT	"YY": Zone numbe. Includes "00~15"	No setting
	sensors		L111	11. Zone numbe. moludes 00 10	

	On/Off of door & window state check	9	9 + X + ENT	"X": 0 or 1.("0":closed; "1": open)	0
Unnecessary to know	If upload arm & disarm to management center	5	5 + X + ENT	" X ": 0 or 1.("0" Not upload; "1": Upload)	0
	User Code	8	8 + 0+ ENT+ X X X X + ENT	"X X X X":4-digit user code	No code

Note: Press ESC to exit from the programming state after finishing programming.

How to change programming password (Users must know and operate)

In order to keep program password safe and to be easily remembered, users can change it via below setting:

[SET + 999999 + ENT + Six Digital New Programming Passwords + ENT + Six Digital New Programming Passwords + ENT]

Notes:

- 1. Press SET, then programming light on. After finishing setup, programming light off.
- 2. The sound "Di Di----" from the alarm host indicates successful operation, "Di Di" indicates failed operation

4. How to operate the Alarm Host? (Necessary for users to know and operate)

- To record a voice message greeting: Slide the switch on the left side of the alarm host to the RECORD ON, press and hold the Microphone button, speak close into the rear side speaker of host, and then release the microphone when finish with voice message greeting. Voice message greeting can be anywhere between 0~9 seconds long.
- To Playback the recorded voice message greeting: Slide the switch on the left side of the alarm host to DC ON, press and hold the playback 🕪 button to playback the recorded voice message greeting.
- Arm: BY wireless remote: press the corresponding arm button and the host will beep once to successfully complete the operation

By Host panel(Keypad): press" ▲ ▼"to choose "armed away" or "armed home"

• Disarm: By wireless remote: press the corresponding disarm button and the host will beep twice to successfully complete the operation

By Host panel(Keypad): 【ESC + master code + ENT 】 →the host will beep twice to successfully complete the operation

- Emergency: By wireless remote: Press Emergency key and the host will alarm immediately;
 - By host panel(Keypad): press \checkmark , and the host will alarm immediately.
- Telephone alarm: After receiving the call, you will hear the recorded voice message immediately, it can be played for 30 seconds repeatedly, then follow the below instruction:
 - 1. Input "8" to enter into the listening status for 20 seconds automatically, you can hear the alarming event sounds from phone. Each extra press of "8" can prolong 20 second listening in.
 - 2. Input"#" to play the recorded voice message for one time automatically
 - 3. Input "*", the host will end the call and stop dialing any auto dialer#.
 - 4. Directly hang off the telephone, the host will end the call and automatically dial the next auto dialer#.
- SMS reporting: Mobile will get SMS like "System Alarming XX, YYYY", "XX" means zone number, "YYYY" means the detailed sensor.
- Arm remotely by phone: 30 seconds after successfully dial the telephone number of host, enter the password
 of host after the beep---enter 1 after beep—the host will automatically hang up after beep to successfully
 complete the operation.

Notes: You can set "Armed Away" remotely by phone, but keep notes that you can't set "Armed Home" by this way.

- Disarm remotely by phone: 30 seconds after successfully dial the telephone number of host, enter the password of host after the beep---enter 0 after beep—the host will automatically hang up after beep to successfully complete the operation.
- Arm by SMS: You can edit SMS "XXXXXXBF" to host panel, the host panel would arm automatically when getting this SMS, and also will message back to mobile "Arm successfully".

Notes: Arm by SMS is only for "Armed away"!

Disarm by SMS: You can edit SMS "XXXXXXCF" to host panel, the host panel would disarm automatically when getting
this SMS, and also will message back to mobile "Disarm successfully".

How to use the extended functions:

- Separate arm and disarm of 8 wired zones: When the host is armed, press "1~8" number key can arm/disarm the cooresponding zone. Status light of the cooresponding zone on indicates armed, off indicates disarmed. Monitor open and closed states of door and window: When the smart zone is ON, the arm operation is normal if all the doors or windows are closed. But if any door or window is open, the host will sounds "Di Di" and at the same time the status light flashes frequently.
 - Note: 1. This function is available only with wireless intelligent door sensor programmed.
 - 2. If arm by phone call, the operation is same as original.
 - 3. If arm by remote controller or wireless keypad, it will arm successfully after two successive arm operation.
- Wireless "Ding-Dong" doorbell: the alarm host will sounds "Ding Dong" three times after each press of the doorbell button.

Note: This is an optional function. To have this function, need to add and program a wireless doorbell button.

5. Cautions

- Alarm processing mode: immediately after the system alarms, it starts to dial in sequence from the 1st group number to the 5th group number(skip empty numbers) automatically. It dials circularly for three times, the answered number and the numbers succussfully reveived SMS will not dial repeatedly.
- Exit delay alert: the alarm host sounds "Di" every 1 second (door/window is closed) within preset exit delay time.
- Alarm delay alert: the alarm host sounds "Di" every 1 second within preset alarm delay time.
- Alarm priority: 1. If the alarm host's own telephone line is accupied when it is alarming, it will cut it and make it unoccupied, at the same time dial out to report alarm event.
 - 2. The alarm host's "Ding Dong" sound will switch to alarm sound and dial to report if it receives alarms signal when sounds "Ding Dong"
- Lower voltage alert: Low-Power light on the host will be on when power gets very low.

Wireless zones:

Zone Number	Sensor Type	Zone Type	Applicable Sensor Name	Remark	
00			Wireless remote & Wireless Keypad		
01 ~ 05		Emorgonov zono	Wireless Smoke Alarm,	Supports upto	
01~05		Emergency zone	Wireless Gas Alarm& Panic button etc.	4 wireless	
06 ~ 10	Wireless sensors	Perimeter zone	Wireless Door/Window Sensor &	sensors for	
00 ~ 10		rennetei zone	Wireless Curtain PIR etc.	each zone	
11 ~ 15		Motion zone	Wireless Wide-Angle PIR Motion Sensor		
11~15			etc.		

Note: Default set before shipment

Wireless	Wireless	Wireless door	Wireless wide-angle	Wireless gas	Wireless
sensor	remote	sensor	PIR sensor	sensor	smoke sensor
Zone Number	00	06	11	02	03

B. Understanding of Basic Accessories (Wireless)

Wireless Remote

Features:

- To control the alarm host to arm and disarm.
- With the emergency key for urgent help.

Specifications:

• Operating power: 27A 12V alkaline battery

Emitting distance: ≥100m (in open area)

Service life: ≤1 year

Installation and Usage:

- For users to take along.
- Generally, press the "Away" key to arm before leaving home; and press the "Disarm" key to disarm; "Home" is setting "Armed home", please take notes that "Arm Home" is only effective for sensors in Perimeter Zone (door sensor\curtain PIR sensor) and sensors in Emergency Zone (Like Gas sensor\Smoke sensor\Glass sensor\Emergency button), it is not effective all sensors in Motion zone(Like wide-angle PIR).
- Please replace the batteries after one year usage and when you feel shorter control distance

How to program

A. Add

- 1. 【Start to program】(Please refer to Table 2)
- 2. [Wireless configuration]: [70 + ENT+ 00 + ENT] (At this time, "Learn" light keep on)

Press any key on remote controller twice successively, if you hear "Di----" form the alarm host and see the "Learn" light flashes five times and off, it indicates successfully added.

- B. Delete
- 3. 【Start to program】(Please refer to Table 2)
- 4. 【Wireless configuration】: 【71 + ENT+ 00 + ENT】if you hear "Di Di---" form the alarm host and see the "Learn" light flashes two times and off, it indicates successfully cancelled.

Notes: 1. You can only add 1 remote controller each time, totally 10 available to be added.

2. All the remote controllers are cancelled after your cancelling operation. You have to do the adding operation if you need one or more.

Wireless Door Sensor

Features:

- Generally set as Perimeter zone.
- If any door or window is opened, it will transmit the alarm signals to the alarm host.

Specifications:

Operating power: 23A 12V alkaline battery


• Emitting distance: ≥100m (in open area)


Service life: ≤1 year

• Alarm Distance: <4cm

Installation and Usage

- Fix the part of magnet onto the door frame in a position of 1.6m above the ground to prevent any children from bumping onto it
- Fix the part of emitting onto the door frame, make sure to keep the part of magnet and part of emitting in parallel, the space between the two parts shall be less than 10mm
- Upon the working light flashes frequently in blue, please replace the batteries





How to add and delete door sensors

A. Add

- 1. 【Start to program】(Please refer to Table 2)
- 2. [Wireless configuration]: [70 + ENT+ XX + ENT] (At this time, "Learn" light keep on)

Notes: "XX" indicates group number of defense zone, including 01~06.

Trigger the door sensor twice successively, if you hear "Di----" form the alarm host and see the "Learn" light flashes five times and off, it indicates successfully added.

- B. Delete
- 1. 【Start to program】(Please refer to Table 2)
- 2. [Wireless configuration]: [71 + ENT+ XX + ENT] if you hear "Di Di---" form the alarm host and see the "Learn" light flashes two times and off, it indicates successfully cancelled.
- Notes: 1. You can only add 1 wireless door sensor each time. Each group is available to add 4 wireless door sensors
 - 2. When exceeds 4.the latter added wireless door sensors will cover the former added one.
 - 3. All the wireless door sensor in this group are cancelled after your cancelling operation for one group . You have to do the adding operation if you need one or more.


Wireless Wide-Angle PIR Sensor

Features:

- Mainly monitor and control indoor stereoscopic space, generally set in Motion Zone.
- When human body enters into the detecting area, the sensor will transmit the alarm signals to the alarm host.



- Operating power: 9V alkaline battery
- Emitting distance: ≥150m (in open area)
- Service life: ≤1 years
- Detecting distance: 110° 10×10m



Installation and Usage

- Fix the bracket on suitable wall surface or in wall corner at a distance of 2~2.4m above the ground;
- Open the sensor shell to connect the batteries well and adjust jumper line (short circuit "5S": The sensor will detect once every 5 seconds; short circuit "5MIN": The sensor will detect once every 5 minutes; suggestion: short circuit "5S" for testing and "5MIN" for normal use;
- Fix the sensor onto the bracket;
- Adjust the sensor to a proper angle and then slide the power switch on the side to "ON", and it will
 enter into the normal working state after 30 seconds;
- Upon the working light flashes frequently in blue, please replace the batteries.

How to add and delete door sensors

A. Add

- 1. 【Start to program】(Please refer to Table 2)
- 2. [Wireless configuration]: [70 + ENT+ XX + ENT] (At this time, "Learn" light keep on)

Notes: "XX" indicates group number of defense zone, including 11~15.

Press the "Learning Emitting Switch" twice successively to trigger PIR sensor, if you hear "Di----" form the

alarm host and see the "Learn" light flashes five times and off, it indicates successfully added.

- B. Cancel
- 1. 【Start to program】(Please refer to Table 2)
- 2. 【Wireless configuration】: 【71 + ENT+ XX + ENT】 if you hear "Di Di---" form the alarm host and see the "Learn" light flashes two times and off, it indicates successfully cancelled.
- Notes: 1. You can only add 1 wireless PIR sensor each time. Each group is available to add 4 wireless PIR sensors
 - 2. When exceeds 4,the latter added wireless PIR sensors will cover the former added one.
 - 3. All the wireless PIR sensors in this group are cancelled after your cancelling operation for one group . You have to do the adding operation if you need one or more.

Wired Siren (omitted)

V. Common Problems and Solutions

Symptoms of Faults	Possible Cause	Solution
The alarm host can't fully record		
The diaminost can thully record	Did not keep pressing the record	Keep pressing the record button all the time
	button all the time while recording	while recording
Repeatedly receiving the alarm telephone	Fail to operate according to the operation instruction of the telephone alarm	Follow the below instructions after answering the alarm phone calls and hearing the recorded message: (See Point 6 of "How to operate the Alarm
		Host?")
Can't receive alarm sms or can't receive sms reply after made arm or disarm operation by sms	 SIM card is not insert properly GSM signal is not good enough 	Insert SIM card properly Adjust alarm host's installation position till the signal status shows "OK"
The host does not alarm after the detector is triggered in arm state	 Caused by the functions of arm mode (Armed Away and Armed Home); Have already setup time for Entry Delay or Exit Delay 	1. "Armed Away" mode: alarm goes off when any sensor is triggered; 2. "Armed Home" mode: alarm goes off when any sensor in Perimeter zone is triggered and it won't alarm when any sensor in Motion zone is triggered 3. Program to adjust the time for Entry Delay or Exit Delay
The PIR sensor doesn't work	 Not properly connected to the power Port of the detector is in the power-down mode. 	 Open the sensor shells to install the batteries well and slide the power switch to "On"; "5S": detect once every 5 seconds; "5MIN": detect once every 5 minutes;
The detecting distance of PIR sensor gets shorter	The ambient temperature in the detecting area is too high.	When the ambient temperature in the detecting area exceeds the human body

		temperature, the detecting distance will get shorter, it's normal.	
The host does not alarm after	•	Follow the operation instruction of "How to	
the new added wireless		program" to activate the new wireless sensor	
detector is triggered.	sensors" to add the new wireless		
	sensor		
The PIR sensor flashes	Batteries are running out.	Replace with new batteries of the same	
frequently in blue.		specification.	
The door sensor's indicator	Batteries are running out.	Replace with new batteries of the same	
flashes frequently.		specification.	
The distance of the remote	Batteries are running out.	Replace with new batteries of the same	
controller gets shorter.		specification.	

VI. Daily Maintenance and Care

This alarm is the hi-tech product with the outstanding design and sophisticated technique, and shall be used carefully. To make the alarm to operate for a long term stably and to prolong the service life, it is recommended that:

- Try to put the alarm host in the dry and well-ventilated places.
- Do not put the host and any wireless detectors in too cold, too hot or dusty places to prevent it from curtailing the service lives of electric parts and preventing the plastic shell from distorting and accelerating to age.
- Do not put the host and any wireless detectors in low and too exposed places to prevent the children from touching them or the thieves from finding them.
- Regular testing is necessary for finding and resolving problems in time.
- Regularly check the batteries in all wireless sensors and replace the running out batteries to ensure the normal operation of them.
- You'd better keep the power of the alarm host and all wireless accessories off while a long-time vacancy of the system.