


Portable Hydrogen water bottle

Pocket

User manual (warranty card)



Thank you for your purchasing this product.

Please read this manual before using and deal this product in proper way.

This manual and Japanese manual work as warranty card. Please keep these manual safely.

If you give this products to other party, please transfer these manuals together.

H₂Station

▼ Precautions

The followings are important for your safety.

The followings are for proper usage of this product and protect your safety or other person's safety to avoid any damage or harm. *name can be referred in "name of parts".



Warning : Content that may cause (risk of serious injury or death) or man-made hazards

+ The weak current flows during hydrogen generation in this product. Please don't drink the hydrogen water during hydrogen generation about persons who has implant apparatus like as pacemaker.

+ It has possibility to burst or leak the water when user puts water in bottle and continuously generates hydrogen. It is because of intensely expended the air in bottle.

Please open the cap of product and drink water when user generates hydrogen continuously 10times.

+ This product's hydrogen water does not change any pH value. Thus everybody can drink the water in peace. But please ask your doctor before drinking it if you have any restriction of fluid intake.

+ The hydrogen water that is generated by this product, please fully drink without saving more than one day. There is likely to cause food poisoning.

+ Do NOT use, store and leave this product under high temperature place, the place in the fire and direct sunlight and inside of the car under blazing sun. It may cause a fire, explosion or heat generation.

+ Do NOT burn this product. That is a risk of explosion or fire. If you want to discard this product, please definitely ask us or dealer you purchase this product.

+Do NOT put inside of high temperature cooking equipment and dishwasher. It becomes a reason of firing, burn and electric shock.

+ When you charge the battery, please always do it without the place where water applied. And please charge the battery after wiping the moisture around of base and jack. It becomes a reason of electric shock, shortage and firing.

+If some of dust or trash attach to the plug of AC-adapter, please insert it to the base after wiping clean it. And please don't wash AC-adapter by water. It becomes a reason of electric shock, shortage and firing.

+ Please put this product on the place without reach of infants. It is expected any trouble and accident which infants swallowed the removable parts. And, please don't lick the ring in the base.

+Do NOT disassemble or modify of base of this product. If you want to discard this product, please definitely ask us or dealer you purchase this product.

+ If you want to replace the battery of this product, please ask us or dealer you purchase this product.



Caution : Content that may result in property damage


- + Do NOT use the hot water 40degC or more high temperature. It becomes a reason of the deformation and damage.
- + You can use only AC-adapter of this product. Otherwise it becomes a reason of failure.
- + Do NOT freeze with pouring water into the bottle. It becomes a reason of rapture or damage.
- + If you clean this product, do NOT wash the base by water. It becomes a reason of failure.
- + Do NOT use carbonated drink in this product.
- + It is expected to remain smell or color in bottle, and screw becomes hard when you use beverages without water. Please always brush the screw and ring by nylon brush after using it. And, please wash the cap and bottle by detergent. (Do NOT use metal brush and abrasive)
- + Do NOT hardly brush the ring when you was the ring
- * It is expected to decrease the generation volume of hydrogen if you rub the ring hardly

- + Please check to close the cap, bottle and base when you carry this product.
- + This product is designed to be used only for electrical outlet in Japanese home (AC100V-240V). If you want to use abroad this product, please ask us or dealer you purchase this product.


H₂Station

▼Name of parts

Body




Cap(reverse side)




Accessories

- AC adaptor
- User manual(this book)



Base(Backside)




▼Battery charge before using

Please use this product before electric charge first

* The charging time depends on the situation at the time of shipment.

1. Open the jackcap
2. Please insert electrical outlet in your home to (AC100-240V) the supplied AC adaptor.
3. Please firmly insert plug into the jack of the AC adaptor.




Start and finish of battery charge

Battery charge is started when light of base lights red.

*It spends about two seconds before lighting red when insert plug into the jack of the AC adaptor. (It is verify time of product itself)

*It finishes battery charge when red light is off.



▼Disassembly, cleaning and assembly before using



When you are new to this product, please clean to decompose the body, and then use.

1. Please remove the parts by loosening the screw on the cap, bottle and base.(See the figure A)
*The cap, bottle and base are plastic, thus please don't use steel scourer and sponge easy to scratch.



There is electrical parts inside the base. Degradation or failure is expected when water enters inside jack of backside. Please fitted the cap tightly and wipe it

2. Please assemble this product. (See the figure B)
* Please confirm that there is grey packing inside of base and cap.
3. Please put beverages into the bottle
(It contains about 350cc)
*Please strongly tighten bottle and base.
Otherwise it become a reason of water leak.
4. Please close the cap, lightly shake the body and check water leak of cap and base.
*There are cases where water is left in between the bottle and the base. Please wipe well the moisture inside of base and bottle.



H₂Station

▼ Usage

Start to generate hydrogen

- Please push the switch. (See the figure C)
- Light of base lights on. (There is a change in a variety of colors)
- Product generates hydrogen for 10 minutes by one push of switch.
- When the light turns off, hydrogen water will be completed.

■ If you want to stop generating hydrogen, please push the switch longer.

You can stop to generate hydrogen. (See the figure C)

■ If you insert the plug in jack during hydrogen generation, status of product becomes charge.

■ Switch is not functioned under battery charge status.

■ When the light of base is flashing red, it is announce of battery charge inquiry.

Please see the section of “Battery charge before using”, and charge the battery.

Reference of battery charge time : About 3hours


*Hydrogen volume and usage count is different depend on water quality.

■ When plug is inserted jack before announce of battery charge inquiry, it becomes battery charge status.

■ It generates hydrogen more a few times after announcing battery charge inquiry.

■ Ring in base has auto-cleaning function, thus it is not necessary cleaning ordinary.

However, if it is seen white accretion(like as Calcium) on the ring, the pot cleaning agent is dissolved in water, should be allowed to stand for a day.



H₂Station

▼If you feel any failure...?

It seems no hydrogen generation even switch is pushed. (Light is on)

Please change to another water or put a few drops of lemon juice.

- * If hydrogen is generated after changing to another water, the previous water is not easy to conduct electricity

Battery charge is unavailable (No light on)

Please check the AC-adaptor is certainly inserted consent.

Please check the plug of AC-adaptor is certainly inserted jack of base.

- * It spends two seconds for lighting the light of base after inserting the plug.

It is expected the life of battery is finished. Battery is a consumable parts. It is recommended regular replacement.(every 3 years)

Water is leaking from each joints.

Please confirm there is packing (Gray) inside of cap and base.

If it is still leaking even there is packing inside of cap and base, please twist cap and bottle more hardly.

- * Sometimes there is remaining water in the gap of bottle and base. This is not water leaking. Please wipe moisture well.

This bottle does not work once you plug off AC adaptor from jack.

It does not work when you connect AC adaptor plug onto recharge jack. When you generate hydrogen, please plug off AC plug and switch on.

Can we wash base unit?

Base unit includes electrical parts. And jack on base is not complete water proof. Please avoid water contact into jack.

What kind of cleaning tool can I use?

You can use soft sponge to clean up the base, not to use hard brush to base.

Precaution of handling of base

- *Inside base, please wipe off gently with well squeezed soft cloth. If you use wet sponge to clean base, cleaning agent or moisture come into jack and it may happen the malfunctions.
 - *If moisture go into jack, the bottle does not work properly. Especially please be careful when you pour water, when you clean up the base and when you recharge the battery.
 - *Please confirm that the jack cap is tightly closed without any gap.
 - *Please confirm no moisture contact at the backside of base.
 - *Please confirm that the plug of AC adaptor has no moisture contact then put it into jack.
 - *Moisture contact inside jack may occur the malfunctions.
 - +Charge light turn on but there is no generation of hydrogen after switch on.
 - +Charge light does not turn on and bottle does not generate hydrogen.
- After purchasing the bottle, these kind of malfunction are caused by moisture.

Please note that these kind of malfunction are out of warranty and can be paid repair.

The logo for H2Station features the text "H2Station" in a blue, sans-serif font. The "2" is a subscript. Above the "i" in "Station", there are three small blue circles of varying sizes, arranged in a slight arc, resembling a molecular structure or a stylized "i" with bubbles.

▼Product Warranty card

This card covers one year warranty if you have any malfunction in proper use written in this user manual. When you want to have a free repair service as warranty, please contact to your dealer where you purchased together with this warranty card. Other party where you did not purchase cannot accept the warranty.

Please note that, if you purchased this products through auction, warranty cannot be accepted.

Serial No.	FLPK-
Purchase date	Year 20 /month /date
Name	
Address	
Phone no.	
Shop name	Pan Asian Trading Co., Ltd.

◆If any failure is occurred in this product, it could be available free-of-charge repair of replacement of failure parts only from your purchase to one year without following case.

- 1)This warranty sheet is none (Please confirm purchase date and shop name in sheet)
- 2)Broken by customer's carelessness or failure by customer's disassembly or modify.
- 3)Corruption during transportation after purchasing
- 4)Reason of failure is peripheral equipment other than this product.
- 5)Corruption or failure caused by natural disaster as firing, earthquake or water/window damage.
- 6)Failure by operation which without user manual's indication.
- 7)We cannot confirm the reproducibility of malfunction.
- 8)Salt damage, Gas damage, abnormal voltage, malfunction caused by electrical source beyond the specification (Voltage and Frequency)
- 9)Malfunction at not home use like business use.
- 10)Exchange of consumable parts
- 11)Recovery by recharging the battery

*Please note, it is without warranty if you are due to the above-mentioned contents.

▼Specification

Size : Diameter77 x height 186(mm)	Material : Cap ABS
Capacity : 350cc	:Bottle PET
Battery : Lithium polymer rechargeable battery	:Base ABS
Accessory: AC-adapter(input 100-240V 50/60hz 0.15A, Output 0.5A)	Packaging material : Box : Paper Protective bag : Mirror mat