## **Contents**

PRODUCT	2
Contents	2
Features	
Power saver	
Plug & play	2
SAFETY	
Electrical	
Common	
SET UP YOUR LCD MONITOR	4
Installation	4
Screen Adjustments	4
OSD Control	
TROUBLE SHOOTING	8
MAINTENANCE	q

### **PRODUCT**

## **Note**: Save the original box and packing material for future shipping needs. **Contents** LCD Monitor and Base. Please refer to Quick Setup. The Accessories in this LCD Monitor Model. Please refer to **Quick Setup**. High Brightness. **Features** Light in weight. Fast response time. Stereo Speaker. Power Saver. Low electromagnetic wave and power saver. Kensington security lock. Safety certifications. Power saver Power control system, also called (Power Saver), is installed inside the LCD Monitor. If the monitor has not been used for a certain period of time, the system will turn the monitor to low voltage mode to save power. Slight moving or any click will return to the original image. The VGA card inside the computer handles **Power Saver**. You can use computer software to set the function. The LCD Monitor is compatible with EPA ENERGY STAR and NÜTEK if used with a VESA DPMS computer. To save power, turn off the power of the LCD monitor when not in use. Plug & play The new VESA Plug and Play function is used which eliminates the complicated and time-consuming installation process. You can use the Plug and Play system without encountering usual installation problems. Your computer system can easily identify and automatically adjust the monitor. The LCD Monitor uses Display Data Channel (DDC) to send Extended Display Identification Data (EDID) to the computer system, so the computer system can be set to monitor auto adjust.

## **SAFETY**

**Note:** Please note the following safety precaution before using this monitor.

Electrical	
Sure the Voltage	<ul> <li>Before connecting the AC power cord to the DC adapter socket, make sure that voltage of the DC adapter is suitable for local power.</li> </ul>
Electrical Shock	<ul> <li>Do not insert any metal object into opening on the LCD monitor casing to prevent electrical shock.</li> </ul>
	To prevent electrical shock, do not touch the interior of the LCD monitor. Only a qualified technician should open the casing of monitor.
	If the power cord is damaged, do not use the LCD monitor. Do not place any object on the power cord, and place the power cord away from crowded areas.
	While pulling the LCD monitor plug away from the socket on the wall, hold the plug not the power cord.
	Do not expose the LCD monitor in the rain or somewhere closed to the water (such as in the kitchen, near the pool).
	<ul> <li>If the LCD monitor is dampened, please unplug the power cord and contact Service Center.</li> </ul>
Unusual condition	If the LCD monitors functions improperly, especially when making unusual noise or spreading strange odor, unplug it immediately and contact service center.
Common	
Monitor and Screen Care	Avoid touching the screen with your fingers or any tough objects. Oil from the skin is difficult to remove, and touching objects to the screen may damage the panel. It is suggested to clean the monitor by first turning it off and using a soft, dry cloth.
	The LCD monitor should be placed in areas with low humidity and less dust. Please watch out for environmental conditions on humidity and ventilation.
	The LCD monitor should be kept away from heat sources and irradiation. For example: kitchen, oven or direct sunlight and etc.
	◆ To reduce glare, avoid placing the monitor in a place that receives direct sunlight.
	<ul> <li>Avoid letting small children play with monitor. The frequent touching of the panel will cause panel to look dirty and will affect the quality of the brightness if too dirty.</li> </ul>
	If moving the monitor, please handle with care when unplugging and moving it.
	<ul> <li>Do not place items over the monitor when placing and adjusting the LCD monitor.</li> </ul>
	If the LCD monitor is not in use for a long time, please unplug it and restore it into the proper package, the original carton & packaging stuffs are preferred.
	The opening on the LCD Monitor casing is for the purpose of ventilation. To prevent overheating, the openings should not be blocked or covered. Do not place the LCD monitor on a bed, sofa, blanket or other soft surfaces; or else the soft objects will block the openings of the LCD monitors.
	If you place the LCD Monitor on a bookshelf or other airtight spaces, it's essential to leave a space of 4"(10cm) distance between the Monitor and the hard surface.
Clean screen	• Ensure the area around the LCD monitor is clean and free of moisture. Please refer to

[Maintenance] chapter for normal maintenance practice.


# **SET UP YOUR LCD MONITOR**

Installation	Note: Please read last section "Safety" before you install the LCD Monitor.	
Notes	Please note the instruction below prior to installing your LCD monitor.	
Installation Position	Choose a position where the reflection of light is minimal and away from a window for maximizing the quality of the screen image.	
	<ul> <li>It is important to keep 30 cm between the LCD monitor to minimize eyestrain.</li> </ul>	
Workstation Height	<ul> <li>Position the LCD monitor slightly above your horizontal vision as you are sitting.</li> </ul>	
Angle of Vision	<ul> <li>Tilt either forward or backward for the most comfortable viewing angle.</li> </ul>	
Quick Installation	This LCD monitor supports connection to a computer or workstation. The steps are described as Quick Setup.	
	<ul> <li>After installation, please refer to "Auto Adjust" for automatic adjust procedures.</li> </ul>	
Screen Adjustments		
Auto Adjust	Though your computer system can identify the new LCD monitor system, the Auto Adjust function can be as to enhance the display. To enter adjust mode, please refer to "OSD Control".	
	◆ Turn the computer and LCD monitor on.	
	<ul> <li>Press 'Auto' button to start Auto Adjust.</li> </ul>	
	The LCD monitor will start the Auto Adjust process automatically for 10 consecutive seconds, where you will notice the image change as the Auto Adjust is working.	
Self Test Function Check (STFC):	<ul> <li>Your LCD monitor provides a STFC function, through which you can check whether the LCD monitor functions are working properly.</li> </ul>	
	♦ If your LCD monitor is properly connected, but there is no image showing and the indicator light keeps orange, please follow the steps below to start STFC.	
	<ul> <li>Shutdown computer and LCD monitor.</li> <li>Unplug the signal connector from the back of computer.</li> <li>Turn the LCD monitor on.</li> </ul>	
	If the image connector is disconnected or damaged, the image shown on following figure will also appear during normal operation.	
	No Signal Input	
	☐ Turn off the LCD monitor and reconnect signal cable, and then turn the computer and LCD monitor on.	
	If the LED of the LCD monitor is an orange color after completing the steps above, please check your VGA card and computer system. Your monitor should be operating properly.	

### **OSD Control**

Thanks to the user-friendly design of OSD (On Screen Display), you can adjust your monitor by the keypads in the front of the monitor.

### Keypad Button Definition




1	Power Switch	Power On/Off
	LED	Power Indicator
		Green: Normal
		Orange: Power Saving
		Off: Power Off
2	Auto / Exit	Automatically optimize positions, phase & clock when OSD
		is not shown
		Exit the OSD menu when OSD is shown
3	Turbo	Quick brightness switching
	Input / Turbo (optional)	D-Sub, DVI input source selection
4	+/25	Selection or adjustment when OSD is shown
		Quick brightness adjustment
5	—/ <b>(</b>	Adjustment when OSD is shown
	,	Quick contrast adjustment
6	Menu	Enter OSD
		Access sub-menu & selection
7	Speaker	

#### **Operate Explanation**

Your LCD has been adjusted to its optimal status before shipment. You can also adjust the image in accordance with the following illustrations and steps.

- Press the "Menu" button to start the OSD feature.
- ◆ Click the "+" or "-" button to select the function to be adjusted.
- Click the "Menu" button to access into the function to be adjusted.
- ◆ Click the "+" or "-" button to change the current setting of the function.
- ◆ To exit the OSD menu or go back to the previous action by clicking the "Auto/Exit" button. It will save the change automatically.
- ◆ To repeat above steps for changing the setting of other functions.



### Notes

- ◆ The OSD disappears several seconds after you stop pressing the buttons while performing an adjustment.
- ♦ Any changes are automatically saved in the memory when the OSD disappears. Turning off the power should be avoided while using the menu.
- Adjustments for clock, phase and positions are saved for each signal timing. Except for these adjustments, all other adjustments have only one setting which applies to all signal timings.
- ◆ The color will change from white to pink while the function is selected.

### **Adjustment of Screen**

#### **Function Definition**

Primary	Secondary	Description
Directory	Directory	
Image	Brightness	Adjust the brightness of the screen.
	Contrast	Adjust the contrast of the image.
	Clock	Adjust the clock pulse of the image.
	Phase	Adjust the focus of the image.
	H. Position	Move the image left and right on the screen.
	V. Position	Move the image up and down on the screen.
	Sharpness	Adjust the picture sharpness of lower resolutions.
Audio	Volume	Adjust the volume of the audio.
	Mute	Set up the audio to be mute on or off.
Color	9300K	Set up the color temp. to be 9300K white color.
	7500K	Set up the color temp. to be 7500K white color.
	6500K	Set up the color temp. to be 6500K white color.
	User/Red	Adjust red/green/blue gain.
	User/Green	
_	User/Blue	
Language	English	Select the language you want.
	Français	
	Italiano	
	Deutsch	
	Español	
	日本語	
	简体中文	
	繁體中文	
Settings		Adjust OSD display time setting.
	OSD Position	Move OSD display position to any one of the following 5
		positions within the overall screen.
		1 2
		3
		l i i i l
		4 5
	Auto Setting	Set up to adjust clock, phase and positions automatically.
	Recall	Restore to factory settings
Input Source	Analog	, , , ,
		Select Analog input source:
(Optional)	Digital	Select Digital input source:

#### **Direct**

You can skip the Menu pages and display an adjustment scale directly by using the following button operations:

- Brightness: Press the Brightness Button when the Menu is not displayed.
- ◆ Contrast: Press the Contrast Button when the Menu is not displayed.
- Auto Setting: Press the Auto Button when the Menu is not displayed.
- Turbo: Press the Input Button when the Menu is not displayed.
  - □ Pct: Picture Mode (High brightness)
  - ☐ Text: Text Mode (Normal)
  - □ Eco Economy (Brightness of back-light is reduced)
  - ☐ Changing to a lower brightness mode can lessen eye fatigue.
  - □ Change from Picture Mode to Text Mode when working with text.
  - □ Change from Text Mode to Economy Modes when viewing the screen for long periods.

# **TROUBLE SHOOTING**

TROODEL SHOOTING		
	Check the information in this section to see if the problems can be solved before requesting repair.  Note: The consumers are only allowed to solve the problems described as below.  Any unauthorized product modification, or failure to follow instructions supplied with the product will end the warranty immediately.	
No image	♦ Make sure power button is ON.	
	Check whether the LCD monitor and computer power cords are plugged and whether there is a supply of power.	
	Check the signal connection between the computer and LCD monitor.	
"Out Of Range"	Check the computer image output resolution and frequency and compare the value with the preset values (Please refer to [Appendix-Display Mode]).	
Fuzzy image	◆ Adjust Phase.	
Image too bright Image too dark	Adjust brightness and contrast by OSD.	
Irregular image	<ul> <li>Check the signal connection between the computer and LCD monitor.</li> <li>Perform Auto Adjust.</li> </ul>	
Distorted image	<ul> <li>Reset the LCD monitor. (perform the "Recall" function by OSD)</li> <li>Take off extra accessories (such as signal extension cord).</li> </ul>	
Image is not centered	<ul> <li>Use OSD Image Menu to adjust H. Position and V. Position.</li> </ul>	
Size is not appropriate	Check image size setting.	
	Perform Auto Adjust.	
Uneven color Color too dark Dark area distorted White color is not white	◆ Use OSD Color Menu to adjust color setting.	
Can't adjust LCD monitor with the buttons in the front. The other problem	Please contact the stores where you purchased the unit or service center listed at your warranty card.	

# **MAINTENANCE**

	102		
	This product is under strict quality control in the production process. Maintaining the LCD monitor, refer to the description as below, and is important for maximizing the display performance and product life.		
	Warring: To prevent electrical shock, do not open the LCD monitor casing. Users shall not repair the LCD monitor on their own. Users' maintenance is limited to cleaning of the parts below.		
Unplug the power	<ul> <li>Unplug the LCD monitor from an AC socket before conducting maintenance.</li> </ul>		
Check the cover	Check to see if the LCD Monitor and accessories are damaged, broken, or strained.		
Clean	Never spray or pour any liquid directly onto the screen or case.		
	<ul> <li>Avoid water or and liquid permeating into the LCD monitor or accessories.</li> </ul>		
Cleaner	<ul> <li>Pure water or non-ammonia, non-alcohol based glass cleaner.</li> <li>Do not use ketene (such as acetone), ethanol, toluene, acetic acid, methane, chloride, or abrasive detergent to clean the monitor because those chemicals can damage the LCD monitor.</li> </ul>		
Screen	<ul> <li>To clean your LCD monitor screen, use water or mild cleaner, as above, to gently moist a soft, clean cloth.</li> <li>If possible, use a special screen cleaner sheet or a solution suitable for static electricity application.</li> </ul>		
Case	☐ To clean your LCD monitor case, use water or mild cleaner, as above, to gently moist a soft, clean cloth.		
Accessory	☐ To clean your accessories, use water or mild cleaner, as above, to gently moist a soft, clean cloth.		
Conserve	If the LCD monitor is not in use for a long time, please unplug and save in original box in order to avoid any unexpected damage.		
Disclaimer	Any damage resulting from use of any cleaner that is not mentioned above is not covered under this warranty term.		