







Application for the Electromagnet:  
10001 Series 10005 Series (Double)




Unit:mm


### Installation Steps of LZ bracket for In-swinging doors




1 Find a mounting location on the door frame for the L bracket. Make sure that the door is still closeable.




2 Tighten the electromagnetic lock on the L bracket by using the fixing screw.




3 Assemble the Z bracket, and make sure that the Z bracket is adjustable.




4 Insert the guide pins into the armature plate.




5 Put one rubber washer between armature plate and the Z bracket.



6 Close the door. Measure the correct position by bringing the armature plate close to the contact surface of the electromagnetic lock.



7 Turn on the power of EM-Lock, and let the armature plate bonds to the EM-lock. Adjust the position between the Z bracket and the door frame.



Finish Once the position is correct, use the screws to permanently mount the Z bracket on the door frame. This should be the last step.

### GIANNI INDUSTRIES, INC.

No. 13, Zhong Sing Road, Tu-Cheng Industrial Zone,  
Tu-Cheng City, Taipei, Taiwan 23678  
Tel: 886-2 2267 7986 / Fax: 886-2 2267 9876  
E-Mail: info@gianni.com.tw  
Website: gianni.tw  
Copyright 2008 Gianni industries, inc. All rights reserved.  
DM-CA-LZ-300 Ver. C Published on 2008.06.11



The products are manufactured under an ISO 9001 & QC 080000 Certified Quality Management Program environment back its product quality, performance and commitment to customer satisfaction.