

250T THERM-A-BIND


Operating Instructions





250T






2a. Plug in and switch on 250T. BOOK PREPARATION
The yellow wait light will
illuminate. 3. Firmly hold sheets to bound and place binding
on lined surface. The firm

will sound and the green light will iluminate.


At this time the 250T is ready.

At this time the 250T is ready for binding.



BOOK PREPARATION
3. Firmly hold sheets to be bound and place binding edge on lined surface. The first horizontal line above the paper will indicate the cover size to use.






4a. Fan and jog paper to insure that all edges are even.4b. Before inserting pages into binder, square the spine along the 2 inside score lines.





5. Holding sheets firmly, insert fully into cover until they are all directly and evenly seated against the spine adhesive.




6. Holding the book loosely, firmly tap spine two or three times against hard surface. This will ensure that all sheet are in contact with spine adhesive.

250T









250T OPERATION

7a. For Therm-A-Bind Covers Insert one or several books (total thickness less then 25mm or 1 inch) into front "Therm-A-Bind" slot. Be sure entire spine is in complete contact with heat surface.

7b. For Copy-Bind Covers Insert only one book into "Copy-Bind" slot. Be sure entire spine is resting all the way into grooved heat surface. 8. Depress "Bind" button. Yellow "Wait" light will illuminate. After 40 seconds a "BEEP" will sound and the green "ready" light will illuminate. Immediately ermove book(s) from 250T.

250T





- 9. Hold the finished book with one hand, with other hand the pinch one end of binding edge mi and run fingers along binding edge to ensure that sheets are securely bound. CAUTION: Binding edge will be warm to the touch.
 - 10. Place the finished book(s) into the rear "cooling" slot. Allow 5 minutes for proper cooling.
- 11. You may continue to bind additional books during the cooling period. Switch off the 250T when you have finished binding all your books.