

## CARE AND MAINTENANCE

This Caframo fan has been designed for many years of problem free operation. There are however a few simple things that you can do to enhance the life of your fan.

1. Keep the air vents clear and free of dirt. These vents are necessary to keep the motor cool while in use. Unplug the fan, and use a vacuum to remove any dirt from the vents.
2. Replace the fan blade should it become damaged.

## TO REPLACE A DAMAGED FAN BLADE

1. Holding the body of the fan in one hand, grasp the damaged blade in your other hand, and pull the blade off the motor shaft.
2. Firmly grasp the new blade and push it straight onto the motor shaft as far as it will go.

To order a replacement fan blade contact:

Customer Service  
Caframo Ltd.  
R.R.#2  
Airport Road  
Warton, Ontario, Canada  
Phone: 1-800-567-3556  
Fax: 519-534-1088

1850 rpm high

- 6 ft. power cord

## READ AND SAVE THESE INSTRUCTIONS

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

**WARNING** - To reduce the risk of fire or electrical shock, do not use this product with any solid-state speed control device (Dimmer Switch).

- Unplug fan before cleaning.
- Use common sense when using this and/or any electrical appliance.
- Do not position too close to any objects which may be drawn into the blades and stop the air flow.
- Do not use outdoors
- Do not use on wet surfaces or immerse in water. Never allow water to drip into the motor housing.
- Do not use if power supply cord becomes frayed or brittle.
- Do not use gasoline, thinners or other harsh chemicals to clean fan.
- Do not use near fireplaces, furnaces, stoves, or other high temperature heat sources.


## Specifications

- 120 volts, 60Hz, 0.38 Amp.
- 4 speeds            1200 rpm low  
                         1350 rpm  
                         1600 rpm



## OPERATION

1. To operate the fan, turn control knob to first setting for low speed, last setting for highest speed.



## OWNER'S MANUAL

Model 967