# TLD (0.8:1) Lens Kit



**Installation Manual** 

R9840900



Barco nv Presentations
Noordlaan 5, 8520 Kuurne
Phone: +32 56.36.82.11
Fax: +32 56.35.86.51
E-mail: presentations.bid@barco.com
Visit us at the web: www.barco.com

# Copyright ©

All rights reserved. No part of this document may be copied, reproduced or translated. It shall not otherwise be recorded, transmitted or stored in a retrieval system without the prior written consent of Barco.

#### **Changes**

Barco provides this manual 'as is' without warranty of any kind, either expressed or implied, including but not limited to the implied warranties or merchantability and fitness for a particular purpose. Barco may make improvements and/or changes to the product(s) and/or the program(s) described in this publication at any time without notice.

This publication could contain technical inaccuracies or typographical errors. Changes are periodically made to the information in this publication; these changes are incorporated in new editions of this publication.

#### Trademarks

Brand and product names mentioned in this manual may be trademarks, registered trademarks or copyrights of their respective holders. All brand and product names mentioned in this manual serve as comments or examples and are not to be understood as advertising for the products or their manufactures.

# **TABLE OF CONTENTS**

1. 1	TLD (0.8:1) Lens	s Kit	3
1	1.1 Kit Contents		:
		nstalled lens	
		w lens	
		ns	
		NS	ì

# 1. TLD (0.8:1) LENS KIT

# 1.1 Kit Contents

#### **Kit Contents**

Contents

- TLD (0.8:1) Lens.
- Installation Manual.
- Toraysee™ Cloth.

# 1.2 Removing the installed lens

#### What has to be done?

Removing the installed lens on the SLM series projector.

# **Necessary Tools**

No tools necessary.



WARNING: Risk of personal injury. Instructions for lens installation must be followed thoroughly.

#### How to remove the installed lens?

To remove the lens, follow the next procedure:

- 1. Support the lens with one hand. (image 1-1)
- 2. Move the handle of the lens anchor system to the left. (image 1-2)
- 3. Take the lens unit out of the lens block. (image 1-3)



Image 1-1 Support the lens with one hand



Image 1-2 Move the handle of the lens anchor system to the left



Image 1-3 Take the lens out of the lens block

# 1.3 Installing the new lens

#### What has to be done?

This new lens has to be installed on the SLM series projector.

# **Necessary Tools**

No tools necessary.



WARNING: Risk of personal injury. Instructions for lens installation must be followed thoroughly.

# How to install the new lens?

- 1. Take the lens assembly out of is packing material and remove the lens caps on both sides.
- 2. Move the handle (A) of the lens anchor system to the right. (image 1-4)  $\,$

3. Push the lens in the lens block gap horizontally, until the lens clicks in lens anchor system.

\*Caution:\* For a table mounted projector, hold the projector when pushing the lens into the lens block to avoid sliding off from the table.



Image 1-4 Lens installation

# 1.4 Focusing the lens

# How to focus the lens?

To focus the lens, follow the next procedure:


1. Rotate the lens barrel (limited range!) for picture focusing. (image 1-5)



Image 1-5 Rotate the lens barrel for picture focusing

# 1.5 Lens Formulas

#### **Lens Formulas**



To calculate the distance between the projector front side and the screen (PD) for a given screen width (SW), use the following formula:

SLM Projector	Formula (in meter)	Formula (in inches)
SLM G5	PD = 0.85 x SW + 0.05	PD = 0.85 x SW + 1.97
SLM G8	PD = 0.85 x SW + 0.05	PD = 0.85 x SW + 1.97
SLM G10	PD = 0.85 x SW + 0.05	PD = 0.85 x SW + 1.97
SLM R6	PD = 0.84 x SW + 0.05	PD = 0.84 x SW + 1.97
SLM R8	PD = 0.84 x SW + 0.05	PD = 0.84 x SW + 1.97
SLM R10	PD = 0.84 x SW + 0.05	PD = 0.84 x SW + 1.97
SLM R12+	PD = 0.77 x SW + 0.05	PD = 0.77 x SW + 1.97

RLM Projector	Formula (Metric)	Formula (Inch)
RLM G5 (*)	PD = 1.06 x SW + 0.07	PD = 1.06 x SW + 2.76
RLM G5+ (*)	PD = 1.06 x SW + 0.07	PD = 1.06 x SW + 2.76
RLM H5 (*)	PD = 0.84 x SW + 0.07	PD = 0.84 x SW + 2.76
RLM R6+	PD = 0.77 x SW + 0.07	PD = 0.77 x SW + 2.76

<sup>(\*)</sup> Optical adapter R9832650 is required

# 1.6 Cleaning the lens



To minimize the possibility of damaging the optical coating or scratching exposed lens surface, we have developed recommendations for cleaning the lens. FIRST, we recommend you try to remove any material from the lens by blowing it off with clean, dry deionized air. DO NOT use any liquid to clean the lenses.

#### **Necessary tools**

Toraysee™ cloth (delivered together with the lens kit). Order number: R379058.

#### How to clean the lens?

Proceed as follow:

- 1. Always wipe lenses with a CLEAN Toraysee™ cloth.
- 2. Always wipe lenses in a single direction.

Warning: Do not wipe back and forwards across the lens surface as this tends to grind dirt into the coating.

- 3. Do not leave cleaning cloth in either an open room or lab coat pocket, as doing so can contaminate the cloth.
- 4. If smears occur when cleaning lenses, replace the cloth. Smears are the first indication of a dirty cloth.



WARNING: Do not use fabric softener when washing the cleaning cloth or softener sheets when drying the cloth.

Do not use liquid cleaners on the cloth as doing so will contaminate the cloth.



**C**AUTION: Other lenses can also be cleaned safely with this Toraysee™ cloth.

# **Revision Sheet**

10:		
		o.com
From:		
Date:		
Please correct the f	ollowing points in this documentation (R	5976273/02):
page	wrong	correct