

INSTALL INSTRUCTIONS C-TCB-12 TELESCOPING COMPUTER BASE 1992-1996 FORD BRONCO


TOOLS REQUIRED:

3/16" Allen wrench
3/8" Standard socket set
3/8" Torx set

3/8" Ratcheting wrench
Open-end wrench set
Powered drill w/ 3/8" drill bit

HARDWARE & COMPONENTS:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1	Pole support assembly	CM93071-12
1	Telescoping pole assembly	CM93072-3
1	Side support brace	CM93162
1	5/16-18 Nylock nut	GSM30017
1	5/16" Flat washer	GSM31006
2	1/4 x 1 Hex head lag bolt	GSM33060



SUB ASSEMBLY:

1. Confirm receipt of all hardware and components.
2. Loosen or remove front inner and outer passenger seat bolts on vehicle.

Always!

- Read all instructions before installing any Havis-Shields Equipment Corp products.
- Check for obstructions (Wire, brake lines, fuel tank, etc.) before drilling any holes!
- Use hardware provided with install kit

INSTALLATION:

1. MOUNT C-TCB-12 INTO VEHICLE:

- Position Pole support assembly on top of passenger seat base front mount.
- Loosely attach inner and outer factory seat bolts.
- Attach Side support brace to pole support assembly using a 5/16-18 Nylock nut and flat washer.
- Attach side support brace to floor of vehicle using ¼" x 1" Hex head lag bolts. A 3/16" pilot hole is required.

Note: Be sure to take caution when drilling through vehicle to avoid hitting brake or gas lines, wires, or any other obstructions.

- Tighten factory seat bolts and 5/16" nylock nut.
- Re-attach Telescoping pole assembly to pole support assembly.
- Mount optional C-3090, computer-mounting platform, to telescoping pole assembly using hardware and instructions provided with C-3090.