


FINAL WIRING CONNECTIONS

Make wiring connections using the EIA color code chart shown below and the instructions included with the head unit. Metra recommends making connections as shown below; Strip, Splice, Solder, Tape. Isolate and individually tape off ends of any unused wires to prevent electrical short circuit.

METRA / EIA WIRING CODE

12V Ignition / Acc.	Red
12V Batt / Memory	Yellow
Ground	Black*
Power Antenna	Blue
Amp Turn-On	Blue / White
Amp Ground	Black / White
Illumination	Orange
Dimmer	Orange / White
Right Front (+)	Gray
Right Front (-)	Gray / Black
Left Front (+)	White
Left Front (-)	White / Black
Right Rear (+)	Violet
Right Rear (-)	Violet / Black
Left Rear (+)	Green
Left Rear (-)	Green / Black



***NOTE:** When Black wire is not present, ground radio to vehicle chassis. All colors may not be present on all leads due to manufacturer's specifications.

INSTALLATION INSTRUCTIONS

70-5511 70-5512*

*Ford Premium Sound System Harness
To Integrate Aftermarket Radio
with Factory Amplifiers and Speakers*

KIT COMPONENTS

70-5511	70-5512 *
<p>Power Harness</p> <p>Amplifier Integration Plug</p>	<p>Amplifier Integration Plug</p>

*Requires 70-1704 power harness

TOOLS REQUIRED FOR INSTALLATION

- Cutting Tool • Tape • Crimping Tool • Connectors



TO INSTALL AN AFTERMARKET RADIO WHILE KEEPING THE FACTORY AMPLIFIER AND SPEAKERS

NOTES

- 1** Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2** Unplug the power and output connectors from the factory radio. (Figure A)
- 3** Splice the wire from the aftermarket radio to the power and amplifier integration harnesses using the color code on page 4 and the instructions included with the aftermarket radio. (Figure B)
- 4** Plug the power and amplifier integration harnesses into the factory power and output connectors.
- 5** Re-connect the negative battery terminal and test the unit for proper operation.

