



*Passenger and Light Truck Tire Owner's Manual and Limited Warranty,  
Including All Applicable Treadwear Limited Warranties, and  
Comp T/A® & g-Force T/A® SSS (Self Supporting Structure) Information*

## THE BFGOODRICH® BRAND PASSENGER AND LIGHT TRUCK LIMITED WARRANTY

### ABOUT THIS WARRANTY

As the original purchaser of a BFGoodrich® brand passenger or light truck tire, you are encouraged to read this booklet carefully to determine which warranty coverages apply to the specific tires that you own. Please also pay close attention to the Owner's Manual part of this booklet since it provides essential safety and maintenance information.

### WHAT IS COVERED AND FOR HOW LONG

#### Workmanship and Materials

BFGoodrich® brand passenger and light truck tires, used in normal service on the vehicle on which they were originally fitted and in accordance with the maintenance recommendations and safety warnings contained in the attached owner's manual, are covered by this limited warranty against defects in workmanship and materials for the life of the original usable tread, or six years from date of purchase, whichever comes first. At that time, all warranties, express or implied, expire. The life of the original usable tread is the original tread down to the level of the treadwear indicators - 2/32nds of an inch (1.6mm) of tread remaining. The date of purchase is documented by a new vehicle registration or tire sales invoice. If no proof of purchase is available, the date of manufacture, as molded on the sidewall, will be

used. Replacement will be made in accordance with the terms and conditions described under "HOW REPLACEMENT CHARGES ARE CALCULATED."

#### Treadwear - For Tires with Mileage Warranty Coverage

Some BFGoodrich® brand tread designs are covered by a manufacturer's limited warranty for treadwear. These tires (hereafter referred to as "mileage tires") have mileage coverage as follows:

<u>Tread Design</u>	<u>Warranted Mileage</u>
Control T/A® M80	80,000 miles
Momentum™ <sup>1</sup>	70,000 miles
Premier® Touring <sup>3</sup>	70,000 miles
Touring T/A® Pro Series (T-Rated) <sup>2</sup>	70,000 miles
Traction T/A®(T-Rated)	70,000 miles
Advantage Plus® <sup>2</sup>	65,000 miles
Control Plus™	65,000 miles
Control T/A® M65	65,000 miles
Premier® A/S <sup>3</sup>	65,000 miles
Traction T/A®(H/V-Rated)	60,000 miles
Commercial T/A® All-Season	50,000 miles*
Momenta® S/E	50,000 miles
Comp T/A® HR4	40,000 miles

## THE BFGOODRICH® BRAND PASSENGER AND LIGHT TRUCK LIMITED WARRANTY

\* The Commercial T/A® All Season is covered for a total of 50,000 miles on a one time only basis. This means that if a mileage warranty claim is made, the replacement tires are warranted only to fulfill the original 50,000 miles.

1. Distributed by American Tire Distributors only.
2. Distributed by Sam's Wholesale Club only.
3. Distributed by Costco Wholesale Club only.

No tire manufacturer can guarantee you a certain number of miles from a given tire. Driving habits, driving conditions, road conditions, and vehicle and tire maintenance all play a part in the tread life of a tire. If a tire does not reach the warranted mileage, and the owner of the tires has complied with the terms and conditions of the warranty, BFGoodrich® brand will replace the tires as follows:

If, within 6 years of the date of purchase, your BFGoodrich® brand mileage tires wear evenly across the tread, down to the treadwear indicators (2/32nds of an inch of tread remaining) before providing the warranted miles of service as indicated on the properly functioning vehicle odometer, they will be replaced with comparable new BFGoodrich® tires for a *pro rata* charge based on the actual mileage received. See "How Replacement Charges are Calculated - Mileage Tires" beginning on page 3.

**You pay the cost of mounting, balancing, and any other service charges and applicable taxes.**

Tires which wear out evenly before delivering the warranted mileage will be replaced on a *pro rata* basis only if:

- 1) You are the original purchaser of the tires, you own the vehicle on which they were originally installed, and the tires have been used only on that vehicle;
- 2) The tires have been rotated and inspected by a participating BFGoodrich® tire retailer every 7500 miles, and the attached Rotation Service Record has been fully completed and signed;
- 3) The completed Rotation Service Record, Original Owner/Tire Installation Information form, and the original invoice are presented to a participating BFGoodrich® tire retailer at the time of adjustment claim; and
- 4) The tires have not become unserviceable due to a condition listed under WHAT IS NOT COVERED (see page 3).

## THE BFGOODRICH® BRAND PASSENGER AND LIGHT TRUCK LIMITED WARRANTY

### Definitions

The “legal life of the tire” is six years from the date of purchase or the life of the “usable tread,” which is defined as the original tread worn down to the level of the treadwear indicators - 2/32nds of an inch (1.6 mm) of tread remaining, whichever comes first. The date of purchase is documented by a new vehicle registration or tire sales invoice. If no proof of purchase is available, the date of manufacture, as molded on the sidewall, will be used. Replacement will be made in accordance with the terms and conditions described under “HOW REPLACEMENT CHARGES ARE CALCULATED.”

### WHAT IS NOT COVERED

Tires which become unserviceable due to:

- Road hazard injury (e.g., a cut, snag, bruise, impact damage or puncture);
- Incorrect mounting of the tire, tire/wheel imbalance or improper repair;
- Misapplication, improper maintenance, racing, underinflation, overinflation or other abuse;

- Operation without a properly functioning low pressure warning system, for Comp T/A® and *g-Force* T/A® SSS tires;
- Uneven or rapid wear which is caused by mechanical irregularity in the vehicle such as wheel misalignment, (a measured tread difference of 2/32nds of an inch or more across the tread on the same tire);
- Accident, fire, chemical corrosion, tire alteration or vandalism;
- Use in commercial applications for treadwear; except for the Commercial T/A® All Season tire;
- Flat spotting caused by improper storage;
- The addition of liquid, solid or gaseous materials other than air, nitrogen or carbon dioxide (for example, waterbase sealers or balancing substances);
- Ozone or weather checking.

## THE BFGOODRICH® BRAND PASSENGER AND LIGHT TRUCK LIMITED WARRANTY

### HOW REPLACEMENT CHARGES ARE CALCULATED

#### Workmanship/Materials

A tire which becomes unserviceable due to a condition covered by this workmanship and materials limited warranty will be replaced with a comparable new BFGoodrich® brand tire, free of charge, when 2/32nds of an inch (1.6mm) or less of the original tread is worn, (or 25% or less, whichever is more beneficial to you) and within 12 months of the date of purchase. The cost of mounting and balancing the tires is included. **You pay the cost of any other service charges and applicable taxes.**

When more than 2/32nds of an inch of original tread has been worn (or more than 25%, whichever is more beneficial to you) or after 12 months from the date of purchase, you must pay the cost of a comparable new BFGoodrich® brand passenger or light truck replacement tire on a *pro rata* basis. The retailer will determine the charge by multiplying the percentage of the original usable tread worn by the current selling price at the adjustment location or the price on the current BFGoodrich® brand Base Price List, whichever is lower. This list is based on a predetermined price intended to fairly represent the actual selling price of the tire.

**You pay the cost of mounting, balancing, and any other service charges and applicable taxes.**

#### Mileage Tires

A tire meeting the conditions for treadwear *pro rata* replacement will be replaced with a comparable new BFGoodrich® brand tire based on the actual mileage received. The participating BFGoodrich® brand tire retailer will determine the charge by multiplying the percent of mileage received by the current actual selling price at the adjustment location or the price for the new tire in the current BFGoodrich® brand Base Price List, whichever is lower. This list is based on a predetermined price intended to fairly represent the actual selling price of the tire. **You pay the cost of mounting, balancing, and any other service charges and applicable taxes.**

## **THE BFGOODRICH® BRAND PASSENGER AND LIGHT TRUCK LIMITED WARRANTY**

### **WHAT YOU MUST DO WHEN MAKING A CLAIM**

When making a claim under the terms of this limited warranty you must present your tire(s) to a participating BFGoodrich® brand tire retailer. The vehicle on which the tires were used must be available for inspection. For treadwear claims you must also present the completed Original Owner/Tire Installation Information form, your original invoice, and the completed and signed Rotation Service Record. BFGoodrich® brand tire retailers are listed in the yellow pages under "Tire Dealers-Retail". Personal identification (i.e. Driver's License, Credit Card, etc.) and vehicle registration may be required. **You pay any service charges for normal vehicle and tire maintenance.**

### **CONDITIONS AND EXCLUSIONS**

This limited warranty does not provide compensation for loss of time, loss of use of vehicle, inconvenience or incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Tires presented for claim remain the property of the consumer

and BFGoodrich® brand accepts no responsibility for loss of, or damage to, tires which are in the custody or control of a BFGoodrich® brand tire retailer for the purpose of inspection for warranty adjustment.

Tires accepted for claim become the property of Michelin North America, Inc. ("MNA"), which is the processor of warranty claims for BFGoodrich® brand tires.

**In the event of a disputed claim, the consumer must make the tire available for further inspection.**

No BFGoodrich® brand representative, employee or retailer has the authority to make or imply any representation, promise or agreement, which in any way varies the terms of this limited warranty.

This limited warranty applies only in the United States.

## ***THE BFGOODRICH® BRAND PASSENGER AND LIGHT TRUCK LIMITED WARRANTY***

### **CONSUMER RIGHTS**

This limited warranty gives you specific legal rights. You may also have other rights which vary from state to state.

### **SAFETY MAINTENANCE INFORMATION**

Read your Tire Owner's Manual, the information on the sidewall of your tires, your vehicle owner's manual and vehicle tire information placard for essential safety and maintenance information.

When service is required:

1. Contact a participating BFGoodrich® tire retailer listed in your yellow pages.
2. If additional assistance is needed in locating a BFGoodrich® retailer, please call, write or email Consumer Relations as listed on page 18.

You should have complete confidence in your new BFGoodrich® tires. Still it's important to register your tires in the event that we need to contact you. For online tire registration, visit [www.bfgoodrichtires.com/register](http://www.bfgoodrichtires.com/register).

 **WARNING**

DISREGARDING ANY OF THE SAFETY PRECAUTIONS AND/OR INSTRUCTIONS  
CONTAINED IN THIS MANUAL MAY RESULT IN TIRE FAILURE OR  
EXPLOSION CAUSING SERIOUS PERSONAL INJURY OR DEATH.



## **DRIVING ON ANY TIRE THAT DOES NOT HAVE THE CORRECT INFLATION PRESSURE IS DANGEROUS**

Any underinflated tire builds up excessive heat that may result in sudden tire destruction. For replacement tires, the correct inflation pressure will be provided by your tire retailer. If not, refer to the vehicle placard. The placard indicates the minimum inflation pressures which must be maintained. However, do not exceed the maximum pressure rating indicated on the tire sidewall.

If your vehicle is equipped with Comp T/A® or *g-Force* T/A® SSS (Self Supporting Structure) tires and a pressure warning system, it is essential that you read and understand the programming, operating, and maintenance instructions provided by the manufacturer of the low tire pressure warning system installed on your vehicle.

## **BFGOODRICH® COMP T/A® & *g-Force* T/A® SSS (SELF SUPPORTING STRUCTURE) TIRES AT LOW OR ZERO AIR PRESSURE**

The handling characteristics of a vehicle with a deflated BFGoodrich® SSS tire, (whether front or rear) are not the same as those of a vehicle with normally inflated tires. A BFGoodrich® SSS tire can build up excessive heat when run underinflated for

an extended period of time. You can travel up to 200 miles at 50 miles per hour on a completely deflated SSS tire. The length of time and distance that an SSS tire will perform at low or zero air pressure will depend upon the severity of the event causing the air loss, the ambient temperature, the speed at which the tire is operated, and the conditions under which the tire is operated (i.e. hard braking, cornering, load, speed, and other sharp maneuvers will greatly reduce the length of time the tire can perform at low or zero air pressure.) Avoid high speeds and hard cornering whenever a low tire pressure warning is activated.

Continuous use of an underinflated tire may lead to sudden tire destruction. If a tire at low or zero pressure begins to vibrate or cause difficulty in vehicle handling, remove the tire immediately and replace with the spare.

NOTE: BFGOODRICH® SSS TIRES ARE TO BE USED ONLY IN CONJUNCTION WITH PROPERLY FUNCTIONING, BFGOODRICH® BRAND APPROVED, LOW TIRE PRESSURE WARNING SYSTEM. Otherwise, all provisions of the limited warranty are void. For a list of approved systems, visit your participating BFGoodrich® tire retailer, or call toll free: **1-877-788-8899**.

## **CHECK THE COLD INFLATION PRESSURES IN ALL YOUR TIRES, INCLUDING THE SPARE, AT LEAST ONCE EACH MONTH**

Failure to maintain correct inflation pressure may result in improper vehicle handling and may cause rapid and irregular tire wear, sudden tire destruction, loss of vehicle control and serious personal injury. Therefore, inflation pressures should be checked at least once each month and always prior to long distance trips. This applies to all tires, including sealant types and self-supporting tires which are as susceptible to losing air pressure as any other type if not properly maintained.

Pressures should be checked when tires are cold; in other words, before they have been driven on. Driving, even for a short distance, causes tires to heat up and air pressure to increase.

## **CHECKING PRESSURES WHEN TIRES ARE HOT**

If inflation pressures are checked after tires have been driven for more than three minutes or more than one mile, the tires become hot and the inflation pressures will increase by approximately 4 psi. Therefore when the tire pressure is adjusted under these conditions, it should be increased to a gauge reading of 4 psi greater than the recommended cold inflation pressure.

### **For Example Only:**

Recommended cold inflation: 30 psi  
Gauge reading of hot tire was found to be: 32 psi  
(Actual pressure is 28 psi)  
Therefore to achieve the 30 psi recommended pressure,  
Inflate to 34 psi (add 2 psi)

**Check the cold pressure as soon as possible, preferably within 24 hours. "Bleeding" air from hot tires could result in underinflation. Use an accurate tire pressure gauge to check pressures. Never allow children to inflate or deflate tires.**

## **FOR COMP T/A® & g-Force T/A® SSS TIRES CHECK INFLATION PRESSURES AS SOON AS POSSIBLE FOLLOWING A LOW PRESSURE WARNING**

Low pressure warning systems are designed to warn the driver of a low tire pressure situation in at least one tire on the vehicle. While your SSS tires are designed to provide continued mobility in the event of an air loss, the sooner you respond to a warning and take corrective action, the greater the likelihood that the damage to the tire can be repaired.

**Always visually inspect your BFGoodrich® SSS tires and use an accurate pressure gauge to check the air pressure in all 4 tires following any low pressure warning.**

**If the tire pressure is at or below 18 psi, proceed to the nearest participating BFGoodrich® tire retailer (or a representative of your vehicle manufacturer if advised to do so in your vehicle owner's manual) and have the tire demounted and inspected for possible internal damage.**

**If you are unable to see any damage to the tire, and the tire pressure is more than 18 psi, reinflate your tire to the proper air pressure (See instructions for checking pressures when tires are hot.) When tires have cooled, check air pressure again. If any tire has lost more than**

**5 psi from the previous check, have the tire inspected at once by a participating BFGoodrich® tire retailer. (Or a representative of your vehicle manufacturer if advised to do so in your vehicle owner's manual). Failure to do so may cause irreparable damage to the tire which may result in sudden tire destruction and personal injury.**

## **TIRE SPINNING**

Do not spin wheels in excess of 35 MPH (55 km/h) as indicated on the speedometer. Excessive speed in a free-running, unloaded tire can cause it to “explode” from centrifugal force. The energy released by such an explosion is sufficient to cause serious physical injury or death. Never allow anyone to stand near or behind the spinning tire.

When in mud, sand, snow, ice or other slippery conditions, do not engage in excessive wheel spin. Accelerating the motor excessively, particularly with automatic transmission vehicles, may cause a drive tire that has lost traction to spin beyond its speed capability. This is also true when balancing a drive tire/wheel assembly on the vehicle using the vehicle engine to spin the tire/wheel assembly.

## HIGH SPEED DRIVING CAN BE DANGEROUS

### Correct inflation pressure is especially important.

However, at high speeds, even with the correct inflation pressure, a road hazard, for example, is more difficult to avoid and if contact is made, has a greater chance of causing tire damage than at a lower speed. Moreover, driving at high speed reduces the reaction time available to avoid accidents and bring your vehicle to a safe stop.

If you see any damage to a tire or wheel, replace it with the spare at once and visit a participating BFGoodrich® tire retailer. Exceeding the maximum speeds shown in the following table for each type of BFGoodrich® tire will cause the tire to build up excessive heat which can cause tire damage that could result in sudden air loss and rapid tire destruction. Failure to control a vehicle when one or more tires experience a sudden air loss can lead to an accident.

In any case, you should not exceed reasonable speeds as indicated by the legal limits and driving conditions.

## SPEED RATINGS

SPEED SYMBOLS are shown on the sidewall of some BFGoodrich® tires. The following table shows the maximum speed corresponding to the symbol.

**\*Some V (or VR) rated tires may have a speed capacity greater than 149 mph (240 km/h).** Consult your participating BFGoodrich® brand tire retailer for maximum speed rating if your vehicle capability exceeds this speed.

**\*\*Z (or ZR) rated tires are designed for use on cars with maximum speed capabilities in excess of 149 mph (240 km/h).**

(W and Y speed ratings are sub-categories of Z).

Consult your BFGoodrich® tire retailer for maximum speed capabilities.

SPEED Ratings	Maximum Speed	
	Km/hr	mph
M	130	81
N	140	87
P	150	93
Q	160	100
R	170	106
S	180	112
T	190	118
H	210	130
V	240	149
V*	240+	149+
W	270	168
Y	300	186
	300+	186+

ZR\*\*  
↓

Although a tire may be speed-rated, we do not endorse the operation of any vehicle in an unsafe or unlawful manner. Speed ratings are based on laboratory tests which relate to performance on the road, but are not applicable if tires are underinflated, overloaded, worn out, damaged, altered, improperly repaired, or retreaded. Furthermore, a tire's speed rating does not imply that a vehicle can be safely driven at the maximum speed for which the tire is rated, particularly under adverse road and weather conditions or if the vehicle has unusual characteristics.

BFGoodrich® highway passenger tires that do not have a speed symbol on the sidewall have a maximum speed rating of 105 mph.

Light truck highway tires that do not have a speed symbol on the sidewall have a maximum speed of 87 mph. Some light truck tires may have higher maximum speeds; consult any BFGoodrich® tire retailer.

**Winter Tires** – BFGoodrich® brand winter tires that do not have a speed symbol on the sidewall or tires with Q symbols have a speed rating of 100 mph (160 km/hr). Winter tires with a speed symbol have a maximum speed rating in the accordance with the symbol.

Studded tires have a maximum speed rating of 93 mph (150 km/hr).

The speed and other ratings of retreaded tires are assigned by the retreader and replace the original manufacturer's ratings.

**IMPORTANT: In order to maintain the speed capability of the vehicle, replacement tires must have speed ratings equal to or higher than those fitted as original equipment (as indicated on the vehicle tire placard or in the owner's manual). If tires with lower speed ratings are fitted, the vehicle's handling may be affected and the speed capability of the vehicle will be lowered to the maximum speed capability of the replacement tires as indicated in the foregoing table.**

**REMEMBER...**High speed driving can be dangerous and may damage your tires.

**AND...**When driving at highway speeds, correct inflation pressure is especially important.

## **INSPECT YOUR TIRES - DO NOT DRIVE ON A DAMAGED TIRE OR WHEEL**

### **Hazards**

Driving over potholes, glass, metal, rocks, wood debris and the like, can damage a tire and should be safely avoided. Unavoidable contact with such hazards should prompt a thorough tire inspection.

If you see damage to your tires or wheels, replace with a spare and immediately visit any participating BFGoodrich® tire retailer for advice.

### **Inspection**

When inspecting your tires, including the spare, check air pressures. If the pressure check indicates that one of your tires has lost pressure of two psi or more, look for signs of penetrations, valve leakage or wheel damage that may account for the air loss.

**Always look for bulges, cracks, cuts, penetrations and abnormal tire wear, particularly on the edges of the tire tread, which may be caused by misalignment or underinflation. If any such damage is found, the tire must be inspected by any participating BFGoodrich® tire**

**retailer at once. Use of a damaged tire could result in sudden tire destruction and rapid air loss. Failure to control a vehicle when one or more tires experience a sudden air loss can lead to an accident.**

All tires will wear out faster when subjected to high speeds as well as hard cornering, rapid starts, sudden stops, frequent driving on roads which are in poor condition, and off-road use. Roads with holes and rocks or other objects can damage tires and cause misalignment of your vehicle. When driving on such roads, drive carefully and slowly, and before driving again at normal or highway speeds, examine your tires for any damage, such as cuts, bulges, penetrations, unusual wear patterns, etc.

### **WEAR BARS**

BFGoodrich® tires contain “Wear-Bars” in the grooves of the tire tread which show up when only 2/32nds of an inch (1.6mm) of tread is remaining. At this stage, tires must be replaced. Tires worn beyond this stage are dangerous.

## **DO NOT OVERLOAD - DRIVING ON ANY OVERLOADED TIRE IS DANGEROUS**

The maximum load rating of your tires is marked on the tire sidewall. Do not exceed this rating. Follow the loading instructions of the manufacturer of your vehicle and this will ensure that your tires are not overloaded. Tires which are loaded beyond their maximum allowable loads for the particular application will build up excessive heat that may cause sudden tire destruction.

Do not exceed the gross axle weight rating for any axle on your vehicle.

## **TRAILER TOWING**

If you anticipate towing a trailer, you should visit any participating BFGoodrich® tire retailer for advice concerning the correct size tire and correct inflation pressures. The size and pressures will depend upon the type and size of trailer and hitch utilized, but in no case must the maximum cold inflation pressure or the tire load rating be exceeded. Check the vehicle tire placard and the owner's manual supplied by the manufacturer of your vehicle for further recommendations on trailer towing.

## **BFGoodrich® Comp T/A® & g-Force T/A® SSS Tires and Trailer Towing**

Operation of BFGoodrich® SSS tires at low or zero air pressure with a trailer in tow is dangerous and is not recommended. If the low pressure warning indicator is activated when a trailer is in tow, stop, disconnect the trailer, and do not continue to tow the trailer until the tire has been repaired and reinflated to the proper air pressure. If the tire cannot be repaired, it must be replaced with a new SSS tire of the same size and tread design, and inflated to the proper pressure before the trailer can be safely towed.

## **WHEEL ALIGNMENT AND BALANCING ARE IMPORTANT FOR SAFETY AND MAXIMUM MILEAGE FROM YOUR TIRES**

### **CHECK HOW YOUR TIRES ARE WEARING AT LEAST ONCE EACH MONTH**

If your tires are wearing unevenly, such as the inside shoulder of the tire wearing faster than the rest of the tread, or if you detect excessive vibration, your vehicle may be out of alignment or balance. These conditions not only shorten the life of your tires but also adversely affect the handling characteristics of your vehicle, which could be dangerous. If you detect irregular wear or vibration, have your alignment and balance checked immediately. Tires which have been run underinflated will show more wear on the shoulders than in the center of the tread.

## TIRE MIXING

For best performance it is recommended that the same size and type of tire be used on all four wheel positions. Casing ply material and ply construction may vary as indicated on the sidewall of the tire. All BFGoodrich® tires of the same size, tread design, and type of ply construction are fully compatible. Before mixing different types of tires in any configuration on any vehicle, be sure to check the vehicle manufacturer's owner's manual for its recommendations.

**It is especially important to check the vehicle manufacturer's owner's manual when mixing, matching or replacing tires on 4-wheel drive vehicles, as this may require special precautions.**

## WINTER DRIVING

Tires which meet the Rubber Manufacturers Association (RMA) definition of snow tires are marked M/S, M+S, or M&S. On such tires, this designation is molded into the sidewall. Tires without this notation are not recommended for winter driving.

**While All-Season tires are designed to provide reliable performance in moderate winter environment, the use of four (4) winter tires is recommended for optimal performance. Tires designated for use in severe winter conditions are marked on at least one sidewall with the letter "M" and "S" plus a pictograph of a mountain with a snowflake on it.**



## TIRE ROTATION

To obtain maximum tire wear, it may be necessary to rotate your tires. Monthly inspection for tire wear is recommended. Your tires should be rotated at the first sign of a difference in tread depth between front and rear tires. If any irregular wear is found, the cause must be corrected to prevent further excessive wear. This is true for all vehicles. Refer to your vehicle owner's manual for instructions on tire rotation. If you do not have an owner's manual for your vehicle, BFGoodrich® brand recommends rotating your tires every 6,000 to 8,000 miles.

To be in compliance with the terms and conditions of the BFGoodrich® mileage tire treadwear coverage, you must have your tires rotated every 7,500 miles and be able to document each rotation. A page for recording the date and mileage at the time of each rotation is provided at the back of this booklet.



When rotating tires with a directional tread pattern, observe the arrows molded on the sidewall which show the direction in which the tire should turn. Care must be taken to maintain the proper turning direction.

As a general rule, whenever only two tires are replaced, the new tires should be put on the rear.

### **CUSTOMIZATION OF TIRES, WHEELS, OR SUSPENSION ON SUVs AND LIGHT TRUCKS**

Due to their size, weight and higher center of gravity, vehicles such as SUVs and light trucks do not have the same handling characteristics as automobiles. Because of these differing characteristics, failure to operate your SUV/truck in a proper and safe manner can increase the likelihood of vehicle rollover. Modifications to your SUV/truck tire size, tire type, wheels or suspension can change its handling characteristics and further increase the likelihood of vehicle rollover. Whether your SUV/truck has the original equipment configuration for tires, wheels and suspension or whether any of these items have been modified, always drive safely, avoid sudden, sharp turns or lane changes and obey all traffic laws. Failure to do so may result in loss of vehicle control leading to an accident and serious injury or death.

### **TIRE ALTERATIONS**

Do not make or allow to be made any alteration to your tires. Alterations may prevent proper performance, leading to tire damage which can result in an accident. Tires which become unserviceable as a result of alterations such as truing, whitewall inlays, addition of balancing or sealant liquids or the use of tire dressings containing petroleum distillates, are excluded from warranty coverage.

### **REPAIRS - WHENEVER POSSIBLE SEE ANY BFGOODRICH® TIRE RETAILER AT ONCE**

If any BFGoodrich® tire sustains a puncture, have the tire demounted and thoroughly inspected by a participating BFGoodrich® tire retailer for possible damage that may have occurred.

A puncture in the tread area of any BFGoodrich® passenger or light truck tire can be repaired provided that the hole is not more than 1/4" (6mm) in diameter, not more than one radial cable per casing ply is damaged, and the tire has not been damaged further by the puncturing object or by running underinflated. Tire punctures consistent with these guidelines can be repaired by following the Rubber Manufacturers Association (RMA) recommended repair procedures.

If damage exceeds these guidelines, the tire must be replaced.

Plug-only repairs done on-the-wheel are considered improper and are therefore, not recommended. Such repairs are not reliable and may cause further damage to the tire.

## STORAGE

Tires contain waxes and emollients to protect their outer surfaces from ozone and weather checking. As the tire rolls and flexes, the waxes and emollients continually migrate to the surface, replenishing this protection throughout the normal use of the tire. Consequently, when tires sit outdoors, unused for long periods of time (a month or more) their surfaces become dry and more susceptible to ozone and weather checking, and the casing becomes susceptible to flat spotting.

For this reason, tires should always be stored in a cool, dry, clean, indoor environment. If storage is for one month or more, eliminate the weight from the tires by raising the vehicle or by removing the tires from the vehicle. Failure to store tires in accordance with these instructions could result in premature aging of the tires and sudden tire failure.

When tires are stored, be sure they are placed away from sources of heat and ozone, such as hot pipes and electric

generators. Be sure the surfaces on which tires are stored are clean and free from grease, gasoline, and other substances which could deteriorate the rubber. **(Tires exposed to these materials during storage or driving could be subject to sudden failure.)**

## FOLLOW THESE MOUNTING RECOMMENDATIONS

Tire changing can be dangerous and must be done by professionally trained persons using proper tools and procedures as specified by the RMA.

Your tires should be mounted on wheels of the correct size and type which are in good, clean condition. Bent, chipped or rusted wheels may cause tire damage. The inside of the tire must be free from foreign material. Have your tire retailer check the wheels before mounting new tires. Mismatched tires and rims can explode during mounting. Also, mismatched tires and rims can result in dangerous tire failure on the road. If a tire is mounted in error on the wrong-sized rim, do not remount it on the proper rim — scrap it. It may have been damaged internally (which is not externally visible) by having been dangerously stretched and could fail on the highway.

Old valves may leak. When new tubeless tires are mounted, have new valves of the correct type installed. Tubeless tires must be mounted only on wheels designed for tubeless tires, i.e., wheels which have safety humps or ledges.

It is recommended that you have your tires and wheels balanced. Tires and wheels which are not balanced may cause steering difficulties, a bumpy ride, and irregular tire wear.

Be sure that all your valves have suitable valve caps. The valve cap is the primary seal against air loss.

### **SPECIAL MOUNTING INSTRUCTIONS FOR Comp T/A® & g-Force T/A® SSS Tires**

Comp T/A® & g-Force T/A® SSS tires are tubeless tires designed to operate in emergency conditions at low or zero air pressure. These tires can be more difficult to mount than conventional tires. They should be mounted and demounted only by a properly trained tire professional. These tires can generate a tremendous amount of heat when run at low or zero pressure. ALWAYS ALLOW THE TIRE TO COOL BEFORE ATTEMPTING TO HANDLE IT. FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY.

### **TEMPORARY SPARE TIRES**

When using any temporary spare tire, be sure to follow the vehicle manufacturer's instructions.

**FAILURE TO OBSERVE ANY OF THE RECOMMENDED PRECAUTIONS CONTAINED IN THIS OWNER'S MANUAL CAN LEAD TO ERRATIC VEHICLE BEHAVIOR AND/OR TIRE DAMAGE POSSIBLY RESULTING IN AN ACCIDENT.**

You should have complete confidence in your new BFGoodrich® tires. Still it's important to register your tires in the event that we need to contact you. For online tire registration, visit [www.bfgoodrichtires.com/register](http://www.bfgoodrichtires.com/register).

Any time you see damage to your tires or wheels, immediately contact your local participating BFGoodrich® tire retailer listed in the yellow pages. If further assistance is required, contact:

United States: 1-877-788-8899

Or Write: Consumer Relations  
P.O. Box 19026  
Greenville SC, 29602-9026

Or Email: [bfgoodrichtires.com](http://bfgoodrichtires.com)

# INDEX

	Page		Page
Alterations .....	16	Storage .....	17
Customization .....	16	Temporary Spares.....	18
High Speed Driving .....	11	Tire & Wheel Inspection .....	12-13
Inflation .....	8-10	Tire Mixing .....	15
Mounting .....	17-18	Trailer Towing .....	14
Overload .....	13-14	Warranty .....	1-6
Repairs .....	16-17	Wear Bars .....	13
Rotation .....	15-16	Wheel Alignment .....	14
Speed Ratings .....	11-12	Wheel Balance .....	14
Spinning .....	10-11	Winter Driving .....	15

**ROTATION SERVICE RECORD** (For Treadwear Limited Warranties only)

Date Tires were Mounted: \_\_\_\_\_

Vehicle Mileage at Time of Mounting: \_\_\_\_\_

DATE OF ROTATION	ODOMETER READING	RETAILER NAME AND ADDRESS	RETAILER SIGNATURE	PSI (check)

To validate the treadwear portion of this warranty, your tires must be inspected and rotated every 7,500 miles and the PSI set as recommended on the vehicle placard.  
**Owner Certification:** I hereby certify that these services were performed as indicated and that I am the original purchaser of the tires and the owner of the vehicle on which they were originally installed and exclusively used.

Consumer Signature \_\_\_\_\_ Date \_\_\_\_\_

**ORIGINAL OWNER/TIRE INSTALLATION INFORMATION**

To be completed at time of purchase

Date of Purchase: _____	Tire Size: _____
Owner Name: _____	Recommended Tire Pressure Front: _____ PSI
Address: _____	Recommended Tire Pressure Rear: _____ PSI
City: _____	DOT No: _____ Tire #1:
State: _____ Zip Code: _____	_____ Tire #2:
Phone No.: _____	_____ Tire #3:
Vehicle Year/Make/Model: _____	_____ Tire #4:
Odometer Reading: _____	_____ Tire #5:
	_____ Tire #6:

**TIRE REMOVAL INFORMATION**

Odometer reading when tires removed: _____	Date Removed: _____	Retailer Name: _____	Retailer Signature: _____
---	------------------------	-------------------------	------------------------------

# NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---



You should have complete confidence in your new BFGoodrich® tires. Still it's important to register your tires in the event that we need to contact you. For online tire registration, visit [www.bfgoodrichtires.com/register](http://www.bfgoodrichtires.com/register).

MNA, P.O. BOX 19026, GREENVILLE, SOUTH CAROLINA 29602-9026