




Powerfix®

Ⓜ Ⓡ WHEEL NUT WRENCH KH4055





Intended use

The wheel nut wrench KH4055 is intended for loosening and tightening of wheel nuts / bolts during a tyre change.

Technical data

Length: 350 mm - 530 mm
Wrench widths: 17 mm and 19 mm

Using the wheel nut wrench

- Park the vehicle on a level surface, put it in a low gear and set the hand break.
- Also secure the vehicle against rolling with appropriate equipment.




Important:

Follow the safety / operating instructions in the operating manual for your vehicle.

- Loosen the wheel nuts / bolts of the wheel to be changed in an alternating cross pattern before lifting the vehicle with the jack.

- Lift the vehicle until the wheel to be changed is no longer in contact with the floor.
- Remove the wheel nuts / bolts in an alternating cross pattern and remove the wheel.
- Put the replacement wheel in position and tightly screw in the wheel nuts / bolts.
- Lower the vehicle and retighten the wheel nuts in an alternating cross pattern with the wheel nut wrench.





⚠ Important:

After changing the wheel, check the air pressure in all tyres.

The wheel nuts / bolts must be inspected again and retightened after approximately 50 km.

Do not perform any work under the vehicle while it is lifted up with the jack.

UK



Kompernaß GmbH
Burgstrasse 21
D-44867 Bochum
www.kompernass.com
ID No.: KH4055_0706_V1

