Lighting Fixture

Installation Instruction

Warning:

Before installing fixture, be sure the electricity to the wires you are working with is shut off either by removing the fuse or by setting the circuit breaker off.

General Information

You don't need special tools to install this fixture. Be sure to follow the steps in the order given.

Under no circumstances should the fixture be hung on house electrical wires. The fixture must be installed by means of support that is installed on a ceiling which contains a radiant type heating system.

Remember that a fuse or circuit breaker protects wires from becoming overheated.

Overheated wires created an overload and cause the fuse to blow or the circuit breaker to trip. The cause of the overload is because too many appliances are on the same line or a short circuit.

Before tracing the wires for a short circuit, be sure to shut off the electricity at the main switch.

If you must replace a blown fuse be sure to replace it with one rated for the ampere capacity of the circuit. For example, if a 15-AMP fuse blows, do not replace it with a 30-AMP fuse. Use only one hand to screw out a fuse, and keep your other hand away from the wall or any other object, while you are touching the fuse.

Assemble the fixture

Carefully remove the fixture from the carton and check that all parts are included, as shown in figure. Be careful not to misplace any of the screws or wire connectors which are needed for installing the fixture.

- Thread top nipple into coupling until tight, place column over top nipple and secure with washer and hex nut.
- 2. Place flat iron onto column and secure with knob.
- 3. Place check ring over top nipple and secure with loop.
- 4. Install light bulbs.

NOTE: DO NOT EXCEED THE SPECIFIED WATTAGE.

- Thread nipple into coupling tight with hex nut, place pipe and caps over nipple and secure with washer and hex nut.
- 6. Place glass and decorative cap over nipple and secure with washer and hex nut.
- 7. Place cap over nipple and secure with finial.

Your installation is now complete. Return power to the junction box and test the fixture.

32112

