

IMI CORNELIUS INC

One Cornelius Place

Anoka, MN 55303-6234

Telephone (800) 238-3600

Facsimile (800) 535-4231

INSTALLATION INSTRUCTIONS

ON WANTE OF BOOT MAY BIODENIO BE

VANTAGE POST-MIX DISPENSERS

Read and understand these instructions thoroughly before installing this Dispensing Valves Keyed Lock-out Switch Kit (P/N 569000262) on the Post-Mix Dispensers. The purpose of the Keyed Lock-Out Switch is to shut off electrical power to the dispensing valves to prevent dispensing of product. Retain these instructions as part of your equipment manual.

LOOSE-SHIPPED PARTS

Note: Only qualified personnel should install this Kit.

Unpack and inspect kit. Make sure items are present and in good condition.

Table 1. Loose-Shipped Parts						
Item No.	Part No.	Name	Qty			
1	560003869	Wiring Harness	1			
2	560003870	Template, Hole Drilling	1			
3	318948000	Lock Key	1			
4	318949000	Hex Nut	1			
5	318569000	Key-Lock Switch	1			
6	569000261	Installation Instructions	1			

KIT INSTALLATION



WARNING: To avoid possible fatal electrical shock or serious injury to Installer, make sure Dispenser is disconneced from power source before attempting to install this kit.

- 1. Disconnect electrical power from the Dispenser
- 2. Remove hood from the Dispenser, then lift hood straight up off the Dispenser for access to the transformer on the refrigeration deck.
- 3. Refer to Figure 1 for location of hole to be drilled in the Dispenser hood for installation of the KEY-LOCK SWITCH (item 5).
- 4. Place TEMPLATE, HOLE DRILLING (item 2) in position on Dispenser hood as shown in Figure 1.
- 5. Drill hole in Dispenser hood as indicated on the hole drilling template, then remove template from the hood.

569000261





FIGURE 1. DISPENSER HOOD

- 6. Install KEY-LOCK SWITCH (item 5) in the hood as shown in Figure 1 and secure with HEX NUT (item 4).
- 7. Refering to Wiring Diagram (Figure 2) disconnect black electrical wire, with push-on terminal on it's end, from terminal on the transformer outlet.
- 8. Connect black electrical wire, disconnected from the transformer outlet terminal, to mating electrical wire terminal on the WIRING HARNESS (item 1).
- 9. Connect other electrical wire of the wiring harness to output terminal on the transformer where the black electrical wire was disconnected from in step 7 preceding.
- 10. Connect other two wiring harness terminals to two terminals on the Key-Lock Switch.
- 11. Install hood on the Dispenser.
- 12. Connect electrical power to the Dispenser, then check Dispenser for proper operation.
- 13. Insert LOCK KEY (item 3) in key-lock switch, then check Dispenser for proper operation.



2