# THE SHARPER IMAGE°

8x20 Monocular

SR294 Instructions



Read and save these instructions.


#### **Caution!**

Viewing the sun can cause permanent eye damage. Do not view the sun with this monocular or with the naked eye.

#### **Important!**

Do not attempt to clean the internal components of the monocular or try to take it apart.

### **Parts Diagram**



## **Focusing**

To focus, rotate the **EYEPIECE FOCUSING RING** until the object appears clear and sharp.

# **Rubber Eyepiece**

This convenient monocular features a rubber eyepiece that can be used with eyeglasses or without eyeglasses. It provides comfort and promotes easier viewing.

### **Using the Microscope**

- 1. Attach the monocular to the microscope by screwing the monocular clockwise on the black part of the microscope piece.
- 2. Adjust the monocular's **EYEPIECE FOCUSING RING** to the highest position (+), then rotate the **MICROSCOPE FOCUSING RING**. Or adjust to the lowest position, then rotate the **MICROSCOPE FOCUSING RING**.
- 3. Fine-tune with the **EYEPIECE FOCUSING RING**.

### **Caring for the Monocular**

- When not in use, always store the monocular in its case.
- When wiping the lenses, use a soft, lint-free cloth.
- To wipe any remaining dirt or smudges, add one or two drops of rubbing alcohol to the cloth.
- Store the monocular in a moisture-free area.

#### Warranty

#### What Is Covered

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

#### **How Long Coverage Lasts**

This warranty runs for 90 days from the date of original purchase.

#### What Is Not Covered This warranty does not cover do

This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, or loss or damage to batteries or removable parts.

#### What The Sharper Image Will Do

The Sharper Image warrants this product against defects in materials and workmanship. When repair is not practical, The Sharper Image will have the option to replace the defective product with a fully warranted, factory-reconditioned product that is the same or has similar functionality.

#### How to Obtain Service

Return the product and receipt, along with a brief explanation of the problem, to:

#### T.S.I. - Returns Department • 2901-A West 60th Street • Little Rock, AR 72209

If you have questions please feel free to contact our customer service representatives at 1-800-344-5555 or by email at care@web.sharperimage.com.

This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.

© 2006 Sharper Image Corporation

Sharper Image Corporation • 350 The Embarcadero, Sixth Floor • San Francisco, CA 94105-1218 • (415) 445-6000 Shop online: www.sharperimage.com

Due to continuing improvements, actual product may differ slightly from the product described herein.

V1 05/06