



Catalog #R09399
DOT Racer Front Brake Hose Kit
for 2004 Honda 599 CB600F
INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Brake Hose Kit. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday or e-mail us at Edelbrock@Edelbrock.com.



IMPORTANT NOTE:

Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.


INSTALLATION INSTRUCTIONS

IMPORTANT NOTE: Do not allow the master cylinder to completely drain of brake fluid at any time during this process. Also, use care when handling brake fluid, as it can quickly damage finished surfaces (paint, plating, etc.).

1. Note routing of factory brake hoses. Remove hoses as well as associated hardware and brackets.
2. Install straight-bent banjo end of Russell upper hose and compound-bend banjo end of Russell lower hose onto right-side caliper using supplied double-banjo bolt. Upper banjo goes next to caliper and bends up and away from caliper. Lower banjo bends up and away from caliper and bends to outside of upper banjo **(See Fig. 1)**.
3. Route lower hose over rear of fender to left-side caliper. Install banjo so that it bends up and away from caliper.
4. Route upper hose up to master cylinder using factory routing. Install banjo onto master cylinder, oriented similar to factory.
5. Locate upper hose to fork tree with factory bracket at factory mounting location. Insert grommet on hose into loop on bracket **(See Fig. 2)**.
6. Locate upper hose and lower hose on right-side fork tube at factory location with supplied large cushion clamp. Attach clamp and reflector to fork tube with factory bolt **(See Fig. 3)**.



7. Locate lower hose on left-side fork tube at factory location with supplied small cushion clamp. Attach clamp and reflector to fork tube with factory bolt (**See Fig. 4**).
8. Check hose clearance throughout entire steering and suspension travel range.
9. Bleed the system and check for leaks while applying pressure.



Edelbrock Corporation, 2700 California Street, Torrance, CA 90503

Toll-Free Tech Line: 1-800-416-8628

Tech E-Mail: Edelbrock@Edelbrock.com