


Your cameras feature the latest technology to ensure high quality images and clear pictures. When connecting your cameras for the first time you may notice a very dark video image or no image at all even though your DVR does not display a “video loss” message. This is not a defect, but indicates that your cameras must be “reset” as follows:


1. With your camera(s) still connected, cover the lens end of your camera with your hand or other object to completely block it.



2. Keep the lens blocked for 10 seconds. You may see a faint red glow from the infrared LEDs. This is another indication that your camera is working properly.




3. Uncover the front of the camera and it should now adjust to the light level and operate normally.



Your cameras feature the latest technology to ensure high quality images and clear pictures. When connecting your cameras for the first time you may notice a very dark video image or no image at all even though your DVR does not display a “video loss” message. This is not a defect, but indicates that your cameras must be “reset” as follows:

1. With your camera(s) still connected, cover the lens end of your camera with your hand or other object to completely block it.



2. Keep the lens blocked for 10 seconds. You may see a faint red glow from the infrared LEDs. This is another indication that your camera is working properly.



3. Uncover the front of the camera and it should now adjust to the light level and operate normally.

