Suggested Settings

Here follows four sample settings to act as starting points from which to develop your own sounds. N.B. Volume should be adjusted to taste.

INPUT GAIN 1 GAIN 2 TREBLE CONTOUR BASS MASTER REVERB SPEED DEPTH CD INPUT

Blues



3ock



Metal/Thrash



Marshall

Marshall Amplification plc Denbigh Road, Bletchley, Milton Keynes, MK1 1DQ, England Tel: [01908] 375411 Fax: [01908] 376118

Web Site - http://www.marshallamps.com

web Site - http://www.marshanamps.com



Whilst the information contained herein is correct at the time of publication, due to our policy of constant improvement and development, Marshall Amplification plc reserve the right to alter specifications without prior notice.



WARNING! - Important safety instructions


PLEASE READ THE FOLLOWING LIST CAREFULLY

- A. THE PLUG attached to the mains lead provided is wired in accordance with the following colour code:

 Blue Neutral. Green/Yellow Earth. Brown Live (UK Only).
- **B.** ALWAYS ensure that the value of the fuse corresponds to the rating marked on the plug.
- C. DO NOT use your Marshall MG amp in damp or wet conditions.
- D. ALWAYS have this equipment serviced or repaired by competent, qualified personnel.
- E. PLEASE READ this instruction manual carefully before switching on.
- F. WARNING This apparatus must be earthed.

KEEP THESE INSTRUCTIONS

G215RCD Front Panel Features



1. Input Jack
Plug your guitar in here.

2. Gain 1

Providing that Gain 2 Control is kept at zero, turning this up to around half way, i.e. around five can result in some great clean sounds. Turning this up past half way will result in your guitar crunching up, ideal for vintage blues or classic rock.

3. Gain 2

This takes off where Gain 1 finishes. Having both Gains off will result in no sound. Turning Gain 2 will result in a distorted tone straight away. Turning up this control even further will result in high gain sounds, ideal for contemporary styles. Cranking up both Gain 1 and Gain 2 will result in monster distortion.

4. Treble

The Treble control will add or take away the higher frequencies in your guitar tone.

5. Contour

The Contour control shifts the mid-range frequencies in your guitar tone. By turning the Contour control fully clockwise you will scoop out of your sound most of the middle frequencies, ideal for thrash tones if combined with high gain settings. By turning the control fully anticlockwise you can get some great fusion type tones.

6. Bass

Turning the Bass control will effect the amount of low frequencies or bottom end in your tone.

7. Master

Volume Controls the overall volume of the amp.

8. Reverb Control

Adding Reverb to your guitar tone will add ambience and size, giving the effect of playing in a large empty room or hall.

9. Chorus On / Off

Switches stereo chorus facility on and off.

Yours Sincerely,

development.

From Jim Marshall

I would like to thank you personally for selecting one of our Marshall MG Series guitar combos.

Your new amplifier has been designed by the same team of British designers who created all of the great Marshall amps. It is built to the customary exacting Marshall standards and will give you an incredible spectrum of sounds to complement a

The Marshall name has adorned many of Britain's finest amps, from the early 1960's through to the present day. Some of the original vintage amps have become highly sought after by both amp collectors and working quitarists alike.

This new line of transistor guitar and bass guitar combos have been released to unanimous acclaim. Your combo is part of a new breed of Marshall

Not only is the sound quality of your Marshall MG

Series amp of a standard that you would only expect

to come from our own design team, the G215RCD

unbelievable spread and size to your sound. The

to play along to CD's. The ultimate home practice

Marshall G215RCD also has a CD input to allow you

I would like to wish you every success with your

new Marshall MG Series amplifier, which I am sure

you will find a pleasure to play for years to come.

amplifier, which has benefited from years of experience and continual investment in research and

features a stereo chorus facility which adds

wide range of playing styles, as well as being

designed to stand the test of time.

Jim Marchael

G215RCD Front Panel Features

10. Speed

Controls the speed of oscillation of the stereo chorus effect.

11. Depth

Controls the depth of oscillation of the stereo chorus effect.

12. CD Input

This is an input for connection to a CD player, tape player, record player or other auxiliary device, to allow you to play along. This is a fixed level input, so volume of your backing music should be adjusted on the auxiliary unit itself.

13. Power On LED

Indicates operating status of combo. Red indicates that amp is switched on.

14. Power Switch

Switches the mains power to the combo.

G215RCD Rear Panel Features



1. Headphones Jack

Plug your headphones in here. This will disconnect the internal speakers.

2. Left Line Out Jack

The Line Out jack is for use for direct connection of the left hand side of your stereo signal to recording equipment or for connection to a P.A. system.

3. Right Line Out Jack

The Line Out jack is for use for direct connection of the right hand side of your stereo signal to recording equipment or for connection to a P.A. system.