

## SELF-POWERED WIRELESS DATA LOGGER WITH ANALOG INPUTS (±5V OR ±10V)

### //APPLICATIONS



 made  
 in  
 Germany

### Featured VIDEO



[BeanDevice® AN-V Xtender Main presentation Video](#)

### USER MANUAL



[BeanDevice® ProcessSensor user manual](#)

### SELECTION GUIDE



[BeanDevice® ProcessSensor selection guide](#)

### //MAIN FEATURES



Analog inputs ±5V or ±10V



Wireless transmission IEEE 802.15.4 with antenna diversity



Integrated sensor power supply, software configurable 4.5V to 20V



Integrated Lithium-thionyl chloride primary cell 6,5Ah



Embedded data logger up to 1million data points



Extended operating temperature range : -40°C to +85°C

//EMBEDDED DATA LOGGER UP TO 1 MILLION DATA POINTS


The BeanDevice® AN-V Xtender integrates an embedded data logger, which can be used to log data when a Wireless Sensor Networks can not be easily deployed on your site. All the data acquisitions are stored on the embedded flash and then transmitted to the BeanGateway® whenever a Wireless Sensor Network is established.

The Datalogger function is compatible with all the data acquisition mode available on your BeanDevice® AN-V Xtender :

- LowDutyCycle Data Acquisition
- Alarm
- Survey

EXAMPLE : DATA ACQUISITION SYSTEM ON WATER TREATMENT PLANT

- The BeanDevice® AN-V Xtender is configured with its Datalogger feature. A standalone installation of the BeanDevice® AN-V Xtender will be done (mounted on the walls), without the necessity for any connection to the BeanGateway®.
- Once the sensors are connected, each data is recorded on the embedded flash.
- When needed a technician working on the site can send a request for a log transmission. Then the BeanDevice® AN-V Xtender starts sending all its logs. If all the logs are successfully transmitted to the BeanGateway®, the flash memory is erased and new logs will be recorded.



For further informations about the Datalogger, please read the following technical note : [TN\\_RF\\_007 – “BeanDevice® DataLogger User Guide ”](#)



## // REMOTE CONFIGURATION & MONITORING

### BeanScape® Basic


The BeanScape® application allows the user to view all the data measurements transmitted by the BeanDevice® AN-V Xtender. With the OTAC (Over-the-Air configuration) feature, the user can remotely configure the BeanDevice® AN-V Xtender.

SEVERAL DATA ACQUISITION MODES ARE AVAILABLE ON THE BEANDEVICE® AN-V XTENDER :

- **Low Duty Cycle Data Acquisition mode (LDCDA)** : the data acquisition is immediately transmitted by radio. The transmission frequency can be configured from 1s to 24h.
- **Alarm Mode** : the measured value is transmitted by radio whenever an alarm threshold (fixed by the user) is detected (4 alarms threshold levels High/Low).
- **Survey Mode** : operates like the Alarm mode but the device sends frequently a beacon frame informing its current status.

### BeanScape® Premium+ Add-on


The BeanScape® Premium+ integrates an OPC DA server (Data Access). OPC DA is particularly well suited for real time measurement and data sharing. Each data/measurement can be associated to a tag or its attributes and shared with one or many OPC clients.



For further informations about the data acquisition modes, please read the following technical note : [TN\\_RF\\_008 – “Data acquisition modes available on the BeanDevice®”](#)



## //CONFIGURABLE SENSOR POWER SUPPLY



The sensor is directly powered by a high accuracy and adjustable DC/DC converter integrated inside the device. The excitation voltage is remotely configurable through the **BeanScope**<sup>®</sup> (4.5 to 20V).

## //EASY BATTERY MAINTENANCE

Fully designed for an easy battery maintenance, **BeanDevice**<sup>®</sup> AN-V Xtender integrates a battery holder which is sealed to IP67, extending the applications into harsher external environments where dust or water would inhibit equipment operation.

STEP 1



STEP 2



STEP 3



Product Reference

**BND-ANV-XTD-NCH-MR**

**N - Number of data acquisition channels:**

**4** : 4 channels

**MR - Measurement Range**

- **5** :  $\pm 5V$  measurement range , - **10** :  $\pm 10V$  measurement range

**Example** : BND-ANV-XTD-4 CH-5 , *BeanDevice® AN-V Xtender with four channels , measurement range:  $\pm 5V$*

Analog data acquisition block specifications

<b>Signal Conditioning</b>	Analog low voltage measurement
<b>Number of channels</b>	4 Channels
<b>A/D Converter</b>	16 bits - SAR Architecture (Successive Approximation Register) with temperature compensation
<b>Measurement range</b> (analog polarity is configurable from the BeanScape®)	BND-ANV-XTD-NCH-5 - IEEE-BT: $\pm 5V$ (bipolar) or 0-10 V (unipolar) BND-ANV-XTD-NCH-10 - IEEE-BT: $\pm 10V$ (bipolar) or 0-20 V (unipolar)
<b>Non-linearity error</b>	$\pm 0.5$ LSB
<b>Measurement accuracy(@25°C)</b>	< 0,08% when operating on battery power
<b>Sensor Connector</b>	M12-5Pins coming with an IP rating IP67   Nema 6

Sensor wiring code (M12 Socket)


**Caption**

**Pwr+** : sensor power supply (4.5 to 20 Volts)

**Gnd** : electrical ground

**Sens+** : sensor signal + input

**Sens-** : Not used



Sensor Power Supply specifications

<b>Excitation voltage range</b>	4.5 Volts to 20Volts , configurable from the BeanScape® software
<b>Excitation voltage accuracy on full scale range(@25°C)</b>	$\pm 0.1\%$
<b>Maximum Output Power (@25°C)</b>	2 Watts

Over-the-air configuration (OTAC) parameters

<b>Data Acquisition mode</b>	<ul style="list-style-type: none"> <li>Low Duty Cycle Data Acquisition (LDCDA) Mode: 1s to 24 hour</li> <li>Alarm &amp; Survey mode: 1s to 24 hour</li> </ul>
<b>Alarm Threshold</b>	2 high levels alarms & 2 low levels alarms
<b>Sensor power supply</b>	4.5 to 20 Volts
<b>Analog Input polarity</b>	Bipolar or Unipolar
<b>Power Mode</b>	Sleeping, Sleeping with Network Listening & Active
<b>TX Power</b>	-7 dBm/ -1 dBm/ +5 dBm/ +11 dBm/ +15 dBm/ +18 dBm



### RF Specifications

<b>Wireless Protocol Stack</b>	IEEE 802.15.4 (2006 version)
<b>WSN Topology</b>	Point-to-Point / Star
<b>Data Rate</b>	250 Kbits/s
<b>RF Characteristics</b>	ISM 2.4GHz - 16 Channels
<b>TX Power</b>	+0 dBm to +18 dBm
<b>Receiver Sensitivity</b>	-95.5 dBm to -104 dBm
<b>Maximum Radio Range</b>	1 Km (L.O.S)
<b>Antenna diversity</b>	2 omnidirectional N-Type antenna , gain of 2.2 dBi , IP67   Nema 6

### Embedded Data Logger

<b>Storage Capacity</b>	up to 1 million data points
<b>Wireless data downloading</b>	3 minutes to download the full memory (average time)

### Environmental and Mechanical

<b>Enclosure</b>	Aluminium, Watertight IP65 – Fire Protection : ULV94/Getex Enclosure dimensions (without antenna) L x l x h : 149.1 mm x 77mm x 60.5 mm Weight: 690 grams
<b>Shock Resistance</b>	10g during 50ms
<b>Operating Temperature</b>	-40 °C to +85 °C
<b>Norms</b>	CE Labelling Directive R&TTE (Radio) ETSI EN 300 328 ROHS - Directive 2002/95/EC

### Power Supply

<b>Current consumption @ 3,3V</b>	<ul style="list-style-type: none"> <li>· During data acquisition : 70mA to 130mA (depends on external sensor power supply)</li> <li>· During Radio transmission : 60 mA @ 0dBm</li> <li>· During sleeping: &lt; 30 µA</li> </ul>
<b>Primary cell protection</b>	High precision primary cell monitoring : <ul style="list-style-type: none"> <li>· Overvoltage Protection, Overcurrent/Short-Circuit Protection, Undervoltage Protection</li> <li>· Primary cell Temperature monitoring</li> <li>· Current accumulation measurement</li> </ul>
<b>Primary cell</b>	Lithium-thionyl chloride 6,5Ah

### Option(s)

<b>Calibration Certificate</b>	Calibration certificate linked to national and international standards (COFRAC)
--------------------------------	---

//GETTING STARTING WITH A WIRELESS SENSOR NETWORK

DESCRIPTION	STARTERKIT REFERENCE
<b>Starterkit Wireless System acquisition BeanDevice AN-V Xtender</b> 1 x <u>BeanGateway Ethernet (Indoor version), Ref. : BGTW-ETH-IND</u> 1 x <u>BeanDevice AN-V Xtender, Ref. : BND-ANV-XTD-4CH</u> 1 x <u>Beanscape Basic, Ref. : BNSC_BASIC</u>	SK_BND_ANV_XTD_4CH_IND
<b>Starterkit Wireless System acquisition BeanDevice AN-V Xtender</b> 1 x <u>BeanGateway Ethernet (Outdoor version), Ref. : BGTW-ETH-OUT</u> 1 x <u>BeanDevice AN-V Xtender, Ref. : BND-ANV-XTD-4CH</u> 1 x <u>Beanscape Basic, Ref. : BNSC_BASIC</u>	SK_BND_ANV_XTD_4CH_OUT

The **BeanDevice® AN-V Xtender** operates only on our Wireless Sensor Networks, you will need the **BeanGateway®** and the **BeanScape®** for starting a wireless sensor networks.



OR



Product specifications are subject to change without notice. Contact Beanair for latest specifications.



## //CONTACT US

FOR MORE INFORMATION :

**[sales@beanair.com](mailto:sales@beanair.com)**Visit our website : **[www.beanair.com](http://www.beanair.com)**Visit our blog : **[www.industrial-wsn.com](http://www.industrial-wsn.com)**

OUR YOUTUBE CHANNEL :



Watch our featured videos on Youtube

## VISIT OUR WEBSITES



VISIT US!