## YOUR **EAGLE™** INFORMATION LABEL

Located on the underside of the **EAGLE**<sup>™</sup> is information that identifies your specific unit. You will be required to provide this information when requesting support from Rainforest Automation or BC Hydro.



MAC Address: Install Code:

Web Address:

MAC: 0000 0000 0000 0000 IN: 0000 0000 0000 0000 http://eagle-000000.local cloudID: 000000 Model: RFA-Z109 EAGLE

 Rainforest Automation, Inc.

 FCC ID: YCXRFA-Z109

 IC: 8919A-RFAZ109

 Made in the USA







NEED HELP WITH THE **EAGLE™**?

For a full user manual, FAQs, and to contact support: www.rainforestautomation.com/eagle\_support/bch

## CAN'T SEE YOUR ELECTRICITY USE INFORMATION?

Contact: hem.support@bchydro.com Phone: 604.224.9376 or 1.800.224.9376

#### MOVING?

Phone: 604.224.9376 or 1.800.224.9376

www.rainforestautomation.com

## WHAT'S IN THE BOX

• EAGLE<sup>™</sup> ENERGY MONITOR

• AC POWER ADAPTER

• ETHERNET CABLE

## CONNECTING TO THE CLOUD

Connect to your **EAGLE™** through the Cloud when you aren't at home.

.

.



- In the Rainforest Web View, click on the settings button in the lower right corner and select "Cloud."
  - Use the drop down menu to select a Cloud service provider.
  - To complete the set-up, set up an account with the Cloud service provider you selected using the 6-digit Cloud ID located on the back of your **EAGLE**<sup>™</sup>.

## LED LIGHT INDICATOR KEY

LED lights on the device give you a quick way to check the status of your EAGLE™.

LIGHT INDICATOR	ပ POWER	<mark>ਸ਼</mark> ਨੂ ETHERNET	CLOUD	"ፚ") Zigbee
Solid Green	Power is on.	IP address obtained.	Connected to Cloud service.	Connected to the electricity meter.
Blinking Green	n/a	n/a	Attempting to connect to Cloud service.	Attempting to connect to the electricity meter.
Double Blinking Green	n/a	n/a	n/a	Attempting to re- connect to the electricity meter.
Off	EAGLE <sup>™</sup> not receiving any power.	No internet service.	EAGLE <sup>™</sup> not configured to a cloud service provider.	No ZigBee link to the meter.

# Get direct access to your energy information in three easy steps.

STEP 1: CONNECT ETHERNET CABLE TO YOUR ROUTER



## STEP 2: CONNECT POWER SUPPLY



STEP 3: ENTER YOUR EAGLE™ WEB ADDRESS IN YOUR WEB BROWSER\* OR USE THE EnergyVUE APP AND START VIEWING YOUR ENERGY DATA



\* Browser must be on same network as device. Address is located on the label on the underside of the unit (eg. http://eagle-000111.local)





SEE THE FULL **EAGLE™** USER GUIDE ON OUR WEBSITE: www.rainforestautomation.com/eagle\_support/bch