







INSTALLATION MANUAL PRIVACY WALL & DECORATIVE PANEL KIT



YARDISTRY

Yardistry

Mount Forest, ON Canada N0G 2L1

Toll Free Customer Support: 1.888.509.4382

info@yardistrystructures.com

www.yardistrystructures.com

Revised 04/18/2012

!IMPORTANT SAFETY NOTICE!

- Yardistry components are intended for privacy, decorative and ornamental use only. **Product is NOT INTENDED for the following:**
 - A safety barrier to prevent unsupervised access to pools, hot tubs, spas, or ponds.
 - Safety railings for elevated platforms or decks.
 - As load bearing support for a building, structure, heavy objects or swings. - Used in structures that trap wind, rain or snow that would create extra load on the product.
- **Permanent structures may require a building permit.** As the purchaser and or installer of this product you are advised to consult local planning, zoning, and building inspection departments for guidance on applicable building codes and or zoning requirements.
- **Wood is NOT flame retardant and will burn.** Grills, fire pits and chimneys are a fire hazard if placed too close to a Yardistry structure. Consult user's manual of the grill, fire pit or chimney for safe distances from combustible materials.
- **During installation, follow all safety warnings provided with your tools and use OSHA approved safety glasses.**
- **Some structures may require two or more people to install safely. Check for underground utilities before digging or driving stakes into the ground!**

General Information: Wood components are manufactured with Cedar (C. Lanceolata) which is protected with factory applied water-based stain. Knots, small checks (cracks) and weathering are naturally occurring and do not affect the strength of the product. Annual application of a water-based water repellent sealant or stain will help reduce weathering and checks.

Warranty: Yardistry products are backed by a 5 year limited lifetime warranty from the date of original retail purchase for manufacturing defects and if installed as per manufacturer's installation instructions.

Patents Pending

Tools Required

- | | | |
|------------------------------|--|------------------|
| • Tape Measure | • #2 Phillips or Robertson Bits or Screwdriver | • Safety Glasses |
| • Carpenters Level | • 1/8" Drill Bit | • Adult Helpers |
| • Carpenters Square | • Pencil | |
| • Standard or Cordless Drill | • 8' Step Ladder | |

Keys To Assemble Success

This identifies information that requires special attention. Improper assembly could lead to an unsafe or dangerous condition.



Use Help



Use Help



Where this is shown, 2 or 3 people are required to safely complete the step. To avoid injury or damage to the assembly make sure to get help!


Measure Distance



Check that assembly is square before tightening bolts.

Use a measuring tape to assure proper location.

Square Assembly



Check that set or assembly is properly level before proceeding.

Use Level



Pre-drill 1/8" & 3/16" Bit




Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.


Tighten Bolts




This indicates time to tighten bolts, but not too tight! Do not crush the wood. This may create splinters and cause structural damage.



12x12 Arched Roof Pergola - YM12505




12x12 Complete Pergola Room - YM11507



Fencing

MATERIAL LIST




R (2) Top and Bottom Rail

Note: Wall assembly in this instruction is shown as a 3 High Lattice Panel with a 1 High X Topper. Depending on kit purchased, images may not be accurate. Please see front cover for what your final set-up should look like. You may also refer to page 3 for what assemblies may look like inside the different units.

- (4) One High X Topper or,
- (4) One High Lattice Topper or,
- (4) One High Faux Glass Topper or,
- (2) One High Arch Topper and (2) of the above

P_3



- (4) Three High Lattice Panel or,
- (4) Three High X Panel

S4



#8 x 2 1/4" Wood Screw

S5




#10 x 1" Pan Head Screw

S7



#8 x 1 1/2" Wood Screw



(6) Panel Clips

Privacy & Decorative Panel Kits:


- 4 High Privacy Lattice / X Panel - YM11515
- 4 High Lattice with Faux Glass Panel - YM11517
- 4 High Privacy Lattice Panel - YM11540
- 4 High Decorative X Panel - YM11544
- 4 High Decorative X / Arch Panel - YM11548
- 4 High Privacy Lattice/ X / Arch Panel - YM11549

STEP 1- ASSEMBLE PANELS

1. Remove the upper metal connectors on both sides of P_3 - Three High_Panel. Reattach the metal connectors to P_3 by securing the bottom two holes of the metal connectors to the top two holes on P_3 so that the metal connectors stick out from the top. Slide P_1 – One High_Topper between the two protruding metal connectors on the top of P_3. Attach the metal connectors to P_1. (Fig. 1A)

***Ensure Panels are oriented correctly! (Fig. 1B)**

2. Secure panels with a S4 - 2 1/4" Wood Screw the location indicated by the large arrow in the direction of the arrow.
3. Repeat until four panel assemblies are created.



4X **P_1** ONE HIGH_TOPPER


4X **S4** #8- 2 1/4" WOOD SCREWS

4X **P_3** THREE HIGH_PANEL


STEP 2- ASSEMBLE WALL



Fig. 1




1. Assemble panels together in configuration shown. (Fig.1) Insert male connector into female. Slide down until flush with adjacent panel as shown. (Fig. 1A)
2. Secure Panels with S4 - 2 1/4" screws provided in pre-drilled holes as indicated by arrows, in the direction of the arrow. (Fig.1)



3. Secure R-Top and Bottom Rails to Panel Assembly with S4 - 2 1/4" Wood Screws locations indicated by arrows in the direction of the arrow. (Fig. 2)

Fig. 2



****R- Top and Bottom Rails will overhang 1/4" on either side of panel.**
***Except with Arch Topper!**
*** R- Top and Bottom Rails may need to be cut to 6' 6 1/2" (2m)**

(It is recommended to use a Mitre Box or Mitre Saw)

2X **R** TOP & BOTTOM RAIL - 78 1/2"


24X **S4** #8- 2 1/4" WOOD SCREWS

1X **R** TOP & BOTTOM RAIL - 78 1/2"

1X **R** TOP & BOTTOM RAIL - 53 1/2" (135.8 CM)


***USE IF YOU HAVE PURCHASED YM11549 OR YM11548 TO ACCOMMODATE THE ARCH TOPPER.

STEP 3- INSTALLING PANEL CLIPS




1. Position Panel Clips in locations indicated in Figures 1 and 1A. **Orient Panel Clips according to whether you want them to be visible or not. (i.e facing inside or facing the outside.)**
2. Panel Clips should be placed in the centre of the post or the leading edge of the clip should be 1 3/8" or 3.5cm away from the side of the post as shown in Fig. 2.
3. With Panel Clips in place, mark screw holes with a pencil and pre-drill holes with a 1/8" drill bit. (Not provided)
4. Secure Panel Clips in locations indicated in figure 1 and 1A with S7- #8 x 1 1/2" wood screws.

Fig. 1A




Note: If you purchased the following units: YM11549 OR YM11548. You MUST mount the top clips at 65" to accommodate the arches.

Fig. 1




Top View



Note: these clip heights are designed for a 4" ground clearance. For ground clearance less than 4" subtract equal number from clip heights for appropriate measurement.

6X - PANEL CLIPS

12X  #8 X 1 1/2" WOOD SCREW

STEP 4- INSTALLING WALL INTO FLAT ROOF PERGOLA



1. With the help of an adult, place the Wall on Panel Clips as shown (Fig.1) allowing a 4" gap between the bottom of the post and the bottom edge of the bottom rail on the panel assembly.
2. With a 1/8" drill bit, predrill holes as shown in figure 2.
3. Fasten the Wall to the post and Panel Clips with a S5- 1" Pan Head Screw provided in location of arrows. (Fig. 1)






Fig. 2. Predrill Holes and Fasten with S5- 1" Pan Head Screw

Fig. 1



6X  #10 x 1" PAN SCREWS

STEP 4- INSTALLING WALL INTO ARCHED PERGOLA



1. With the help of an adult, place the Wall on Panel Clips as shown (Fig.1) allowing a 1" gap between the bottom of the post and the bottom edge of the bottom rail on the panel assembly.
2. With a 1/8" drill bit, predrill holes as shown in figure 2.
3. Fasten the Wall to the post and Panel Clips with a S5- 1" Pan Head Screw provided in location of arrows. (Fig. 1)






Fig. 2. Predrill Holes and Fasten with S5- 1" Pan Head Screw

Fig. 1



6X  #10 x 1" PAN SCREWS

STEP 4- INSTALLING WALL INTO FENCE



1. With the help of an adult, place the Wall on Panel Clips as shown (Fig.1) allowing a 4" gap between the bottom of the post and the bottom edge of the bottom rail on the panel assembly.
2. With a 1/8" drill bit, predrill holes as shown in figure 2.
3. Fasten the Wall to the post and Panel Clips with a S5- 1" Pan Head Screw provided in location of arrows. (Fig. 1)






Fig. 2. Predrill Holes and Fasten with S5- 1" Pan Head Screw

Fig. 1



6X  #10 x 1" PAN SCREWS