



## 5000G (11 LB.) GLASS DIGITAL SCALE USER'S MANUAL



### **WARNING:**

Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

**Item# 30737**



## 5000G (11 LB.) GLASS DIGITAL SCALE USER'S MANUAL

Thank you very much for choosing an IRONTON™ product! For future reference, please complete the owner's record below:

Model: \_\_\_\_\_ Purchase Date: \_\_\_\_\_

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it.

This machine is designed for certain applications only. The distributor strongly recommends this machine is not modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the machine until you have first contacted the distributor to determine if it can or should be performed on the product.

For technical questions and replacement parts, please call 1-800-222-5381.

### TECHNICAL SPECIFICATIONS

Measurements in three modes: grams, ounces and pounds

Max. capacity: 5000g, 176 oz., 11 lbs.

Weighing Increments: 1g, 0.01 oz., 0.001 lb.

Scale construction: ABS

Platform construction: Tempered glass

Platform diameter: 5 7/8in.

Operates on one lithium button cell CR2032 (included).

### GENERAL SAFETY REGULATIONS



**WARNING:** Read and understand all instructions.

**WARNING:** The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

- Keep the work area clean and dry. Damp or wet work areas can result in damage to the product.
- Keep children away from work area. Do not allow children to handle this product.
- Always wear ANSI-approved safety glasses and heavy-duty work gloves during assembly and use. Do not wear loose clothing or jewelry, which can get caught in moving parts.
- Store idle equipment. When not in use, tools and equipment should be stored in a dry location to inhibit rust. Always lock up tools and equipment, and keep out of reach of children.
- Use the right tool for the job. Do not attempt to force small equipment to do the work of larger industrial equipment. There are certain applications for which this equipment was designed. It will do the job better and more safely at the capacity for which it was intended. Do not modify this equipment, and do not use this equipment for a purpose for which it was not intended.
- Check for damaged parts. Before using this product, carefully check that it will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged or worn parts immediately.
- Do not overreach. Keep proper footing and balance at all times to prevent tripping, falling, back injury, etc.
- DO NOT use the equipment when tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating this equipment may result in serious personal injury.
- Industrial applications must follow OSHA requirements.



**GUIDE TO SAFETY OPERATION**


**⚠ WARNING:** The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

- (1) Use the scale on a clean and flat table or other level surface.
- (2) Do not overload the scale. 5000g/ 176 oz./ 11 lbs. is the maximum allowable weight before you tare the containers.
- (3) Do not apply excessive pressure or drop the scale. Use the scale with care to prevent damage.
- (4) Use soft cloth to clean the scale. Water or any chemical detergent can easily go inside the scale and damage it.
- (5) Check the condition of battery and the touch point of platform contacts well with the scale body if the scale doesn't work.
- (6) Replace depleted batteries as soon as possible. Replacement batteries (CR2032) are available from the distributor.
- (7) This scale is designed for household use only. Not for commercial use.

**OPERATION INSTRUCTIONS**



**1. Key Function**

- (1) Function of the ON/TARE key: Power on, Power off, Tare
- (2) Function of UNIT key: Unit exchange between g, oz. and lb.



**2. Battery Replacement**

When installing or replacing the battery, please open the cover on the bottom, and install/ replace the battery with one CR2032 lithium button cell properly. Re-place cover before operation.



**3. Operation**

**NOTE: Do not overload the scale.**  
Place the scale on a flat table with the button cell on. Make sure it is steady before operation.  
(1) Press ON/TARE key to power on, the display flashes "88888" for about 3 seconds before it goes to standby and shows 0.



- (2) Press UNIT key to change the unit between g, oz. and lb.



- (3) Put item onto the platform, display shows the total weight of the item.



**(4) Tare Deduction:**


- ①. Put the container on the platform, it displays the weight of the container.



- ③. Put item into the container, display shows the net weight of the item.



- ②. Press ON/TARE key, the number of the weight is zero. If you take the vessel away, the number of the weight will be negative.



**4. Error Display**

- (1) If the display will show "0-ld", it indicates that the scale is overloaded.
- (2) If the display shows "LO", it indicates that the power is low and it is time to replace the battery.
- (3) If the display shows "OUT2" and the power is off, it indicates that the scale is unsteady or overloaded.

**WARRANTY**  
1-year limited warranty



Distributed by:  
Northern Tool + Equipment Co., Inc.  
Burnsville, MN 55306  
NorthernTool.com  
Made in China