



## User's manual DTFC12

The DTFC12 is a easy way to regulate the rpm of a for example a extractor fan.  
Maximum power use is 2x1350Watt.

### Connecting the DTFC12

1. Connect the extractor fans to the DTFC12
2. Plug the DTFC12 in the wall outlet
3. Press the **P** button on the ecotron.
4. Now you can adjust the temperature by using the up and down arrow's.
5. When you have set you're temperature, press the **P** button again.
6. When the lamp K1 is on, you can adjust the minimum speeds.
7. When K1 is off you can adjust the maximum speed
8. **Warning; The maximum amount that can be used on the DTFC12 IS 2x6Amps. Never remove the plug when the TFC12 is active. First turn all speeds to 0%**

#### Notes