

## USER'S MANUAL

GB NL F D DK RU

--- QRG/PORTABLE POWER CHARGER  
2600mAh Pure/01-14/V02 ---



### DECLARATION OF CONFORMITY

Company:	TE-GROUP nv
Address:	Kapelstraat 61, 2950 Kapellen - BELGIUM

declare, that the following equipment:

Product Name:	mr Handsfree Portable Power Charger
Product Type:	Portable Power Charger 2600 mAh

Conforms with the following safety requirements of the directives 2004/108EC, and is guaranteed by the CE-symbol.

Standards:  
EN55022:2010, EN55024:2010  
EN61000-3-2:2006+A1:2009+A2:2009, EN61000-3-3:2008



ILLUSTRATION 1




ILLUSTRATION 2





ILLUSTRATION 3



### PACKAGE CONTENTS

- Portable Power Charger
- Micro USB charging cable 50 cm

GB

### CHARGING THE PORTABLE POWER CHARGER

1. Connect the micro USB charging cable in the Portable Power Charger's IN port.  
**Option 1** [See illustration 1]:  
Connect the USB plug of the charging cable to your computer's USB port or another USB 2.0 compatible port.  
**Option 2** [See illustration 2]:  
Connect the USB plug of the charging cable to the USB port of the universal USB AC adapter (not provided, optional). Plug the AC adapter into a wall socket.
2. The Portable Power Charger's LED indicator turns red to indicate that the battery is being charged. The charger can be charged in ON or OFF position. Charging time is about 3-4 hours.
3. When the battery is fully charged, the LED indicator turns off. Disconnect the charger. The Portable Power Charger is now ready for use.

### OPERATION OF THE PORTABLE POWER CHARGER [See illustration 3]

**Important! The Portable Power Charger must be fully charged before use.**

1. Connect the USB plug of the micro USB cable to the 5V OUT port of the Portable Power Charger.
2. Connect the other side of the cable to your device, or use your own USB charging cable (originally supplied with your device).
3. Connect your device.
4. Turn the Portable Power Charger ON by pressing the button.
5. The LED indicator turns blue, indicating that the Charger is charging your device.

#### Remarks:

- When the LED indicator turns OFF, the Charger needs to be recharged.
- **When the Charger is not in use, it must be turned OFF. This prevents the charger from discharging.**

### SAFETY INSTRUCTIONS

- The lithium-ion rechargeable battery used in this charging device may present a risk of fire or chemical burn if mis-treated. Do not disassemble, expose to heat above 100° C, or incinerate. Misusing or incorrectly connecting the charging device may cause electric shock to users and damage equipment. Read instructions carefully. The charging device may become warm and may reach 50°C under extended high power operation. During operation, keep the charging device away from materials that may be affected by these temperatures.

- When used correctly, lithium-ion rechargeable batteries provide a safe and dependable source of portable power. However, if they are misused or abused, this may result in leakage, burns, fire or explosion/disassembly, causing personal injury or damage to other devices.
- Do not disassemble the charging device. There are no user-serviceable parts inside. Incorrect reassembly may result in shock or fire hazard.
- Do not drop or subject the charging device to strong mechanical shock.
- Do not expose the charging device to moisture, water, rain, snow or spray.
- Do not insert any object into the ports or openings of the charging device.
- Do not operate the charging device if it has received a sharp blow, been dropped, or otherwise been damaged in any way.
- Do not use in environments where the temperature is 40°C or higher.
- Keep out of reach of children.
- To reduce the risk of electric shock, unplug the charging device from any power source before attempting any maintenance or clearing.

### TECHNICAL DATA

Input: DC 5V - 500-800 mA  
Output: DC 5V - 1A = 1000 mA  
Capacity: Samsung 2600 mAh Li-ion high power 13 wh

### DISPOSAL

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.

### CUSTOMER SUPPORT

For more information, technical questions and return requests concerning this product, you should contact support@mrhandsfree.com.

### GUARANTEE

Mr Handsfree is a registered trademark of TE-Group NV. The mr Handsfree brand stands for superior product quality and outstanding customer service. That is why mr Handsfree warrants this product against all defects in material and workmanship for a period of **two (2) years** from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of mr Handsfree under this guarantee can be downloaded from our website: [www.mrhandsfree.com](http://www.mrhandsfree.com).